

supported device.txt

"Retail Branding, Marketing Name, Device, Model "
" , , AD681H, Smartfren Andromax AD681H"
" , , FJL21, FJL21"
" , , Luno, Luno"
" , , T31, Panasonic T31"
" , , hws7721g, MediaPad 7 Youth 2"
"3Q, OC1020A, OC1020A, OC1020A"
"7EI even, IN265, IN265, IN265"
"A. O. I. . ELECTRONICS FACTORY, A. O. I. . , TR10CS1_11, TR10CS1"
"AG Mobile, AG_Go-Tab_Access, md789hwag, AG_Go-Tab_Access"
"AG Mobile, AG_Tab_7_0, AG_Tab_7_0, AG_Tab_7_0"
"AG Mobile, Ghost, Ghost, Ghost"
"AG Mobile, Status, Status, Status"
"AG Mobile, Swift, Swift, Swift"
"AG Mobile, ULTRA, Ultra, Ultra"
"AMTC, AMTC MD1001 Tablet, MD1001, MD1001"
"AMTC, AMTC MD7008, MD7008A, MD7008"
"AMTC, AMTC MD7081, MD7081A, MD7081"
"AOC, A2272PWHT, AOC_WW, G2SMNT"
"AOC, AOC-A2272PW4T, AOC_WW, G3SMNTA22"
"AOC, AOC-A2272PW4T, AOC_WW, G3SMNTA24"
"AOC, AOC-A2472PW4T, G3SMNTA24, G3SMNTA24"
"AV, AV10, RCT6203W46, AV10"
"AV, AV7, RCT6773W22, AV7"
"AZBox, AZDroid, AZDroid, AZDroid"
"AZPEN, AZPEN A720, wi ng-i net, A720"
"AZPEN, AZPEN A920, wi ng-i bt, A920"
"Abocom, AboCom A08SM, A08, A08S"
"Acer, , C6, Acer E320"
"Acer, , C6, Acer E320-orange"
"Acer, , C7, E330"
"Acer, , C8n, E350"
"Acer, , K3, E130"
"Acer, , T2, AT390"
"Acer, , T603T, TD600"
"Acer, , a3, Stream"
"Acer, , a5, S300"
"Acer, , c4, E310"
"Acer, , k4, E140"
"Acer, , k5, E210"
"Acer, A1-713, acer_apri lia, A1-713"
"Acer, A1-810, mango, A1-810"
"Acer, A1-811, mango, A1-811"
"Acer, A1-830, ducati , A1-830"
"Acer, A100, vangogh, A100"
"Acer, A101, vangogh, A101"
"Acer, A110, a110, A110"
"Acer, A3-A10, zara, A3-A10"
"Acer, A3-A11, zara, A3-A11"
"Acer, A3-A20, acer_harley, A3-A20"
"Acer, A3-A20FHD, acer_harleyfhd, A3-A20FHD"
"Acer, A3-A30, omega, A3-A30"
"Acer, AK330s, C8n, AK330S"
"Acer, Aspire A3, aa3-600, AA3-600"
"Acer, B1-710, B1-710, B1-710"
"Acer, B1-711, B1-711, B1-711"
"Acer, B1-720, b1-720, b1-720"
"Acer, B1-721, b1-721, b1-721"
"Acer, B1-730, vespatn, B1-730"
"Acer, B1-730HD, vespa, B1-730HD"
"Acer, B1-820, ci ti zen, B1-820"
"Acer, B1-A71, B1-A71, B1-A71"
"Acer, Cl oudMobile S500, a9, S500"

supported device.txt

"Acer, DA220HQL, DA220HQL, DA220HQL"
"Acer, DA221HQL, da1, DA221HQL"
"Acer, DA222HQL, da2, DA222HQL"
"Acer, DA222HQLA, da2, DA222HQLA"
"Acer, DA222HQLA, da222hql a, DA222HQLA"
"Acer, DA223HQL, da3, DA223HQL"
"Acer, DA226HQ, da6, DA226HQ"
"Acer, DA241HL, DA241HL, DA241HL"
"Acer, DA245HQL, da245hql, DA245HQL"
"Acer, E380, acer_e3n, E380"
"Acer, G1-715, G1-715, G1-715"
"Acer, G100W, maya, G100W"
"Acer, I110, I1, I110"
"Acer, Icona One 7, vespa, B1-730HD"
"Acer, Icona One 7, G1-725, G1-725"
"Acer, Icona One 7, vespa, B1-730HD"
"Acer, Icona One 7, vespa2, B1-750"
"Acer, Icona One 7, vespatn, B1-730"
"Acer, Icona One 8, vespa8, A1-850"
"Acer, Icona One 8, vespa8, B1-810"
"Acer, Icona Tab 10, acer_harley, A3-A20"
"Acer, Icona Tab 10, acer_harleyfhd, A3-A20FHD"
"Acer, Icona Tab 7, acer_apri lia, A1-713"
"Acer, Icona Tab 7, acer_apri li ahd, A1-713HD"
"Acer, Icona Tab 8, ducati 2fhd, A1-840FHD"
"Acer, Icona Tab 8, ducati 2hd, A1-840"
"Acer, Icona Tab 8, ducati 2hd3g, A1-841"
"Acer, Icona Tab A100 (VanGogh), vangogh, A100"
"Acer, Icona Tab A100 (VanGogh), vangogh, A101"
"Acer, Icona Tab A200, pi casso_e, A200"
"Acer, Icona Tab A210, pi casso_e2, A210"
"Acer, Icona Tab A211, pi casso_e2, A211"
"Acer, Icona Tab A500, pi casso, A500"
"Acer, Icona Tab A501, pi casso, A501"
"Acer, Icona Tab A510, pi casso_m, A510"
"Acer, Icona Tab A511, pi casso_m, A511"
"Acer, Icona Tab A700, pi casso_mf, A700"
"Acer, Icona Tab A701, pi casso_mf, A701"
"Acer, Icona TalkTab 7, acer_a1_724, A1-724"
"Acer, Li qui d, a1, Acer Li qui d"
"Acer, Li qui d, a1, Acer S100"
"Acer, Li qui d, a1, Li qui d"
"Acer, Li qui d 200, acer_z200, Z200"
"Acer, Li qui d C1, I1, I110"
"Acer, Li qui d E1, C10, V360"
"Acer, Li qui d E2, C11, V370"
"Acer, Li qui d E3, acer_e3, E380"
"Acer, Li qui d E3, acer_e3n, E380"
"Acer, Li qui d E3S, acer_ZXR, Z130"
"Acer, Li qui d E600, e600, E600"
"Acer, Li qui d E700, acer_e39, E39"
"Acer, Li qui d Gal lant E350, C8, AK330"
"Acer, Li qui d Gal lant E350, C8, E350"
"Acer, Li qui d Jade, acer_S55, S55"
"Acer, Li qui d Jade S, acer_S56, S56"
"Acer, Li qui d Jade Z, acer_S57, S57"
"Acer, Li qui d Mi ni, C4R, E310"
"Acer, Li qui d S1, a10, S510"
"Acer, Li qui d S2, a12, S520"
"Acer, Li qui d S3, s3, S53"
"Acer, Li qui d X1, s3, S53"
"Acer, Li qui d Z200, acer_z200, Z200"
"Acer, Li qui d Z205, acer_z205, Z205"

supported device.txt

"Acer, Li qui d Z205, acer_z205p, Z205"
"Acer, Li qui d Z205, acer_z205p, Z205P"
"Acer, Li qui d Z220, z220, Z220"
"Acer, Li qui d Z3, ZX, Z130"
"Acer, Li qui d Z3, acer_ZXR, Z130"
"Acer, Li qui d Z320, T012, T012"
"Acer, Li qui d Z330, T01, T01"
"Acer, Li qui d Z4, acer_Z6, Z160"
"Acer, Li qui d Z410, acer_z410, Z410"
"Acer, Li qui d Z5, acer_ZXL, Z150"
"Acer, Li qui d Z500, acer_Z500, Z500"
"Acer, Li qui d Z520, acer_z520, Z520"
"Acer, Li qui d Z530, acer_T02, T02"
"Acer, Li qui d Z630, acer_t03, T03"
"Acer, Li qui dMT, a4, Acer Li qui d Metal "
"Acer, Li qui dMT, a4, Li qui d MT"
"Acer, Li qui dMT, a4, Li qui d Metal "
"Acer, M3-2200, da2, M3-2200"
"Acer, MWND1, MW1, MWND1"
"Acer, N3-2200, da2, N3-2200"
"Acer, Pi casso, pi casso, A501"
"Acer, Pi casso, ventana, A500"
"Acer, Pi casso, ventana, G100W"
"Acer, Pi casso, ventana, TPA60W"
"Acer, TA2, ta2, TA272HUL"
"Acer, TA272HUL, ta2, TA272HUL"
"Acer, TPA60W, maya, TPA60W"
"Acer, Tab 7, td070va1, TD070VA1"
"Acer, Z110, Z1, Z110"
"Acer, Z120, Z2, Z120"
"Al I Vi ew, A5 Easy, A5_Easy, A5_Easy"
"Al I Vi ew, A5 Easy, A5_Easy, A5_Easy_TM"
"Al I Vi ew, A5 Quad PI us, A5_Quad_PI us, A5_Quad_PI us"
"Al I Vi ew, A5 Quad PI us, A5_Quad_PI us, A5_Quad_PI us_TM"
"Al I Vi ew, A6 Duo, A6_Duo, A6_Duo"
"Al I Vi ew, AX4 Nano PI us, AX4Nano_pl us, AX4Nano_pl us"
"Al I Vi ew, C6 Quad 4G, C6_Quad_4G, C6Quad_4G"
"Al I Vi ew, E2 Jump, ALLVI EW_E2_Jump, E2_Jump"
"Al I Vi ew, E3 Li vi ng, E3_Li vi ng, E3_Li vi ng"
"Al I Vi ew, E3 Si gn, E3_Si gn, E3_Si gn"
"Al I Vi ew, E4, E4, E4"
"Al I Vi ew, E4 Li te, E4_Li te, E4_Li te"
"Al I Vi ew, P5 Energy, P5_Energy, P5_Energy"
"Al I Vi ew, P5 Li fe, P5Li fe, P5Li fe_TM"
"Al I Vi ew, P5Li fe, P5Li fe, P5Li fe"
"Al I Vi ew, P6 Energy, P6_Energy, P6_Energy_TM"
"Al I Vi ew, P6 Qmax, P6_Qmax, P6_Qmax"
"Al I Vi ew, P6_Energy, P6_Energy, P6_Energy"
"Al I Vi ew, P8 Energy, P8_Energy, P8_Energy"
"Al I Vi ew, V1 Vi per E, V1_Vi per_E, V1_Vi per_E"
"Al I Vi ew, V1 Vi per I 4G, V1_Vi per_I 4G, V1_Vi per_I 4G"
"Al I Vi ew, V1 Vi per I 4G, V1_Vi per_I 4G, V1_Vi per_I 4G_PL"
"Al I Vi ew, V1 Vi per I 4G, V1_Vi per_I 4G, V1_Vi per_I 4G_TM"
"Al I Vi ew, V1 Vi per I 4G, V1_Vi per_I 4G_PL, V1_Vi per_I 4G_PL"
"Al I Vi ew, V1 Vi per L, V1_Vi per_L, V1_Vi per_L"
"Al I Vi ew, V1 Vi per S4G, V1_Vi per_S4G, V1_Vi per_S4G"
"Al I Vi ew, V2 Vi per, V2_Vi per, V2_Vi per"
"Al I Vi ew, V2 Vi per X, V2_Vi per_X, V2_Vi per_X"
"Al I Vi ew, Vi va C701, Vi va_C701, Vi va_C701"
"Al I Vi ew, Vi va H10 LTE, Al I vi ew_Vi vaH10LTE_KK, Vi vaH10LTE"
"Al I Vi ew, Vi va H7 LTE, Al I vi ew_Vi vaH7LTE_KK, Vi vaH7LTE"
"Al I Vi ew, Vi va H8 LTE, Al I vi ew_Vi vaH8LTE_KK, Vi vaH8LTE"
"Al I Vi ew, Vi va H8 Li fe, H8_Li fe, H8_Li fe"

supported device.txt

"Al I Vi ew, X2 Soul Li te, X2_Soul _Li te, X2_Soul _Li te"
"Al I Vi ew, X2 Soul Li te, X2_Soul _Li te, X2_Soul _Li te_TM"
"Al I Vi ew, X2 Soul Mi ni , X2_Soul _Mi ni , X2_Soul _Mi ni "
"Al I Vi ew, X2 Soul PR0, X2_Soul _PR0, X2_Soul _PR0"
"Al I Vi ew, X2 Soul Xtreme, X2_Soul _Xtreme, X2_Soul _Xtreme"
"Al I fi ne, Al I fi ne M721, 86S, M721"
"Al I fi ne, Al I fi ne PC1038Q, Fi ne10_Joy, PC1038Q"
"Al phascan, SAT2242 WorkTab, ADP_WW, G2SMNT"
"Amgoo, AM506, AM506, AM506"
"Ampl i fy, TL10RA3, TL10RA3_1, TL10RA3"
"Ampl i fy, TR10CD3, TR10CD3_1, TR10CD3"
"Ampl i fy, TR10CD3, TR10CD3_2, TR10CD3"
"Anydata, , ASP320Q_GSM, ASP320Q_ANDI "
"Anydata, Aquari s I8, bq_Aquari s, bq_Aquari s"
"Anydata, Auchan MI D7317CP Tabl et, MI D7317CP"
"Anydata, COBY MI D7055, MI D7055, MI D7055"
"Anydata, Carrefour CT710, M755ND, CT710"
"Anydata, Carrefour CT720 / Emdoor EM63 Tabl et, EM63, EM63"
"Anydata, Coby MI D1065, MI D1065, MI D1065"
"Anydata, Coby MI D7065, MI D7065, MI D7065"
"Anydata, Coby MI D8065, MI D8065, MI D8065"
"Anydata, D2-721G, D2-721G, D2-721G"
"Anydata, D2-727G, D2-727, D2-727"
"Anydata, DOP0 GMS-718 Tabl et / Di scovery, DT088, GS-718"
"Anydata, DOTPAD DP3D8 / Gadmei , E8-3D, DP3D8"
"Anydata, Di gi x TAB-840_G, TAB-840_G, TAB-840_G"
"Anydata, Evi ant MT8000, PDM829MD, MT8000"
"Anydata, Garmi n nuvi 3590, scorpi o, nuvi 3590"
"Anydata, Garmi n nuvi 3595, scorpi o, nuvi 3595"
"Anydata, Grundi g GR-TB10S Tabl et, GR-TB10S, GR-TB10S"
"Anydata, HCL ME TABLET PC U2, M712MC, U2"
"Anydata, HKC P771A, P771A_WI FI , P771A"
"Anydata, HKC P774A, P774A, P774A"
"Anydata, HKC P776A, P776A, P776A"
"Anydata, HKC P778A, HKCP778A, P778A"
"Anydata, HKC P886A, P886A, P886A"
"Anydata, HS_7DTB14, HS_7DTB14, HS_7DTB14"
"Anydata, Insi gni a NS-13T001 Tabl et, oracl e, NS-13T001"
"Anydata, Ji ateng JT1241, JT1241, JT1241"
"Anydata, Lazer MD7305 Tabl et / AMTC, MD7305, MD7305"
"Anydata, Le Pan S, oracl e, Le Pan S"
"Anydata, LePanI I , LePanI I _wi fi , LePanI I "
"Anydata, Leader I 10A-LE, I 10A-LE, I 10A-LE"
"Anydata, Mach_Speed Tri o G2 Tabl et, Tri o_Steal th_G2, G2"
"Anydata, Marqui s Tabl et, marqui s_tabl et, Marqui s_MP977"
"Anydata, Matsuni chi M97, oracl e, M97"
"Anydata, Monster M7 Tabl et, MONSTERM7, M7"
"Anydata, Nextbook NX007HD Tabl et, M7000ND, NX007HD"
"Anydata, Nextbook NX008HD8G Tabl et, M8000ND, NX008HD8G"
"Anydata, Nextbook NX008HI Tabl et / Carrefour CT810, M909NP, NX008HI "
"Anydata, Nextbook Next7D12 Tabl et, M757ND, Next7D12"
"Anydata, Nextbook Next7P12, M727MC, Next7P12"
"Anydata, Pendo PNDPP48GP, PNDPP48GP, PNDPP48GP"
"Anydata, Phi I i ps W336, Crane, Phi I i ps W336"
"Anydata, Phi I i ps W536, Phi I i ps_WG-MANTO-RU_B, Phi I i ps W536"
"Anydata, Phi I i ps W626, sangfei 73_gb, W626"
"Anydata, Phi I i ps W632, robot, Phi I i ps W632"
"Anydata, Phi I i ps W832, Phi I i ps_WG-ROVER-RU_A, Phi I i ps W832"
"Anydata, Proscan PLT7223G, PLT7223G, PLT7223G"
"Anydata, Proscan PLT7777, AMLMI D710K, PLT7777"
"Anydata, Proscan PLT8223G, PLT8223G, PLT8223G"
"Anydata, RCA RCT6078W2, AMLEM62, RCT6078W2"
"Anydata, RCA RCT6078W2, EM62, RCT6078W2"

supported device.txt

"Anydata, TecToy TT-2500, AML757ND, TECTOYTT2500"
"Anydata, Visual Land Prestige 7D, PR07D, PR07D"
"Anydata, Vivitar Camelio Tablet, PI070H04CA, Camelio Family tablet"
"Anydata, Vivitar X0 Tablet, PI070H08X0, X0 Learning tablet"
"Anydata, Zeki TBDG773, TBDG773, TBDG773"
"Anydata, ematic EGP008, EGP008, EGP008"
"Anydata, ematic EGP010, EGP010, EGP010"
"Anydata, ematic EGS004, EGS004, EGS004"
"Anydata, ematic EGS102, EGS102, EGS102"
"Anydata, essentialb ST8003/FT8001 Tablet, M805ND, Smart\` TAB 8003"
"Anydata, iCraig CMP748, CMP748, CMP748"
"Anydata, iCraig CMP749, CMP749, CMP749"
"Apex, MT-734G, MT-734G, MT-734G"
"Apex, TM772, TM772, TM772"
"Apex, TM785CH, tm785ch, TM785CH"
"Archos, , A101S, ARCHOS 101G9"
"Archos, , A101S, Archos 101 Internet Tablet"
"Archos, , A80S, ARCHOS 80G9"
"Archos, , A80S, Archos 80 Internet Tablet"
"Archos, 101 Childpad, A101CHP, ARCHOS 101 CHILDPAD"
"Archos, 101 Cobalt, AC101CO, Archos 101 Cobalt"
"Archos, 101 G9, A101, ARCHOS 101G9"
"Archos, 101 Magnus, ac101ma, ARCHOS 101 Magnus"
"Archos, 101 Neon, A101NE, Archos 101 Neon"
"Archos, 101 Platinum, A101PL, ARCHOS 101 PLATINUM"
"Archos, 101 Titanium, A101TI, ARCHOS 101 TITANIUM"
"Archos, 101 XS, A101XS, ARCHOS 101G10"
"Archos, 101 Xenon, a101xe, Archos 101 Xenon"
"Archos, 101XS2, AC101XS2, ARCHOS 101 XS 2"
"Archos, 101b XS2, ac101bxs2, ARCHOS 101b XS2"
"Archos, 40 Titanium, a40ti, Archos 40 Titanium"
"Archos, 40b Titanium, a40btisr, Archos 40b Titanium Surround"
"Archos, 40c Titanium, ac40cti, Archos 40c Titanium"
"Archos, 45 Helium 4G, a45he, Archos 45 Helium 4G"
"Archos, 45 Platinum, msm8625, Archos 45 Platinum"
"Archos, 45 Titanium, a45ti, Archos 45 Titanium"
"Archos, 45c Platinum, ac45cpl, Archos 45c Platinum"
"Archos, 50 Helium 4G, a50he, Archos 50 Helium 4G"
"Archos, 50 Neon, a50ne, Archos 50 Neon"
"Archos, 50 Oxygen, a50ox, Archos 50 Oxygen"
"Archos, 50 Platinum, msm8625, Archos 50 Platinum"
"Archos, 50 Titanium, a50ti, Archos 50 Titanium"
"Archos, 50b Helium, ac50bhe, AC50BHE"
"Archos, 50b Helium, ac50bhe, Archos 50b Helium 4G"
"Archos, 50b Platinum, ac50bpl, Archos 50b Platinum"
"Archos, 50c Oxygen, a50cox, Archos 50c Oxygen"
"Archos, 53 Platinum, msm8625, Archos 53 Platinum"
"Archos, 53 Titanium, a53ti, Archos 53 Titanium"
"Archos, 70 Cobalt, AC70CO, ARCHOS 70 COBALT"
"Archos, 70 Neon, ac70ne, Archos 70 Neon"
"Archos, 70 Titanium, A70TI, ARCHOS 70 TITANIUM"
"Archos, 70 Xenon, a70xe, Archos 70 Xenon"
"Archos, 70b Titanium, A70BTI, ARCHOS 70b TITANIUM"
"Archos, 79 Neon, a79ne, Archos 79 Neon"
"Archos, 79 Platinum, AC79PL, ARCHOS 79 PLATINUM"
"Archos, 79 Xenon, a79xe, Archos 79 Xenon"
"Archos, 80 Carbon, AC80CA, ARCHOS 80 Carbon"
"Archos, 80 Childpad, A80CHP, ARCHOS 80 CHILDPAD"
"Archos, 80 Cobalt, A80CO, ARCHOS 80 COBALT"
"Archos, 80 G9, A80, ARCHOS 80G9"
"Archos, 80 Platinum, A80PL, ARCHOS 80 PLATINUM"
"Archos, 80 Titanium, A80TI, ARCHOS 80 TITANIUM"
"Archos, 80 XS, A80XSK, ARCHOS 80XSK"

supported device.txt

"Archos, 80 Xenon, A80XE, Archos 80 Xenon"
"Archos, 80b Plati num, A80BPL, ARCHOS 80b PLATI NUM"
"Archos, 9.4\'\ ' FFF, ac94fff, 9.4\'\ ' FFF"
"Archos, 90 Neon, a90ne, Archos 90 Neon"
"Archos, 90b Neon, ac90bne, Archos 90b Neon"
"Archos, 97 Carbon, A97C, ARCHOS 97 CARBON"
"Archos, 97 Cobal t, AC97CO, Archos 97 Cobal t"
"Archos, 97 Plati num, A97PL, ARCHOS 97 Plati num"
"Archos, 97 Ti tani um HD, A97TIHD, ARCHOS 97 TITANI UMHD"
"Archos, 97 Xenon, A97XE, ARCHOS 97 XENON"
"Archos, 97b Plati num, AC97BPL, ARCHOS 97b PLATI NUM"
"Archos, 97b Ti tani um, A97BTI, ARCHOS 97b TITANI UM"
"Archos, ARCHOS 101 Oxygen, ac101ox, Archos 101 Oxygen"
"Archos, ARCHOS 35b Ti tani um, ac35bti, Archos 35b Ti tani um"
"Archos, ARCHOS 50b Neon, ac50bne, Archos 50b Neon"
"Archos, ARCHOS 50c Hel i um, ac50che, Archos 50c Hel i um"
"Archos, ARCHOS 52 Plati num, ac52pl, Archos 52 Plati num"
"Archos, ARCHOS 62 Xenon, ac62xe, Archos 62 Xenon"
"Archos, ARCHOS 90 Copper, ac90cv, Archos 90 Copper"
"Archos, Archos 101 Copper, ac101cv, Archos 101 Copper"
"Archos, Archos 101 Hel i um, ac101he, Archos 101 Hel i um"
"Archos, Archos 101 Xenon, ac101cxe, Archos 101c Xenon"
"Archos, Archos 101 Xenon, ac101xev2, Archos 101 Xenon v2"
"Archos, Archos 101D Neon, ac101dne, Archos 101d Neon"
"Archos, Archos 101b Copper, ac101bcv, Archos 101b Copper"
"Archos, Archos 101b Neon, ac101bne, Archos 101b Neon"
"Archos, Archos 101b Plati num, ac101bpl, Archos 101b Plati ni um"
"Archos, Archos 101c Neon, ac101cne, Archos 101c Neon"
"Archos, Archos 40c Ti tani um, ac40cti v2, ARCHOS 40C TI v2"
"Archos, Archos 45 Neon, ac45ne, Archos 45 Neon"
"Archos, Archos 45b Hel i um, ac45bhe, AC45BHE"
"Archos, Archos 45b Hel i um, ac45bhe, ARCHOS 45b Hel i um"
"Archos, Archos 50 Di amond, ac50da, Archos 50 Di amond"
"Archos, Archos 50 Oxygen pl us, ac50oxpl us, Archos 50 Oxygen Pl us"
"Archos, Archos 59 Ti tani um, ac59ti, Archos 59 Ti tani um"
"Archos, Archos 59 Xenon, ac59xe, Archos 59 Xenon"
"Archos, Archos 64 Xenon, ac64xe, Archos 64 Xenon"
"Archos, Archos 70 Copper, ac70cv, Archos 70 Copper"
"Archos, Archos 70 Hel i um, ac70he, Archos 70 Hel i um"
"Archos, Archos 70 Plati num, ac70pl, Archos 70 Plati num"
"Archos, Archos 70b Cobal t, a70bco, Archos 70b Cobal t"
"Archos, Archos 70b Xenon, ac70bx, Archos 70b Xenon"
"Archos, Archos 70c Cobal t, ac70cco, Archos 70c Cobal t"
"Archos, Archos 70c Ti tani um, ac70cti, Archos 70c Ti tani um"
"Archos, Archos 70i t 2, A70i t2, ARCHOS 70i t2"
"Archos, Archos 70i t 2, A70i t2, ARCHOS 70i t2G8"
"Archos, Archos 79 Cobal t, ac79co, Archos 79 Cobal t"
"Archos, Archos 80 Hel i um, ac80he, Archos 80 Hel i um 4G"
"Archos, Archos 80b Hel i um, ac80bhe, Archos 80b Hel i um"
"Archos, Archos 80b xenon, ac80bx, Archos 80b Xenon"
"Archos, Archos 90b Copper, ac90bcv, Archos 90b Copper"
"Archos, Archos 96 Xenon, ac96xe, Archos 96 Xenon"
"Archos, Archos ArcBook, a101db, Archos 101 DB"
"Archos, Archos Smarthome La Poste, hometabl et, Archos Smart Home Tabl et"
"Archos, Archos80cpl _I oreal, ac80cpl, Archos 80c Plati num"
"Archos, Auchan Qi Li ve 45, ql 45, Qi Li ve 45"
"Archos, Auchan Qi Li ve 50, ql 50, Qi Li ve 50"
"Archos, Auchan Qi Li ve 40, ql 40, Qi Li ve 40"
"Archos, Auchan Qi Li ve8, Qi Li ve8, Qi Li ve 8"
"Archos, Auchan Qi Li ve8QC, Qi Li ve8QC, Qi Li ve 8QC"
"Archos, Auchan Qi Li ve97, Qi Li ve97, Qi Li ve 97"
"Archos, Auchan Qi Li ve97R, Qi Li ve97R, Qi Li ve 97R"
"Archos, Auchan Sel ecl i ne 10, SELECLI NE10, Sel ecl i ne 10"

supported device.txt

"Archos, Bush 10.0 MyTablet, ac101dpl, Bush 10.0 MyTablet"
 "Archos, ""Bush 4"""" Android Phone""", ac40cti, Bush 4 Android"
 "Archos, ""Bush 5"""" Android Phone""", ac50bne, BUSH 5 Android"
 "Archos, Bush 7.0 MyTablet, ac70pl, Bush 7.0 MyTablet"
 "Archos, Bush 7.85 MyTablet, ac79bu, Archos 79c Neon"
 "Archos, Bush 8.0 MyTablet, ac80cpl, Bush 8.0 MyTablet"
 "Archos, Bush MyTablet 7, ac70bu, Archos 70 Carbon"
 "Archos, Bush MyTablet 7, ac70bu, BUSH 7.0 TABLET"
 "Archos, Bush MyTablet 2, a80bu, Bush Mytablet 2"
 "Archos, ChefPad, A97CFP, Archos Chefpad"
 "Archos, FamilyPad 2, A133FP2, ARCHOS FAMILYPAD 2"
 "Archos, GamePad, A70GP, ARCHOS GAMEPAD"
 "Archos, GamePad 2, A70GP2, ARCHOS GAMEPAD2"
 "Archos, KUNO 4+, kuno4p, KUNO 4+ "
 "Archos, Kuno, KUNO4, KUNO4"
 "Archos, MyTablet 101, ac101bu, BUSH 10.1 TABLET"
 "Archos, QiLive 101, aqi live101, QILIVE 101"
 "Archos, QiLive 53, msm8625, QiLive 53"
 "Archos, QiLive 7, qilive7, QiLive 7"
 "Archos, QiLive 97R2, qilive97r2, QiLive 97R-2"
 "Archos, QiLive79, QiLive79, QiLive 79"
 "Archos, QiLive7V2, ql70v2, QiLive 70v2"
 "Archos, Quechua Phone 5, A50RG11, Quechua Phone 5"
 "Archos, Quechua Tablet 8, A80RG11, A80RG11"
 "Archos, Smart Home Tablet, hometablet, Archos Smart Home Tablet"
 "Archos, TV Connect, LUDO, ARCHOS LUDOG10"
 "Astak, NEOS, Wenu, NEOS"
 "Astro Queo, A712, A712, A712"
 "AstroQueo, polaris_wi fi only, polaris-wi fi only, A912"
 "Asus, , EP71, ME171"
 "Asus, , TF300T, ASUS Transformer Pad TF300T"
 "Asus, , a10, Asus A10"
 "Asus, , a10, Garmin-Asus A10"
 "Asus, , ventana, Transformer TF101"
 "Asus, \t MeMO Pad 7 (ME176CX), K013_1, K013"
 "Asus, \t Transformer Pad (TF103CE), K010E, K010E"
 "Asus, \t Transformer Pad (TF103CE), K010E_1, K010E"
 "Asus, ASUS ETBW11AA, ETBW11AA, ETBW11AA"
 "Asus, ASUS ETBW11AA, TF101G, ETBW11AA"
 "Asus, ASUS Fonepad 8, K016_4, K016"
 "Asus, ASUS Fonepad ME371MG, ME371MG, ME371MG"
 "Asus, ASUS MeMO Pad Smart 10, ME301T, ME301T"
 "Asus, ASUS Trans AiO P1801, P1801-T, ASUS Tablet P1801-T"
 "Asus, ASUS TransBook Trio, TX201LA, TX201LA"
 "Asus, ASUS Transformer AiO P1801, P1801-T, ASUS Tablet P1801-T"
 "Asus, ASUS Transformer AiO P1802, P1802-T, ASUS Tablet P1802-T"
 "Asus, ASUS Transformer Book Trio, TX201LA, TX201LA"
 "Asus, ASUS Transformer Pad, K010_1, K010"
 "Asus, ASUS Transformer Pad Infinity, TF700KL, ASUS Transformer Pad TF700KL"
 "Asus, ASUS Transformer Pad TF300TG, TF300TG, ASUS Transformer Pad TF300TG"
 "Asus, ASUS Transformer Pad TF300TL, TF300TL, ASUS Transformer Pad TF300TL"
 "Asus, ASUS Transformer Pad TF502T, TF502T, ASUS Transformer Pad TF502T"
 "Asus, ASUS Transformer Pad TF600T, TF600T, ASUS Transformer Pad TF600T"
 "Asus, ASUS ZenWatch, anthias, ASUS ZenWatch"
 "Asus, Cube, asus_google_cube, asus_google_cube"
 "Asus, Eee Pad, EeePad, Transformer TF101"
 "Asus, Eee Pad, EeePad, Transformer TF101G"
 "Asus, Eee Pad Slider, SL101, Slider SL101"
 "Asus, Eee Pad TF101, TF101, TF101"
 "Asus, Eee Pad TF101, TF101, Transformer TF101"
 "Asus, Eee Pad TF101-Wi MAX, TF101-Wi MAX, TF101-Wi MAX"
 "Asus, Eee Pad Transformer, TF101, Transformer TF101"
 "Asus, Eee Pad Transformer Prime, TF201, TF201"

supported device.txt

"Asus, Eee Pad Transformer Prime, TF201, Transformer Prime TF201"
 "Asus, Eee Pad Transformer Prime, TF201, Transformer TF201"
 "Asus, EeePad Slider SL101, SL101, Slider SL101"
 "Asus, Fonepad 7 (FE170CG), K012, K012"
 "Asus, Fonepad 7 (FE171CG), K01N_1, K01N"
 "Asus, Fonepad 7 (FE171CG), K01N_2, K01N"
 "Asus, Fonepad 7 (FE171MG), K01F, K01F"
 "Asus, Fonepad 7 (FE375CG), K019_1, K019"
 "Asus, Fonepad 7 (FE375CXG), K019_3, K019"
 "Asus, Fonepad 7 (FE375CXG), K019_4, K019"
 "Asus, Fonepad 7 (ME175CG), K00Z, K00Z"
 "Asus, Fonepad 7 (ME372CG), K00E, K00E"
 "Asus, Fonepad 7 LTE (FE375CL), K01Q, K01Q"
 "Asus, Fonepad 7 LTE (ME372CL), K00Y, K00Y"
 "Asus, Fonepad 7 (FE375CXG), K019_2, K019"
 "Asus, Fonepad 8 (FE380CG), K016_1, K016"
 "Asus, Fonepad 8 (FE380CXG), K016_2, K016"
 "Asus, Fonepad 8 (FE380CXG), K016_3, K016"
 "Asus, Fonepad Note 6 (ME560CG), K00G, K00G"
 "Asus, MeMO PAD, me172v, ME172V"
 "Asus, MeMO Pad (ME103K), K01E_1, K01E"
 "Asus, MeMO Pad (ME103K), K01E_2, K01E"
 "Asus, MeMO Pad 10 (ME102A), K00F, K00F"
 "Asus, MeMO Pad 7, K013C, K013C"
 "Asus, MeMO Pad 7 (FE7010CG), K012_2, K012_2"
 "Asus, MeMO Pad 7 (ME170C), K017, K017"
 "Asus, MeMO Pad 7 (ME171C), K01U_1, K01U"
 "Asus, MeMO Pad 7 (ME171C), K01U_2, K01U"
 "Asus, MeMO Pad 7 (ME176C), K013, K013"
 "Asus, MeMO Pad 7 (ME176CX), K013_1, K013"
 "Asus, MeMO Pad 7 (ME572C), K007, K007"
 "Asus, MeMO Pad 7 (ME70C), K01A, K01A"
 "Asus, MeMO Pad 7 LTE (ME375CL), K00X, ASUS MeMO Pad 7"
 "Asus, MeMO Pad 7 LTE (ME572CL), K00R, K00R"
 "Asus, MeMO Pad 7 LTE (ME7530CL), K00X_1, K00X"
 "Asus, MeMO Pad 8 (AST21), K015, AST21"
 "Asus, MeMO Pad 8 (ME181C), K011, K011"
 "Asus, MeMO Pad 8 (ME181CX), K011_1, K011"
 "Asus, MeMO Pad 8 (ME581C), K01H, K01H"
 "Asus, MeMO Pad 8 (ME581CL), K015, K015"
 "Asus, MeMO Pad FHD 10 (ME302KL), ME302KL, ME302KL"
 "Asus, MeMO Pad HD 7 (ME173X), ME173X, ME173X"
 "Asus, MeMO Pad HD 7 (ME173XX), K00U, K00U"
 "Asus, MeMO Pad HD 8 (ME180A), K00L, K00L"
 "Asus, MeMO Pad HD7 Dual SIM (ME175KG), ASUS-K00S, ASUS K00S"
 "Asus, MeMo Pad 10 (ME302C), ME302C, ME302C"
 "Asus, MeMo Pad HD 7 (ME173XX), K00U, K00U"
 "Asus, Nexus 7 (2012), grouper, Nexus 7"
 "Asus, Nexus 7 (2012), tilapia, Nexus 7"
 "Asus, Nexus 7 (2013), deb, Nexus 7"
 "Asus, Nexus 7 (2013), flo, Nexus 7"
 "Asus, Nexus Pi ayer, fugu, Nexus Pi ayer"
 "Asus, Nuvi fone, a50, Garm n-Asus A50"
 "Asus, PadFone, PadFone, PadFone"
 "Asus, PadFone 2, A68, PadFone 2"
 "Asus, PadFone E (A68M), ASUS-T008, PadFone T008"
 "Asus, PadFone Infi ni ty, A80, PadFone Infi ni ty"
 "Asus, PadFone Infi ni ty, ASUS-A80, PadFone Infi ni ty"
 "Asus, PadFone Mi ni , ASUS-T00C, PadFone T00C"
 "Asus, PadFone S (PF500KL), ASUS_T00N, ASUS_T00N"
 "Asus, PadFone X (A91), ASUS-T00D, ASUS PadFone X"
 "Asus, PadFone X mi ni (PF450CL), ASUS-T00S, ASUS PadFone X mi ni "
 "Asus, PadFone X mi ni (PF450CL), ASUS-T00S, ASUS_T00T"

supported device.txt

"Asus, PadFone mi ni , ASUS-T00C, PadFone T00C"
 "Asus, PadFone mi ni , ASUS_T00E, ASUS_T00E"
 "Asus, RTC-700A, RTC-tablet, RTC-tablet"
 "Asus, T101TA, T10xTA, T10xTA"
 "Asus, TF700T, TF700T, ASUS Pad TF700T"
 "Asus, TF700T, TF700T, ASUS Transformer Pad TF700T"
 "Asus, TX201LAF, TX201LAF, TX201LAF"
 "Asus, The new PadFone Infi ni ty (A86), ASUS-A86, PadFone T004"
 "Asus, Transformer Pad, TF300T, ASUS Pad TF300T"
 "Asus, Transformer Pad, TF300T, ASUS Transformer 300"
 "Asus, Transformer Pad, TF300T, ASUS Transformer Pad TF300T"
 "Asus, Transformer Pad (TF103C), K010, K010"
 "Asus, Transformer Pad (TF103C), K010_3, K010"
 "Asus, Transformer Pad (TF103CG), K018, K018"
 "Asus, Transformer Pad (TF303CL), K014, K014"
 "Asus, Transformer Pad (TF303K), K01B, K01B"
 "Asus, Transformer Pad Infi ni ty (TF701T), K00C, K00C"
 "Asus, Transformer TF101G, TF101G, Transformer TF101G"
 "Asus, ZenFone 2 (ZE500CL), ASUS_Z00D, ASUS ZenFone 2"
 "Asus, ZenFone 2 (ZE500CL), ASUS_Z00D, ASUS ZenFone 2E"
 "Asus, ZenFone 2 (ZE500CL), ASUS_Z00D, Z00D"
 "Asus, ZenFone 2 (ZE550ML), Z008_1, ASUS_Z008D"
 "Asus, ZenFone 2 (ZE551ML), Z00A, ASUS_Z00AD"
 "Asus, ZenFone 2 (ZE551ML), Z00A, ASUS_Z00ADA"
 "Asus, ZenFone 2 (ZE551ML), Z00A_1, ASUS_Z00AD"
 "Asus, ZenFone 2 (ZE551ML), Z00A_1, ASUS_Z00ADB"
 "Asus, ZenFone 2 Laser (ZE500KG), ASUS_ZOORD_5, ASUS_ZOORD"
 "Asus, ZenFone 2 Laser (ZE500KG), ASUS_ZOORD_7, ASUS_ZOORD"
 "Asus, ZenFone 2 Laser (ZE500KL), ASUS_Z00E_1, ASUS_Z00ED"
 "Asus, ZenFone 2 Laser (ZE500KL), ASUS_Z00E_2, ASUS_Z00ED"
 "Asus, ZenFone 2 Laser (ZE500KL), ASUS_Z00E_2, ASUS_Z00EDB"
 "Asus, ZenFone 2 Laser (ZE550KL), ASUS_ZOOL_63, ASUS_ZOOLD"
 "Asus, ZenFone 2 Laser (ZE550KL), ASUS_ZOOL_63, ASUS_ZOOLDC"
 "Asus, ZenFone 2 Laser (ZE550KL), ASUS_ZOOL_93, ASUS_ZOOLD"
 "Asus, ZenFone 2 Laser (ZE551KL), ASUS_ZOOT, ASUS_ZOOTD"
 "Asus, ZenFone 2 Laser (ZE600KL), ASUS_ZO0M, ASUS_ZO0MD"
 "Asus, ZenFone 2 Laser (ZE601KL), ASUS_Z011, ASUS_Z011D"
 "Asus, ZenFone 4 (A400CG), ASUS_T00I, ASUS_T00I "
 "Asus, ZenFone 4 (A400CG), ASUS_T00I, ASUS_T00I -D"
 "Asus, ZenFone 4 (A450CG), ASUS_T00Q, ASUS_T00Q"
 "Asus, ZenFone 5, ASUS_T00F, ASUS_T00F"
 "Asus, ZenFone 5, ASUS_T00J, ASUS_T00J"
 "Asus, ZenFone 5 (A500CG), ASUS_T00F, ASUS_T00F"
 "Asus, ZenFone 5 (A500CG), ASUS_T00F1, ASUS_T00F"
 "Asus, ZenFone 5 (A501CG), ASUS_T00J1, ASUS_T00J"
 "Asus, ZenFone 5 (A502CG), ASUS_T00K, ASUS_T00K"
 "Asus, ZenFone 5 LTE (A500KL), ASUS_T00P, ASUS_T00P"
 "Asus, ZenFone 6, ASUS_T00G, ASUS_T00G"
 "Asus, ZenFone 6 (A600CG), ASUS_T00G, ASUS_T00G"
 "Asus, ZenFone 6 (A601CG), ASUS_Z002, ASUS_Z002"
 "Asus, ZenFone C (ZC451CG), ASUS_Z007, ASUS_Z007"
 "Asus, ZenFone Sel fi e (ZD551KL), ASUS_Z00U_1, ASUS_Z00UD"
 "Asus, ZenFone Sel fi e (ZD551KL), ASUS_Z00U_2, ASUS_Z00UD"
 "Asus, ZenPad 10 (Z300C), P023_1, P023"
 "Asus, ZenPad 10 (Z300C), P023_2, P023"
 "Asus, ZenPad 10 (Z300CG), P021, P021"
 "Asus, ZenPad 10 (Z300CL), P01T_1, P01T_1"
 "Asus, ZenPad 7.0 (Z370C), P01W, P01W"
 "Asus, ZenPad 7.0 (Z370CG), P01V_1, P01V"
 "Asus, ZenPad 7.0 (Z370CG), P01V_2, P01V"
 "Asus, ZenPad 7.0 (Z370KL), P002_2, P002"
 "Asus, ZenPad 7.0 (Z370KL), P002_1, P002"
 "Asus, ZenPad C 7.0 (Z170C), P01Z, P01Z"

supported device.txt

"Asus, ZenPad C 7.0 (Z170C), P01Z_2, P01Z"
 "Asus, ZenPad C 7.0 (Z170CG), P01Y, P01Y"
 "Asus, ZenPad C 7.0 (Z170CG), P01Y_2, P01Y"
 "Asus, ZenPad C 7.0 (Z170MG), P001, P001"
 "Asus, ZenPad C 7.0 (Z170MG), P001_2, P001"
 "Asus, ZenPad S 8.0 (Z580C), P01M_2, P01M"
 "Asus, ZenPad S 8.0 (Z580CA), P01M_1, P01MA"
 "Asus, ZenPad S 8.0 (Z580CA), P01M_3, P01MA"
 "Asus, ZenPadC 7.0 (Z170MG), P001_2, P001_2"
 "Asus, Zenfone Go (ASUS_Z00VD), ASUS_Z00VD, ASUS_Z00VD"
 "Asus, Zenpad 8 LTE, P024_2, P024"
 "Asus, Zenpad 8 LTE, P024_4, P024"
 "Asus, Zenpad 8.0 (Z380C), P022_1, P022"
 "Asus, Zenpad 8.0 (Z380C), P022_2, P022"
 "Asus, Zenpad 8.0 (Z380KL), P024_1, P024"
 "Asus, \xe9\xa3\xb\x9b\xe9\xa6\xac (T500TLT), ASUS_X002, ASUS_X002"
 "AtGames-zooti, ZOOTI PAD ZT-701, ZT-701, ZT-701"
 "Auchan, Q. 4514, Q4514, Q4514"
 "Auchan, Q4T10I N, Q4T10I N, Q4T10I N"
 "Auchan, Q4T7I N, Q4T7I N, Q4T7I N"
 "Auchan, Q4T7I N3G, Q4T7I N3G, Q4T7I N3G"
 "Auchan, Q4T8I N, Q4T8I N, Q4T8I N"
 "Auchan, QI LIVE, Q4T10I NK, Q4T10I NK"
 "Auchan, S3T10I N, S3T10I N, S3T10I N"
 "Auchan, S3T10I N3G, S3T10I N3G, S3T10I N3G"
 "Auchan, S3T7I N, S3T7I N, S3T7I N"
 "Auchan, S3T7I N, astar-d86, S3T7I N"
 "Auchan, S3T7I N3G, S3T7I N3G, S3T7I N3G"
 "Auchan, Sel ecl i ne X35T, X35T, X35T"
 "Auchan, Sel ecl i ne-854599, 854599, Sel ecl i ne-854599"
 "Auchan, ""Smartphone 5"""" Q. 4094""", ac50bhe, Q. 4094"
 "Audi ovox, Audi ovox T752 Tabl et, AD7L, T752"
 "Audi ovox, Audi ovox T852 Tabl et, MI D30801, T852"
 "Avoca, STB7012, STB7012, STB7012"
 "Avoca, STB7013, AVOCA, STB7013"
 "Avoca, STB8098, STB8098, STB8098"
 "Avoca, STB9097, STB9097, STB9097"
 "BMobi l e, AX1060, AX1060, AX1060"
 "BMobi l e, AX660, Bmobi l e, AX660"
 "BMobi l e, AX700, Bmobi l e, AX700"
 "BYD, DynaVox T10, T10, T10"
 "BYD, FarEastone Smart 502, Smart502, Smart 502"
 "BYD, I NHON G3, G3, G3"
 "BYD, K-Touch E815, E815, E815"
 "BYD, M601, M601, M601"
 "BYD, Moi i E996+, E996pl us, moi i E996+ "
 "BYD, PT452E, PT452E, Di gma Li nx 4.5 PT452E"
 "BYD, Presti gi o PAP5430, PAP5430, PAP5430"
 "BYD, SI 4301, SI 4301, SI 4301"
 "BYD, SOLO S450, S450, S450"
 "BYD, SP355AWG, msm7627a_sku3, SP355AWG"
 "BYD, Smart 401, ti anyu72_wet_j b3, Smart 401"
 "BYD, Smart 402, hawai i _garnet_c_w68tk, Smart402"
 "BYD, Sol o S350, S350, S350"
 "BYD, WI SKY W032I, W032I, W032I "
 "BYD, X910, X910, XOLO X910"
 "BYD, Zi ppers, Zi ppers, Vexi a Zi ppers"
 "Barnes and Nobl e, N00K\xc2\xae HD, hummi ngbi rd, BNTV400"
 "Barnes and Nobl e, N00K\xc2\xae HD+, ovati on, BNTV600"
 "Beel i ne, Beel i ne Pro 2, Beel i ne_Pro_2, Beel i ne Pro 2"
 "Beel i ne, Beel i ne Tab, Beel i ne_Tab, Beel i ne Tab"
 "Beel i ne, Beel i ne Tab 2, Tab_2, Tab_2"
 "Beel i ne, Beel i ne_Tab I S, Beel i ne_Tab_I S, Beel i ne_Tab_I S"

supported device.txt

"Beeline, Smart Dual, Beeline, Beeline Smart Dual"
"BenQ, A3, A3, A3"
"BenQ, Agora 4G, Agora_4G, Agora 4G"
"BenQ, Agora_4G_Pro, Agora_4G_Pro, Agora 4G Pro"
"BenQ, Agora_Lite, Agora_Lite, Agora Lite"
"BenQ, B502, B502, B502_SA"
"BenQ, B505, B505, B505"
"BenQ, B50_CHT, B50, B50_CHT"
"BenQ, BenQ A3, A3, A3"
"BenQ, BenQ A3c, BenQ_A3c, BenQ A3c"
"BenQ, BenQ B50, B50, B50"
"BenQ, BenQ B502, B502, B502"
"BenQ, BenQ B506, B506_TW, B506_TW"
"BenQ, BenQ F3, F3, F3"
"BenQ, BenQ F4, benq_a3s, BenQ A3s"
"BenQ, BenQ F5, BENQ_F5, BenQ F5"
"BenQ, BenQ F5, F5, BenQ F5"
"BenQ, BenQ F52_09, F52, F52_09"
"BenQ, BenQ F5_06, F5, F5_06"
"BenQ, BenQ F5_13, F5, F5_13"
"BenQ, BenQ F5_15, F5, F5_15"
"BenQ, BenQ F5_16, F5, F5_16"
"BenQ, BenQ F5_18, F5, F5_18"
"BenQ, BenQ F5_19, F5, F5_19"
"BenQ, BenQ T3, T3_17A, BenQ T3"
"BenQ, BenQ T3_08, T3_17A, BenQ T3"
"BenQ, F52, F52, F52_05"
"BenQ, Harrier Mini, harrier_mini, Harrier Mini from EE"
"BenQ, Harrier from EE, Harrier, Harrier from EE"
"BenQ, Harrier_Tab, harrier_tab, Harrier Tab from EE"
"BenQ, JD-150, JD-150_P1, JD-150"
"BenQ, JM-250, JM-250, JM-250"
"BenQ, JM-250, JM-250_P1, JM-250"
"BenQ, Kogan 4G+, Agora_4G_PLUS, Agora 4G+"
"BenQ, PT2200, PT2200, PT2200"
"BenQ, T3, T3, BenQ T3"
"BenQ, T3_17A, T3_17A, BenQ T3"
"BenQ, T47, T47, T47_05"
"Best Buy, Transformer Pad (TF103C), K010, K010"
"Bi gben, BB8252, Bi gben-TAB, BB8252"
"Bi gben, GAMETAB-ONE, GAMETAB-ONE, GAMETAB-ONE"
"Bi natone, SMART64, SMART64, SMART64"
"Bi natone, Smart 63, SMART63, SMART63"
"Bi natone, Smart 66, SMART66, SMART66"
"Bi tmore, Bi tmore Tab870, Tab870, Tab870"
"Bi tmore, GTAB700, GTAB700, NID_7010"
"Bi tmore, GTAB900, GTAB900, S952"
"Bi tmore, LUXYA MID704DC Tablet / Bi tmore Tab770, MY7317P, Tab770"
"Bi tti um, Tough Mobile, grani te, Bi tti um Tough Mobile"
"Bl aupunkt, Endeavour101, Bl aupunkt, Endeavour101"
"Bl u, Dash X, BLU_DASH_X, BLU DASH X"
"Bl u, STUDIO 7.0 LTE, bl u_s0010tw, BLU STUDIO 7.0 LTE"
"Bl u, STUDIO 7.0 LTE, bl u_s0010uu, BLU STUDIO 7.0 LTE"
"Bl uebi rd, BM180, BM180, BM180"
"Bl uedot, BLUEDOT BNT-700K, BNT-700K, BNT-700K"
"Booken, Cybook Tablet, cybtt10_bk, Cybook-Tablet"
"Borqs, Fal con, fal con, fal con"
"Bouygues Telecom, Bbox Mi ami, HMB4213H, Bouygtel TV"
"Bouygues Telecom, Bouygues Telecom Bs 451, Bs_451, Bs 451"
"Brightstar, M80461U, M80471U, M80471U"
"British Telecom, HomeSmartphone d800, d800, BT Home SmartPhone S II"
"Bunbungame, Mi SS, Mi SS, Mi SS"
"Bunbungame, KALOS, FG6Q_N, KALOS"

supported device.txt

"Bush, MyTablet 79, ac79bu, BUSH 7.85 TABLET"
"C&M, Smart TV II, stb_catv_cnm, SX930C-CC"
"CAT, CAT B15, TOUGH, B15"
"CAT, CAT B15Q, B15Q, B15Q"
"CHN TELECOM, CHN-UCAN MJ, l efhd, CHN-UCAN MJ"
"CJ HelloVision, Hello TV Smart, SX930C_CJ, SX930C_CJ"
"CMCC, M811, m811, M811"
"CMCC, M811, m811hk, M811"
"COMIO, AD7003, AD7003, AD7003"
"CZ Electronics, M3s, M3s, M3s"
"Camelus, Camelus L10, TR-10HBT, L10"
"Camelus, Camelus L7, TR-7U, L7"
"Candor, PHS-601, phs601, PHS-601"
"Carrefour, CT1000, Carrefour, CT1000"
"Carrefour, CT726, CT726, CT726"
"Carrefour, CT826, CT826, CT826"
"Carrefour, Carrefour CT1020W, M1010FP, CT1020W"
"Carrefour, Carrefour CT820, M878LP, CT820"
"Casper, TA80CA2, TA80CA2_1, TA80CA2"
"Casper, VIA T7D, VIA-T7D, VIA-T7D"
"Casper, VIA T7D 3G, VIA-T7D-3G, VIA-T7D-3G"
"Casper, VIA_T41, VIA_T41, VIA_T41"
"Cat, B15Q, CatB15Q, B15Q"
"Cat, CatS50c, CatS50c, S50c"
"Cat, S30, CatS30, S30"
"Cat, S40, CatS40, S40"
"Cat, S50, CatS50, S50"
"Ceibal, TC80RA1, TC80RA1_3, TC80RA1"
"Ceibal, TC80RA6, TC80RA6_1, TC80RA6"
"Cellon, A27, C8680, A27"
"Cellon, A5801, C8680, A5801"
"Cellon, Alphi ce, M8047, Alphi ce"
"Cellon, C3668, C3668, C3668"
"Cellon, Cl, Dream-C1, Cl "
"Cellon, CJ-1984, C8690, C8690"
"Cellon, CJ-1984, C8690, CJ-1984"
"Cellon, CJ-1984, C8690, ELITE 4.7 HD"
"Cellon, E1, Dream-E1, E1 "
"Cellon, E111, Dream-E3, E111 "
"Cellon, EK-8680, C8680, EK-8680"
"Cellon, Expl osi on, C8690, Expl osi on"
"Cellon, HW-W900, C8690, HW-W900"
"Cellon, HWW820, C8680, HW-W820"
"Cellon, Houston, C8680, Houston"
"Cellon, I CON, I CON, I CON"
"Cellon, IQ 1.1, IQ1-1, i -mobile IQ1-1"
"Cellon, Li nx PS474S, C8690, Li nx PS474S"
"Cellon, MTC SMART Run, SMART_Run, MTC SMART Run"
"Cellon, Mach, C8680, Mach"
"Cellon, Newman N2, C8690, Newman N2"
"Cellon, Q, M8047XT, Q"
"Cellon, S21, S21, Q-Smart S21"
"Cellon, SI, Dream-S1, SI "
"Cellon, SM55, C8660, C8660"
"Cellon, SM55, C8660, SM55"
"Cellon, Starmobile KNI GHT, KNI GHT, Starmobile KNI GHT"
"Cellon, VEON_C8680, C8680, VEON_C8680"
"Cellon, i -STYLE7, c8669SA, i -mobile i -STYLE 7"
"Cellon, i -STYLE7A, c8669SA, i -mobile i -STYLE 7A"
"Cellon, i -mobile IQ X, M8047SA, i -mobile IQ X"
"Cellon, i -mobile IQ X, M8047SA, i -mobile IQ XA"
"Cellon, i -mobile IQ X2A, M8050SA, i -mobile IQ X2"
"Cellon, i -mobile IQ X2A, M8050SA, i -mobile IQ X2A"

supported device.txt

"Cellon,iris pro 30,pro30,iris pro 30"
"Cellon,starTIM1,starTIM1,starTIM1"
"Cherry Mobile,Cherry W900 LTE,al7,W900 LTE"
"Cherry Mobile,H220,cti h220_sprout,H220"
"Cherry Mobile,One,H940_sprout,H940"
"Cisico,Cisico CP-DX650,CP-DX650,CP-DX650"
"Cisico,Cisico DX70,CP-DX70,CP-DX70"
"Cisico,Cisico Desktop Collaboration Experience DX70,CP-DX70,CP-DX70"
"Cisico,Cisico Desktop Collaboration Experience DX80,CP-DX80,CP-DX80"
"Claresta,G4,G4,G4"
"Claresta,G5,G5,G5"
"Claresta,G6,G6,G6"
"Claresta,S6PI us,S6PI us,S6PI us"
"Climentoni,ClEmpad 4.4 Basic Special,ClEmpad2_special,ClEmpad2_special "
"Climentoni,ClEmpad 4.4 PI us,ClEmpad2_pi us,ClEmpad2_pi us"
"Climentoni,ClEmpad 4.4 XL,ClEmpad2_XL,ClEmpad2_XL"
"Climentoni,ClEmpad 5.0 XL,ClEmpad_HR_XL,ClEmpad_HR_XL"
"Climentoni,ClEmpad Call,CLEMPADCALL,CLEMPADCALL"
"Climentoni,ClEmpad HR,ClEmpad_HR,ClEmpad_HR"
"Climentoni,ClEmpad HR PI us,ClEmpad_HR_PI us,ClEmpad_HR_PI us"
"Climentoni,My First ClEmpad HR,MFC_HR,MFC_HR"
"Climentoni,My First ClEmpad HR PI us,MFC_HR_PI us,MFC_HR_PI us"
"Climentoni,My first ClEmpad 4.4 Basic Special,MFC2_Special,MFC2_Special "
"Climentoni,My first ClEmpad 4.4 PI us,MFC2_PI us,MFC2_PI us"
"ClckN Kids,ClckN Kids,g04e,CK07T"
"Cloudfone,Cloudfone One 6.95,one695_1_coho,one695_1"
"Cloudfone,Cloudfone One 6.95,one695_1_coho,one695_1_coho"
"Cloudfone,Cloudfone One 7.0,one7_0_4_coho,one7_0_4"
"Cloudfone,Cloudfone One 7.0,one7_0_4_coho,one7_0_4_coho"
"Cloudfone,Cloudfone One 8.0,one8_0_1_coho,one8_0_1"
"Cloudfone,Cloudfone One 8.0,one8_0_1_coho,one8_0_1_coho"
"Compal,,CA22,COSMO DUO"
"Compal,,CAP5,A600"
"Compal,,CAP6,A600"
"Compal,,CAP7,A300"
"Compal,,CAP7,A8"
"Compal,,CAP7,W12"
"Compal,,cap2,Andy"
"Compal,,penguin,AX 8.6"
"Compal,TANK 4.5,ka09,TANK 4.5"
"Condor,C1+,C1PI us,C1+ "
"Condor,C7,PGN_506,PGN-506"
"Condor,C_5,u970_5,C-6"
"Condor,Condor A9,PGN_507,PGN-507"
"Condor,Condor C6+,PGN_508,PGN-508"
"Condor,HS-U939,u939e_6,HS-U939"
"Condor,PGN404,PGN404,PGN404"
"Condor,PGN509,PGN509,PGN509"
"Condor,PGN511,PGN511,PGN511"
"Cool pad,,7019_msm7627a,Cool pad 7019"
"Cool pad,,7560U,Ni vo"
"Cool pad,,801E,801E"
"Cool pad,,8710,8710"
"Cool pad,,9960,YL-Cool pad 9960"
"Cool pad,,CP5832,5832"
"Cool pad,,CP5880,5880"
"Cool pad,,CP7728,Cool pad7728"
"Cool pad,,CP8870,8870"
"Cool pad,,CP9130,N930"
"Cool pad,,Cool pad7290,Cool pad 7290"
"Cool pad,,Cool pad9080W,Cool pad 9080W"
"Cool pad,,dkb,8150"
"Cool pad,,dkb,8180"

supported device.txt

"Cool pad, , dkb, 8810"
"Cool pad, , msm7627_5820, Cool pad 5820"
"Cool pad, , msm7627_SP150, MTS-SP150"
"Cool pad, , msm7627_surf, 5860"
"Cool pad, , msm7627_surf, 7260"
"Cool pad, , msm7627_w706, Cool pad W706+ "
"Cool pad, , msm7627_w706T, Cool pad W706+ "
"Cool pad, , msm7627_w708, Cool pad W708"
"Cool pad, , msm7627a_5860S, 5860S"
"Cool pad, , msm7627a_5870, 5870"
"Cool pad, , msm7627a_7230, 7230"
"Cool pad, , msm7627a_7266, 7266"
"Cool pad, , msm7627a_9120, 9120"
"Cool pad, , msm7627a_PAP4000, PAP4000"
"Cool pad, , msm7627a_cp5910, 5910"
"Cool pad, , msm7627a_ea58, Cool pad 5010"
"Cool pad, , msm7627a_ea92, Cool pad 5210"
"Cool pad, , msm7627a_sku3, 5110"
"Cool pad, , msm7627a_sku3, 5860A"
"Cool pad, , msm7627a_sku3, 7260A"
"Cool pad, , msm8660_9900, 9900"
"Cool pad, , msm8660_CP8950, 8950"
"Cool pad, 5860E, CP5860E, 5860E"
"Cool pad, 801EM, 801EM, 801EM"
"Cool pad, 8970L, 8970L, Cool pad 8970L"
"Cool pad, Bs501, cp8870u, Bs 501"
"Cool pad, CM001, Cool padCM001, Cool pad CM001"
"Cool pad, CP5108, msm7627a_a8_5108_new, Cool pad 5108"
"Cool pad, CP5210A, msm7627a_d7_5210a, Cool pad 5210A"
"Cool pad, CP5310, cp5310, Cool pad 5310"
"Cool pad, CP5660S, 5560S, 5560S"
"Cool pad, CP5952, Cool pad5952, Cool pad 5952"
"Cool pad, CP8021, Cool pad8021, Cool pad 8021"
"Cool pad, CP8089, CP8089, Cool pad 8089"
"Cool pad, CP8089Q, CP8089Q, Cool pad 8089Q"
"Cool pad, CP8295M, 8295M, Cool pad8295M"
"Cool pad, CP8735, 8735, Cool pad 8735"
"Cool pad, CP8750, 8750, Cool pad8750"
"Cool pad, CP9190L, Cool pad9190L, Cool pad 9190L"
"Cool pad, CP9250L, Cool pad9250L, Cool pad 9250L"
"Cool pad, CP9970, 9970, Cool pad 9970"
"Cool pad, CPA520, Cool padA520, Cool pad A520"
"Cool pad, CPT1, Cool padT1, Cool pad T1"
"Cool pad, Cool mi ni , Cool mi ni , Cool mi ni "
"Cool pad, Cool pad 3700A, 3700A, CP3700A"
"Cool pad, Cool pad 5109, Cool pad5109, Cool pad 5109"
"Cool pad, Cool pad 5200, Cool pad5200, Cool pad 5200"
"Cool pad, Cool pad 5216D, 5216D, Cool pad 5216D"
"Cool pad, Cool pad 5217, msm8610, Cool pad 5217"
"Cool pad, Cool pad 5218S, msm8x25q_a5y_5218s, Cool pad 5218S"
"Cool pad, Cool pad 5219, 5219, Cool pad 5219"
"Cool pad, Cool pad 5219_C00, 5219_C00, Cool pad 5219_C00"
"Cool pad, Cool pad 5891, Cool pad5891, Cool pad 5891"
"Cool pad, Cool pad 5891S, Cool pad5891S, Cool pad 5891S"
"Cool pad, Cool pad 5951, Cool pad5951, Cool pad 5951"
"Cool pad, Cool pad 7061, CP7061, Cool pad 7061"
"Cool pad, Cool pad 7230S, Cool pad7230S, Cool pad 7230S"
"Cool pad, Cool pad 7232, CP7232, Cool pad 7232"
"Cool pad, Cool pad 7251, Cool pad7251, Cool pad 7251"
"Cool pad, Cool pad 7270, Cool pad7270, Cool pad 7270"
"Cool pad, Cool pad 7270I , 7270I , I dea ULTRA Pro"
"Cool pad, Cool pad 7275, CP7275, Cool pad 7275"
"Cool pad, Cool pad 7295A, Cool pad7295A, Cool pad 7295+ "

supported device.txt

"Cool pad, Cool pad 7295A, Cool pad7295A, Cool pad 7295A"
"Cool pad, Cool pad 7296, Cool pad7296, Cool pad 7296"
"Cool pad, Cool pad 7620L, Cool pad7620L, Cool pad 7620L"
"Cool pad, Cool pad 8079, Cool pad8079, Cool pad 8079"
"Cool pad, Cool pad 8122, Cool pad8122, Cool pad 8122"
"Cool pad, Cool pad 8198W, Cool pad8198W, Cool pad 8198W"
"Cool pad, Cool pad 8297D, Cool pad8297D, Cool pad 8297D"
"Cool pad, Cool pad 8297L-I 00, Cool pad8297L-I 00, Cool pad 8297L-I 00"
"Cool pad, Cool pad 8729, Cool pad8729, Cool pad 8729"
"Cool pad, Cool pad 8730L, Cool pad8730L, Cool pad 8730L"
"Cool pad, Cool pad 8736, 8736, Cool pad 8736"
"Cool pad, Cool pad 8971, 8971, Cool pad 8971"
"Cool pad, Cool pad 9150W, Cool pad9150W, Cool pad 9150W"
"Cool pad, Cool pad 9190_T00, Cool pad9190_T00, Cool pad 9190_T00"
"Cool pad, Cool pad 9970L, 9970L, Cool pad 9970L"
"Cool pad, Cool pad 9976A, Cool pad9976A, Cool pad 9976A"
"Cool pad, Cool pad Fl o, 7560T, Cool pad Fl o"
"Cool pad, Cool pad5218D, msm7627a_a5y_5218d, Cool pad_5218D"
"Cool pad, Cool pad5315, msm8610_s10_cp5315, Cool pad 5315"
"Cool pad, Cool pad5872, Cool pad5872, Cool pad 5872"
"Cool pad, Cool pad5879T, Cool pad5879T, Cool pad 5879T"
"Cool pad, Cool pad5891Q, Cool pad5891Q, Cool pad 5891Q"
"Cool pad, Cool pad5892, Cool pad5892, Cool pad 5892"
"Cool pad, Cool pad5950, Cool pad5950, Cool pad 5950"
"Cool pad, Cool pad5950T, Cool pad5950T, Cool pad 5950T"
"Cool pad, Cool pad7270_W00, Cool pad7270_W00, Cool pad 7270_W00"
"Cool pad, Cool pad7295C, Cool pad7295C, Cool pad 7295C"
"Cool pad, Cool pad7295C_C00, Cool pad7295C_C00, Cool pad 7295C_C00"
"Cool pad, Cool pad7295I, Cool pad7295I, Spi ce Mi -515"
"Cool pad, Cool pad7295T, Cool pad7295T, Cool pad 7295T"
"Cool pad, Cool pad7296S, Cool pad7296S, Cool pad 7296S"
"Cool pad, Cool pad7298A, Cool pad7298A, Cool pad 7298A"
"Cool pad, Cool pad7298D, Cool pad7298D, Cool pad 7298D"
"Cool pad, Cool pad7320, Cool pad7320, Cool pad 7320"
"Cool pad, Cool pad7920, 7920, Cool pad7920"
"Cool pad, Cool pad801ES, 801ES, 801ES"
"Cool pad, Cool pad8085Q, Cool pad8085Q, Cool pad8085Q"
"Cool pad, Cool pad8198T, 8198T, Cool pad8198T"
"Cool pad, Cool pad8297W, Cool pad8297W, Cool pad 8297W"
"Cool pad, Cool pad8705, Cool pad8705, Cool pad 8705"
"Cool pad, Cool pad8720L, Cool pad8720L, Cool pad 8720L"
"Cool pad, Cool pad8908, 8908, Cool pad8908"
"Cool pad, Forward_EVOLVE, Forward_EVOLVE, Forward_EVOLVE"
"Cool pad, I dea ULTRA, Cool pad7295S, I dea ULTRA"
"Cool pad, Karbonn Ti tani um S5 Pl us, Karbonn, Karbonn Ti tani um S5 Pl us"
"Cool pad, MEDI ON P5001, MEDI ON, MEDI ON P5001"
"Cool pad, MEDI ON P5001, P5001, MEDI ON P5001"
"Cool pad, Mtag 353, msm7627a_ea92_mts, Mtag 353"
"Cool pad, STARADDI CT I I I , cp8861u, STARADDI CT I I I "
"Cool pad, Spi ce Mi -496, Cool pad7268I , Spi ce Mi -496"
"Cool pad, Vodafone Smart 4G, cp8860u, Vodafone Smart 4G"
"Cool pad, VodafoneSmart4, VodafoneSmart4, Vodafone Smart 4"
"Cool pad, VodafoneSmart4turbo, VodafoneSmart4turbo, Vodafone Smart 4 turbo"
"Cool pad, cp7236, msm8610_w7_cp7236, Cool pad 7236"
"Crosscal I , ODYSSEY, ODYSSEY3G, ODYSSEY"
"DEA Factory, KTAB, KTAB, KTAB"
"DI FRNCE, DI T702201, DI T702201, NI D_7010"
"Danew, DANEW Dsl i de971DC, Dsl i de971DC, Dsl i de971DC"
"Danew, DSI i de 710, Dsl i de710, Dsl i de710"
"Danew, Danew DSI i de 750, Danew_DSI i de750, DSI i de750"
"Danew, Danew Dsl i de 1013, DSI i de1013, DSI i de 1013"
"Del I , , Del I _Grappa, Del I Aero"
"Del I , , Del I _Grappa, Mi ni _3i G"

supported device.txt

"Dell , , Streak10Pro, Dell Streak 10 Pro"
 "Dell , , qsd8250_surf, Dell Mini 5"
 "Dell , , qsd8250_surf, Dell Streak"
 "Dell , , streak7, Dell Streak 7"
 "Dell , , streak7, streak7"
 "Dell , , streakpro, 101DL"
 "Dell , , streakpro, Dell V04B"
 "Dell , , streakpro, GS01"
 "Dell , , venue, Bi zSmartPhone"
 "Dell , , venue, Dell Venue"
 "Dell , Cloud Connect, capri_wyse, CS-1A13"
 "Dell , Dell Venue 10, S0, Venue 10 5050"
 "Dell , Dell Venue 7040, EP, Venue 10 7040"
 "Dell , Streak, streak, 001DL"
 "Dell , Streak, streak, Dell M01M"
 "Dell , Streak, streak, Dell Streak"
 "Dell , Venue 7, LW, Venue 7 3741"
 "Dell , Venue 7, Venue7, Venue 7 3740"
 "Dell , Venue 7, Venue7, Venue7 3740"
 "Dell , Venue 7, Venue7, Venue7 3740 LTE"
 "Dell , Venue 7, thunderbird, Venue 7 3730"
 "Dell , Venue 7, thunderbird, Venue 7 HSPA+ "
 "Dell , Venue 8, BB, Venue 8 7840"
 "Dell , Venue 8, BB, Venue 8 7840 LTE"
 "Dell , Venue 8, Venue8, Venue 8 3840"
 "Dell , Venue 8, Venue8, Venue8 3840"
 "Dell , Venue 8, Venue8, Venue8 3840 LTE"
 "Dell , Venue 8, yellowtail, Venue 8 3830"
 "Dell , Venue 8, yellowtail, Venue 8 HSPA+ "
 "Digi Land, DL1010Q, DL1010Q, DL1010Q"
 "Digi Land, DL700D, DL700D, DL700D"
 "Digi Land, DL701Q, DL701Q, DL701Q"
 "Digi Land, DL785D, DL785D, PLT7803G"
 "Digi Lite, TA70CA1, TA70CA1, TA70CA1"
 "Digi Lite, TA70CA2, TA70CA2_1, TA70CA2"
 "Digi Lite, TA70CA3, TA70CA3_1, TA70CA3"
 "Digi Lite, TR10CD1, TR10CD1_5, TR10CD1"
 "Digi Lite, TR10CS1, TR10CS1_3, TR10CS1"
 "Diginos, Diginos DG-D07S/GP, DG-D07SGP, DG-D07SGP"
 "Digtal 2, Digtal 2 Deluxe, nucl ear-D2_Deluxe, Digtal 2-Deluxe"
 "Digtal 2, Digtal 2 Platinum, D2-963G, Digtal 2 Platinum"
 "Digtal 2, Digtal 2 Plus, Digtal 2Plus, Digtal 2 Plus"
 "Digtal Stream, Digtal Stream DWA1015D Tablet, DWA1015D, DWA1015D"
 "Digitron, i-Buddie, TR10CD1_10, TR10CD1"
 "Digitron, i_Buddie, TR10CS1_12, TR10CS1"
 "Digi x, TAB-740_G, TAB-740_G, TAB-740_G"
 "Digitron, i-Buddie, TR10CD1_11, TR10CD1"
 "Dopo, DOP0 EM63 Tablet, EM63, EM63"
 "Dopo, DOP0 GS-918, GS_918, GS-918"
 "Dopo, DP7856K, DP7856K, DP7856K"
 "Dopo, DPA23D, polaris-wifi only, DPA23D"
 "Dopo, DPM1081, RCT6203W46, DPM1081"
 "Dopo, DPM7827, RCT6773W22, DPM7827"
 "Doro, 825A, 825A, Doro 824"
 "Doro, 825A, 825A, Doro Liberto 825"
 "Doro, Doro Liberto 820 Mini, 820Mini, Doro Liberto 820 Mini "
 "Doro, Liberto 810, Liberto810, Doro Liberto 810"
 "Doro, Liberto 810, Liberto810, Doro Liberto 810-orange"
 "Doro, Liberto 810, Liberto810_S12, Doro Liberto 810"
 "Doro, Liberto 820, Liberto820, Doro Liberto 820"
 "Doro, Liberto 820 Mini, 820Mini, Doro Liberto 820 Mini "
 "Doro, Liberto 822 / 8030, DSB0010, Doro Liberto 822"
 "Dreamax, DMX-ST7A, DMX-ST7A, DMX-ST7A"

supported device.txt

"EBN, NEBUPOS3, UY3A, NEBUPOS3"
"ECS, Real Pad MA7BX2, Real Pad_MA7BX2_1, Real Pad MA7BX2"
"ECS, TC69CA2, TC69CA2_1, TC69CA2"
"ECS, TC70RA1, TC70RA1_2, TC70RA1"
"ECS, TI10RA1, TI10RA1_1, TI10RA1"
"ECS, TL10RA2, TL10RA2_1, TL10RA2"
"ECS, TP10RA1, TP10RA1_1, TP10RA1"
"ECS, TR10CS1, TR10CS1_8, TR10CS1"
"ECS, TR10RS1, TR10RS1_11, TR10RS1"
"ECS, TR10RS1, TR10RS1_2, TR10RS1"
"EG936D, Hi sense, EG936D, HS-EG936D"
"EMTEC, EMTEC F400, f400, f400"
"ENTITY, GDENTMY7317, GDENTMY7317, GDENTMY7317"
"ENVIZEN DIGITAL, ENVIZEN DIGITAL V917G, GK-MID9022, V917G"
"ENVIZEN DIGITAL, V100MD, V100MD, V100MD"
"ESI Enterprises, CKT3, CKT3, CKT3"
"ESI Enterprises, DT101Bv51, DT101Bv51, DT101Bv51"
"ESI Enterprises, DT7v51B, DT7v51B, DT7v51B"
"ESI Enterprises, Trinity T101, Trinity_T101, Trinity T101"
"ESI Enterprises, Trinity T900, Trinity_T900, Trinity T900"
"Edcon, Motion E1.1, MotionE11, MotionE11"
"Edcon, Platform vp.1, VerssedVP1, Verssed VP1"
"Edcon, Platform vp.2, VerssedVP2, Verssed VP2"
"Edcon, VERSSED platform vp.2.1, VERSSEDvp2-1, VERSSED vp2.1"
"Edcon, Verssed Platform VP3.0, VERSSED_Vp3, VERSSED vp3"
"Ematic, Cubby, SproutChannel Cubby, SproutChannel Cubby"
"Ematic, EGD078, EGD078, EGD078"
"Ematic, EGD170, EGD170, Ematic EGD170"
"Ematic, EGD172, EGD172, EGD172"
"Ematic, EGD213, EGD213, EGD213"
"Ematic, EGQ178, EGQ178, EGQ178"
"Ematic, EGQ223, EGQ223, EGQ223"
"Ematic, EGQ337, EGQ337, EGQ337"
"Ematic, EGQ347, EGQ347, EGQ347"
"Ematic, EGQ367, EGQ367, EGQ367"
"Ematic, EGQ377, EGQ377, EGQ377"
"Ematic, EGQ780, EGQ780, EGQ780"
"Ematic, EMATICEGS109, EGS109, EGS109"
"Ematic, Ematic EGD103, EGD103, EGD103"
"Ematic, Ematic EGQ307, EGQ307, EGQ307"
"Ematic, Ematic EGQ327M, EGQ327M, EGQ327M"
"Ematic, Ematic EGS017, EGS017, EGS017"
"Ematic, Ematic ETH102, ETH102, ETH102"
"Ematic, FunTab 2, FunTab2, FunTab2"
"Ematic, Sprout Channel Cubby, Cubby, SproutChannel Cubby"
"Emdoor, EM_I8180, em_i8180, em_i8180"
"Emerson, EM9, EM9, EM9"
"Emerson, Emerson EM749/748, EM749_748, EM749_748"
"Enspert, , E-TAB, E-TAB"
"Enspert, , ESP_E301, ESP_E301BK"
"Enspert, , ESP_E301, ESP_E301V"
"Enspert, , ESP_E301, ESP_E301VD"
"Enspert, , ESP_E301, ESP_E301VE"
"Enspert, , e201, ESP_E201V7"
"Enspert, , e201, enspert_e201"
"Enspert, , Illuminus, ITP-S100WD"
"Enspert, , s8073, Miacle"
"Enspert, CINCKING, s9081, CINCKING"
"Enspert, CINCKING, s9081, Cynus T2"
"Enspert, CINCKING, s9081, IMD501"
"Enspert, CINCKING, s9081, freebit Panda"
"Enspert, CINKSLIM, s8073, CINKSLIM"
"Enspert, CINKSLIM, s8073, FIY_IQ442"

supported device.txt

"Enspert, CINK SLIM, s8073, WIKO-CINK SLIM"
"Enspert, Carrefour CT1010, Carrefour, CT1010"
"Enspert, Cynus F3, s7511, Cynus F3"
"Enspert, DARKSIDE, s9301, Cinema"
"Enspert, DARKSIDE, s9301, DARKSIDE"
"Enspert, Lazer X40E, X40E, X40E"
"Enspert, MG, MGA930, A930"
"Enspert, STAIRWAY, s9111, STAIRWAY"
"Enspert, WIKO CINK PEAX, s9091, CINK PEAX"
"Enspert, WIKO CINK PEAX, s9091, EverClassic"
"Enspert, WIKO CINK+, s7505, CINKPLUS"
"Enspert, WIKO SUBLIM, s9070, SUBLIM"
"Enspert, WIKO CINK FIVE, s9201, CINK FIVE"
"Enspert, WIKO CINK FIVE, s9201, Cynus T5"
"Enspert, ori on, ori on, NGM Ori on"
"Enspert, vani tysmart, vani tysmart, NGM Vani ty Smart"
"Entel , OWN I62S, OWN-I62S, OWN-I62S"
"Entel , S3015, S3015, S3015"
"Essenti el B, Essenti el B Smart\` TAB 7800, fi ber-785q6, Smart\` Tab_7800"
"Essenti el B, Essenti el B Smart\` TAB 9001, fi ber-smart, Smart\` TAB 9001"
"Etul i ne, ETL-S4521, u939e_2, ETL-S4521"
"Etul i ne, ETL-S5042, u970_4, ETL-S5042"
"EuroLeague, Eurol eague I7a, Eurol eague, Eurol eaguePhone"
"Evercoss, One X, A65_sprout, EVERCOSS A65"
"EveryPad2, Lenovo, A3500F, EveryPad2"
"Evi ant, EVC100, EVI ANT_EVT100, EVI ANT_EVT100"
"Evi ant, EVC80, EVI ANT_EVC80, EVC80"
"Expl ay, 4Game, 4Game, 4Game"
"Expl ay, ATV, ATV, ATV"
"Expl ay, Ai r, Ai r, Ai r"
"Expl ay, Atom, Atom, Atom"
"Expl ay, Bi t, Bi t, Bi t"
"Expl ay, Bri l l i ant, Cosmi c, Bri l l i ant"
"Expl ay, Cosmi c, Cosmi c, Cosmi c"
"Expl ay, Craft, Craft, Craft"
"Expl ay, Di scovery, Pri me, Di scovery"
"Expl ay, Easy, Easy, Easy"
"Expl ay, Favori te, Favori te, Favori te"
"Expl ay, Fog, Fog, Fog"
"Expl ay, Fresh, Fresh, Fresh"
"Expl ay, Fresh, Fresh_NF, Fresh_NF"
"Expl ay, Gravi ty, T4728, Gravi ty"
"Expl ay, Hi t, Hi t, Hi t"
"Expl ay, Imperi um 7, T4729, Imperi um7"
"Expl ay, Imperi um 8, T4730, Imperi um8"
"Expl ay, Indi go, Indi go, Indi go"
"Expl ay, Joy TV, Joy_TV, Joy_TV"
"Expl ay, Leader, Leader, Leader"
"Expl ay, Li ght, Li ght, Li ght"
"Expl ay, Li ght 3G, Pri me, Li ght"
"Expl ay, M1 Pl us, Fog, M1 Pl us"
"Expl ay, Onl i ner 4, G4187, Onl i ner4"
"Expl ay, Onyx, Onyx, Onyx"
"Expl ay, Party, Party, Party"
"Expl ay, Phantom, Phantom, Phantom"
"Expl ay, Pl anet, G4187, Pl anet"
"Expl ay, Pri me, Pri me, Pri me"
"Expl ay, Pul sar, Pul sar, Pul sar"
"Expl ay, Ri o Pl ay, Ri oPl ay, Ri oPl ay"
"Expl ay, Shi ne, T5246, Shi ne"
"Expl ay, Styl e, T5246, Styl e"
"Expl ay, Surfer777 3G, Leader, Surfer7773G"
"Expl ay, Tab Mi ni , TabMi ni , TabMi ni "

supported device.txt

"Expl ay, Tornado, Tornado, Tornado"
"Expl ay, Tornado 3G, Tornado3G, Tornado3G"
"Expl ay, Vega, Vega, Vega"
"Expl ay, Wi nner, T4728, Wi nner"
"Expl ay, Wi nner 7, T4729, Wi nner7"
"Expl ay, Wi nner 8, T4730, Wi nner8"
"FBC, M24I S810, MX24, TDA02"
"FBC, M24I S820, fst01ms, M24I S820"
"FaceVsi on, FaceVsi on OC1020A, OC1020A, FV-FG6"
"FarEastTone, Smart 403, msm8226, Smart 403"
"FarEastTone, Smart 505, Smart505, Smart 505"
"FarEastTone, Smart501, Smart501, Smart501"
"FarEastTone, Smart503, MC2, Smart503"
"Fi nggo, FWSP-S1000, FWSP-S1000-HW, FWSP-S1000"
"Fi nggo, FWTA-T1000, FWTA-T1000, FWTA-T1000"
"Fl y, Ci rrus 2, Ci rrus_2, FS504"
"Fl y, Dune 3, Dune_3, IQ4507"
"Fl y, Dune 4, Dune_4, Fl y IQ4508"
"Fl y, FLY IQ4421 Quad, IQ4421_Quad, IQ4421 Quad"
"Fl y, Fl y ERA Nano 7, Fl y_IQ4407, IQ4407"
"Fl y, Fl y EVO Chi c 1, IQ4405_Quad, Fl y IQ4405_Quad"
"Fl y, Fl y Ego Art 2, Fl y_Ego_Art_2, Fl y Ego Art 2"
"Fl y, Fl y Era Energy 1, IQ4502_Quad, IQ4502 Quad"
"Fl y, Fl y Era Li fe 2, IQ456, IQ456"
"Fl y, Fl y Era Nano 6, Era_Nano_6, IQ4406"
"Fl y, Fl y Era Nano 8, IQ4400, IQ4400"
"Fl y, Fl y Era Nano 9, IQ436i , IQ436i "
"Fl y, Fl y Era Style 3, IQ4415_Quad, IQ4415 Quad"
"Fl y, Fl y Evo Chi c 2, IQ459, IQ459"
"Fl y, Fl y Evo Chi c 2, IQ459, IQ459 Quad"
"Fl y, Fl y Evo Energy4, IQ4501, Evo Energy4"
"Fl y, Fl y Evo Tech 3, IQ4414_Quad, IQ4414 Quad"
"Fl y, Fl y FS451, Ni mbus1, FS451"
"Fl y, Fl y FS502, Ci rrus_1, FS502"
"Fl y, Fl y IQ434, IQ434, IQ434"
"Fl y, Fl y IQ4420 Quad, IQ4420_Quad, IQ4420 Quad"
"Fl y, Fl y IQ4490i , IQ4490i , IQ4490i "
"Fl y, Fl y IQ4503, IQ4503, FLY IQ4503"
"Fl y, Fl y IQ4503 Quad, IQ4503_Quad, IQ4503 Quad"
"Fl y, Fl y IQ4504 Quad, IQ4504_Quad, IQ4504 Quad"
"Fl y, Fl y IQ4505, IQ4505, Fl y IQ4505"
"Fl y, Fl y IQ4505 Quad, IQ4505_Quad, IQ4505 Quad"
"Fl y, Fl y IQ4512 Quad, IQ4512_Quad, IQ4512 Quad"
"Fl y, Fl y IQ4513, IQ4513, IQ4513"
"Fl y, Fl y IQ4513 Octa, IQ4513_Octa, IQ4513 Octa"
"Fl y, Fl y IQ4514 Quad, IQ4514_Quad, Fl y IQ4514"
"Fl y, Fl y IQ4514 Quad, IQ4514_Quad, Fl y IQ4514 AF"
"Fl y, Fl y IQ4514 Quad, IQ4514_Quad, IQ4514 Quad"
"Fl y, Fl y IQ4515 Quad, IQ4515_Quad, IQ4515 Quad"
"Fl y, Fl y IQ4516 Octa, IQ4516_Octa, IQ4516"
"Fl y, Fl y IQ4516 Octa, IQ4516_Octa, IQ4516 Octa"
"Fl y, Fl y IQ458 Quad Evo Tech 2, IQ458, IQ458 Quad"
"Fl y, Fl y IQ4602, Fl y_IQ4602, Fl y IQ4602"
"Fl y, Fl y IQ4602, IQ4602_Quad, IQ4602 Quad"
"Fl y, Fl y Iri s, FLY_IQ4400, FLY_IQ4400_AF"
"Fl y, Fl y Ni mbus 2, Ni mbus_2, FS452"
"Fl y, Fl y Ni mbus 4, Ni mbus_4, FS551"
"Fl y, Fl y Ni mbus3, Ni mbus3, FS501"
"Fl y, Fl y Phoeni x 2, IQ4410i , Phoeni x 2"
"Fl y, Fl y Stratus 1, Stratus1, FS401"
"Fl y, Fl y Ii fe Connect 10.1, Fl y Ii fe Connect_101_3G_2, Fl y Ii fe Connect 10.1 3G 2"
"Fl y, Fl y Ii fe Connect 7 3G 2, Fl y Ii fe7, Fl y Ii fe Connect 7 3G 2"
"Fl y, Fl y Ii fe Connect 7.85 3G 2, Fl y Ii fe, Fl y Ii fe Connect 7.85 3G 2"

supported device.txt

"Fly, IQ4401, IQ4401, IQ4401"
"Fly, IQ4409 Quad, IQ4409_Quad, IQ4409 Quad"
"Fly, IQ4413 Quad, IQ4413_Quad, IQ4413_Quad"
"Fly, IQ4415, IQ4415, IQ4415"
"Fly, IQ4416, IQ4416, IQ4416"
"Fly, IQ4417 Quad, IQ4417_Quad, IQ4417 Quad"
"Fly, IQ4418, IQ4418, Fly IQ4418 AF"
"Fly, IQ4418, IQ4418, IQ4418"
"Fly, IQ4509, IQ4509, IQ4509"
"Fly, IQ4551, Epi c_Note, IQ4551"
"Fly, IQ4601, IQ4601, IQ4601"
"Fly, Tornado One, IQ4511_Octa, FLY IQ4511"
"Fly, Tornado One, IQ4511_Octa, IQ4511 Octa"
"Fly, Tornado One, IQ4511_Octa, IQ4511 TR"
"Foxconn, , A1, MUCHTEL A1"
"Foxconn, , A800, Wel l coM-A800"
"Foxconn, , Boston, Boston"
"Foxconn, , Boston, Orange_Boston"
"Foxconn, , FE6, FE6"
"Foxconn, , G1305, GSmart-G1305"
"Foxconn, , K2, E120"
"Foxconn, , K3, E130"
"Foxconn, , SF4Y6, SF4Y6"
"Foxconn, , a1, Rstream-A1"
"Foxconn, , a800, Wel l coM-A800"
"Foxconn, , a89, Wel l coM-A89"
"Foxconn, , a99, Wel l coM-A99"
"Foxconn, , axi oo, PI C0pad-QGN"
"Foxconn, , fb0, FI H-FB0"
"Foxconn, , fm600, Camangi -FM600"
"Foxconn, , hd710, Commti va-HD710"
"Foxconn, , m500, MUSN-M500"
"Foxconn, , magnumhd, cherry-MagnumHD"
"Foxconn, , mangrove7, Camangi -Mangrove7"
"Foxconn, , mi 410, CSL-MI 410"
"Foxconn, , msm7627_surf, EV-S110"
"Foxconn, , msm7627_surf, FI H-FOX"
"Foxconn, , msm7627_surf, FI H-FM6"
"Foxconn, , msm7627_surf, KT-F100"
"Foxconn, , msm7627_surf, KT-S110"
"Foxconn, , muchtel a2, MUCHTEL-A2"
"Foxconn, , musn-t800, Cherry-MUSN-T800"
"Foxconn, , superi on, cherry mobi l e-SUPERI ON"
"Foxconn, , t800, MUSN-T800"
"Foxconn, , vi go410, Axi oo-VI G0410"
"Foxconn, , vt100, V-T100"
"Foxconn, A5, A5, A5"
"Foxconn, CSL Spi ce MI 700, mi 700, CSL_Spi ce_MI 700"
"Foxconn, CSL Spi ce MI 700, mi 700, Spi ce_MI 700"
"Foxconn, Casper_VI A_A6108, SI 1, Casper_VI A_A6108"
"Foxconn, Commti va N700, n700, Commti va-N700"
"Foxconn, Dol phi n 70e Bl ack, dbl ack, Dol phi n 70e Bl ack"
"Foxconn, InFocus IN260, IN260, IN260"
"Foxconn, MUSN COUPLE, coupl e, COUPLE"
"Foxconn, SH530U, sh530u, SH530U"
"Foxconn, SH930W, FCN, SH930W"
"Foxconn, SHARP SH837W, S1U, SH837W"
"Foxconn, SHARP SH630E, SAE, SHP-SH630E"
"Foxconn, SHARP SH631W, S2U, SH631W"
"Foxconn, SHARP SH837W, S1U, SH837W"
"Foxconn, Vi ewPhone3, vi ewphone3, Vi ewPhone3"
"Foxconn, XOLO, AZ510, X900"
"Foxconn, XOLO_X1000, SI 1, XOLO_X1000"

supported device.txt

"Foxconn, vi zi o VP700, S1U, VP700"
"Foxconn, vi zi o VP800, FCN, VP800"
"Freebox, Freebox Mini 4K, fbx61c, Freebox Player Mini "
"Fuj i tsu, ARROWS A SoftBank 101F, SBM101F, 101F"
"Fuj i tsu, ARROWS A SoftBank 201F, SBM201F, 201F"
"Fuj i tsu, ARROWS A SoftBank 202F, SBM202F, 202F"
"Fuj i tsu, ARROWS A SoftBank 301F, SBM301F, 301F"
"Fuj i tsu, ARROWS ES IS12F, FJI 12, IS12F"
"Fuj i tsu, ARROWS Ki ss F-03D, f11sky, F-03D"
"Fuj i tsu, ARROWS Ki ss F-03E, F03E, F-03E"
"Fuj i tsu, ARROWS M01, M01, M01"
"Fuj i tsu, ARROWS M305, M305, M305"
"Fuj i tsu, ARROWS M555, M555, M555"
"Fuj i tsu, ARROWS M555, M555SB, M555"
"Fuj i tsu, ARROWS Me F-11D, F11D, F-11D"
"Fuj i tsu, ARROWS NX F-06E, F06E, F-06E"
"Fuj i tsu, ARROWS S EM01F, EM01F, EM01F"
"Fuj i tsu, ARROWS Tab F-05E, F05E, F-05E"
"Fuj i tsu, ARROWS Tab FJT21, FJT21_j p_kdi , FJT21"
"Fuj i tsu, ARROWS Tab LTE F-01D, bl aze_ tabl et, F-01D"
"Fuj i tsu, ARROWS Tab Wi -Fi FAR70B, FAR70B, FAR70B"
"Fuj i tsu, ARROWS Tab Wi -Fi FAR75A/70A, bl aze_ tabl et, FAR7"
"Fuj i tsu, ARROWS V F-04E, F04E, F-04E"
"Fuj i tsu, ARROWS X F-02E, F02E, F-02E"
"Fuj i tsu, ARROWS X F-10D, F10D, F-10D"
"Fuj i tsu, ARROWS X LTE F-05D, bl aze, F-05D"
"Fuj i tsu, ARROWS Z FJL22, FJL22_j p_kdi , FJL22"
"Fuj i tsu, ARROWS Z ISW11F, FJI 11, ISW11F"
"Fuj i tsu, ARROWS Z ISW13F, FJI 13, ISW13F"
"Fuj i tsu, ARROWS ef FJL21, FJL21, FJL21"
"Fuj i tsu, ARROWS mu F-07D, f11apo, F-074"
"Fuj i tsu, ARROWS mu F-07D, f11apo, F-07D"
"Fuj i tsu, ARROWS mu F-07D, f11apo, FJJB091"
"Fuj i tsu, Di sney Mobi le on docomo F-07E, F07E, F-07E"
"Fuj i tsu, Di sney Mobi le on docomo F-08D, bl aze, F-08D"
"Fuj i tsu, F-01F, F01F, F-01F"
"Fuj i tsu, F-01H, F01H, F-01H"
"Fuj i tsu, F-02F, F02F, F-02F"
"Fuj i tsu, F-02G, F02G, F-02G"
"Fuj i tsu, F-03F, F03F, F-03F"
"Fuj i tsu, F-03G, F03G, F-03G"
"Fuj i tsu, F-04F, F04F, F-04F"
"Fuj i tsu, F-04G, F04G, F-04G"
"Fuj i tsu, F-05F, F05F, F-05F"
"Fuj i tsu, F-05G, F05G, F-05G"
"Fuj i tsu, F-06F, F06F, F-06F"
"Fuj i tsu, F-09D ANTEPRI MA, F09D, F-09D"
"Fuj i tsu, F-09E, F09E, F-09E"
"Fuj i tsu, F-12C, f11ei f, F-12C"
"Fuj i tsu, FARTM9334P1, FARTM9334, FARTM9334P1"
"Fuj i tsu, FARTM933KZ, FARTM933KZ, FARTM933KZ"
"Fuj i tsu, FARTMB611Y, FARTMB611Y, FARTMB611Y"
"Fuj i tsu, FHMD001, FHMD001, FHMD001"
"Fuj i tsu, M305, M305, M305"
"Fuj i tsu, M363/P, UY1, M363/P"
"Fuj i tsu, Pati o100, Pati o100, Pati o100"
"Fuj i tsu, Pati o100, Pati o100_3G, Pati o100_3G"
"Fuj i tsu, REGZA Phone IS11T, TSI 11, IS11T"
"Fuj i tsu, REGZA Phone T-01C, tg03, IS04"
"Fuj i tsu, REGZA Phone T-01C, tg03, T-01C"
"Fuj i tsu, REGZA Phone T-01D, bl aze, T-01D"
"Fuj i tsu, REGZA Phone T-02D, T02D, T-02D"
"Fuj i tsu, Raku-Raku SMART PHONE F-12D, F12D, F-12D"

supported device.txt

"Fujitsu, Raku-Raku SMART PHONE2 F-08E, F08E, F-08E"
"Fujitsu, STYLISTIC M350/CA2, M350, M350"
"Fujitsu, STYLISTIC M532, mx532, M532"
"Fujitsu, STYLISTIC M702, M702, M702"
"Fujitsu, STYLISTIC MH350, MH350, MH350"
"Fujitsu, STYLISTIC S01, S01, S01-orange"
"Fujitsu, SZJ-JS101, SZJ101, SZJ-JS101"
"Funai Electric, , smdkv210, ALM-001J"
"Future Mobile Technology, Dual 8, FMT-NT8A42-01, FMT-NT8A42-01"
"Future Mobile Technology, FMT-NM7054-01, FMT-NM7054-01, FMT-NM7054-01"
"Future Mobile Technology, FMT-NM7054-03, FMT-NM7054-03, FMT-NM7054-03"
"Future Mobile Technology, FMT-NM7058-03, FMT-NM7058-03, FMT-NM7058-03"
"Future Mobile Technology, netsurferDUAL 7, FMT-NM7116-01, FMT-NM7116-01"
"G53, TA71CA3, TA71CA3_1, TA71CA3"
"GD Classbook, TA80CA1, TA80CA1_2, TA80CA1"
"GENERAL MOBILE, General Mobile E-tab 4, mehmet, e-tab4"
"GOCLEVER, QUANTUM_700S/QUANTUM 700S, QUANTUM_700S, QUANTUM_700S"
"GOCLEVER, TQ700/QUANTUM 700/TAB, TQ700, TQ700"
"GSmart, Akta A4, Akta_A4, Akta_A4"
"GSmart, Arty A3, Arty_A3, GSmart Arty A3"
"GSmart, GSmart Aku A1, Aku_A1, GSmart Aku A1"
"GSmart, GSmart Alto A2, Alto_A2, GSmart Alto A2"
"GSmart, GSmart GS202+, GSmart_GS202, GSmart GS202+ "
"GSmart, GSmart GSmart SX1, GBC_bravo, GSmart SX1"
"GSmart, GSmart Guru G1, Guru_G1, GSmart Guru G1"
"GSmart, GSmart Maya M1, MayaM1, GSmart Maya M1"
"GSmart, GSmart Maya M1 v2, Maya_M1_v2, GSmart Maya M1 v2"
"GSmart, GSmart Rey R3, Rey_R3, GSmart Rey R3"
"GSmart, GSmart Rio R1, Rio_R1, GSmart Rio R1"
"GSmart, GSmart Roma R2, Roma_R2, GSmart Roma R2"
"GSmart, GSmart SX1, bravo, GSmart SX1"
"GSmart, GSmart Sierra S1, GSmart_Sierra_S1, GSmart Sierra S1"
"GSmart, GSmart T4, GSmart_T4, GSmart T4"
"GSmart, GSmart Tuku T2, Tuku_T2, GSmart Tuku T2"
"GSmart, GX2, GBC_ares, GX2"
"GSmart, Mi ka M2, Mi ka_M2, GSmart Mi ka M2"
"GSmart, Mi ka M3, Mi ka_M3, GSmart Mi ka M3"
"GSmart, Saga_S3, Saga_S3, GSmart Saga S3"
"GSmart, Si mba SX1, GBC_bravo, Si mba SX1"
"GSmart, Si mba SX1, bravo, Si mba SX1"
"Gal apad, Gal apad S6, GALAPAD_S6, GALAPAD_S6"
"Garmi n, , a10, Garmi n-Asus A10"
"Garmi n, Monterra, monterra, Monterra"
"Garmi n, Nuvi 3595, scorpio, nuvi 3595"
"Garmi n, Nuvi fone, a50, Garmi n-Asus A50"
"Garmi n, Nuvi fone, a50, Garmi nfone"
"Garmi n, Nuvi fone, a50, nuvi fone A50"
"Garmi n, Nuvi fone, a50, n\xc3\xbcvi fone A50"
"Garmi n, nuvi 3590, scorpio, nuvi 3590"
"Garmi n, nuvi 3592, scorpio, nuvi 3592"
"Garmi n, nuvi 3595, scorpio, nuvi 3595"
"General Mobile, Discovery Air, Discovery_Air, Discovery Air"
"General Mobile, Discovery II Mini, Discovery_II_Mini, Discovery II Mini "
"General Mobile, General Mobile 4G, gm4g_s_sprout, General Mobile 4G"
"General Mobile, General Mobile 4G, gm4gtkc_s_sprout, General Mobile 4G"
"General Mobile, General Mobile 4G Dual, gm4g_sprout, General Mobile 4G Dual "
"General Mobile, E-Tab10, blue_eye, E-Tab10"
"Geniatech, Enjoy TV Quad-Core Box, ATV581, Enjoy TV Quad-Core Box"
"Getac, Getac Z710, z710, Getac Z710"
"Gi gabyte, , G1317S, GSmart G1317S"
"Gi gabyte, 9788, 9788, 9788"
"Gi gabyte, Boston 4G, boston_4g, Boston 4G"
"Gi gabyte, E9771, E9771, E9771"

supported device.txt

"Gi gabyte, GSmart G1310, G1310, GSmart G1310"
"Gi gabyte, GSmart G1315, G1315, GSmart G1315"
"Gi gabyte, GSmart G1317, G1317D, GSmart G1317D"
"Gi gabyte, GSmart G1342, msm7627a, GSmart G1342"
"Gi gabyte, GSmart G1345, msm7627_sku2, GSmart G1345"
"Gi gabyte, GSmart G1355, G1355, GSmart G1355"
"Gi gabyte, GSmart G1362, G1362, GSmart G1362"
"Gi gabyte, GSmart GS202, GS202, GSmart GS202"
"Gi gabyte, Gi gabyte SB506, SB506, SB506"
"Gi gabyte, Gi gabyte SB510 / IBT-102, SB510, SB510"
"Gi gabyte, Hipstreet 9DTB7 / Lazer MY9308P, AMLMY9308P, 9DTB7"
"Gi gabyte, Hipstreet 9DTB7 / Lazer MY9308P, AMLMY9308P, MY9308P"
"Gi gabyte, P102g, P102g, P102G"
"Gi gabyte, PAPI LIO G1, inhon77_cidal s, INHON PAPI LIO G1"
"Gi gabyte, PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008, MI D1005_K, GS-1008"
"Gi gabyte, PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008, MI D1005_K, MAGPAD"
"Gi gabyte, PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008, MI D1005_K, PLT1066"
"Gi gabyte, PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008, MI D1005_K, TEACTAB"
"Gi gabyte, SAF3011, SAF3011, SAF3011"
"Gi gabyte, TB100, TB100, Gi gabyte TB100"
"Gi gabyte, TB100, TB100, TB100"
"Gi gabyte, TECNO P3S, P3S, TECNO P3S"
"Gi gabyte, TM105, TM105, TM105"
"Gi gabyte, TM105A, TM105A, Aero1021/P1021HCBA4C1VXX"
"Gi gabyte, TM105A, TM105A, Gi aci er"
"Gi gabyte, TM105A, TM105A, Qrypton1010"
"Gi gabyte, TM105A, TM105A, TM105A"
"Gi gabyte, TM75A, TM75A, GSmart7Tab"
"Gi gabyte, TM75A, TM75A, Qrypton7"
"Gi gabyte, TM75A, TM75A, TM75A"
"Gi gabyte, TM75A, TM75A, Voyager"
"Gi gabyte, TM75A-V, TM75A-V, TM75A-V"
"Gi gabyte, W5510, W5510, W5510"
"Gi gabyte, W6360, W6360, W6360"
"Gi gabyte, mexi co, Lani x, i l i umPAD"
"Gi gaset, Gi gaset QV1030, FG6Q, Gi gaset QV1030"
"Gi gaset, Gi gaset QV830, UY8, Gi gaset QV830"
"Gi gaset, Gi gaset QV831, UY8, Gi gaset QV831"
"Gi gaset, Maxwel I 10, maxwel I _10, 80-1"
"Gi gaset, Maxwel I -10, maxwel I _10, 80-1"
"Gi gaset, SL930, I i on_s, SL930"
"Gi onee, F301, F301, F301"
"Gi onee, F303, F303, F303"
"Gi onee, ForwardZero, V6L, V6L"
"Gi onee, GN9000, S5_5, GN9000"
"Gi onee, GN9006, GN9006, GN9006"
"Gi onee, GN9006, GN9006, Gi ONEE S7"
"Gi onee, M2, M2, M2"
"Gi onee, M3, Gi ONEE_M3, M3"
"Gi onee, M3, M3, M3"
"Gi onee, M3mi ni , Gi ONEE_WBL7315, M3mi ni "
"Gi onee, P3S, Gi ONEE_WBW5613, P3S"
"Gi onee, P4, P4, P4"
"Gi onee, P4S, P4S, P4S"
"Gi onee, P6, P6, P6"
"Gi onee, S_pl us, Gi ONEE_WBL7511, S_pl us"
"Gi onee, S5. 1, GN9005, GN9005"
"Gi onee, S5. 1, S5_1, S5. 1"
"Gi onee, S5. 5, S5_5, S5. 5"

supported device.txt

"Gionee, V4S, V4S, V4S"
"Gionee, V5, V5, V5"
"GoCl ever, INSI GNI A_550i , INSI GNI A_550i , INSI GNI A_550i "
"GoCl ever, QUANTUM_1010N, QUANTUM_1010N, QUANTUM_1010N"
"GoCl ever, QUANTUM_400_LI TE, QUANTUM_400_LI TE, QUANTUM_400_LI TE"
"GoCl ever, QUANTUM_550, QUANTUM_550, QUANTUM_550"
"Googl e, Gal axy S4 Googl e Pl ay edi ti on, j gedl te, GT-I9505G"
"Googl e, Proj ect Tango Tabl et Devel opment Ki t, yel lowstone, Proj ect Tango Tabl et Devel opment Ki t"
"Googl e, Proj ect Tango Tabl et Devel opment Ki t, yel lowstone, Yel lowstone"
"Gradi ente, i phone C600, GBC_bravo, i phone C600"
"Gradi ente, i phone C600, bravo, i phone C600"
"Grundig, GTB1030, TA10CA2, TA10CA2"
"Grundig, GTB1050, GTB1050, GTB_1050"
"Grundig, GTB850, GTB850, GTB_850"
"Grundig, TC69CA2, GTB801, GTB_801"
"Gtel , A714 Vi vo Pl ay, A714_Vi vo_Pl ay, A714_Vi vo_Pl ay"
"Gtel , A716 Inspi re Li fe, A716_Inspi re_Li fe, A716_Inspi re_Li fe"
"Gtel , A726 Infi ni ty Li te, A726_Infi ni ty_Li te, A726_Infi ni ty_Li te"
"HANNSpree, HANNSpree HSG1279, HANNSpad, HSG1279"
"Hi sense, HS-EG916, EG916, HS-EG916"
"HKC, HKC_A79 Tabl et, EM62, A79"
"HKT, eye3, UY3-PCW, eye3"
"HP, 10, spruce, HP_10"
"HP, 10 Pl us, torsa, HP_10 Pl us"
"HP, 7 G2, redwood, HP_7 G2"
"HP, 7 Pl us, l lex, HP_7 Pl us"
"HP, 7 Pl us G2, deschutes, HP_7 Pl us G2"
"HP, 7 Tabl et, Mesqui te, HP_7"
"HP, 7 Voi ce Tab, kl ondi ke, HP_7 Voi ceTab"
"HP, 7 Voi ceTab, yukon, HP_7 Voi ceTab"
"HP, 7. 1, Hol ly, HP_7. 1"
"HP, 8, Fir, HP_8"
"HP, 8 G2, mapl e, HP_8 G2"
"HP, Bonsai_10 HD, bonsai_10, HP_Sl ate_10 HD"
"HP, HP_Sl ate_7, pi ne, HP_Sl ate_7"
"HP, HP_Sl ateBook_10 x2 PC, 3645, HP_Sl ateBook_10 x2 PC"
"HP, Pro Sl ate_10 EE G1, bulldog, HP_Pro Sl ate_10 EE G1"
"HP, Pro Sl ate_10 EE G1, hound, HP_Pro Sl ate_10 EE G1"
"HP, Pro Sl ate_10 EE G1, poodl e, HP_Pro Sl ate_10 EE G1"
"HP, Pro Sl ate_10 EE G1, terri er, HP_Pro Sl ate_10 EE G1"
"HP, Pro Sl ate_12, dane, HP_Pro Sl ate_12"
"HP, Pro Sl ate_8, mal amute, HP_Pro Sl ate_8"
"HP, Sl ate_10 HD, bonsai_10, HP_Sl ate_10 HD"
"HP, Sl ate_10 Pl us, l inkpl us, HP_Sl ate_10 Pl us"
"HP, Sl ate_17, franky, HP_Sl ate_17"
"HP, Sl ate_21 Pro, ranger, Sl ate_21 Pro"
"HP, Sl ate_6 Voi ce Tab, pomegranate, HP_Sl ate_6 Voi ce Tab"
"HP, Sl ate_6 Voi ce Tab_11 , avocado, HP_Sl ate_6 Voi ce Tab_11 "
"HP, Sl ate_6 Voi ceTab Pl us, mekong, HP_Sl ate_6 Voi ceTab Pl us"
"HP, Sl ate_7 Beats Speci al Edi ti on, fai rfax, HP_Sl ate_7 Beats Speci al Edi ti on"
"HP, Sl ate_7 Beats Speci al Edi ti on, fai rfax, HP_Sl ate_7 Beats Speci al Edi ti on"
"HP, Sl ate_7 Extreme, ol ive, HP_Sl ate_7 Extreme"
"HP, Sl ate_7 HD, bonsai_10, HP_Sl ate_10 HD"
"HP, Sl ate_7 HD, bonsai_7, HP_Sl ate_7 HD"
"HP, Sl ate_7 Voi ce Tab, al mond, HP_Sl ate_7 Voi ce Tab"
"HP, Sl ate_7 Voi ceTab UI tra, charm, HP_Sl ate_7 Voi ceTab UI tra"
"HP, Sl ate_8 Pl us, vogue, HP_Sl ate_8 Pl us"
"HP, Sl ate_8 Pro, dogwood, HP_Sl ate_8 Pro"
"HP, Sl ate_21, phobos, Sl ate_21"
"HP, Sl ate_7 Pl us, bi rch, HP_Sl ate_7 Pl us"
"HP, Sl ate_8 Pro, fi g, HP_Sl ate_8 Pro"
"HP, Sl ateBook_14, 200a, HP_Sl ateBook_14 PC"

supported device.txt

"HP, Tablet 10, bal sa, HP_10_Tablet"
 "HP, Voice Tab 7, almond, HP_Slate 7 Voice Tab"
 "HTC, , express, HTC Flyer"
 "HTC, , express, PG41200"
 "HTC, , expresskt, HTC_P515E"
 "HTC, , rider, HTC_X515E"
 "HTC, , tagh, HTC Incredible E S715e"
 "HTC, \tADR6325, lexikon, ADR6325"
 "HTC, ADR6330VW, bliss, ADR6330VW"
 "HTC, ADR6425LVW, vigor, ADR6425LVW"
 "HTC, AT&T HTC One X+, evitaeul, HTC_EVARE_UL"
 "HTC, AT&T HTC One X+, evitaeul, HTC One X+"
 "HTC, Ari a, liberty, HTC Ari a"
 "HTC, Ari a, liberty, HTC Ari a A6380"
 "HTC, Ari a, liberty, HTC Grati a A6380"
 "HTC, Ari a, liberty, HTC Liberty"
 "HTC, Butterfly S, dl xpul, HTC Butterfly s"
 "HTC, Butterfly S, dl xpul, HTC_Butterfly_s_901s"
 "HTC, Chacha, chacha, HTC ChaCha A810b"
 "HTC, Chacha, chacha, HTC ChaCha A810e"
 "HTC, Chacha, chacha, HTC ChaChaCha A810e"
 "HTC, Chacha, chacha, HTC Status"
 "HTC, D616t, htc_a32ml_dtul, HTC D626t"
 "HTC, D626t, htc_a32ml_dtul, HTC D626t"
 "HTC, Desire, bravo, HTC Desire"
 "HTC, Desire, bravo, X06HT"
 "HTC, Desire, bravoc, PB99400"
 "HTC, Desire 320, htc_v01_u, HTC OPF11"
 "HTC, Desire 320, htc_v01_u, HTC Desire 320"
 "HTC, Desire 510, htc_a11ul8x26, HTC Desire 510"
 "HTC, Desire 516 dual sim, htc_v2_dcg, HTC Desire 516 dual sim"
 "HTC, Desire 516 dual sim, htc_v2_dug, HTC Desire 516 dual sim"
 "HTC, Desire 516 dual sim, htc_v2_dug, HTC V2"
 "HTC, Desire 620 dual sim, htc_a31dtul, HTC_D620u"
 "HTC, Desire 626, htc_a32dcgl, HTC D626d"
 "HTC, Desire 626, htc_a32ul, HTC_D626x"
 "HTC, Desire 626, htc_a32ul, HTC_D630x"
 "HTC, Desire 820, htc_a51ul, HTC OPFJ4"
 "HTC, Desire 820, htc_a51ul, HTC Desire 820"
 "HTC, Desire 826, htc_a52dwgl, HTC D826d"
 "HTC, Desire 828, htc_a51bml_dtul, HTC D828w"
 "HTC, Desire D820mini, htc_a31dtul, HTC D820mt"
 "HTC, Desire D820mini, htc_a31dtul, HTC D820mu"
 "HTC, Desire D826, htc_a52dwgl, HTC D826d"
 "HTC, Desire HD, ace, 001HT"
 "HTC, Desire HD, ace, Desire HD"
 "HTC, Desire HD, ace, HTC Desire HD A9191"
 "HTC, Desire HD, ace, Inspire HD"
 "HTC, Desire L by HTC, cp2u, Desire L by HTC"
 "HTC, Desire S, saga, HTC Desire S"
 "HTC, Desire VC, pri modd, HTC Desire VC"
 "HTC, Desire VC, pri modd, HTC Desire VC T328d"
 "HTC, Desire VC, pri modd, HTC PRO_DD"
 "HTC, Desire VC, pri modd, HTC T328d"
 "HTC, Droid DNA, dl x, HTC6435LRA"
 "HTC, Droid DNA, dl x, HTC6435LVW"
 "HTC, Droid Eris, desi rec, Eris"
 "HTC, Droid Eris, desi rec, Pulse"
 "HTC, Droid Incredible, inc, ADR6300"
 "HTC, EVO 3D, shooter, HTCEVOV4G"
 "HTC, EVO 3D, shooter, PG86100"
 "HTC, EVO LTE 4G, jewel, EVO"
 "HTC, EVO Shift 4G, speedy, PG06100"

supported device.txt

"HTC, Evo 4G, supersonic, PC36100"
"HTC, Flyer, flyer, HTC Flyer"
"HTC, Flyer, flyer, HTC Flyer P510e"
"HTC, Flyer, flyer, HTC Flyer P511e"
"HTC, Flyer, flyer, HTC Flyer P512"
"HTC, Flyer, flyer, HTC_Flyer_P512_NA"
"HTC, G1, dream, HTC Dream"
"HTC, G2, vision, HTC Vision"
"HTC, G2, vision, T-Mobile G2"
"HTC, HTC OP9C8, htc_a5dwgl, HTC OP9C8"
"HTC, HTC OP9C8, htc_a5dwgl, HTC Desire 816 dual sim"
"HTC, HTC OPK72, htc_hiaur_ml_tuhl, HTC OPK72"
"HTC, HTC OPK72, htc_hiaur_ml_tuhl, HTC One M9PLUS"
"HTC, HTC OPM912, htc_a32eulatt, HTC OPM912"
"HTC, HTC OPM912, htc_a32eulatt, HTC Desire 626"
"HTC, HTC 5060 dual sim, z4dug, HTC Desire 500 dual sim"
"HTC, HTC 601e, m4, HTC 601e"
"HTC, HTC 606w, cp3dug, HTC 606w"
"HTC, HTC 606w, cp3dug, HTC Desire 600"
"HTC, HTC 606w, cp3dug, HTC Desire 600 dual sim"
"HTC, HTC 606w, cp3dug, HTC P049120"
"HTC, HTC 608t, cp3dtg, HTC 608t"
"HTC, HTC 609d, cp3dcg, HTC 609d"
"HTC, HTC 6160, zaradug, HTC 6160"
"HTC, HTC 619d, zarawl, HTC 619d"
"HTC, HTC 7060, cp5dug, HTC 7060"
"HTC, HTC 710C, htc_a5chl, 710C"
"HTC, HTC 802d, m7cdwg, HTC 802d"
"HTC, HTC 803e, t6ul, HTC 803e"
"HTC, HTC 8060, t6dug, HTC 8060"
"HTC, HTC 8088, t6tl, HTC 8088"
"HTC, HTC 809d, t6dwg, HTC 809d"
"HTC, HTC 8160, t6uhl, HTC 8160"
"HTC, HTC 9060, dl xpul, HTC 901e"
"HTC, HTC 9060, m7, HTC 801e"
"HTC, HTC 9060, m7cdug, HTC 802w"
"HTC, HTC 9088, dl pdtu, HTC 9088"
"HTC, HTC 919d, dl pdwg, HTC 919d"
"HTC, HTC Butterfly, dl xu, HTC Butterfly"
"HTC, HTC Butterfly, dl xu, HTC DLX_U"
"HTC, HTC Butterfly, dl xu, HTC X920e"
"HTC, HTC Butterfly, dl xub1, HTC Butterfly"
"HTC, HTC Butterfly, dl xub1, HTC DLXUB1"
"HTC, HTC Butterfly 2, htc_b2ul, HTC Butterfly 2"
"HTC, HTC Butterfly 2, htc_b2ul, HTC_B810x"
"HTC, HTC Butterfly s 9060, dl pdug, HTC 9060"
"HTC, HTC D316d, htc_v2_c, HTC D316d"
"HTC, HTC D610t, htc_a3tl, HTC D610t"
"HTC, HTC D728w, htc_a50cml_dtul, HTC D728w"
"HTC, HTC D816d, htc_a5dwg, HTC D816d"
"HTC, HTC D816d, htc_a5dwg, HTC_D816d"
"HTC, HTC D816e, htc_a5dugl, HTC D816e"
"HTC, HTC D816h, htc_a5mgp_dug, HTC D816h"
"HTC, HTC D816t, htc_a5tl, HTC D816t"
"HTC, HTC D816v, htc_a5dwgl, HTC D816v"
"HTC, HTC D816w, htc_a5dug, HTC D816w"
"HTC, HTC D820 Mini, htc_a31dtul, HTC D820mt"
"HTC, HTC D820t, htc_a51dtul, HTC D820t"
"HTC, HTC D820u, htc_a51dtul, HTC D820u"
"HTC, HTC D826t, htc_a52dtul, HTC D826t"
"HTC, HTC DROID DNA, dl x, HTC6435LRA"
"HTC, HTC DROID Incredible 4G LTE, fi rebal I, ADR6410LRA"
"HTC, HTC DROID Incredible 4G LTE, fi rebal I, ADR6410LVW"

supported device.txt

"HTC, HTC DROID Incredible 4G LTE, fireball , ADR64100M"
"HTC, HTC Desire 200, gtou, HTC Desire 200"
"HTC, HTC Desire 200, gtou, HTC_Desire_200"
"HTC, HTC Desire 210 dual sim, htc_v0_dug, HTC Desire 210 dual sim"
"HTC, HTC Desire 300, g3u, HTC 301e"
"HTC, HTC Desire 300, g3u, HTC Desire 300"
"HTC, HTC Desire 300, g3u, HTC_OP6A1"
"HTC, HTC Desire 300, g3u, HTC_Desire_300"
"HTC, HTC Desire 310, htc_v1_dug, HTC D310w"
"HTC, HTC Desire 310, htc_v1_dug, HTC Desire 310 dual sim"
"HTC, HTC Desire 310, htc_v1_u, HTC Desire 310"
"HTC, HTC Desire 310, htc_v1_u, HTC_D310n"
"HTC, HTC Desire 310, htc_v1_u, HTC_V1"
"HTC, HTC Desire 320, htc_v01_u, HTC OPF120"
"HTC, HTC Desire 320, htc_v01_u, HTC Desire 320"
"HTC, HTC Desire 326G dual sim, htc_v01a_dug, HTC 2PNT1"
"HTC, HTC Desire 326G dual sim, htc_v01a_dug, HTC Desire 326G dual sim"
"HTC, HTC Desire 500, z4u, HTC Desire 500"
"HTC, HTC Desire 500, z4u, HTC_Desire_500"
"HTC, HTC Desire 500 dual sim, z4dug, HTC 5060"
"HTC, HTC Desire 500 dual sim, z4dug, HTC Desire 500 dual sim"
"HTC, HTC Desire 501, htc_csnu, HTC Desire 501"
"HTC, HTC Desire 501, htc_csnu, HTC_603h"
"HTC, HTC Desire 501 dual sim, csndug, HTC Desire 501 dual sim"
"HTC, HTC Desire 5088, z4td, HTC 5088"
"HTC, HTC Desire 510, htc_a11chl , OPCV1"
"HTC, HTC Desire 510, htc_a11ul , HTC OPCV20"
"HTC, HTC Desire 510, htc_a11ul , HTC Desire 510"
"HTC, HTC Desire 510, htc_a11ul , HTC_OPCV2"
"HTC, HTC Desire 512, htc_a11aul 8x26, HTC Desire 512"
"HTC, HTC Desire 516, htc_v2_dcg, HTC D516d"
"HTC, HTC Desire 516, htc_v2_dtg, HTC D516t"
"HTC, HTC Desire 516, htc_v2_dug, HTC C2"
"HTC, HTC Desire 516, htc_v2_dug, HTC D516w"
"HTC, HTC Desire 516, htc_v2_dug, HTC V2"
"HTC, HTC Desire 516 dual sim, htc_v2_dug, HTC Desire 516 dual sim"
"HTC, HTC Desire 520, htc_a12ul , HTC OPG01"
"HTC, HTC Desire 526, htc_a13wl , HTC OPM31"
"HTC, HTC Desire 526, htc_a13wl , HTC Desire 526"
"HTC, HTC Desire 526, htc_a13wl , HTCD100LVW"
"HTC, HTC Desire 526, htc_a13wl pp, HTCD100LVWPP"
"HTC, HTC Desire 526G+ dual sim, htc_v02_dug, HTC OPL41"
"HTC, HTC Desire 526G+ dual sim, htc_v02_dug, HTC OPL4100"
"HTC, HTC Desire 526G+ dual sim, htc_v02_dug, HTC Desire 526G dual sim"
"HTC, HTC Desire 526G+ dual sim, htc_v02_dug, HTC Desire 526GPLUS dual sim"
"HTC, HTC Desire 526G+ dual sim, htc_v02_dug, HTC_D526h"
"HTC, HTC Desire 526GPLUS, htc_v02_u, HTC OPL41"
"HTC, HTC Desire 526GPLUS, htc_v02_u, HTC Desire 526G"
"HTC, HTC Desire 600, cp3dug, HTC Desire 600"
"HTC, HTC Desire 600 Dual SIM, cp3dug, HTC Desire 600 dual sim"
"HTC, HTC Desire 600c Dual SIM, cp3dcg, HTC 609d"
"HTC, HTC Desire 600c Dual SIM, cp3dcg, HTC Desire 600c dual sim"
"HTC, HTC Desire 601, zara, HTC Desire 601"
"HTC, HTC Desire 601, zara, HTC_OP4E2"
"HTC, HTC Desire 601, zaracl , HTC Desire 601"
"HTC, HTC Desire 601, zaracl , HTCOP4E1"
"HTC, HTC Desire 601 dual sim, zaradug, HTC Desire 601 dual sim"
"HTC, HTC Desire 606w, cp3dug, HTC 606w"
"HTC, HTC Desire 609d, cp3dcg, HTC 609d"
"HTC, HTC Desire 610, htc_a3qhdu , HTC Desire 610"
"HTC, HTC Desire 610, htc_a3qhdu , HTC_OP902"
"HTC, HTC Desire 610, htc_a3qhdu , HTC_D610x"
"HTC, HTC Desire 610, htc_a3ul , HTC Desire 610"

supported device.txt

"HTC, HTC Desire 612, htc_a3qhdcl , HTC OP9030"
"HTC, HTC Desire 612, htc_a3qhdcl , HTC Desire 612"
"HTC, HTC Desire 616 dual sim, htc_v3_dug, HTC D616w"
"HTC, HTC Desire 616 dual sim, htc_v3_dug, HTC Desire 616 dual sim"
"HTC, HTC Desire 616 dual sim, htc_v3_dug, HTC V3"
"HTC, HTC Desire 620, htc_a31ul , HTC OPE64"
"HTC, HTC Desire 620, htc_a31ul , HTC Desire 620"
"HTC, HTC Desire 620G dual sim, htc_a31mg_dug, HTC OPE65"
"HTC, HTC Desire 620G dual sim, htc_a31mg_dug, HTC Desire 620G dual sim"
"HTC, HTC Desire 620G dual sim, htc_a31mg_dug, HTC_D620h"
"HTC, HTC Desire 626, htc_a32ewl , HTCD200LVW"
"HTC, HTC Desire 626, htc_a32ewl pp, HTCD200LVWPP"
"HTC, HTC Desire 626, htc_a32ul , HTC Desire 626"
"HTC, HTC Desire 626, htc_a32ul_emea, HTC Desire 626"
"HTC, HTC Desire 626 dual sim, htc_a32ml_dtul , HTC Desire 626 dual sim"
"HTC, HTC Desire 626G+ dual sim, htc_a32mg_dug, HTC OPM11"
"HTC, HTC Desire 626G+ dual sim, htc_a32mg_dug, HTC Desire 626G dual sim"
"HTC, HTC Desire 626G+ dual sim, htc_a32mg_dug, HTC Desire 626GPLUS dual sim"
"HTC, HTC Desire 626G+ dual sim, htc_a32mg_dug, HTC_D626ph"
"HTC, HTC Desire 626s, htc_a32eul , HTC Desire 625"
"HTC, HTC Desire 626s, htc_a32eul , HTC Desire 626s"
"HTC, HTC Desire 626s, htc_a32eul_la, HTC Desire 626s"
"HTC, HTC Desire 626s, htc_a32ewhl , OPM92"
"HTC, HTC Desire 626s, htc_a32ewhl , HTC OPM92"
"HTC, HTC Desire 700 dual sim, cp5dug, HTC Desire 700 dual sim"
"HTC, HTC Desire 700 dual sim, cp5dwg, HTC Desire 700 dual sim"
"HTC, HTC Desire 700 dual sim, cp5dwg, HTC_709d"
"HTC, HTC Desire 7060, cp5dug, HTC_7060"
"HTC, HTC Desire 7088, cp5dtu, HTC_7088"
"HTC, HTC Desire 709d, cp5dwg, HTC_709d"
"HTC, HTC Desire 728G dual sim, htc_a50cmg_dwg, HTC_2PQ83"
"HTC, HTC Desire 728G dual sim, htc_a50cmg_dwg, HTC Desire 728G dual sim"
"HTC, HTC Desire 816, htc_a5chl , HTC Desire 816"
"HTC, HTC Desire 816, htc_a5ul , HTC Desire 816"
"HTC, HTC Desire 816, htc_a5ul , HTC_OP9C2"
"HTC, HTC Desire 816, htc_a5ul , HTC_D816x"
"HTC, HTC Desire 816 dual sim, htc_a5dug, HTC Desire 816 dual sim"
"HTC, HTC Desire 816 dual sim, htc_a5dwg, HTC Desire 816 dual sim"
"HTC, HTC Desire 816G dual , htc_a5mgp_dug, HTC Desire 816G dual sim"
"HTC, HTC Desire 816G dual sim, htc_a5mg_dug, HTC Desire 816G dual sim"
"HTC, HTC Desire 816G dual sim, htc_a5mgp_dug, HTC_D816h"
"HTC, HTC Desire 816G dual sim, htc_a5mgp_dug, HTC Desire 816G dual sim"
"HTC, HTC Desire 820, htc_a51ul , HTC Desire 820"
"HTC, HTC Desire 820 dual sim, htc_a51dtul , HTC Desire 820 dual sim"
"HTC, HTC Desire 820G PLUS dual sim, htc_a50mgp_dug, HTC Desire 820G PLUS dual sim"
"HTC, HTC Desire 820G PLUS dual sim, htc_a50mgp_dug, HTC Desire 820G dual sim"
"HTC, HTC Desire 820G PLUS dual sim, htc_a50mgp_dug, HTC_D820pi "
"HTC, HTC Desire 820q dual sim, htc_a50dtul , HTC Desire 820q dual sim"
"HTC, HTC Desire 820s, htc_a50ml_dtul , HTC_D820ts"
"HTC, HTC Desire 820s, htc_a50ml_dtul , HTC_D820us"
"HTC, HTC Desire 820s, htc_a50ml_dtul , HTC Desire 820s dual sim"
"HTC, HTC Desire 820s dual sim, htc_a50ml , HTC Desire 820s dual sim"
"HTC, HTC Desire 826, htc_a52dtul , HTC_D826w"
"HTC, HTC Desire 826, htc_a52tuhl , HTC_D826y"
"HTC, HTC Desire 826 4G
\xe7\xa7\xbb\xe5\x8b\x95\xe5\x85\xac\xe9\x96\x8b\xe7\x89\x88(\xe5\x8f\x8c\xe5\x8d\xa1\xe5\x8f\x8c\xe5\xbe\x85), htc_a52dtul , HTC_D826t"
"HTC, HTC Desire 826 dual sim, htc_a52dtul , HTC Desire 826 dual sim"
"HTC, HTC Desire 826 dual sim, htc_a52dwgl , HTC Desire 826 dual sim"
"HTC, HTC Desire 828 dual sim, htc_a51bml_dwgl , HTC_2PRE2"
"HTC, HTC Desire 828 dual sim, htc_a51bml_dwgl , HTC Desire 828 dual sim"
"HTC, HTC Desire C, gol fc, HTC Desire C"
"HTC, HTC Desire C, gol fu, HTC Desire C"

supported device.txt

"HTC, HTC Desire D626w, htc_a32ml_dtul , HTC D626w"
 "HTC, HTC Desire EYE, htc_eyetuhl , HTC OPFH2"
 "HTC, HTC Desire EYE, htc_eyetuhl , HTC Desire EYE"
 "HTC, HTC Desire EYE, htc_eyetuhl , HTC_M910x"
 "HTC, HTC Desire EYE, htc_eyeu1 , HTC OPFH11"
 "HTC, HTC Desire EYE, htc_eyeu1 , HTC Desire EYE"
 "HTC, HTC Desire EYE, htc_eyeu1_att, HTC Desire Eye"
 "HTC, HTC Desire L dual sim, cp2dug, HTC Desire L dual sim"
 "HTC, HTC Desire P, magni u, HTC Desire P"
 "HTC, HTC Desire SV, magni ds, HTC Desire SV"
 "HTC, HTC Desire V, pri mods, HTC Desire Q"
 "HTC, HTC Desire V, pri mods, HTC Desire U"
 "HTC, HTC Desire V, pri mods, HTC Desire U dual sim"
 "HTC, HTC Desire V, pri mods, HTC Desire V"
 "HTC, HTC Desire V, pri mods, HTC PROMI N_U"
 "HTC, HTC Desire V, pri mods, HTC PRO_DS"
 "HTC, HTC Desire V, pri mods, HTC T327w"
 "HTC, HTC Desire V, pri mods, HTC T328w"
 "HTC, HTC Desire X, protou, HTC Desire X"
 "HTC, HTC Desire X, protou, HTC P00_U"
 "HTC, HTC Desire X dual sim, protodug, HTC Desire X dual sim"
 "HTC, HTC Desire XC dual sim, protodcg, HTC Desire XC dual sim"
 "HTC, HTC Desire320, htc_v01_u, HTC Desire_320"
 "HTC, HTC Desire815G, htc_a5mgp_u, HTC Desire 816G"
 "HTC, HTC E9pt, htc_a55ml_dtul , HTC E9pt"
 "HTC, HTC E9pw, htc_a55ml_dtul , HTC E9pw"
 "HTC, HTC E9t, htc_a53ml_dtul , HTC E9t"
 "HTC, HTC E9w, htc_a53ml_dtul , HTC E9w"
 "HTC, HTC EVO 3D ISW12HT, shooterk, ISW12HT"
 "HTC, HTC EVO 3D X515m, shooteru, HTC EVO 3D X515a"
 "HTC, HTC EVO 3D X515m, shooteru, HTC EVO 3D X515m"
 "HTC, HTC EVO 3D X515m, shooteru, HTC Inspire 3D"
 "HTC, HTC EVO 4G LTE, jewel , EVO"
 "HTC, HTC Explorer A310e, pi co, HTC Explorer"
 "HTC, HTC Explorer A310e, pi co, HTC Explorer A310b"
 "HTC, HTC Explorer A310e, pi co, HTC Explorer A310e"
 "HTC, HTC Hero, hero, ERA G2 Touch"
 "HTC, HTC Hero, hero, HTC Hero"
 "HTC, HTC Hero, hero, T-Mobi le G2 Touch"
 "HTC, HTC Hero, hero, T-Mobi le_G2_Touch"
 "HTC, HTC Hero, hero, dopod A6288"
 "HTC, HTC J Butterfly, dl xj , HTL21"
 "HTC, HTC J One, m7wl j , HTL22"
 "HTC, HTC J Z321e, val entewxc9, HTC J Z321e"
 "HTC, HTC M8si , htc_m8ql tuhl , HTC M8si "
 "HTC, HTC M8t, htc_m8tl , HTC M8t"
 "HTC, HTC M9, htc_hi mau1 att, HTC One M9"
 "HTC, HTC M9et, htc_hi ma_ace_ml_dtul , HTC M9et"
 "HTC, HTC M9ew, htc_hi ma_ace_ml_dtul , HTC M9ew"
 "HTC, HTC M9pw, htc_hi au_ml_tuhl , HTC M9pw"
 "HTC, HTC M9pw, htc_hi aur_ml_tuhl , HTC M9pw"
 "HTC, HTC M9w, htc_hi mauhl , HTC M9w"
 "HTC, HTC ONE, m7cdug, HTC One dual sim"
 "HTC, HTC ONE A9, htc_hi aeul , HTC One A9"
 "HTC, HTC ONE M8s, htc_m8ql ul , HTC One M8s"
 "HTC, HTC ONE M8s, htc_m8ql ul , HTC_OPKV1"
 "HTC, HTC ONE S, vi l l e, HTC One S"
 "HTC, HTC ONE SV, k2u, HTC K2_U"
 "HTC, HTC ONE SV, k2u, HTC One SV"
 "HTC, HTC ONE SV, k2ul , HTC One SV"
 "HTC, HTC One, m7, HTC 801e"
 "HTC, HTC One, m7, HTC One"
 "HTC, HTC One, m7, HTC One 801e"

supported device.txt

"HTC, HTC One, m7, HTC_PN071"
"HTC, HTC One, m7cdtu, HTC 802t"
"HTC, HTC One, m7cdtu, HTC 802t 16GB"
"HTC, HTC One, m7cdug, HTC 802w"
"HTC, HTC One, m7cdug, HTC One dual sim"
"HTC, HTC One, m7cdwg, HTC 802d"
"HTC, HTC One, m7cdwg, HTC One dual 802d"
"HTC, HTC One, m7cdwg, HTC One dual sim"
"HTC, HTC One, m7wls, HTC One"
"HTC, HTC One, m7wls, HTCONE"
"HTC, HTC One, m7wlv, HTC One"
"HTC, HTC One (E8), htc_mecdwg, HTC M8Sd"
"HTC, HTC One (E8), htc_mectl, HTC M8St"
"HTC, HTC One (E8), htc_mectl, HTC One_E8"
"HTC, HTC One (E8), htc_mecul, HTC One_E8"
"HTC, HTC One (E8), htc_mecul, HTC_M8Sx"
"HTC, HTC One (E8), htc_mecwhl, OPAJ5"
"HTC, HTC One (E8) dual sim, htc_mecdug, HTC One_E8 dual sim"
"HTC, HTC One (E8) dual sim, htc_mecdug, HTC_M8Sy"
"HTC, HTC One (E8) dual sim, htc_mecdwg, HTC OPAJ4"
"HTC, HTC One (E8) dual sim, htc_mecdwg, HTC One_E8 dual sim"
"HTC, HTC One (E8) \xe6\x97\xb6\xe5\xb0\x9a\xe7\x89\x88, htc_mectl, HTC M8St"
"HTC, HTC One (E8) \xe6\x97\xb6\xe5\xb0\x9a\xe7\x89\x88 4G
LTE\xe5\x8f\x8c\xe5\x8d\xa1\xe5\x8f\x8c\xe5\xbe\x85\xe8\x81\x94\xe9\x80\x9a\xe7\x89\x88, htc_mecdug, HTC M8Sw"
"HTC, HTC One (E8) \xe6\x99\x82\xe5\xb0\x9a\xe7\x89\x884G LTE
\xe7\xa7\xbb\xe5\x8a\xa8\xe7\x89\x88, htc_mectl, HTC M8Ss"
"HTC, HTC One (M8 EYE), htc_mel_suhl, HTC OP6B900"
"HTC, HTC One (M8 EYE), htc_mel_suhl, HTC One_M8 Eye"
"HTC, HTC One (M8 Eye), htc_mel_suhl, HTC OP6B9"
"HTC, HTC One (M8 Eye), htc_mel_suhl, HTC One_M8 Eye"
"HTC, HTC One (M8), htc_m8, HTC M8w"
"HTC, HTC One (M8), htc_m8, HTC One_M8"
"HTC, HTC One (M8), htc_m8, HTC_OP6B"
"HTC, HTC One (M8), htc_m8, HTC_OP6B6"
"HTC, HTC One (M8), htc_m8, HTC_M8x"
"HTC, HTC One (M8), htc_m8dug, HTC One_M8 dual sim"
"HTC, HTC One (M8), htc_m8dug, HTC M8d"
"HTC, HTC One (M8), htc_m8whl, 831C"
"HTC, HTC One (M8), htc_m8wl, HTC One_M8"
"HTC, HTC One (M8), htc_m8wl, HTC6525LVW"
"HTC, HTC One (M8) (4G LTE \xe5\x8f\x8c\xe5\x8d\xa1\xe5\x8f\x8c\xe5\xbe\x85
\xe8\x81\x94\xe9\x80\x9a\xe7\x89\x88), htc_m8dug, HTC M8e"
"HTC, HTC One 801e, m7, HTC One 801e"
"HTC, HTC One 801e, m7, HTC One 801s"
"HTC, HTC One A9, htc_hiaeuhi, HTC One A9"
"HTC, HTC One A9, htc_hiaeuhi, HTC_A9u"
"HTC, HTC One A9, htc_hiaeuhi, HTC One A9"
"HTC, HTC One A9, htc_hiaeuhi, 2PQ93"
"HTC, HTC One Dual 802d, m7cdwg, HTC One dual 802d"
"HTC, HTC One Dual Sim, m7cdwg, HTC One dual sim"
"HTC, HTC One E8 dual, htc_mecdug, HTC_M8Sd"
"HTC, HTC One E9 dual sim, htc_a53ml_dtul, HTC OPL31"
"HTC, HTC One E9 dual sim, htc_a53ml_dtul, HTC One E9 dual sim"
"HTC, HTC One E9PLUS dual sim, htc_a55ml_dtul, HTC One E9PLUS dual sim"
"HTC, HTC One E9s dual sim, htc_a50aml, HTC D826sw"
"HTC, HTC One E9s dual sim, htc_a50aml, HTC One E9s dual sim"
"HTC, HTC One E9s dual sim, htc_a50aml, HTC_E9sx"
"HTC, HTC One Google Play edition, m7, HTC One"
"HTC, HTC One M8 eye 4G LTE
\xe7\xa7\xbb\xe5\x8a\xa8\xe5\xae\x9a\xe5\x88\xb6\xe7\x89\x88, htc_mel_suhl, HTC M8Et"
"HTC, HTC One M8 eye 4G LTE\xe8\x81\x94\xe9\x80\x9a\xe7\x89\x88, htc_mel_suhl, HTC M8Ew"
"HTC, HTC One M9, htc_hiaeuhi, OPAJ10"

supported device.txt

"HTC, HTC One M9, htc_hi mauhl , HTC OPJA10"
 "HTC, HTC One M9, htc_hi mauhl , HTC One M9"
 "HTC, HTC One M9, htc_hi mauhl , HTC_OPJA10"
 "HTC, HTC One M9, htc_hi mauhl , HTC_M9u"
 "HTC, HTC One M9, htc_hi mauh , HTC One M9"
 "HTC, HTC One M9, htc_hi mauh att, HTC One M9"
 "HTC, HTC One M9, htc_hi mawhl , HTC One M9"
 "HTC, HTC One M9, htc_hi mawl , HTC6535LRA"
 "HTC, HTC One M9, htc_hi mawl , HTC6535LVW"
 "HTC, HTC One M9 \xe2\x80\x93 OPJA2, htc_hi mawhl , OPJA2"
 "HTC, HTC One M9+, htc_hi au_ml _tuhl , HTC OPK71"
 "HTC, HTC One M9+, htc_hi au_ml _tuhl , HTC M9pt"
 "HTC, HTC One M9+, htc_hi au_ml _tuhl , HTC One M9PLUS"
 "HTC, HTC One M9+, htc_hi au_ml _tuhl , HTC_M9pw"
 "HTC, HTC One M9PLUS, htc_hi au_ml _tuhl , HTC One M9PLUS"
 "HTC, HTC One ME dual sim, htc_hi ma_ace_ml _dtul , HTC OPLA1"
 "HTC, HTC One ME dual sim, htc_hi ma_ace_ml _dtul , HTC One ME dual sim"
 "HTC, HTC One S, vi l l e, HTC One S"
 "HTC, HTC One S, vi l l e, HTC VLE_U"
 "HTC, HTC One S, vi l l ec2, HTC One S"
 "HTC, HTC One S, vi l l ec2, HTC Z560e"
 "HTC, HTC One S Speci al Edi ti on, vi l l epl us, HTC One S Speci al Edi ti on"
 "HTC, HTC One SC, cp2dcg, HTC One SC"
 "HTC, HTC One SC, cp2dcg, HTC One SC T528d"
 "HTC, HTC One SV, k2cl , C525c"
 "HTC, HTC One SV, k2pl ccl , HTC One SV"
 "HTC, HTC One SV, k2ul , HTC K2_UL"
 "HTC, HTC One SV, k2ul , HTC One SV"
 "HTC, HTC One SV BLK, k2pl ccl , HTC One SV"
 "HTC, HTC One SV BLK, k2pl ccl , HTC One SV BLK"
 "HTC, HTC One V, pri moc, HTC One V"
 "HTC, HTC One V, pri mou, HTC ONE V"
 "HTC, HTC One V, pri mou, HTC One V"
 "HTC, HTC One VX, totemc2, HTC One VX"
 "HTC, HTC One X, endeavoru, HTC One X"
 "HTC, HTC One X, endeavoru, HTC S720e"
 "HTC, HTC One X, evi ta, HTC One X"
 "HTC, HTC One X+, enrnc2b, HTC One X+ "
 "HTC, HTC One X+, evi tareul , HTC One X+ "
 "HTC, HTC One XL, evi ta, HTC One X"
 "HTC, HTC One XL, evi ta, HTC One XL"
 "HTC, HTC One XL, evi ta, HTC_One_XL"
 "HTC, HTC One XL, evi tautl , HTC EVA_UTL"
 "HTC, HTC One max, t6ul , HTC One max"
 "HTC, HTC One max, t6ul , HTC_One_max"
 "HTC, HTC One max, t6whl , HTCOP3P7"
 "HTC, HTC One mi ni , htc_m4, HTC One mi ni "
 "HTC, HTC One mi ni , m4, HTC One mi ni "
 "HTC, HTC One mi ni , m4, HTC_One_mi ni _601e"
 "HTC, HTC One mi ni , m4, HTC_PO582"
 "HTC, HTC One mi ni 2, htc_memul , HTC One mi ni 2"
 "HTC, HTC One mi ni 2, htc_memul , HTC_M8MI Nx"
 "HTC, HTC One mi ni 2, htc_memul , HTC_One_mi ni _2"
 "HTC, HTC One mi ni 601E, m4, HTC_One_mi ni _601e"
 "HTC, HTC One remi x, htc_memwl , HTC6515LVW"
 "HTC, HTC One_E8, htc_mecul _emea, HTC One_E8"
 "HTC, HTC Onex X, endeavoru, HTC One X"
 "HTC, HTC P0091, csndug, HTC P0091"
 "HTC, HTC Rhyme S510b, bl i ss, HTC Rhyme S510b"
 "HTC, HTC S720e, endeavoru, HTC S720e"
 "HTC, HTC Sal sa C510e, i cong, HTC Sal sa C510b"
 "HTC, HTC Sal sa C510e, i cong, HTC Sal sa C510e"
 "HTC, HTC Sensati on XL wi th Beats Audi o X315e, runnymede, HTC Sensati on XL wi th Beats

supported device.txt

Audio X315b"
"HTC, HTC Sensation XL with Beats Audio X315e, runnymede, HTC Sensation XL with Beats
Audio X315e"
"HTC, HTC Sensation XL with Beats Audio X315e, runnymede, HTC-X315E"
"HTC, HTC Sensation XL with Beats Audio X315e, runnymede, Sensation XL with Beats
Audio"
"HTC, HTC T329d, protodcg, HTC T329d"
"HTC, HTC T528w, cp2dug, HTC Desire L dual sim"
"HTC, HTC Velocity 4G, holiday, HTC PH39100"
"HTC, HTC Velocity 4G, holiday, HTC Raider X710e"
"HTC, HTC Velocity 4G, holiday, HTC Velocity 4G"
"HTC, HTC Velocity 4G, holiday, HTC Velocity 4G X710s"
"HTC, HTC Velocity 4G, holiday, HTC-X710a"
"HTC, HTC WF5w, htc_a50bml, HTC WF5w"
"HTC, HTC Wildfire S A515c, marvel c, HTC Wildfire S A515c"
"HTC, HTC Wildfire S A515c, marvel c, HTC-PG762"
"HTC, HTC Wildfire S A515c, marvel c, USCCADR6230US"
"HTC, HTC desire 608t, cp3dtg, HTC 608t"
"HTC, HTC first, mystul, HTC first"
"HTC, HTC6435LVW, dlx, HTC6435LVW"
"HTC, HTC909d, dl pdwg, HTC 919d"
"HTC, HTCDesire612VZW, htc_a3qhdcl, HTC331ZLVW"
"HTC, HTCDesire612VZW, htc_a3qhdcl, HTC331ZLVWPP"
"HTC, HTCDEV0Desi gn4G, ki ngdom, HTC Acqui re"
"HTC, HTCDEV0Desi gn4G, ki ngdom, HTC EVO Desi gn C715e"
"HTC, HTCDEV0Desi gn4G, ki ngdom, HTC Hero S"
"HTC, HTCDEV0Desi gn4G, ki ngdom, HTC Ki ngdom"
"HTC, HTCDEV0Desi gn4G, ki ngdom, HTCDEV0Desi gn4G"
"HTC, HTCDEV0Desi gn4G, ki ngdom, PH44100"
"HTC, HTCOneMaxVZW, t6wl, HTC6600LVW"
"HTC, HTC_OP3P5, t6ul, HTC_OP3P5"
"HTC, HTC_OP4E2, zara, HTC_OP4E2"
"HTC, HTC_OPFJ50, htc_a51tuhl, HTC_OPFJ50"
"HTC, HTC_A510c, marvel c, HTC_A510c"
"HTC, HTC_Amaze_4G, ruby, HTC Amaze 4G"
"HTC, HTC_Amaze_4G, ruby, HTC Ruby"
"HTC, HTC_Amaze_4G, ruby, HTC_Amaze_4G"
"HTC, HTC_D626q, htc_a32ml_dtul, HTC Desire 626 dual sim"
"HTC, HTC_D626q, htc_a32ml_dtul, HTC_D626q"
"HTC, HTC_D728x, htc_a50cml_dtul, HTC Desire 728 dual sim"
"HTC, HTC_D728x, htc_a50cml_dtul, HTC_D728x"
"HTC, HTC_D820f, htc_a51tuhl, HTC_D820f"
"HTC, HTC_D820u, htc_a51dtul, HTC_D820u"
"HTC, HTC_D820ys, htc_a50ml, HTC_D820ts"
"HTC, HTC_D820ys, htc_a50ml, HTC_D820ys"
"HTC, HTC_D820ys, htc_a50ml_dtul, HTC_D820ys"
"HTC, HTC_E9pw, htc_a55ml_dtul, HTC_E9pw"
"HTC, HTC_E9x, htc_a53ml_dtul, HTC_E9x"
"HTC, HTC_M9ew, htc_hi ma_ace_ml_dtul, HTC_M9ew"
"HTC, HTC_M9px, htc_hi aur_ml_tuhl, HTC_M9px"
"HTC, HTL23, htc_b2wlj, HTL23"
"HTC, HTV31, htc_b3uhl, HTV31"
"HTC, Hero, heroc, HERO200"
"HTC, ISW13HT, val entewx, ISW13HT"
"HTC, Incredi ble 2, vi vow, ADR6350"
"HTC, Incredi ble 2, vi vow, HTC Incredi ble S 710d"
"HTC, Incredi ble S, vi vo, HTC Incredi ble S"
"HTC, Incredi ble S, vi vo, HTC_S710E"
"HTC, KDDI Infobar A02, i mnj, HTX21"
"HTC, Legend, I legend, HTC Legend"
"HTC, Nexus 9, fl ounder, Nexus 9"
"HTC, Nexus 9 LTE, fl ounder_I te, Nexus 9"
"HTC, Nexus One, passi on, Nexus One"

supported device.txt

"HTC, One XL, evita, HTC One XL"
"HTC, Puccini, puccini lte, HTC PG09410"
"HTC, Puccini, puccini lte, HTC-P715a"
"HTC, Sensation 4G, pyramid, HTC Sensation"
"HTC, Sensation 4G, pyramid, HTC Sensation 4G"
"HTC, Sensation 4G, pyramid, HTC Sensation XE with Beats Audio"
"HTC, Sensation 4G, pyramid, HTC Sensation XE with Beats Audio Z715a"
"HTC, Sensation 4G, pyramid, HTC Sensation XE with Beats Audio Z715e"
"HTC, Sensation 4G, pyramid, HTC Sensation Z710a"
"HTC, Sensation 4G, pyramid, HTC Sensation Z710e"
"HTC, Sensation 4G, pyramid, HTC-Z710a"
"HTC, Thunderbolt, mecha, ADR6400L"
"HTC, Thunderbolt, mecha, HTC Mecha"
"HTC, Wildfire, buzz, HTC Wildfire"
"HTC, Wildfire CDMA, bee, HTC Bee"
"HTC, Wildfire CDMA, bee, HTC Wildfire"
"HTC, Wildfire S, marvel, HTC Wildfire S"
"HTC, Wildfire S, marvel, HTC Wildfire S A510b"
"HTC, Wildfire S, marvel, HTC Wildfire S A510e"
"HTC, Wildfire S, marvel, HTC-A510a"
"HTC, HTC Desire 601, zara, HTC Desire 601"
"HTC, htc desire 400 dual sim, cp2dug, HTC Desire 400 dual sim"
"HTC, htc desire 610, htc_a3qhdul, HTC Desire 610"
"HTC, htc desire x, protou, HTC Desire X"
"HTC, myTouch 3G, sapphire, HTC Magic"
"HTC, myTouch 3G, sapphire, T-Mobile myTouch 3G"
"HTC, myTouch 3G Slide, espresso, T-Mobile myTouch 3G Slide"
"HTC, myTouch 4G, glacier, HTC Glacier"
"HTC, myTouch 4G, glacier, HTC Panache"
"HTC, myTouch 4G Slide, doubleshot, myTouch_4G_Slide"
"Hair, A-TT00, A-TT00, A-TT00"
"Hair, AD6B1H, AD6B1H, Smartfren Andromax AD6B1H"
"Hair, AT7003, AT7003, AT7003"
"Hair, Beeline Smart 3, Beeline_Smart3, Beeline Smart 3"
"Hair, CDP7TAB4C8, CDP7TAB4C8, CDP7TAB4C8"
"Hair, CETAB10KML9, CETAB10KML9, CETAB10KML9"
"Hair, CETAB7ML9, CETAB7ML9, CETAB7ML9"
"Hair, CETAB9ML9, CETAB9ML9, CETAB9ML9"
"Hair, CMP_765, CMP_765, CMP_765"
"Hair, CT1030, CT1030, CT1030"
"Hair, CT301_W818, msm7627a, CT301_W818"
"Hair, CT825, fiber-a31stm, CT825"
"Hair, CYCLONE_ODYSSEY, CYCLONE_ODYSSEY, CYCLONE_ODYSSEY"
"Hair, D2-721, D2-721G, D2-721G"
"Hair, D2-751G, d2PAD, D2-751G"
"Hair, D2-927G, D2-927G, D2-927G"
"Hair, D2-961G, D2-961G, D2-961G"
"Hair, G30, G30, G30"
"Hair, G700, G700, G700"
"Hair, GF88, I7A-LE, I7A-LE"
"Hair, HG-9041, HG-9041, HG-9041"
"Hair, HS-10DTB4, HS-10DTB4, HS-10DTB4"
"Hair, HS-7DTB25, HS-7DTB25, HS-7DTB25"
"Hair, HS-7DTB29-8GB, HS-7DTB29-8GB, HS-7DTB29-8GB"
"Hair, HS-9DTB37, HS_9DTB37, HS_9DTB37"
"Hair, HT-I860, HT-I860, HT-I860"
"Hair, Hair, Homesurf744, Bi natone Homesurf744 / Hubble Smart7 (Homesurf744)"
"Hair, Hair, PAD69H, PAD69H"
"Hair, Hair, PAD_D85, pad_d85"
"Hair, Hair, W627, W627"
"Hair, Hair, W861, W861"
"Hair, HomeSurf742_AT7003, HomeSurf742_AT7003, HomeSurf742_AT7003"
"Hair, Homesurf844, Homesurf844, Bi natone Homesurf844 / Hubble Smart8 (Homesurf844)"

supported device.txt

"Hai er, Hyasong T1, HyasongT1, HyasongT1"
"Hai er, INGO-TAB, INGO-TAB, INGO-TAB"
"Hai er, Konnect_350, Konnect_350, Konnect_350"
"Hai er, L50, M916-D500-PAK, L50"
"Hai er, LE32U5000A, LE32U5000A, LE32U5000A"
"Hai er, LE39M7000CF, LE39M7000CF, LE39M7000CF"
"Hai er, LE40U5000A, LE40U5000A, LE40U5000A"
"Hai er, LE43B7600A, LE43B7600A, LE43B7600A"
"Hai er, LE43U5000A, LE43U5000A, LE43U5000A"
"Hai er, LE48M7000CF, LE48M7000CF, LE48M7000CF"
"Hai er, LE49U5000A, LE49U5000A, LE49U5000A"
"Hai er, LE55M7000CF, LE55M7000CF, LE55M7000CF"
"Hai er, Logi com S9782, Logi com-S9782, Logi com-S9782"
"Hai er, MD210, MD210, MD210"
"Hai er, MEGAFON MS3A, Megafon, MS3A"
"Hai er, MT-700, MT-700, MT-700"
"Hai er, NE010-1, NE010-1, NE010-1"
"Hai er, NE07-1, NE07-1, NE07-1"
"Hai er, NE07-2, NE07-2, NE07-2"
"Hai er, NE08-1, NE08-1, NE08-1"
"Hai er, P2, P2, P2"
"Hai er, PAD1021, PAD1021, PAD1021"
"Hai er, PAD1042, PAD1042, PAD1042"
"Hai er, PAD712, PAD712, PAD712"
"Hai er, PAD722, PAD722, PAD722"
"Hai er, PAD841, PAD841, PAD841"
"Hai er, PADCT1010W, PADCT1010W, PADCT1010W"
"Hai er, PAD_1042, PAD_1042, PAD_1042"
"Hai er, PNDPP410GP, PNDPP410GP, PNDPP410GP"
"Hai er, PNDPP44Q7GPBLK, PNDPP44Q7GPBLK, PNDPP44Q7GPBLK"
"Hai er, PNDPP47GP, PNDPP47GP, PNDPP47GP"
"Hai er, SP-5100, SP-5100, SP-5100"
"Hai er, Ski II, Ski II, Ski II"
"Hai er, Smartfren Andromax AD681H, AD681H, Smartfren Andromax AD681H"
"Hai er, Smartfren Andromax AD9A1H, AD9A1H, Smartfren Andromax AD9A1H"
"Hai er, StarQ_Q5002, StarQ_Q5002, Q5002"
"Hai er, T785B, T785B, T785B"
"Hai er, TAB-700, TAB_700, TAB-700"
"Hai er, TAB-700, TAB_700, TAB700MPG"
"Hai er, TMK27A2, TMK27A2, TMK27A2"
"Hai er, V3, V3, V3"
"Hai er, W717, W717, W717"
"Hai er, W757, W757, W757"
"Hai er, W860, W860, W860"
"Harri s, Harri s 12131-1000, msm8660_cougar, Harri s 12131-1000"
"Hi ghScreen, Power Fi ve, PowerFi ve, PowerFi ve"
"Hi ghScreen, Power Four, PowerFour, PowerFour"
"Hi pstreet, 785TB4, 785TB4, 785TB4"
"Hi pstreet, 7DTB25, 7DTB25, 7DTB25"
"Hi pstreet, 7DTB37, 7DTB37, 7DTB37"
"Hi pstreet, 9DTB38, 9DTB38, 9DTB38"
"Hi pstreet, 9DTB39, 9DTB39, 9DTB39"
"Hi pstreet, Beeline smart 4, Beeline_Smart_4, Beeline Smart 4"
"Hi pstreet, ETAB_M7023G, ETAB_M7023G, ETAB_M7023G"
"Hi pstreet, El ectron, 8DTB38, 8DTB38"
"Hi pstreet, HS-10DTB12, Hi pstreet, HS-10DTB12"
"Hi pstreet, HS-10DTB12A, RCT6203W46, HS_10DTB12A"
"Hi pstreet, HS-7DTB27, HS-7DTB27, HS-7DTB27"
"Hi pstreet, HS-7DTB35, HS-7DTB35, HS-7DTB35"
"Hi pstreet, HS-7DTB35, RCT6773W22, HS_7DTB35"
"Hi pstreet, HS-7DTB39, HS-7DTB39, HS-7DTB39"
"Hi pstreet, HS-9DTB7A, HS-9DTB7A, HS-9DTB7A"
"Hi pstreet, Hi pstreet HS-10DTB8, HS-10DTB8, HS-10DTB8"

supported device.txt

"Hi pstreet, Mi cron, 7DTB41, 7DTB41"
"Hi pstreet, Nanho_T775, Nanho_T775, Nanho_T775"
"Hi pstreet, Phantom, Phantom, 10DTB10"
"Hi pstreet, Phoeni x2, Phoeni x2, Phoeni x2"
"Hi pstreet, Synergy, 11DTB1, 11DTB1"
"Hi pstreet, Yupi roi d, Yupi roi d, Yupi roi d"
"Hi sense, , AD683G, AD683G"
"Hi sense, , AD685G, New Andromax-i "
"Hi sense, , E820, HS-E820"
"Hi sense, , E910, E910"
"Hi sense, , E910, HS-E910"
"Hi sense, , E912, HS-E912"
"Hi sense, , E912S, HS-E912S"
"Hi sense, , E920, HS-E920"
"Hi sense, , E926, E926"
"Hi sense, , E930, HS-E930"
"Hi sense, , E956, HS-E956"
"Hi sense, , E956Q, HS-E956Q"
"Hi sense, , EG870, HS-EG870"
"Hi sense, , EG876, HS-EG876"
"Hi sense, , EG901, HS-EG901"
"Hi sense, , EG909, HS-EG909"
"Hi sense, , EG950, HS-EG950"
"Hi sense, , EG970, HS-EG970"
"Hi sense, , P4013, MEDI ON-P4013"
"Hi sense, , SIMPI us, MegaFon SIM+ "
"Hi sense, , T818, HS-T818"
"Hi sense, , TP9101, HS-M170AT"
"Hi sense, , TP9102, M1101AT"
"Hi sense, , U2, U2"
"Hi sense, , U8, HS-U8"
"Hi sense, , U820, HS-U820"
"Hi sense, , U820A, HS-U820"
"Hi sense, , U820A, U1+ "
"Hi sense, , U820AVN, HS-U820"
"Hi sense, , U860, HS-U860"
"Hi sense, , U909, HS-U909"
"Hi sense, , U909B, HS-U909B"
"Hi sense, , U909B_6, HS-U909"
"Hi sense, , U909B_MN, U2S"
"Hi sense, , U912, HS-U912"
"Hi sense, , U950, HS-U950"
"Hi sense, , U950_6, HS-U950"
"Hi sense, , U950_MN, U3"
"Hi sense, , U950_ae, HS-U950"
"Hi sense, , U958, HS-U958"
"Hi sense, , U960Q, HS-U960Q"
"Hi sense, , W2400, W2400"
"Hi sense, , m3101, M3101BW"
"Hi sense, , m370, M370BW"
"Hi sense, , t909, HS-T909"
"Hi sense, , t950, HS-T950"
"Hi sense, , t958, HS-T958"
"Hi sense, , t960, HS-T960"
"Hi sense, 55H6SG, Vi si on, Vi si on"
"Hi sense, Andromax-c, AD686G, Andromax-c"
"Hi sense, C-4, C_4, C-4"
"Hi sense, CMB405, L690AE, CMB405"
"Hi sense, CMB501, u970_carrefour, CMB501"
"Hi sense, CMB510, L696, CMB510"
"Hi sense, D2-M, HS6735MT, D2-M"
"Hi sense, E100T, E100T, Hi sense E100T"
"Hi sense, E100TAE, E100TAE, LT-W1"

supported device.txt

"Hi sense, E200T, E200T, HS-E200T"
"Hi sense, E2070, mt8312, E2070"
"Hi sense, E2371CH, rk3026, E2371CH"
"Hi sense, E260T, E260T, HS-E260T"
"Hi sense, E260U, E260U, Hi sense E260U"
"Hi sense, E270BSA, E270BSA, E270BSA"
"Hi sense, E600MH02, E600MH02, HS-E600M"
"Hi sense, E601M, E601M, E601M"
"Hi sense, E860, E860, E860"
"Hi sense, EG680, eg980ae, EG680"
"Hi sense, EG68AE, EG668AE, LT668"
"Hi sense, EG929, EG929_TW, EG929"
"Hi sense, EG950, EG950TW, EG950"
"Hi sense, EG970, EG970TW, EG970"
"Hi sense, EG978, EG978, HS-EG978"
"Hi sense, EG98, EG98, EG98"
"Hi sense, EG98, EG98TW, EG98"
"Hi sense, EG981, EG981, HS-EG981"
"Hi sense, F270BW, F270BW, F270BW"
"Hi sense, F5070, mt8389, F5070"
"Hi sense, F5180, f5180, F5180"
"Hi sense, F5281CH, rk3288, F5281CH"
"Hi sense, G1, G1, G1"
"Hi sense, G2-3GP, G2-3GP, G2-3GP"
"Hi sense, G610M, G610M, Hi sense G610M"
"Hi sense, H800T, H800T, HS-H800T"
"Hi sense, H910, HS8939QC, Hi sense H910"
"Hi sense, H910-F01, HS8939QC, Hi sense H910"
"Hi sense, Hi sense E50-T, HS8909QC, Hi sense E50-T"
"Hi sense, HS- G610, HS8916QC, HS-G610"
"Hi sense, HS- L682, HS8916QC, HS-L682"
"Hi sense, HS-E600M, E600M, HS-E600M"
"Hi sense, HS-E620M, E620M, HS-E620M"
"Hi sense, HS-E917, E917, HS-E917"
"Hi sense, HS-E936, E936, HS-E936"
"Hi sense, HS-E968, E968, HS-E968"
"Hi sense, HS-EG929, EG929, HS-EG929"
"Hi sense, HS-EG929, EG929, msm8625"
"Hi sense, HS-EG939, EG939, HS-EG939"
"Hi sense, HS-EG958, EG958, HS-EG958"
"Hi sense, HS-EG966, EG966, HS-EG966"
"Hi sense, HS-EG971, EG971, HS-EG971"
"Hi sense, HS-EG980, eg980, HS-EG980"
"Hi sense, HS-EG98C, EG98C, HS-EG98C"
"Hi sense, HS-G610, HS8916QC, HS-G610"
"Hi sense, HS-I 630M, msm8226, HS-I 630M"
"Hi sense, HS-I 630T, msm8226, HS-I 630T"
"Hi sense, HS-T9, T9, HS-T9"
"Hi sense, HS-T926, t926, HS-T926"
"Hi sense, HS-T928, t928, HS-T928"
"Hi sense, HS-T939, HS-T939, HS-T939"
"Hi sense, HS-T959, t959, HS-T959"
"Hi sense, HS-T959S, t959s, HS-T959S"
"Hi sense, HS-T959S1, t959s1, HS-T959S1"
"Hi sense, HS-T966, HS-T966, HS-T966"
"Hi sense, HS-T967, HS-T967, HS-T967"
"Hi sense, HS-T968, t968, HS-T968"
"Hi sense, HS-T968S, t968s, HS-T968S"
"Hi sense, HS-T970, t970, HS-T970"
"Hi sense, HS-T978, t978, HS-T978"
"Hi sense, HS-T980, t980, HS-T980"
"Hi sense, HS-U601, HS7731SP, HS-U601"
"Hi sense, HS-U820, U820B, HS-U820"

supported device.txt

"Hi sense, HS-U9, U9, HS-U9"
"Hi sense, HS-U912, U912A_1, HS-U912"
"Hi sense, HS-U912, U912B, HS-U912"
"Hi sense, HS-U912, U912C, HS-U912"
"Hi sense, HS-U929, u929de, HS-U929"
"Hi sense, HS-U929, u929de_3, HS-U929"
"Hi sense, HS-U936, U936, HS-U936"
"Hi sense, HS-U939, u939, HS-U939"
"Hi sense, HS-U939, u939e_1, HS-U939"
"Hi sense, HS-U939, u939e_3, HS-U939"
"Hi sense, HS-U939, u939e_4, HS-U939"
"Hi sense, HS-U939, u939e_5, HS-U939"
"Hi sense, HS-U950, U950_5, HS-U950"
"Hi sense, HS-U961, HS6572MT, HS-U961"
"Hi sense, HS-U961, u961, HS-U961"
"Hi sense, HS-U961, u961e_1, HS-U961"
"Hi sense, HS-U966, u966, HS-U966"
"Hi sense, HS-U966, u966ae, HS-U966"
"Hi sense, HS-U970, u970e_6, HS-U970"
"Hi sense, HS-U970, u970s_export, HS-U970"
"Hi sense, HS-U970E, u970t, HS-U970E"
"Hi sense, HS-U971, U971AE, HS-U971"
"Hi sense, HS-U978, u978, HS-U978"
"Hi sense, HS-U98, U98, U98"
"Hi sense, HS-U98, U98_FR, HS-U98"
"Hi sense, HS-U980, u980, HS-U980"
"Hi sense, HS-U980, u980b, HS-U980"
"Hi sense, HS-U980, u980be, HS-U980"
"Hi sense, HS-U980, u980be_1, HS-U980"
"Hi sense, HS-U980, u980be_2, HS-U980"
"Hi sense, HS-U980, u980ce_1, HS-U980"
"Hi sense, HS-U980, u980ce_3, HS-U980"
"Hi sense, HS-U980, u980ce_4, HS-U980"
"Hi sense, HS-U980, u980ce_5, HS-U980"
"Hi sense, HS-X5T, X5T, HS-X5T"
"Hi sense, HS-X68T, x68t, HS-X68T"
"Hi sense, HS-X6T, X6T, HS-X6T"
"Hi sense, HS-X8C, x8c, HS-X8C"
"Hi sense, HS-X8T, X8T, HS-X8T"
"Hi sense, HS-X8U, x8u, HS-X8U"
"Hi sense, Hi sense D1-M, D1_M, Hi sense D1-M"
"Hi sense, Hi sense E360M, e360m, Hi sense E360M"
"Hi sense, Hi sense E51-M, HS8909QC, Hi sense E51-M"
"Hi sense, Hi sense E602T, E602T, Hi sense E602T"
"Hi sense, Hi sense E613M, E613M, Hi sense E613M"
"Hi sense, Hi sense E620M, E602M, Hi sense E602M"
"Hi sense, Hi sense E621T, E621T, Hi sense E621T"
"Hi sense, Hi sense E622M, E622M, Hi sense E622M"
"Hi sense, Hi sense E625T, E625T, Hi sense E625T"
"Hi sense, Hi sense EG606, EG606_TW, EG606"
"Hi sense, Hi sense I 631M, i 631m, Hi sense I 631M"
"Hi sense, Hi sense I 632M, I 632M, Hi sense I 632M"
"Hi sense, Hi sense I 632T, I 632T, Hi sense I 632T"
"Hi sense, Hi sense I 635T, HS8916QC, Hi sense I 635T"
"Hi sense, Hi sense I 639M, I 639M, Hi sense I 639M"
"Hi sense, Hi sense I 639T, I 639T, Hi sense I 639T"
"Hi sense, Hi sense I 639T, I 639TA, Hi sense I 639T"
"Hi sense, Hi sense I 639T, I 639TA1, Hi sense I 639T"
"Hi sense, Hi sense L682, HS8916QC, HS-L682"
"Hi sense, Hi sense L682, HS8916QC, Hi sense L682"
"Hi sense, Hi sense M10-M, HS9830SP, Hi sense M10-M"
"Hi sense, Hi sense M20- T, HS8909QC, Hi sense M20-T"
"Hi sense, Hi sense TV, hi sense_gx1200v, hi sense_gx1200v"

supported device.txt

"Hi sense, I 300T, I 300T, Hi sense I 300T"
"Hi sense, I 630U, I 630U, Hi sense I 630U"
"Hi sense, K220_FHD, mst628, K220_FHD"
"Hi sense, L681, HS8916QC, L681"
"Hi sense, L691, I 691, HS-L691"
"Hi sense, L691, I 691e_2, HS-L691"
"Hi sense, L691AE, msm8226, HS-L691"
"Hi sense, L695, HS8929QC, HS-L695"
"Hi sense, LED32G180, hi senseLED32G180, LED32G180"
"Hi sense, LED32K220, mst628, LED32K220"
"Hi sense, LED32K280J3D, mt5880, LED32K280J3D"
"Hi sense, LED32K360, mt5880, LED32K360"
"Hi sense, LED32K360J, mt5880, LED32K360J"
"Hi sense, LED32K360J3D, mt5880, LED32K360J3D"
"Hi sense, LED32K360X3D, mt5880, LED32K360X3D"
"Hi sense, LED32K370, mt5880, LED32K370"
"Hi sense, LED32K600J, mt5880, LED32K600J"
"Hi sense, LED32K600X3D, mt5880, LED32K600X3D"
"Hi sense, LED32K610X3D, mt5880, LED32K610X3D"
"Hi sense, LED32L288, mt5880, LED32L288"
"Hi sense, LED39K280J3D, mt5880, LED39K280J3D"
"Hi sense, LED39K360J, mt5880, LED39K360J"
"Hi sense, LED39K360X3D, mt5880, LED39K360X3D"
"Hi sense, LED39K600X3D, mt5880, LED39K600X3D"
"Hi sense, LED39K600X3DU, mst901, LED39K600X3DU"
"Hi sense, LED39K610X3D, mt5880, LED39K610X3D"
"Hi sense, LED39K680X3DU, mt5327, LED39K680X3DU"
"Hi sense, LED40K260X3D, mt5880, LED40K260X3D"
"Hi sense, LED40K360J, mt5880, LED40K360J"
"Hi sense, LED40K360X3D, mt5880, LED40K360X3D"
"Hi sense, LED40K370, mt5880, LED40K370"
"Hi sense, LED40K681X3DU, msd6a918, LED40K681X3DU"
"Hi sense, LED40L288, mt5880, LED40L288"
"Hi sense, LED42G200, hi senseLED42G200, LED42G200"
"Hi sense, LED42K280J3D, mt5880, LED42K280J3D"
"Hi sense, LED42K330X3D, mt5880, LED42K330X3D"
"Hi sense, LED42K360J, mt5880, LED42K360J"
"Hi sense, LED42K360X3D, mt5880, LED42K360X3D"
"Hi sense, LED42K370, mt5880, LED42K370"
"Hi sense, LED42K380U, msd6a918, LED42K380U"
"Hi sense, LED42K560X3D, hi senseLED42K560X3D, LED42K560X3D"
"Hi sense, LED42K600A3D, mt5880, LED42K600A3D"
"Hi sense, LED42K600X3D, mt5880, LED42K600X3D"
"Hi sense, LED42K610J3DP, mt5880, LED42K610J3DP"
"Hi sense, LED42K610X3D, mt5880, LED42K610X3D"
"Hi sense, LED42K660X3D, hi senseLED42K660X3D, LED42K660X3D"
"Hi sense, LED42K680X3DU, mt5327, LED42K680X3DU"
"Hi sense, LED42L288, mt5880, LED42L288"
"Hi sense, LED46K260X3D, mt5880, LED46K260X3D"
"Hi sense, LED46K280J3D, mt5880, LED46K280J3D"
"Hi sense, LED46K330X3D, mt5880, LED46K330X3D"
"Hi sense, LED46K360J, mt5880, LED46K360J"
"Hi sense, LED46K360X3D, mt5880, LED46K360X3D"
"Hi sense, LED46K660X3D, hi sense6a801, LED46K660X3D"
"Hi sense, LED47K560J3D, hi senseLED47K560J3D, LED47K560J3D"
"Hi sense, LED47K600X3D, mt5880, LED47K600X3D"
"Hi sense, LED47K610J3DP, mt5880, LED47K610J3DP"
"Hi sense, LED48K360X3D, mt5880, LED48K360X3D"
"Hi sense, LED48K370, mt5880, LED48K370"
"Hi sense, LED48K380U, msd6a918, LED48K380U"
"Hi sense, LED48K681X3DU, msd6a918, LED48K681X3DU"
"Hi sense, LED48L288, mt5880, LED48L288"
"Hi sense, LED50G05, hi senseLED50G05, LED50G05"

supported device.txt

"Hi sense, LED50K260X3D, mt5880, LED50K260X3D"
"Hi sense, LED50K360J, mt5880, LED50K360J"
"Hi sense, LED50K360X3D, mt5880, LED50K360X3D"
"Hi sense, LED50K370, mt5880, LED50K370"
"Hi sense, LED50K380U, msd6a918, LED50K380U"
"Hi sense, LED50K610X3D, mt5880, LED50K610X3D"
"Hi sense, LED50K660X3D, hi senseLED50K660X3D, LED50K660X3D"
"Hi sense, LED50K680X3DU, mt5327, LED50K680X3DU"
"Hi sense, LED50L288, mt5880, LED50L288"
"Hi sense, LED50XT880G3D, hi senseLED50XT880G3D, LED50XT880G3D"
"Hi sense, LED50XT880G3DU, mst901, LED50XT880G3DU"
"Hi sense, LED50XT900X3DU, mt5327, LED50XT900X3DU"
"Hi sense, LED55K260X3D, mt5880, LED55K260X3D"
"Hi sense, LED55K360X3D, mt5880, Hi sense LED55K360X3D"
"Hi sense, LED55K370, mt5880, LED55K370"
"Hi sense, LED55K380U, msd6a918, LED55K380U"
"Hi sense, LED55K600A3D, mt5880, LED55K600A3D"
"Hi sense, LED55K600X3D, mt5880, LED55K600X3D"
"Hi sense, LED55K610X3D, mt5880, LED55K610X3D"
"Hi sense, LED55K680X3DU, mt5327, LED55K680X3DU"
"Hi sense, LED55L288, mt5880, LED55L288"
"Hi sense, LED55XT780G3D, hi senseLED55XT780G3D, LED55XT780G3D"
"Hi sense, LED55XT810X3DU, msd6a918, LED55XT810X3DU"
"Hi sense, LED55XT880G3DU, mst901, LED55XT880G3DU"
"Hi sense, LED55XT900X3DU, mt5327, LED55XT900X3DU"
"Hi sense, LED58K280J, mt5880, LED58K280J"
"Hi sense, LED58K280U, mt5327, LED58K280U"
"Hi sense, LED58K610X3D, mt5880, LED58K610X3D"
"Hi sense, LED58K680X3DU, mt5327, LED58K680X3DU"
"Hi sense, LED58XT880G3D, hi senseLED58XT880G3D, LED58XT880G3D"
"Hi sense, LED58XT880J3DU, mst901, LED58XT880J3DU"
"Hi sense, LED60K380, mt5327, LED60K380"
"Hi sense, LED65K560J3DTB, hi senseLED65K560J3DTB, LED65K560J3DTB"
"Hi sense, LED65K560J3DTR, hi senseLED65K560J3DTR, LED65K560J3DTR"
"Hi sense, LED65K600X3D, mt5880, LED65K600X3D"
"Hi sense, LED65K680X3DU, mt5327, LED65K680X3DU"
"Hi sense, LED65XT780G3D, hi senseLED65XT780G3D, LED65XT780G3D"
"Hi sense, LED65XT800X3DU, mt5327, LED65XT800X3DU"
"Hi sense, LED65XT810X3DU, msd6a918, LED65XT810X3DU"
"Hi sense, LED65XT880G3D, hi senseLED65XT880G3D, LED65XT880G3D"
"Hi sense, LED65XT880G3DF, hi senseLED65XT880G3DF, LED65XT880G3DF"
"Hi sense, LED65XT880G3DU, mst901, LED65XT880G3DU"
"Hi sense, LED65XT890G3D, hi senseLED65XT890G3D, LED65XT890G3D"
"Hi sense, LED65XT900G3DU, mst901, LED65XT900G3DU"
"Hi sense, LED65XT900X3DU, mt5327, LED65XT900X3DU"
"Hi sense, LED75XT890G3D, mst901, LED75XT890G3D"
"Hi sense, LED75XT910G3DU, mt5327, LED75XT910G3DU"
"Hi sense, LED84XT900G3D, hi senseLED84XT900G3D, LED84XT900G3D"
"Hi sense, LED85XT910G3DU, mt5327, Vi si on20"
"Hi sense, LT100K6900A, mt5327, LT100K6900A"
"Hi sense, M20-M, HS9830SP, Hi sense M20-M"
"Hi sense, M3101BCD, m3101bcd, M3101BCD"
"Hi sense, M470BSA, m470, M470BSA"
"Hi sense, M470BSD, m470bsd, M470BSD"
"Hi sense, M470BSE, m470bse, M470BSE"
"Hi sense, M470BSG, m470bsg, M470BSG"
"Hi sense, M470BSS, m470bss, M470BSS"
"Hi sense, M701, M701, M701"
"Hi sense, M821, HS8916QC, M821"
"Hi sense, MEDI ON E4001, E4001, MEDI ON E4001"
"Hi sense, MEDI ON X4701, x4701, MEDI ON X4701"
"Hi sense, Oysters Paci fi c 800, x4701ae, Oysters Paci fi c 800"
"Hi sense, PX1900, atm7039c, PX1900"

supported device.txt

"Hi sense, PX1900ES, atm7039c, PX7"
"Hi sense, PX2000, hi sensepx2000, PX2000"
"Hi sense, PX2700, g18ref, PX2700"
"Hi sense, PX2800, hi sensepx2800, PX2800"
"Hi sense, PX3000, mt5880, Hi sense PX3000"
"Hi sense, PX3000, mt5880, PX3000"
"Hi sense, PX3100, mt5880, PX3100"
"Hi sense, SKi 630t, msm8226, SKi 630t"
"Hi sense, STARSHINE 4, HS6572MT, STARSHINE 4"
"Hi sense, STARTRAIL 6 4G, L681, STARTRAIL 6 4G"
"Hi sense, Sero 7, rk3168, E2171CA"
"Hi sense, Sero 7, rk3168, E2171MX"
"Hi sense, Sero 7, rk3168, E2171TK"
"Hi sense, Sero 8, rk3188, E2281"
"Hi sense, Sero 8, rk3188, E2281CA"
"Hi sense, Sero 8, rk3188, E2281MX"
"Hi sense, Sero 8, rk3188, E2281TK"
"Hi sense, Sero 8, rk3188, E2281UK"
"Hi sense, Sero 8 pro, rk3288, F5281"
"Hi sense, Sero7, rk3168, E2171SS"
"Hi sense, Sero7 LE, rk3026, E2371"
"Hi sense, Sero8, rk3188, E2281SS"
"Hi sense, SoundTab MA-317, rk3028a, Hi sense SoundTab MA-317"
"Hi sense, SoundTab MA-327, rk3028a, Hi sense SoundTab MA-327"
"Hi sense, U606AE, U606AE, HS-U606"
"Hi sense, U606AE, U606AE, PHS-402"
"Hi sense, U607, U607, Bouygues Tel ecom Bs 403"
"Hi sense, U609, U609, HS-U609"
"Hi sense, U610, U610, HS-U610"
"Hi sense, U610, U610E_1, HS-U610"
"Hi sense, U688BE, MSM8212, HS-U688"
"Hi sense, U800, U800, HS-U800"
"Hi sense, U800E-1, U800E_1, HS-U800"
"Hi sense, U800E-1, U800E_1, HS-U800E-1"
"Hi sense, U966, u966e_1, U966"
"Hi sense, U970, u970e_8, U970"
"Hi sense, U988, U988, HS-U988"
"Hi sense, U988E-1, U988E_1, HS-U988"
"Hi sense, U988E-2, U988E_2, HS-U988"
"Hi sense, VH777, VH777, VH777"
"Hi sense, VI DAA_TV, Hi 3751, VI DAA_TV"
"Hi sense, VI DAA_TV, mt5861, VI DAA_TV"
"Hi sense, VI DAA_TV, mt5890, VI DAA_TV"
"Hi sense, Vi daa, hel i um3, H7"
"Hi sense, Vi si on, Vi si on, Vi si on"
"Hi sense, Vi si on 2.5, vi si on2_5, vi si on2_5"
"Hi sense, W270BD, W270BD, W270BD"
"Hi sense, WA912, U912ATW, WA912"
"Hi sense, WA960, U960Q_1, WA960"
"Hi sense, WM8, wm8980s, WM8"
"Hi sense, X1E1, X1E1, HS-X1"
"Hi sense, XOLO, us9230e1, XOLO T1000"
"Hi sense, l 691, msm8226, HS-L691"
"Hi sense, vi si on2_1, vi si on2_1, vi si on2_1"
"Hon Hai Preci si on Industry Co. , Ltd. , , EP10_wi fi , PocketBook A10"
"Hon Hai Preci si on Industry Co. , Ltd. , , EP5A_wi fi , PocketBook A7"
"Hon Hai Preci si on Industry Co. , Ltd. , Germany, S9714, LI FETAB_S9714"
"Hon Hai Preci si on Industry Co. , Ltd. , nabi _XD, XD, NABI XD-NV10C"
"Honda, A-DA, e1853, 14A-DA"
"Honda, A-DA, e1853, MY15ADA"
"Honda, MY15ADA, koel sch, MY15ADA"
"Honda, Pi l ot, koel sch, MY15ADA"
"Honeywel l , 70eL00, dbl ack, Dol phi n 70e Bl ack"

supported device.txt

"Honeywell , 70eLW0, dbl ack_wo, Dol phi n 70e BI ack"
 "Honeywell , 70eLWN, dbl ack_wn, Dol phi n 70e BI ack"
 "Honeywell , D75E, 75E-LON, D75E"
 "Honeywell , Dol phi n CT50, CT50LON-CS13S, CT50"
 "Honeywell , Dol phi n CT50, CT50LFN-CS13S, CT50"
 "Honeywell , Dol phi n CT50, CT50LUN-CS13S, CT50"
 "Honeywell , Honeywell CN51, CN51_NCO, CN51 NCO"
 "Honeywell , Honeywell CN51, CN51_NCF, CN51 NCF"
 "Honeywell , Honeywell CN51, CN51_NCU, CN51 NCU"
 "Honeywell , Honeywell CN51, CN51_NNO, CN51 NNO"
 "Honeywell , Honeywell CN51, CN51_QCO, CN51 QCO"
 "Honeywell , Honeywell CN51, CN51_QCF, CN51 QCF"
 "Honeywell , Honeywell CN51, CN51_QCU, CN51 QCU"
 "Honeywell , Honeywell CN51, CN51_QNO, CN51 QNO"
 "Honeywell , Honeywell Dol phi n 70e BI ack, dbl ack_gn, Dol phi n 70e BI ack"
 "Honeywell , Honeywell Dol phi n 70e BI ack, dbl ack_go, Dol phi n 70e BI ack"
 "Honeywell , Honeywell Dol phi n 70e BI ack, dbl ack_wn, Dol phi n 70e BI ack"
 "Honeywell , Honeywell Dol phi n 70e BI ack, dbl ack_wo, Dol phi n 70e BI ack"
 "Huawei , , C8600, C8600"
 "Huawei , , CHT8000, CHT8000"
 "Huawei , , Huawei U8180, Huawei Ideos X1"
 "Huawei , , Huawei U8180, Huawei U8180"
 "Huawei , , Huawei U8180, IDEOS X1"
 "Huawei , , Huawei U8180, Kyivstar Terra"
 "Huawei , , Huawei U8180, Starshi ne"
 "Huawei , , Huawei U8180, Stockholm"
 "Huawei , , Huawei U8180, U8180"
 "Huawei , , Pul se, Pul se"
 "Huawei , , T8300, HUAWEI T8300"
 "Huawei , , T8600, HUAWEI T8600"
 "Huawei , , T8828, HUAWEI T8828"
 "Huawei , , U8110, EQ U8110"
 "Huawei , , U8110, Huawei "
 "Huawei , , U8110, Huawei U8110"
 "Huawei , , U8110, MTC_A"
 "Huawei , , U8110, Pul se Mi ni "
 "Huawei , , U8110, TSP21"
 "Huawei , , U8110, Turkcel I T10"
 "Huawei , , U8110, U8110"
 "Huawei , , U8110, I i fe:) Androi d"
 "Huawei , , U8300, U8300"
 "Huawei , , U8500, HUAWEI IDEOS U8500"
 "Huawei , , U8500, MTC_EVO"
 "Huawei , , dtab01, dtab01"
 "Huawei , , hwC8813Q, HUAWEI C8813Q"
 "Huawei , , hwC8860E, HUAWEI C8860E"
 "Huawei , , hwD2-2010, HUAWEI D2-2010"
 "Huawei , , hwG510-0200, HUAWEI Ascend G510"
 "Huawei , , hwG510-0200, HUAWEI G510-0200"
 "Huawei , , hwG510-0200, Orange Daytona"
 "Huawei , , hwG510-0251, HUAWEI G510-0251"
 "Huawei , , hwG520-T10, HUAWEI G520-T10"
 "Huawei , , hwG525-U00, HUAWEI Ascend G525"
 "Huawei , , hwG525-U00, HUAWEI G525-U00"
 "Huawei , , hwS42HW, S42HW"
 "Huawei , , hwS7-901w, A01HW"
 "Huawei , , hwT8808D, HUAWEI T8808D"
 "Huawei , , hwT8830Pro, T8830Pro"
 "Huawei , , hwU9202L, U9202L-1"
 "Huawei , , hwU9202L, U9202L-3"
 "Huawei , , hwc8500, C8500"
 "Huawei , , hwc8511, C8511"
 "Huawei , , hwc8511, MTS-SP101"

supported device.txt

"Huawei , , hwc8512, C8512"
"Huawei , , hwc8600, C8600"
"Huawei , , hwc8650, C8650"
"Huawei , , hwc8650e, HUAWEI C8650+ "
"Huawei , , hwc8655, HUAWEI C8655"
"Huawei , , hwc8800, C8800"
"Huawei , , hwc8800, MTS-SP140"
"Huawei , , hwc8810, HUAWEI C8810"
"Huawei , , hwc8812E, HUAWEI C8812E"
"Huawei , , hwc8813, HUAWEI C8813"
"Huawei , , hwc8825D, HUAWEI C8825D"
"Huawei , , hwc8826D, HUAWEI C8826D"
"Huawei , , hwc8850, HUAWEI -C8850"
"Huawei , , hwc8860E, HUAWEI C8860E"
"Huawei , , hwc8860V, C8860V"
"Huawei , , hwc8950D, HUAWEI C8950D"
"Huawei , , hwc980, CM980"
"Huawei , , hwes8100, ES8100"
"Huawei , , hwes8500, Huawei ES8500"
"Huawei , , hwh866c, H866C"
"Huawei , , hwh866c, HUAWEI H866C"
"Huawei , , hwh867g, Huawei -H867G"
"Huawei , , hwh868c, HUAWEI H868C"
"Huawei , , hwh881c, HUAWEI H881C"
"Huawei , , hwm650, Express"
"Huawei , , hwm650, M650"
"Huawei , , hwm660, M660"
"Huawei , , hwm860, HUAWEI -M860"
"Huawei , , hwm865c, M865C"
"Huawei , , hwm866, HUAWEI M866"
"Huawei , , hwm866, M866"
"Huawei , , hwm866, USCCADR3310"
"Huawei , , hwm886, M886"
"Huawei , , hwm920, HUAWEI -M920"
"Huawei , , hwm931, HUAWEI -M931"
"Huawei , , hwmt1-u06, HUAWEI MT1-U06"
"Huawei , , hwp2-0000, HUAWEI P2-0000"
"Huawei , , hwp2-6011, HUAWEI P2-6011"
"Huawei , , hwp2-6011, HUAWEI P2-6011-orange"
"Huawei , , hws10101u, Medi aPad 10 FHD"
"Huawei , , hws10101w, GT01"
"Huawei , , hws10101w, Medi aPad 10 FHD"
"Huawei , , hws10201u, Medi aPad 10 LINK"
"Huawei , , hws7300c, HUAWEI Medi aPad"
"Huawei , , hws7300u, HUAWEI Medi aPad"
"Huawei , , hws7300u, Huawei S7-312u"
"Huawei , , hws7300u, Medi aPad"
"Huawei , , hws7300u, Spri ngBoard"
"Huawei , , hws7300w, HUAWEI Medi aPad"
"Huawei , , hws7930u, Medi aPad 7 Li te"
"Huawei , , hws7930w, Medi aPad 7 Li te"
"Huawei , , hwt8620, T8620"
"Huawei , , hwt8830, T8830"
"Huawei , , hwt8833, HUAWEI T8833"
"Huawei , , hwt8950, HUAWEI T8950"
"Huawei , , hwt8950N, HUAWEI T8950N"
"Huawei , , hwt8951, HUAWEI T8951"
"Huawei , , hwt9200, T9200"
"Huawei , , hwt9510e, T9510E"
"Huawei , , hwu8180, Netphone 501"
"Huawei , , hwu8180, U8180"
"Huawei , , hwu8185, U8185"
"Huawei , , hwu8186, U8186"

supported device.txt

"Huawei , , hwu8230, U8230"
 "Huawei , , hwu8350, Barcelona"
 "Huawei , , hwu8350, GM FOX"
 "Huawei , , hwu8350, Huawei U8350"
 "Huawei , , hwu8350, MTC Pro"
 "Huawei , , hwu8350, Personal U8350"
 "Huawei , , hwu8350, Temptation"
 "Huawei , , hwu8350, U8350"
 "Huawei , , hwu8350, U8350-51"
 "Huawei , , hwu8500, Grameenphone Crystal "
 "Huawei , , hwu8500, HUAWEI IDEOS_U8500"
 "Huawei , , hwu8500, Huawei U8500"
 "Huawei , , hwu8500, ICE"
 "Huawei , , hwu8500, MF8503"
 "Huawei , , hwu8500, MTC Evo"
 "Huawei , , hwu8500, MegaFon U8500"
 "Huawei , , hwu8500, U8500"
 "Huawei , , hwu8510, Beeline_E500"
 "Huawei , , hwu8510, GM Ultimate Slim"
 "Huawei , , hwu8510, Huawei IDEOS X3"
 "Huawei , , hwu8510, Huawei U8510"
 "Huawei , , hwu8510, MTC Bravo"
 "Huawei , , hwu8510, S41HW"
 "Huawei , , hwu8510, U8510"
 "Huawei , , hwu8520, U8520"
 "Huawei , , hwu8600, U8600"
 "Huawei , , hwu8650, HUAWEI SONIC"
 "Huawei , , hwu8650, HUAWEI IDEOS_U8650"
 "Huawei , , hwu8650, Huawei U8650"
 "Huawei , , hwu8650, Kyivstar Aqua"
 "Huawei , , hwu8650, MTC 955"
 "Huawei , , hwu8650, SONIC"
 "Huawei , , hwu8650, Turkcell T20"
 "Huawei , , hwu8650, U8650"
 "Huawei , , hwu8650, U8650-1"
 "Huawei , , hwu8651, Astro"
 "Huawei , , hwu8651, Prism"
 "Huawei , , hwu8651, U8651"
 "Huawei , , hwu8651, U8651T"
 "Huawei , , hwu8652, Huawei -U8652"
 "Huawei , , hwu8652, U8652"
 "Huawei , , hwu8652-51, U8652-51"
 "Huawei , , hwu8655, Etisalat"
 "Huawei , , hwu8655, HUAWEI IDEOS Y 200"
 "Huawei , , hwu8655, Personal U8655-51"
 "Huawei , , hwu8655, STARTRAIL II"
 "Huawei , , hwu8655, U8655"
 "Huawei , , hwu8655, U8655-1"
 "Huawei , , hwu8655, U8655-51"
 "Huawei , , hwu8660, SONIC"
 "Huawei , , hwu8661, HUAWEI U8661"
 "Huawei , , hwu8665, Huawei -U8665"
 "Huawei , , hwu8666, MTC Fit"
 "Huawei , , hwu8666, U8666-1"
 "Huawei , , hwu8666, U8666-51"
 "Huawei , , hwu8666-51, U8666-51"
 "Huawei , , hwu8666e, HUAWEI U8666E"
 "Huawei , , hwu8666e, MegaFon SP-A3"
 "Huawei , , hwu8666e-51, HUAWEI U8666E"
 "Huawei , , hwu8666e-51, HUAWEI U8666E-51"
 "Huawei , , hwu8666n, HUAWEI U8666N"
 "Huawei , , hwu8667, U8667"
 "Huawei , , hwu8680, T-Mobile myTouch"

supported device.txt

"Huawei , , hwu8681, HUAWEI U8681"
"Huawei , , hwu8730, T-Mobile myTouch Q"
"Huawei , , hwu8800, IDEOS X5"
"Huawei , , hwu8800, MTC Neo"
"Huawei , , hwu8800, U8800"
"Huawei , , hwu8800, Ucel I "
"Huawei , , hwu8800, u8800"
"Huawei , , hwu8800-51, Huawei U8800-51"
"Huawei , , hwu8800-51, IDEOS X5"
"Huawei , , hwu8800-51, U8800"
"Huawei , , hwu8800-51, U8800-51"
"Huawei , , hwu8800Pro, HUAWEI _I IDEOS_X5"
"Huawei , , hwu8800Pro, Huawei U8800Pro"
"Huawei , , hwu8800Pro, IDEOS X5"
"Huawei , , hwu8800Pro, MTC Neo"
"Huawei , , hwu8800Pro, RBM_HD"
"Huawei , , hwu8800Pro, U8800 Pro"
"Huawei , , hwu8800Pro, U8800Pro"
"Huawei , , hwu8812D, U8812D"
"Huawei , , hwu8815, HUAWEI Ascend G 300"
"Huawei , , hwu8815, HUAWEI U8815"
"Huawei , , hwu8815, HUAWEI _Ascend G 300"
"Huawei , , hwu8815, Personal U8815-51"
"Huawei , , hwu8815, U8815"
"Huawei , , hwu8815, U8815-51"
"Huawei , , hwu8815n, HUAWEI U8815N"
"Huawei , , hwu8815n, U8815N"
"Huawei , , hwu8816, MTC Vi va"
"Huawei , , hwu8816, U8816"
"Huawei , , hwu8818, HUAWEI U8818"
"Huawei , , hwu8818, U8818"
"Huawei , , hwu8820, U8820"
"Huawei , , hwu8825-1, Bs 401"
"Huawei , , hwu8825-1, HUAWEI Ascend G 330"
"Huawei , , hwu8825-1, HUAWEI U8825-1"
"Huawei , , hwu8825D, HUAWEI U8825D"
"Huawei , , hwu8832D, U8832D"
"Huawei , , hwu8836D, U8836D"
"Huawei , , hwu8850, 007HW"
"Huawei , , hwu8850, HUAWEI -U8850"
"Huawei , , hwu8860, GS02"
"Huawei , , hwu8860, HUAWEI _U8860"
"Huawei , , hwu8860, TURKCELL Maxi PR05"
"Huawei , , hwu8860, U8860"
"Huawei , , hwu8860, U8860-51"
"Huawei , , hwu8867Z, U8867Z"
"Huawei , , hwu8950-1, HUAWEI U8950-1"
"Huawei , , hwu8950-51, HUAWEI U8950-51"
"Huawei , , hwu8950D, HUAWEI U8950D"
"Huawei , , hwu8950N-1, HUAWEI U8950N-1"
"Huawei , , hwu8950N-51, HUAWEI U8950N-51"
"Huawei , , hwu9000, HUAWEI -U9000"
"Huawei , , hwu9200, U9200"
"Huawei , , hwu9200, U9200E"
"Huawei , , hwu9200-92, GS03"
"Huawei , , hwu9200-92, U9200"
"Huawei , , hwu9200E, U9200E"
"Huawei , , hwu9201L, 201HW"
"Huawei , , hwu9500, U9500E"
"Huawei , , hwu9501L, HW-01E"
"Huawei , , hwu9508, HUAWEI U9508"
"Huawei , , hwu9510, HUAWEI U9510"
"Huawei , , hwu9510, U9510"

supported device.txt

"Huawei , , hwu9510e, HUAWEI U9510E"
 "Huawei , , hwu9700L, GL07S"
 "Huawei , , hwum840, UM840"
 "Huawei , , hwy210-0010, HUAWEI Y210-0010"
 "Huawei , , hwy210-0100, HUAWEI Ascend Y 210"
 "Huawei , , hwy210-0100, HUAWEI Y210-0100"
 "Huawei , , hwy210-0151, HUAWEI Y210-0151"
 "Huawei , , hwy210-0200, HUAWEI Ascend Y 210D"
 "Huawei , , hwy210-0200, HUAWEI Ascend Y 210D"
 "Huawei , , hwy210-0200, HUAWEI Y210-0200"
 "Huawei , , hwy210-0200, Leopard MF808"
 "Huawei , , hwy210-0200, NATCOM N8302"
 "Huawei , , hwy210-0200, VIETTEL V8404"
 "Huawei , , hwy210-0251, HUAWEI Y210-0251"
 "Huawei , , hwy210-2010, HUAWEI Y210-2010"
 "Huawei , , hwy220t, HUAWEI Y 220T"
 "Huawei , , msm7201a, Pulse"
 "Huawei , , msm7201a, U8230"
 "Huawei , , msm7225, Beeline_E300"
 "Huawei , , msm7225, Grameenphone Crystal "
 "Huawei , , msm7225, HUAWEI IDEOS U8500"
 "Huawei , , msm7225, HUAWEI IDEOS_U8500"
 "Huawei , , msm7225, Huawei "
 "Huawei , , msm7225, Huawei U8300"
 "Huawei , , msm7225, Ideos"
 "Huawei , , msm7225, MTC Evo"
 "Huawei , , msm7225, Pulse Mini "
 "Huawei , , msm7225, RBM C"
 "Huawei , , msm7225, S31HW"
 "Huawei , , msm7225, Smile"
 "Huawei , , msm7225, Tactile internet"
 "Huawei , , msm7225, Turkcell T10"
 "Huawei , , msm7225, U8110"
 "Huawei , , msm7225, U8300"
 "Huawei , , msm7225, U8500"
 "Huawei , , msm7225, Vodafone 845"
 "Huawei , , msm7227, 004HW"
 "Huawei , , msm7230, IDEOS X5"
 "Huawei , , msm7230, u8800"
 "Huawei , , msm7625, C8600"
 "Huawei , , msm7625, HUAWEI -M860"
 "Huawei , , msm7625, Ideos"
 "Huawei , , msm7625, M860"
 "Huawei , , msm7625, U8180"
 "Huawei , , orinoui ac8688V, ORINOUIA C8688V"
 "Huawei , , qsd8k_s7, HUAWEI -S7"
 "Huawei , , qsd8k_s7, IDEOS S7"
 "Huawei , , qsd8k_s7, Ideos S7"
 "Huawei , , qsd8k_s7, Oysters SmaKit S7"
 "Huawei , , qsd8k_s7, S7"
 "Huawei , , qsd8k_slim, IDEOS S7 Slim"
 "Huawei , , u8800, u8800"
 "Huawei , A199, hwa199, HUAWEI A199"
 "Huawei , ALE-CL00, hwALE-Q, HUAWEI ALE-CL00"
 "Huawei , ALE-L02, hwALE-H, 503HW"
 "Huawei , ALE-L02, hwALE-H, ALE-L02"
 "Huawei , ALE-L04, hwALE-Q, HUAWEI ALE-L04"
 "Huawei , ALE-L21, hwALE-H, ALE-L21"
 "Huawei , Ascend D, hwu9500, U9500"
 "Huawei , B199, hwB199, HUAWEI B199"
 "Huawei , C8812, hwc8812, HUAWEI C8812"
 "Huawei , C8813DQ, hwC8813DQ, HUAWEI C8813DQ"
 "Huawei , C8815, hwC8815, HUAWEI C8815"

supported device.txt

"Huawei , C8816, hwC8816, HUAWEI C8816"
"Huawei , C8816D, hwC8816D, HUAWEI C8816D"
"Huawei , C8817D, hwC8817D, C8817D"
"Huawei , C8817E, hwC8817E, HUAWEI C8817E"
"Huawei , C8817L, hwC8817L, HUAWEI C8817L"
"Huawei , C8818, hwC8818, HUAWEI C8818"
"Huawei , CHC-U01, hwCHC-H, CHC-U01"
"Huawei , CHC-U03, hwCHC-H, CHC-U03"
"Huawei , CHC-U23, hwCHC-H, CHC-U23"
"Huawei , CHM-CL00, hwCHM-Q, CHM-CL00"
"Huawei , CHM-U01, hwCHM-H, CHM-U01"
"Huawei , CM990, hwCM990, CM990"
"Huawei , CRR-CL00, HWCRR, HUAWEI CRR-CL00"
"Huawei , CRR-TL00, HWCRR, HUAWEI CRR-TL00"
"Huawei , CRR-UL00, HWCRR, HUAWEI CRR-UL00"
"Huawei , Che1-CL10, Che1, Che1-CL10"
"Huawei , Che1-CL20, Che1, Che1-CL20"
"Huawei , Che1-L04, Che1, Che1-L04"
"Huawei , Che2-L11, hwChe2, Che2-L11"
"Huawei , Che2-L23, hwChe2, Che2-L23"
"Huawei , Che2-TL00, hwChe2, Che2-TL00"
"Huawei , Che2-TL00H, hwChe2, Che2-TL00H"
"Huawei , Che2-TL00M, hwChe2, Che2-TL00M"
"Huawei , Che2-UL00, hwChe2, Che2-UL00"
"Huawei , Chi na, m330, M330"
"Huawei , D2, hwD2-6070, HUAWEI D2-6070"
"Huawei , G350, HWG350, HUAWEI G350-U20"
"Huawei , G350, hwg350, HUAWEI G350"
"Huawei , G350, hwg350, HUAWEI G350-U00"
"Huawei , G506, hwG506-U151, HUAWEI G506-U151"
"Huawei , G510, hwG510-0010, HUAWEI G510-0010"
"Huawei , G510, hwG510-0100, HUAWEI G510-0100"
"Huawei , G510, hwG510-0100, Huawei G510-0100"
"Huawei , G510, hwG510-0100, Huawei G510-0100-orange"
"Huawei , G520, hwG520-5000, HUAWEI G520-5000"
"Huawei , G521-L076, HWG521-L, HUAWEI G521-L076"
"Huawei , G521-L176, HWG521-L, HUAWEI G521-L176"
"Huawei , G526, hwG526-L11, G526-L11"
"Huawei , G526, hwG526-L22, G526-L22"
"Huawei , G526, hwG526-L33, G526-L33"
"Huawei , G527, hwG527-U081, G527-U081"
"Huawei , G535-L11, hwG535-L11, HUAWEI G535-L11"
"Huawei , G535-L11, hwG535-L11, Kestrel "
"Huawei , G535-L11, hwG535-L11, Orange Gova"
"Huawei , G535-L11, hwG535-L11, Speedsurfer"
"Huawei , G535-L11, hwG535-L11, U1 tym5"
"Huawei , G6, hwG6-T00, HUAWEI G6-T00"
"Huawei , G6-C00, hwG6-C00, HUAWEI G6-C00"
"Huawei , G6-L11, hwG6-L11, HUAWEI G6-L11"
"Huawei , G6-L22, hwG6-L22, HUAWEI G6-L22"
"Huawei , G6-L33, hwG6-L33, HUAWEI G6-L33"
"Huawei , G6-U00, hwG6-U00, HUAWEI G6-U00"
"Huawei , G6-U10, hwG6-U10, HUAWEI G6-U10"
"Huawei , G6-U251, hwG6-U251, HUAWEI G6-U251"
"Huawei , G6-U34, hwG6-U34, HUAWEI G6-U34"
"Huawei , G606, HWG606, HUAWEI G606-T00"
"Huawei , G610, hwG610-T00, HUAWEI G610-T00"
"Huawei , G610, hwG610-U00, G610-U00"
"Huawei , G610, hwG610-U00, HUAWEI G610-U00"
"Huawei , G610, hwG610-U30, HUAWEI G610-U30"
"Huawei , G610-T01, hwG610-T01, HUAWEI G610-T01"
"Huawei , G610-T11, hwG610-T11, HUAWEI G610-T11"
"Huawei , G610-U15, hwG610-U15, HUAWEI G610-U15"

supported device.txt

"Huawei , G610-U20, hwG610-U20, HUAWEI G610-U20"
"Huawei , G610C, hwG610-C00, HUAWEI G610-C00"
"Huawei , G615-U10, hwG615-U10, G615-U10"
"Huawei , G615-U10, hwG615-U10, HUAWEI G615-U10"
"Huawei , G616-L076, HWG616-L, HUAWEI G616-L076"
"Huawei , G620-L72, hwG620-L72, HUAWEI G620-L72"
"Huawei , G620-L75, hwG620-L75, G620-L75"
"Huawei , G620S-L01, hwG620S-L01, G620S-L01"
"Huawei , G620S-L02, hwG620S-L02, G620S-L02"
"Huawei , G620S-L03, hwG620S-L03, G620S-L03"
"Huawei , G620S-L03, hwG620S-L03, HUAWEI G620"
"Huawei , G620S-L03, hwG620S-L03, Personal Huawei G620S"
"Huawei , G620S-UL00, hwG620S-UL00, G620S-UL00"
"Huawei , G621-TL00, hwG621-TL00, G621-TL00"
"Huawei , G621-TL00M, hwG621-TL00, G621-TL00M"
"Huawei , G628-TL00, HWG628-TL, HUAWEI G628-TL00"
"Huawei , G629-UL00, HWG629-UL, HUAWEI G629-UL00"
"Huawei , G630-U00, hwG630-U00, HUAWEI G630-U00"
"Huawei , G630-U10, hwG630-U10, G630-U10"
"Huawei , G630-U20, hwG630-U20, G630-U20"
"Huawei , G630-U251, hwG630-U251, G630-U251"
"Huawei , G630-U251, hwG630-U251, HUAWEI G630-U251"
"Huawei , G660-L075, hwG660-L075, HUAWEI G660-L075"
"Huawei , G7-L03, hwG7-L03, G7-L03"
"Huawei , G7-L03, hwG7-L03, HUAWEI G7"
"Huawei , G7-L03, hwG7-L03, HUAWEI G7-L03"
"Huawei , G7-TL00, hwG7-TL00, G7-TL00"
"Huawei , G7-TL00, hwG7-TL00, HUAWEI G7-TL00"
"Huawei , G700, hwG700-T00, HUAWEI G700-T00"
"Huawei , G700, hwG700-U00, HUAWEI G700-U00"
"Huawei , G700-T01, hwG700-T01, HUAWEI G700-T01"
"Huawei , G700-U10, hwG700-U10, HUAWEI G700-U10"
"Huawei , G700-U20, hwG700-U20, HUAWEI G700-U20"
"Huawei , G716, hwG716-L070, HUAWEI G716-L070"
"Huawei , G718, hwG718, HUAWEI G718"
"Huawei , G730, hwG730-C00, HUAWEI G730-C00"
"Huawei , G730, hwG730-T00, HUAWEI G730-T00"
"Huawei , G730, hwG730-U00, HUAWEI G730-U00"
"Huawei , G730-L075, hwG730-L075, HUAWEI G730-L075"
"Huawei , G730-U10, hwG730-U10, HUAWEI G730-U10"
"Huawei , G730-U251, hwG730-U251, HUAWEI G730-U251"
"Huawei , G730-U27, hwG730-U27, HUAWEI G730-U27"
"Huawei , G730-U30, hwG730-U30, HUAWEI G730-U30"
"Huawei , G735-L03, hwG735, G735-L03"
"Huawei , G735-L12, hwG735, G735-L12"
"Huawei , G735-L23, hwG735, G735-L23"
"Huawei , G740, hwG740-L00, G740-L00"
"Huawei , G740, hwG740-L00, Orange Yumo"
"Huawei , G750-T00, hwG750-T00, HUAWEI G750-T00"
"Huawei , G750-T01, hwG750-T01, HUAWEI G750-T01"
"Huawei , G750-T01M, hwG750-T01M, HUAWEI G750-T01M"
"Huawei , G750-T20, hwG750-T20, HUAWEI G750-T20"
"Huawei , G750-U10, hwG750-U10, HUAWEI G750-U10"
"Huawei , G7500, HWG7500, HUAWEI G7500"
"Huawei , GRA-CL00, HWGRA, HUAWEI GRA-CL00"
"Huawei , GRA-CL10, HWGRA, HUAWEI GRA-CL10"
"Huawei , GRA-L09, HWGRA, HUAWEI GRA-L09"
"Huawei , GRA-TL00, HWGRA, HUAWEI GRA-TL00"
"Huawei , GRA-UL00, HWGRA, HUAWEI GRA-UL00"
"Huawei , GRA-UL10, HWGRA, HUAWEI GRA-UL10"
"Huawei , Gran_Rorai ma, hws7721u, Ori noqui a Gran Rorai ma + S7-722u"
"Huawei , H30-C00, hwH30-C00, H30-C00"
"Huawei , H30-L01, hwH30, HONOR H30-L01"

supported device.txt

"Huawei , H30-L01M, hwH30, HONOR H30-L01M"
 "Huawei , H30-L02, hwH30, H30-L02"
 "Huawei , H30-L02, hwH30, HONOR H30-L02"
 "Huawei , H30-T00, hwH30-T00, H30-T00"
 "Huawei , H60, hwH60, H60-L01"
 "Huawei , H60-J1, hwH60, HW-H60-J1"
 "Huawei , H60-L01, hwH60, H60-L01"
 "Huawei , H60-L02, hwH60, H60-L02"
 "Huawei , H60-L03, hwH60, H60-L03"
 "Huawei , H60-L04, hwH60, H60-L04"
 "Huawei , H60-L11, hwH60, H60-L11"
 "Huawei , H60-L12, hwH60, H60-L12"
 "Huawei , H60-L21, hwH60, H60-L21"
 "Huawei , H60-L21, hwH60-L21, H60-L21"
 "Huawei , H882L, hwh882l , H882L"
 "Huawei , H891L, hwH891L, HUAWEI H891L"
 "Huawei , H892L, hwH892L, HUAWEI H892L"
 "Huawei , HUAWEI C199, hwc199, HUAWEI C199"
 "Huawei , HUAWEI C199s, hwc199s, HUAWEI C199s"
 "Huawei , HUAWEI G630, hwG630-T00, HUAWEI G630-T00"
 "Huawei , HUAWEI G7-L01, hwG7-L01, G7-L01"
 "Huawei , HUAWEI G7-L02, hwG7-L02, HUAWEI G7-L02"
 "Huawei , HUAWEI G7-L11, hwG7-L11, HUAWEI G7-L11"
 "Huawei , HUAWEI G7-UL20, hwG7-UL20, HUAWEI G7-UL20"
 "Huawei , HUAWEI H871G, hwh871g, HUAWEI H871G"
 "Huawei , HUAWEI MT7-J1, hwmt7, HUAWEI MT7-J1"
 "Huawei , HUAWEI MT7-L09, hwmt7, HUAWEI MT7-L09"
 "Huawei , HUAWEI Medi aPad 10 Li nk+, hws10231l , 402HW"
 "Huawei , HUAWEI Medi aPad 10 Li nk+, hws10231l , Medi aPad 10 Li nk+ "
 "Huawei , HUAWEI Medi aPad 10 Li nk+, hws10231l , S10-232L"
 "Huawei , HUAWEI Medi aPad 10 Li nk+, hws10231l , SpeedTAB"
 "Huawei , HUAWEI Medi aPad 7 Youth2, hws7721u, Medi aPad 7 Youth 2 "
 "Huawei , HUAWEI Medi aPad 7 Youth2, hws7721u, S7-721u"
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , 403HW"
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , CNPC Securi ty Pad S1"
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , HUAWEI Medi aPad M1 8.0 "
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , Medi aPad M1 8.0 "
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , Medi aPad M1 8.0 (LTE) "
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , Medi aPad M1 8.0 (WI FI) "
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , S8-303L"
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , S8-303LT"
 "Huawei , HUAWEI Medi aPad M1 8.0, hws8301l , S8-306L"
 "Huawei , HUAWEI Medi aPad X1 7.0, hw7d501l , 7D-501u"
 "Huawei , HUAWEI Medi aPad X1 7.0, hw7d501l , Medi aPad X1 "
 "Huawei , HUAWEI Medi aPad X1 7.0, hw7d501l , Medi aPad X1 7.0 "
 "Huawei , HUAWEI Medi aPad X1 7.0, hw7d501l , X1 7.0 "
 "Huawei , HUAWEI P6, hwp6-u06, HUAWEI Ascend P6 "
 "Huawei , HUAWEI P6, hwp6-u06, HUAWEI P6-U06 "
 "Huawei , HUAWEI P6, hwp6-u06, HUAWEI P6-U06-orange "
 "Huawei , HUAWEI P7-L11, hwp7, HUAWEI P7-L11 "
 "Huawei , HUAWEI WATCH, sturgeon, HUAWEI WATCH "
 "Huawei , HUAWEI Y536-A1, hwY536A1, HUAWEI Y536A1 "
 "Huawei , HUAWEI Y6 Pro, HWTIT-AL00, HUAWEI TIT-AL00 "
 "Huawei , HUAWEI Y6 Pro, HWTIT-L6735, HUAWEI TIT-CL10 "
 "Huawei , HUAWEI Y6 Pro, HWTIT-L6735, HUAWEI TIT-TL00 "
 "Huawei , HUAWEI Y610, HWY610-U, HUAWEI Y610-U00 "
 "Huawei , HUAWEI Y618, HWY618-T, HUAWEI Y618-T00 "
 "Huawei , HW-03E, HW-03E, HW-03E "
 "Huawei , HoI -T00, HWHoI -T, HoI -T00 "
 "Huawei , HoI -U10, HWHoI -U, HoI -U10 "
 "Huawei , HoI -U19, HWHoI -U, HoI -U19 "
 "Huawei , Honor 4A, hnSCL-Q, SCL-AL00 "
 "Huawei , Honor 4A, hnSCL-Q, SCL-CL00 "

supported device.txt

"Huawei , Honor 4A, hnSCL-Q, SCL-TL00"
 "Huawei , Honor 4A, hnSCL-Q, SCL-TL00H"
 "Huawei , Honor3, hwH30-T10, H30-T10"
 "Huawei , Honor3, hwH30-U10, H30-U10"
 "Huawei , Honor3, hwhn3-u00, HUAWEI HN3-U00"
 "Huawei , Honor3, hwhn3-u01, HUAWEI HN3-U01"
 "Huawei , Huawei G620-A2, hwG620-A2, HUAWEI G620-A2"
 "Huawei , IDEOS, U8150, Comet"
 "Huawei , IDEOS, U8150, I deos"
 "Huawei , IDEOS, u8150, I deos"
 "Huawei , Ice-Twi st, Ice-Twi st, Ice-Twi st"
 "Huawei , M220, hwmedi aqm220, M220"
 "Huawei , M220, hwmedi aqm220, M220c"
 "Huawei , M220, hwmedi aqm220, dTV01"
 "Huawei , M310, hwsingl eboxm310w, M310"
 "Huawei , M620, M620, M620"
 "Huawei , M620, M620, TB01"
 "Huawei , M835, hwm835, HUAWEI -M835"
 "Huawei , M860, M860, M860"
 "Huawei , M865, hwm865, M865"
 "Huawei , M865, hwm865, USCCADR3305"
 "Huawei , M868, hwm868, HUAWEI M868"
 "Huawei , MS4C, hwMS4C, MS4C"
 "Huawei , MT2-L01, hwmt2-l 01, HUAWEI MT2-L01"
 "Huawei , MT2-L02, hwmt2-l 02, HUAWEI MT2-L02"
 "Huawei , MT2-L03, hwMT2L03, MT2L03"
 "Huawei , MT2-L05, hwmt2-l 05, HUAWEI MT2-L05"
 "Huawei , MT2L03LI TE, hwMT2L03LI TE, MT2L03"
 "Huawei , MT7-CLOO, hwmt7, HUAWEI MT7-CLOO"
 "Huawei , MT7-TL00, hwmt7, HUAWEI MT7-TL00"
 "Huawei , MT7-TL10, hwmt7, HUAWEI MT7-TL10"
 "Huawei , MT7-UL00, hwmt7, HUAWEI MT7-UL00"
 "Huawei , Mate, hwmt1-t00, HUAWEI MT1-T00"
 "Huawei , Mate S, HWCRR, HUAWEI CRR-L09"
 "Huawei , Mate2, hwmt2-c00, HUAWEI MT2-C00"
 "Huawei , Medi aPad Vogue, hws7601u, Medi aPad 7 Li te II "
 "Huawei , Medi aPad Vogue, hws7601u, Medi aPad 7 Vogue"
 "Huawei , Medi aPad Youth, hws7701w, Medi aPad 7 Youth"
 "Huawei , Medi aPad7, hws7601us, Medi aPad 7 Vogue"
 "Huawei , Medi aPad7, hws7601w, Medi aPad 7 Vogue"
 "Huawei , Nexus 6P, angl er, Nexus 6P"
 "Huawei , P2, hwp2-6070, HUAWEI P2-6070"
 "Huawei , P6, hwp6-c00, HUAWEI P6-C00"
 "Huawei , P6, hwp6-t00, HUAWEI P6-T00"
 "Huawei , P6, hwp6-t00, HUAWEI P6-T00V"
 "Huawei , P6S, hwP6s-l 04, P6 S-L04"
 "Huawei , P6S-L04, hwp6s-l 04, 302HW"
 "Huawei , P6S-U06, hwp6s-u06, HUAWEI P6 S-U06"
 "Huawei , P7 mi ni , hwP7Mi ni , HUAWEI P7 mi ni "
 "Huawei , P7-L00, hwp7, HUAWEI P7-L00"
 "Huawei , P7-L05, hwp7, HUAWEI P7-L05"
 "Huawei , P7-L07, hwp7, HUAWEI P7-L07"
 "Huawei , P7-L09, hwp7, HUAWEI P7-L09"
 "Huawei , P7-L10, hwp7, HUAWEI P7-L10"
 "Huawei , P7-L12, hwp7, HUAWEI P7-L12"
 "Huawei , PE-CLOO, hwPE, PE-CLOO"
 "Huawei , PE-TL00M, hwPE, PE-TL00M"
 "Huawei , PE-TL10, hwPE, PE-TL10"
 "Huawei , PE-TL20, hwPE, PE-TL20"
 "Huawei , PE-UL00, hwPE, PE-UL00"
 "Huawei , Pri sm II , hwu8686, Pri sm II "
 "Huawei , S10, hws10103I , Medi aPad 10 FHD"
 "Huawei , S10, hws10201I , Medi aPad 10 LI NK"

supported device.txt

"Huawei , S7, hws7601c, Medi aPad 7 Vogue"
"Huawei , S7, hws7601w, Medi aPad 7 Vogue"
"Huawei , S7, hws7701u, Medi aPad 7 Youth"
"Huawei , S7, hws7930u, Ori noqui a Rorai ma S7-932u"
"Huawei , S7, hws7951w, Medi aPad 7 Li te+ "
"Huawei , S7, hws7951w, Tel pad Dual S "
"Huawei , S7, hws7961w, Tel pad QS "
"Huawei , S7, hws7961w, Tel pad Quad S "
"Huawei , SC-CLOO, HWSC-CLOO, HUAWEI SC-CLOO "
"Huawei , SC-UL10, HWSC-UL10, HUAWEI SC-UL10 "
"Huawei , T-Mobi le Pul se, U8100, Huawei _8100-9 "
"Huawei , T-Mobi le Pul se, U8100, Tacti le i nternet "
"Huawei , T-Mobi le Pul se, U8100, U8100 "
"Huawei , T-Mobi le Pul se, U8100, Vi deocon_V7400 "
"Huawei , T1 10, hwt1a21I, HUAWEI Medi aPad T1 10 4G "
"Huawei , T1 10, hwt1a21I, T1-A21L "
"Huawei , T1 10, hwt1a21I, T1-A21w "
"Huawei , T1 10, hwt1a21I, T1-A23L "
"Huawei , T101, hwt101, T-101 "
"Huawei , T101, hwt101, T101 PAD "
"Huawei , T102, hwt102, QH-10 "
"Huawei , T102, hwt102, T102 PAD "
"Huawei , T801, hwt801, T801 PAD "
"Huawei , T802, hwt802, MT-803G "
"Huawei , T802, hwt802, T802 PAD "
"Huawei , U8120, U8120, Vodafone 845 "
"Huawei , U8220, U8220, Pul se "
"Huawei , U8220, U8220, U8220 "
"Huawei , U8220, U8220, U8220PLUS "
"Huawei , U8230, U8230, U8230 "
"Huawei , U8687, hwu8687, Huawei -U8687 "
"Huawei , UNI ON, hwY538, Y538 "
"Huawei , V858, hwu8160, Huawei 858 "
"Huawei , V858, hwu8160, MTC 950 "
"Huawei , V858, hwu8160, MTC Mi ni "
"Huawei , V858, hwu8160, Vodafone 858 "
"Huawei , Vogue7, hws7601u, Medi aPad 7 Cl assi c "
"Huawei , Vogue7, hws7601u, Medi aPad 7 Li te II "
"Huawei , Vogue7, hws7601u, Medi aPad 7 Vogue "
"Huawei , X2, HWGemi ni , GEM-703L "
"Huawei , X2, HWGemi ni , GEM-703LT "
"Huawei , Y210, oay210, Ori noqui a Auyantepui Y210 "
"Huawei , Y220, HWY220-U, Y220-U00 "
"Huawei , Y220, HWY220-U, Y220-U05 "
"Huawei , Y220, HWY220-U, Y220-U17 "
"Huawei , Y220-T10, hwy220-t10, HUAWEI Y220-T10 "
"Huawei , Y220-U10, HWY220-U, Y220-U10 "
"Huawei , Y221-U03, HWY221-U, HUAWEI Y221-U03 "
"Huawei , Y221-U03, QAY221-U, ORI NOQUI A Auyantepui +Y221-U03 "
"Huawei , Y221-U12, HWY221-U, HUAWEI Y221-U12 "
"Huawei , Y221-U22, HWY221-U, HUAWEI Y221-U22 "
"Huawei , Y221-U33, HWY221-U, HUAWEI Y221-U33 "
"Huawei , Y221-U43, HWY221-U, HUAWEI Y221-U43 "
"Huawei , Y221-U53, HWY221-U, HUAWEI Y221-U53 "
"Huawei , Y300, hwY300-0100, HUAWEI Ascend Y300 "
"Huawei , Y300, hwY300-0100, HUAWEI Y300-0100 "
"Huawei , Y300, hwY300-0151, HUAWEI Y300-0151 "
"Huawei , Y300, hwY300-0151, Pel ephone-Y300- "
"Huawei , Y300-0000, hwY300-0000, HUAWEI Y300-0000 "
"Huawei , Y301A1, hwY301A1, Huawei Y301A1 "
"Huawei , Y301A2, hwY301A2, Huawei Y301A2 "
"Huawei , Y320, hwy320-c00, HUAWEI Y320-C00 "
"Huawei , Y320-T00, HWY320-T00, HUAWEI Y320-T00 "

supported device.txt

"Huawei , Y320-U01, HWY320, HUAWEI Y320-U01"
"Huawei , Y320-U01, HWY320, Y320-U01"
"Huawei , Y320-U10, HWY320-U, HUAWEI Y320-U10"
"Huawei , Y320-U151, HWY320-U, HUAWEI Y320-U151"
"Huawei , Y320-U30, HWY320-U, HUAWEI Y320-U30"
"Huawei , Y320-U351, HWY320-U, HUAWEI Y320-U351"
"Huawei , Y321, HWY321-U, HUAWEI Y321-U051"
"Huawei , Y321, hwy321-c00, HUAWEI Y321-C00"
"Huawei , Y325-T00, HWY325-T, HUAWEI Y325-T00"
"Huawei , Y330, hwY330-U05, Bucare Y330-U05"
"Huawei , Y330, hwY330-U05, HUAWEI Y330-U05"
"Huawei , Y330, hwY330-U21, HUAWEI Y330-U21"
"Huawei , Y330-C00, hwY330-C00, HUAWEI Y330-C00"
"Huawei , Y330-U01, hwY330-U01, HUAWEI Y330-U01"
"Huawei , Y330-U01, hwY330-U01, Luno"
"Huawei , Y330-U07, hwY330-U07, HUAWEI Y330-U07"
"Huawei , Y330-U08, hwY330-U08, HUAWEI Y330-U08"
"Huawei , Y330-U11, hwY330-U11, HUAWEI Y330-U11"
"Huawei , Y330-U11, hwY330-U11, V8510"
"Huawei , Y330-U15, hwY330-U15, HUAWEI Y330-U15"
"Huawei , Y330-U17, hwY330-U17, HUAWEI Y330-U17"
"Huawei , Y336-A1, hwY336-A1, HUAWEI Y336-A1"
"Huawei , Y336-U02, HWY336-U, HUAWEI Y336-U02"
"Huawei , Y336-U12, HWY336-U, HUAWEI Y336-U12"
"Huawei , Y340-U081, hwY340-U081, Y340-U081"
"Huawei , Y360-U03, HWY360-U, HUAWEI Y360-U03"
"Huawei , Y360-U103, HWY360-U6572, HUAWEI Y360-U103"
"Huawei , Y360-U12, HWY360-U, HUAWEI Y360-U12"
"Huawei , Y360-U23, HWY360-U, HUAWEI Y360-U23"
"Huawei , Y360-U31, HWY360-U, HUAWEI Y360-U31"
"Huawei , Y360-U42, HWY360-U, HUAWEI Y360-U42"
"Huawei , Y360-U61, HWY360-U, HUAWEI Y360-U61"
"Huawei , Y360-U72, HWY360-U6572, HUAWEI Y360-U72"
"Huawei , Y360-U82, HWY360-U6572, HUAWEI Y360-U82"
"Huawei , Y360-U93, HWY360-U6572, HUAWEI Y360-U93"
"Huawei , Y511-T00, HWY511-T, HUAWEI Y511-T00"
"Huawei , Y511-T00, HWY511-T, Y511-T00"
"Huawei , Y511-U00, HWY511-U, Y511-U00"
"Huawei , Y511-U10, HWY511-U, HUAWEI Y511-U10"
"Huawei , Y511-U251, HWY511-U, HUAWEI Y511-U251"
"Huawei , Y511-U30, HWY511-U, HUAWEI Y511-U30"
"Huawei , Y511-U30, HWY511-U, VI ETTEL V8506"
"Huawei , Y516-, HWY516-T, HUAWEI Y516-T00"
"Huawei , Y518-T00, HWY518-T, HUAWEI Y518-T00"
"Huawei , Y520-U03, HWY520-U, HUAWEI Y520-U03"
"Huawei , Y520-U12, HWY520-U, HUAWEI Y520-U12"
"Huawei , Y520-U22, HWY520-U, HUAWEI Y520-U22"
"Huawei , Y520-U33, HWY520-U, HUAWEI Y520-U33"
"Huawei , Y523-L076, HWY523, HUAWEI Y523-L076"
"Huawei , Y523-L176, HWY523, HUAWEI Y523-L176"
"Huawei , Y530, hwY530-U00, HUAWEI Y530-U00"
"Huawei , Y530-U051, hwY530-U051, HUAWEI Y530"
"Huawei , Y530-U051, hwY530-U051, HUAWEI Y530-U051"
"Huawei , Y535, HWY535-C00, HUAWEI Y535-C00"
"Huawei , Y535D-C00, HWY535D-C00, HUAWEI Y535D-C00"
"Huawei , Y540-U01, HWY540-U, HUAWEI Y540-U01"
"Huawei , Y541-U02, HWY541-U, HUAWEI Y541-U02"
"Huawei , Y541-U02, HWY541-U, Y541-U02"
"Huawei , Y550-L01, hwY550-L01, HUAWEI Y550-L01"
"Huawei , Y550-L02, hwY550-L02, HUAWEI Y550-L02"
"Huawei , Y550-L02, hwY550-L02, Y550-L02"
"Huawei , Y550-L03, hwY550-L03, HUAWEI Y550"
"Huawei , Y550-L03, hwY550-L03, HUAWEI Y550-L03"

supported device.txt

"Huawei , Y550-L03, hwY550-L03, Personal Huawei Y550"
 "Huawei , Y550-L03, hwY550-L03, Y550-L03"
 "Huawei , Y560-CL00, HWY560-CL, HUAWEI Y560-CL00"
 "Huawei , Y560-L01, HWY560-L, HUAWEI Y560-L01"
 "Huawei , Y560-U02, HWY560-U, HUAWEI Y560-U02"
 "Huawei , Y560-U12, HWY560-U, HUAWEI Y560-U12"
 "Huawei , Y560-U23, HWY560-U, HUAWEI Y560-U23"
 "Huawei , Y600, HWY600-U, HUAWEI Y600-U00"
 "Huawei , Y600, HWY600-U, HUAWEI Y600-U151"
 "Huawei , Y600, HWY600-U, HUAWEI Y600-U20"
 "Huawei , Y600-U351, HWY600-U, HUAWEI Y600-U351"
 "Huawei , Y600-U40, HWY600-U, HUAWEI Y600-U40"
 "Huawei , Y600D-C00, HWY600D-C00, HUAWEI Y600D-C00"
 "Huawei , Y625-U03, KVV625-U, Kavak Y625-U03"
 "Huawei , Y625-U13, HWY625-U, HUAWEI Y625-U13"
 "Huawei , Y625-U21, HWY625-U, HUAWEI Y625-U21"
 "Huawei , Y625-U32, HWY625-U, HUAWEI Y625-U32"
 "Huawei , Y625-U43, HWY625-U, HUAWEI Y625-U43"
 "Huawei , Y625-U51, HWY625-U, HUAWEI Y625-U51"
 "Huawei , Y635-CL00, hwY635, HUAWEI Y635-CL00"
 "Huawei , Y635-L01, hwY635, Y635-L01"
 "Huawei , Y635-L02, hwY635, HUAWEI Y635-L02"
 "Huawei , Y635-L02, hwY635, Y635-L02"
 "Huawei , Y635-L03, hwY635, HUAWEI Y635-L03"
 "Huawei , Y635-L03, hwY635, Y635-L03"
 "Huawei , Y635-L21, hwY635, Y635-L21"
 "Huawei , Youth, hws7701u, Ori noqui a Gran Rorai ma S7-702u"
 "Huawei , d-01G, d-01G, d-01G"
 "Huawei , eH811, hweH811, eH811"
 "Huawei , hw204HW, hw204HW, 204HW"
 "Huawei , m881, hwm881, HUAWEI M881"
 "Huawei , t1_8p0, hws8701, Medi aPad T1 8. 0"
 "Huawei , t1_8p0, hws8701, S8-701u"
 "Huawei , t1_8p0, hws8701, S8-701w"
 "Hyundai , UI tra Energy PI us, UI tra_Energy_PI us, UI tra Energy PI us"
 "Hyundai , UI tra Lati tude, UI tra_Lati tude, UI tra Lati tude"
 "Hyundai , UI tra Style, UI tra_Style, UI tra Style"
 "I CL-KME CS OJSC, TR10CD1, TR10CD1_7, TR10CD1"
 "I CRAIG, I CRAIG CMP 756, Omega9, CMP 756"
 "I CRAIG, I CRAIG CMP 759, Omega7, CMP 759"
 "I DEA, i 4901, i 4901, i 4901"
 "I NQ Mobi le, , camden, Camden"
 "I NQ Mobi le, , camden, I NQ Cl oud Touch"
 "I NQ Mobi le, , camden, I NQ Cl oud Touch -parrot"
 "I NQ Mobi le, , msm7627_surf, I NQ Mayfai r (EU)"
 "I PRODA, T1144, T1144, T1144"
 "I ce Phone, I ce Phone Mi ni , i ce_phone_mi ni , I ce-Phone Mi ni "
 "I mpecca, ET7050D, ET7050D, ET7050D"
 "I net-Tabl et, D711HC_PG, D711HC_PG, D711HC_PG"
 "I net-Tabl et, D7911L3BC_OGS, D7911L3BC_OGS, D7911L3BC_OGS"
 "I nfi ni ty, I nfi ni ty-10. 1-v2, I nfi ni ty-101-v2, I nfi ni ty-10. 1-v2"
 "I nfi ni ty, I nfi ni ty-10. 1-v3, I nfi ni ty_101_v3, I nfi ni ty-10. 1-v3"
 "I nfi ni x, H0T 2, I nfi ni x_X510, I nfi ni x X510"
 "I nfi ni x, H0T NOTE, I nfi ni x-X551, I nfi ni x-X551"
 "I nfi ni x, I nfi ni x, I nfi ni x_X510_sprout, I nfi ni x X510"
 "I nfi ni x, I nfi ni x X505, X505, I nfi ni x X505"
 "I nfi ni x, RACE Bl ot2, I nfi ni x_X454, I nfi ni x X454"
 "I nfi ni x, X405, up09_i nfi ni x_x405_gms, I nfi ni x X405"
 "I nfi ni x, Zero 2, I nfi ni x_X509, I nfi ni x X509"
 "I nfocus, Amazi ng A8, D78, Amazi ng A8"
 "I nfocus, C7, C2107, C2107"
 "I nfocus, CS1 8. 0, cs180, CS180"
 "I nfocus, I N610, MG2, I N610"

supported device.txt

"Infocus, IN810, VKY, IN810"
"Infocus, IN815, VK3, IN815"
"Infocus, InFocus Big Tab, IF195a, IF195a"
"Infocus, InFocus Big Tab, IF236a, IF236a"
"Infocus, InFocus FP-U320-INF-WLTW, U320-WF, FP-U320-INF-WLTW"
"Infocus, InFocus IN260, IN260, IN260"
"Infocus, InFocus IN335, IVM, IN335"
"Infocus, InFocus M2, LSO, InFocus M2"
"Infocus, InFocus M2+, LSC, InFocus M2PLUS"
"Infocus, InFocus M210, M210, M210"
"Infocus, InFocus M260, ZL2, InFocus M260"
"Infocus, InFocus M310, H1W, InFocus M310"
"Infocus, InFocus M320, M320, InFocus M320"
"Infocus, InFocus M320e, M320e, InFocus M320e"
"Infocus, InFocus M350, G30, InFocus M350"
"Infocus, InFocus M350, G3E, InFocus M350"
"Infocus, InFocus M370, FOT, M370"
"Infocus, InFocus M370i, FAT, M370i "
"Infocus, InFocus M510t, TID, InFocus M510t"
"Infocus, InFocus M530, G20, InFocus M530"
"Infocus, InFocus M550, ZZ1, InFocus M550"
"Infocus, InFocus M550 3D, ZD1, InFocus M550 3D"
"Infocus, InFocus M808i, ZM1, InFocus M808i "
"Infocus, InFocus M810, VNA, InFocus M810"
"Infocus, InFocus M810t, VNA, InFocus M810t"
"Infocus, InFocus M812, VN2, InFocus M812"
"Infocus, InFocus M812i, V2I, InFocus M812i "
"Infocus, InFocus NewTab F1, f1, NewTab F1"
"Infocus, InFocus M320e, M320e, InFocus M320e"
"Infocus, M210, M210, M210"
"Infocus, M2_3G, G10, InFocus M2_3G"
"Infocus, M310, H1W, InFocus M310"
"Infocus, M320, M320, InFocus M320"
"Infocus, M320e, M320e, InFocus M320e"
"Infocus, M320m, M320m, InFocus M320m"
"Infocus, M320u, M320, InFocus M320u"
"Infocus, M330, D77, InFocus M330"
"Infocus, M510, TID_CHT, M510"
"Infocus, M510t, TID, InFocus M510t"
"Infocus, M511, TID_CHT, M510"
"Infocus, M511, TID_TWN, M511"
"Infocus, M512, MC2_CN, InFocus M512"
"Infocus, M512, MC2_CN, M512"
"Infocus, M518, MC2_APT, M518"
"Infocus, M535_00WW, G40, InFocus M535"
"Infocus, Smart503, MC2, Smart503"
"Infocus, T3000, P7M, T3000"
"Inhon, L55, L55, L55"
"Insignia, INSI GNIA FLEX 8\`xe2\x80\x99\`xe2\x80\x99 LTE Android
Tablet, ns_15t8lte, NS-15T8LTE"
"Insignia, INSI GNIA NS-14T002, ns_14t002, NS-14T002"
"Insignia, Insignia Flex 10.1, ns_14t004, NS-14T004"
"Insignia, ""Insignia Flex 8""""""", ns_15at08, NS-15AT08"
"Insignia, MID7802RA, MID7802RA, NS-P16AT785HD"
"Insignia, NS-15AT07, NS-15AT07, NS-15AT07"
"Insignia, NS-15AT10, TA120, NS-15AT10"
"Insignia, NS-P10A6100, NS-P10A6100, NS-P10A6100"
"Insignia, NS-P16AT10, NS-P16AT10, NS-P16AT10"
"Intel, , SP-A20i, SP-A20i "
"Intel, , bl ackbay, Xolo_X900"
"Intel, , noonhill, AZ210A"
"Intel, , noonhill, AZ210B"
"Intel, , noonhill, SP-A20i "

supported device.txt

"Intel , AQ710A, Sal i tpa, AQ710A"
"Intel , Eti sal at E-20, zeeyabeach, BT230"
"Intel , Orange San Di ego, AZ210A, AZ210A"
"Intel , Orange avec Intel Insi de, AZ210B, AZ210B"
"Intel , TR10CD1 (PVT2), TR10CD1_4, TR10CD1"
"Intel , TR10CD1 (PVT2), TR10CD1_6, TR10CD1"
"Intel , TR10CS1 (PVT2), TR10CS1_4, TR10CS1"
"Intel , Xol o X500, zeeyabeach, Xol o_X500"
"Intel , Yol o, zeeyabeach, BT210"
"Intenso, Intenso Tab814S, Tab814S, Tab814S"
"Intenso, Tab734, Tab734, Tab734"
"Intermec, CN51, CN51_NCO, CN51 NCO"
"Intermec, CN51, CN51_NCF, CN51 NCF"
"Intermec, CN51, CN51_NCU, CN51 NCU"
"Intermec, CN51, CN51_NNO, CN51 NNO"
"Intermec, CN51, CN51_QCO, CN51 QCO"
"Intermec, CN51, CN51_QCF, CN51 QCF"
"Intermec, CN51, CN51_QCU, CN51 QCU"
"Intermec, CN51, CN51_QNO, CN51 QNO"
"I tworks, TM705, TM705, NI D_7010"
"JLab, JLab_PRO-7, pol ari s-p1gms, JLab PRO-7"
"JP Sacouto, Fl ag Mi l l v2, MG101A2T_BT, Fl ag Mi l l v2"
"JP Sacouto, Fl ag Mi l l v2, MG101A2T_BT_A50, Fl ag Mi l l v2"
"JP Sacouto, Fl ag Mi l l v2, MG101A2T_BT_W32, Fl ag Mi l l v2"
"JP Sacouto, Mi ni Mi l l v2, MG070A2T_BT, Mi ni Mi l l v2"
"JVC, DM65UXR\\DM65USR\\DM85UXR, mstarnapol i_atsc, DM65UXR"
"JVC KENWOOD Hol di ngs, I nc. , , gener, RY-AP1"
"K-Touch, , whi stl er, W808"
"KAZAM, KAZAM TV 4. 5, KOT49H, KAZAM TV 45"
"KAZAM, KAZAM TV 4. 5, TV_45, KAZAM TV 45"
"KAZAM, KAZAM Thunder 345, Thunder_345, KAZAM Thunder 345"
"KAZAM, KAZAM Thunder 345 LTE, Thunder_345_LTE, KAZAM Thunder 345 LTE"
"KAZAM, KAZAM Thunder 345 LTE, Thunder_345_LTE, Thunder3 45 LTE"
"KAZAM, KAZAM Thunder 345L, Thunder_345L, KAZAM Thunder 345L"
"KAZAM, KAZAM Thunder 347, Thunder_347, Thunder 347"
"KAZAM, KAZAM Thunder 350L, Thunder_350L, KAZAM Thunder 350L"
"KAZAM, KAZAM Thunder 550, TH55025, KAZAM Thunder 550"
"KAZAM, KAZAM Thunder 550L, TH5L5025, KAZAM Thunder 550L"
"KAZAM, KAZAM Thunder2 45L, Thunder2_45, KAZAM THUNDER2 45L"
"KAZAM, KAZAM Thunder2 50, Thunder2_50, KAZAM Thunder2 50"
"KAZAM, KAZAM Tornado 348, Tornado_348, Tornado 348"
"KAZAM, KAZAM Tornado 350, KAZAM_Tornado_350, KAZAM Tornado 350"
"KAZAM, KAZAM Tornado 455L, KAZAM_Tornado_455L, KAZAM Tornado 455L"
"KAZAM, KAZAM Tornado2 50, Tornado2_50, KAZAM Tornado2 50"
"KAZAM, KAZAM Trooper 440L, Trooper_440L, KAZAM Trooper 440L"
"KAZAM, KAZAM Trooper 445L, TR4L4544, KAZAM Trooper 445L"
"KAZAM, KAZAM Trooper 450, KAZAM_Trooper_450, KAZAM Trooper 450"
"KAZAM, KAZAM Trooper 450L, KAZAM_Trooper_450L, KAZAM_Trooper_450L"
"KAZAM, KAZAM Trooper 451, Trooper_451, KAZAM Trooper 451"
"KAZAM, KAZAM Trooper 455, TR45544, KAZAM Trooper 455"
"KAZAM, KAZAM Trooper 540, TR54015, KAZAM Trooper 540"
"KAZAM, KAZAM Trooper 550L, TR5L5025, KAZAM Trooper 550L"
"KAZAM, KAZAM Trooper 551, TR550115, KAZAM Trooper 551"
"KAZAM, KAZAM Trooper 555, TR55515, KAZAM Trooper 555"
"KAZAM, KAZAM Trooper2 40, Trooper2_40, KAZAM Trooper2 40"
"KAZAM, KAZAM Trooper2 45, Trooper2_45, Trooper2 45"
"KAZAM, KAZAM Trooper2 50, Trooper2_50, KAZAM Trooper2 50"
"KAZAM, KAZAM Trooper2 60, Trooper2_60, Kazam Trooper2 60"
"KAZAM, TROOPER X3. 5, KAZAM, Trooper_X35"
"KAZAM, TROOPER X4. 0, KAZAM, Trooper_X40"
"KAZAM, TROOPER X5. 5, KAZAM, Trooper_X55"
"KD Interacti ve, KD Interacti ve Kuri o10S, C13300A, Kuri o10S"
"KD Interacti ve, KD Interacti ve Kuri o4S, C13200A, Kuri o4S"

supported device.txt

"KD Interactive, KD Interactive Kuri o7S, C13000A, Kuri o7S"
 "KD Interactive, Kuri o Phone, C14500, Kuri oPhone"
 "KD Interactive, Kuri o Tab - Extrem, g03k, C14100"
 "KLI PAD, KLI PAD_SMART_D71, KLI PAD_SMART_D71, KLI PAD_SMART_D71"
 "KLI PAD, KLI PAD_SMART_D791, KLI PAD_SMART_D791, KLI PAD_SMART_D791"
 "K000K, C600, GBC_bravo, C600"
 "KT Tech, , s120, KM-S120"
 "KT Tech, , s200, KM-S200"
 "KT Tech, , s220, KM-S220"
 "KT Tech, , s220H, KM-S220H"
 "KT Tech, , s300, KM-S300"
 "KT Tech, , s330, KM-S330"
 "KT Tech, EV-S100, s100, EV-S100"
 "KT Tech, TAKE SUIT, e100, KM-E100"
 "Kall ey, Kl ic, SA, K4-02 4G"
 "Karbonn, Sparkle V, Sparkle V_sprout, Sparkle V"
 "Kennex, MD7053G, MD7053G, MD7053G"
 "Ketablet, Ketablet, TR10CS1_6, TR10CS1"
 "Kiano, Slim_Tab_8, Slim_Tab_8, Slim_Tab_8"
 "Kobo, Arc 10HD, macallan, arc 10HD"
 "Kobo, Arc 7, lbp8, arc 7"
 "Kobo, Arc 7HD, cardhu, arc 7HD"
 "Kobo, Kobo Arc, zeus, Arc"
 "Kobo, Kobo Vox, pegasus, Vox"
 "Kodak, IM5, IM5, IM5"
 "Kodak, SP4, SP4, SP4"
 "Konrow, Pri mo, PRI MO, PRI MO"
 "Konrow, Smartfi ve, KONROW_Smartfi ve, Smartfi ve"
 "Kyocera, , SCP-8600, Zi o"
 "Kyocera, , WX06K, WX06K"
 "Kyocera, 404KC, 404KC, 404KC"
 "Kyocera, BASIO, KYV32, KYV32"
 "Kyocera, Bri gadi er, E6782, E6782"
 "Kyocera, DI GNO, KYI 11, ISW11K"
 "Kyocera, DI GNO, KYL22, KYL22"
 "Kyocera, DI GNO Dual , WX04K, WX04K"
 "Kyocera, DI GNO R, 202K, 202K"
 "Kyocera, DI GNO S, KYL21, KYL21"
 "Kyocera, DI GNO T, 302KC, 302KC"
 "Kyocera, DMO15K, DMO15K, DMO15K"
 "Kyocera, DuraForce, E6560, KYOCERA-E6560"
 "Kyocera, DuraForce, E6560C, E6560C"
 "Kyocera, DuraForce, E6560L, E6560L"
 "Kyocera, DuraForce, E6560T, E6560T"
 "Kyocera, DuraForce, E6762, USCC-E6762"
 "Kyocera, DuraScout, E6782L, E6782L"
 "Kyocera, Echo, KSP8000, KSP8000"
 "Kyocera, Echo, M9300, M9300"
 "Kyocera, Event, C5133, Event"
 "Kyocera, HONEY BEE, 101K, 101K"
 "Kyocera, Honeybee Touch, 201K, 201K"
 "Kyocera, Hydro, C5170, C5170"
 "Kyocera, Hydro, C5171, Hydro"
 "Kyocera, Hydro AIR, C6745, KYOCERA-C6745"
 "Kyocera, Hydro EDGE, C5215, C5215"
 "Kyocera, Hydro El i te, C6750, C6750"
 "Kyocera, Hydro I CON, C6730, C6730"
 "Kyocera, Hydro LI FE, C6530, C6530"
 "Kyocera, Hydro LI FE, C6530N, C6530N"
 "Kyocera, Hydro PLUS, C5171R, Hydro"
 "Kyocera, Hydro PLUS, C5171R, Hydro_PLUS"
 "Kyocera, Hydro VI BE, C6725, C6725"
 "Kyocera, Hydro WAVE, C6740, C6740"

supported device.txt

"Kyocera, Hydro WAVE, C6740N, C6740N"
"Kyocera, Hydro XTRM, C6522, C6522"
"Kyocera, Hydro XTRM, C6522N, C6522N"
"Kyocera, Hydro XTRM, C6721, USCC-C6721"
"Kyocera, INFOBAR A03, KYV33, KYV33"
"Kyocera, KC-01, KC-01, KC-01"
"Kyocera, LUCE, KCP01K, KCP01K"
"Kyocera, Mi I ano, C5120, C5120"
"Kyocera, Mi I ano, C5121, C5121"
"Kyocera, Ri se, C5155, C5155"
"Kyocera, Ri se, C5156, Ri se"
"Kyocera, S301, KC-S301AE, KC-S301AE"
"Kyocera, TORQUE, SKT01, SKT01"
"Kyocera, TORQUE G01, KYY24, KYY24"
"Kyocera, TORQUE G02, KYV35, KYV35"
"Kyocera, TORQUE (KC-S701), KC-S701, KC-S701"
"Kyocera, Torque, E6710, Torque"
"Kyocera, TorqueXT, E6715, E6715"
"Kyocera, URBANO L01, KYY21, KYY21"
"Kyocera, URBANO L02, KYY22, KYY22"
"Kyocera, URBANO L03, KYY23, KYY23"
"Kyocera, URBANO PROGRESSO, KYY04, URBANO PROGRESSO"
"Kyocera, URBANO V01, KYV31, KYV31"
"Kyocera, URBANO V02, KYV34, KYV34"
"Kyocera, WX10K, WX10K, WX10K"
"Kyocera, Zi o, SCP-8600, Zi o"
"Kyocera, mi rai e, KYL23, KYL23"
"Kyocera, zi o, msm7627_kb60, Zi o"
"Kyocera, zi o, msm7627_surf, Zi o"
"Kyocera, zi o, pl s8600, Zi o"
"Kyowon, AI I & G PAD, mypad2, KA-E410W"
"LGE, , AS855, LG-AS855"
"LGE, , LGP970, LG-P970"
"LGE, , US855, USCC-US855"
"LGE, , al essi , LG-E720"
"LGE, , al essi , LG-E720b"
"LGE, , al ohag_302-220, LG-C710h"
"LGE, , bl ack, LG-KU5900"
"LGE, , bproj_214-07, LG-P970"
"LGE, , bproj_222-88, LG-P970"
"LGE, , bproj_226-10, LG-P970"
"LGE, , bproj_228-03, LG-P970"
"LGE, , bproj_231-01, LG-P970"
"LGE, , bproj_232-05, LG-P970"
"LGE, , bproj_234-33, LG-P970"
"LGE, , bproj_260-03, LG-P970"
"LGE, , bproj_454-xxx, LG-P970"
"LGE, , bproj_530-XXX, LG-P970"
"LGE, , bproj_BAL-xxx, LG-P970"
"LGE, , bproj_OPEN-CN, LG-P970"
"LGE, , bproj_VDF-XXX, LG-P970"
"LGE, , cosmo_268-06, LG-P920"
"LGE, , cosmo_302-720, LG-P925g"
"LGE, , cosmo_454-XXX, LG-P920"
"LGE, , cosmo_466-92, LG-P920"
"LGE, , cosmo_505-XXX, LG-P920"
"LGE, , cosmo_515-XXX, LG-P920"
"LGE, , cosmo_525-01, LG-P920"
"LGE, , cosmo_525-05, LG-P920"
"LGE, , cosmo_724-02, LG-P920h"
"LGE, , cosmo_724-05, LG-P920h"
"LGE, , cosmo_724-xxx, LG-P920h"
"LGE, , cosmo_BAL-XXX, LG-P920"

supported device.txt

"LGE, , cosmo_CIS-XXX, LG-P920"
"LGE, , cosmo_ESA-XXX, LG-P920"
"LGE, , cosmo_H3G-XXX, LG-P920"
"LGE, , cosmo_MOR-XXX, LG-P920"
"LGE, , cosmo_OPEN-CN, LG-P920"
"LGE, , cosmo_OPT-XXX, LG-P920"
"LGE, , cosmo_TMO-XXX, LG-P920"
"LGE, , cosmo_VDF-XXX, LG-P920"
"LGE, , cosmo_tcl -mx, LG-P920h"
"LGE, , cosmo_viv-br, LG-P920h"
"LGE, , e510_724-XX, LG-E510f"
"LGE, , envt2, USCC-US760"
"LGE, , envt2, VS761"
"LGE, , envt2, enV Pro"
"LGE, , envt2, enV Touch2"
"LGE, , gel ato_262-xx, LG-P690"
"LGE, , gel ato_425-02, LG-P690f"
"LGE, , gel ato_460-xx, LG-P690"
"LGE, , gel ato_460-xx, LG-P693"
"LGE, , gel ato_are-xx, LG-P690"
"LGE, , gel ato_bal -xx, LG-P690"
"LGE, , gel ato_hkg-xx, LG-P690"
"LGE, , gel ato_mor-xx, LG-P690"
"LGE, , gel ato_nfc_234-10, LG-P692"
"LGE, , gel ato_nfc_530-24, LG-P692"
"LGE, , gel ato_nfc_timit, LG-P692"
"LGE, , gel ato_ngr-xx, LG-P690"
"LGE, , gel ato_sgp-xx, LG-P690"
"LGE, , gel ato_tmb-sk, LG-P690"
"LGE, , gel ato_tur-xx, LG-P690"
"LGE, , gel ato_winit, LG-P690"
"LGE, , gel atods_bal -xxx, LG-P698"
"LGE, , gel atods_ngr-xxx, LG-P698"
"LGE, , gel atods_open-xx, LG-P698"
"LGE, , gel atods_tha-xxx, LG-P698f"
"LGE, , hub, LG-LU3000"
"LGE, , ku9500, KU9500"
"LGE, , l1e, LG-P875"
"LGE, , l95g, LG-L95G"
"LGE, , ls700, LG-LS700"
"LGE, , lu2300, LU2300"
"LGE, , lu3100, LG-LU3100"
"LGE, , msm8660_surf, LG-LU6200"
"LGE, , p2, LG-P940h"
"LGE, , p925g, LG-P925g"
"LGE, , p940, LG-P940"
"LGE, , p990_208-10, LG-P990"
"LGE, , p990_214-01, LG-P990"
"LGE, , p990_219-10, LG-P990"
"LGE, , p990_226-01, LG-P990"
"LGE, , p990_228-01, LG-P990"
"LGE, , p990_234-xx, LG-P990"
"LGE, , p990_262-02, LG-P990"
"LGE, , p990_454-xxx, LG-P990"
"LGE, , p990_466-92, LG-P990"
"LGE, , p990_466-xxx, LG-P990"
"LGE, , p990_505-xxx, LG-P990"
"LGE, , p990_525-01, LG-P990"
"LGE, , p990_525-05, LG-P990"
"LGE, , p990_BAL-xxx, LG-P990"
"LGE, , p990_esa-xxx, LG-P990"
"LGE, , p990h, LG-P990h"
"LGE, , p990h_334-020, LG-P990h"

supported device.txt

"LGE, , p990h_716-10, LG-P990h"
"LGE, , p990h_722-34, LG-P990h"
"LGE, , p990h_724-05, LG-P990h"
"LGE, , p990h_730-01, LG-P990h"
"LGE, , p990h_730-03, LG-P990h"
"LGE, , p990h_CTM-xxx, LG-P990h"
"LGE, , p990h_SSV-xxx, LG-P990h"
"LGE, , p993, LG-P993"
"LGE, , star, LG-P990hN"
"LGE, , uni va_228-01, LG-E510"
"LGE, , uni va_454-xx, LG-E510"
"LGE, , uni va_525-01, LG-E510"
"LGE, , uni va_525-05, LG-E510"
"LGE, , uni va_722-34, LG-E510g"
"LGE, , uni va_bal -xxx, LG-E510"
"LGE, , uni va_neu-xx, LG-E510"
"LGE, , uni va_open_cn, LG-E510"
"LGE, , uni va_tha-xx, LG-E510f"
"LGE, , uni va_tmo-gr, LG-E510"
"LGE, , uni va_vdf-es, LG-E510"
"LGE, , v900aus, LG-V900"
"LGE, , v901tnw, LG-V901"
"LGE, , x2_450-08, LG-KU8800"
"LGE, , x3, LG-P880"
"LGE, 070 touch, w3voip, LG-FL40L"
"LGE, AKA, aka, LG-F520L"
"LGE, AKA, aka, LG-F520S"
"LGE, AKA, aka, LG-H788"
"LGE, Al I y, al oha, AS740"
"LGE, Al I y, al oha, Al I y"
"LGE, Al I y, al oha, Al oha"
"LGE, Al I y, al oha, US740"
"LGE, Android TV, cosmo, LG Google TV"
"LGE, Android TV, eden, LG Android TV V4"
"LGE, Android TV, eden, LG Google TV G3 KR"
"LGE, Android TV G3, eden, LG Google TV G3"
"LGE, DM-01G, DM-01G, DM-01G"
"LGE, Enact, fx3q, VS890 4G"
"LGE, Escape, l1a, LG-P870"
"LGE, Eve, EVE, GW620"
"LGE, Eve, EVE, LG GW620"
"LGE, Eve, EVE, LG GW620F"
"LGE, Eve, EVE, LG GW620R"
"LGE, Eve, EVE, LG GW620g"
"LGE, Eve, EVE, LG KH5200"
"LGE, Eve, EVE, LG-GW620"
"LGE, Eve, EVE, LG-KH5200"
"LGE, F60, e2, LG-D390"
"LGE, F60, e2, LG-D390AR"
"LGE, F60, e2ds, LG-D392"
"LGE, F60, e2n, LG-D390n"
"LGE, F60, e2nac, LG-D393"
"LGE, F60, e2nam, LGMS395"
"LGE, F60, e2nas, LGLS660"
"LGE, F60, e2nav, VS810PP"
"LGE, G Pad 10.1, e9wifi, LG-V700"
"LGE, G Pad 10.1, e9wifi n, LG-V700n"
"LGE, G Pad 10.1 LTE, e9lte, LG-VK700"
"LGE, G Pad 10.1 LTE, e9lte, VK700"
"LGE, G Pad 7.0, e7wifi, LG-V400"
"LGE, G Pad 7.0, e7wifi, LG-V400S1"
"LGE, G Pad 7.0, e7wifi, LG-V400Y1"
"LGE, G Pad 7.0 LTE, e7lte, LG-V410"

"LGE, G Pad 7.0 LTE, e7lte, LGUK410"
"LGE, G Pad 8+, altev2, AK815"
"LGE, G Pad 8.0, e8wifi, LG-V480"
"LGE, G Pad II 8.0, t8wifi, LG-V498"
"LGE, G Pro Li te, luv90ds, LG-D685"
"LGE, G Pro Li te, luv90ds, LG-D686"
"LGE, G Pro Li te, luv90nfc, LG-D683"
"LGE, G Pro Li te, luv90nfc, LG-D684"
"LGE, G Pro Li te, luv90ss, LG-D680"
"LGE, G Pro Li te, luv90ss, LG-D681"
"LGE, G Pro Li te, luv90ss, LG-D682"
"LGE, G Pro Li te, luv90ss, LG-D682TR"
"LGE, G Pro2, b1, LG-F350K"
"LGE, G Pro2, b1, LG-F350L"
"LGE, G Pro2, b1, LG-F350S"
"LGE, G Pro2, b1w, LG-D838"
"LGE, G Styl o, g4styl usw, LG-F560K"
"LGE, G Vi sta, b2l ds, LG-D690"
"LGE, G Vi sta, x10, VS880"
"LGE, G Watch, dory, G Watch"
"LGE, G Watch R, lenok, G Watch R"
"LGE, G pad 8.0, e8wifi, LG-V480"
"LGE, G pad 8.0 LTE, e8lte, LG-V490"
"LGE, G2 MI NI, g2m, LG-D620"
"LGE, G2 MI NI, g2mds, LG-D618"
"LGE, G2 MI NI, g2mss, LG-D610"
"LGE, G2 MI NI, g2mss, LG-D610AR"
"LGE, G2 MI NI, g2mss, LG-D610TR"
"LGE, G2 MI NI, g2mv, LG-D625"
"LGE, G2 mi ni 4G LTE, g2mv, LG-D625"
"LGE, G3 Beat, jagdsnm, LG-D726"
"LGE, G3 Beat, jagdsnm, LG-D728"
"LGE, G3 Beat, jagdsnm, LG-D729"
"LGE, G3 Beat, jagn, LG-F470K"
"LGE, G3 Beat, jagn, LG-F470L"
"LGE, G3 Beat, jagn, LG-F470S"
"LGE, G3 Beat, jagnm, LG-D722J"
"LGE, G3 Beat, jagnm, LG-D727"
"LGE, G3 S, jag3gds, LG-D724"
"LGE, G3 S, jag3gss, LG-D723"
"LGE, G3 S, jagnm, LG-D722"
"LGE, G3 S, jagnm, LG-D722AR"
"LGE, G3 S, jagnm, LG-D725PR"
"LGE, G3 Screen, l i ger, LG-F490L"
"LGE, G3 Styl us, b2l dsn, LG-D690n"
"LGE, G3 Styl us, b2l ss, LG-D693"
"LGE, G3 Styl us, b2l ss, LG-D693AR"
"LGE, G3 Styl us, b2l ss, LG-D693TR"
"LGE, G3 Styl us, b2l ssn, LG-D693n"
"LGE, G3 Vi gor, jagc, LGLS885"
"LGE, G3 Vi gor, jagnm, LG-D725"
"LGE, G4 Beat, p1bssn, LG-H735"
"LGE, G4 vi gor, p1bssn, LG-H731"
"LGE, GA7800, eden, LG Androi d TV V4"
"LGE, GPAD 7.0 LTE, e7lte, VK410"
"LGE, Gentl e, cf, LG-F580L"
"LGE, Gpad 7.0, e7wifi, LG-V400"
"LGE, Gx2, b2l n, LG-F430L"
"LGE, Homeboy2, t8wi 7u, LG-V607L"
"LGE, Ice cream Smart, vfpv, LG-F440L"
"LGE, Intui ti on, batman_vzw, VS950 4G"
"LGE, L Bel l o, luv80ds, LG-D335"
"LGE, L Bel l o, luv80ds, LG-D335E"

supported device.txt

"LGE, L Bel l o, l uv80ds, LG-D337"
"LGE, L Fi no, l 70p, LG-D290"
"LGE, L Fi no, l 70p, LG-D290AR"
"LGE, L Fi no, l 70pds, LG-D295"
"LGE, L Fi no, l 70pn, LG-D290"
"LGE, L-01F, g2, L-01F"
"LGE, L20, l uv20ds, LG-D105"
"LGE, L20, l uv20ss, LG-D100"
"LGE, L20, l uv20ss, LG-D100AR"
"LGE, L20, l uv20ts, LG-D107"
"LGE, L30 Sporty, l uv30ds, LG-D125"
"LGE, L30 Sporty, l uv30ss, LG-D120"
"LGE, L30 Sporty, l uv30ss, LG-D120AR"
"LGE, L45, l o_2, LG-X130g"
"LGE, L45, l o_2_ds, LG-X132"
"LGE, L50 Sporty, l uv50ds, LG-D221"
"LGE, L50 Sporty, l uv50ds, LG-D227"
"LGE, L50 Sporty, l uv50ss, LG-D213"
"LGE, L50 Sporty, l uv50ss, LG-D213AR"
"LGE, L50 Sporty, l uv50ssn, LG-D213"
"LGE, L60, l o_1, LG-X135"
"LGE, L60, l o_1, LG-X137"
"LGE, L60, l o_1, LG-X140"
"LGE, L60, l o_1, LG-X145"
"LGE, L60, l o_1, LG-X147"
"LGE, L65, w55, LG-D280"
"LGE, L65, w55ds, LG-D285"
"LGE, L65, w55n, LG-D280"
"LGE, L7 l l, vee7e, LG-P712"
"LGE, L7 l l, vee7e, LG-P714"
"LGE, L7 l l Dual, vee7ds, LG-P716"
"LGE, L70, w5, LG-D320"
"LGE, L70, w5, LG-D320AR"
"LGE, L70, w5, LGAS323"
"LGE, L70, w5c, LGLS620"
"LGE, L70, w5ds, LG-D325"
"LGE, L70, w5n, LG-D320"
"LGE, L70, w5n, LG-D329"
"LGE, L70, w5ts, LG-D340f8"
"LGE, L70 CDMA, w5c, LGL41C"
"LGE, L90, w7, LG-D400"
"LGE, L90, w7, LG-D405"
"LGE, L90, w7, LG-D415"
"LGE, L90, w7ds, LG-D410"
"LGE, L90, w7n, LG-D400"
"LGE, L90, w7n, LG-D405"
"LGE, L90 Dual, w7dsn, LG-D410"
"LGE, LBel l o, l uv80ss, LG-D331"
"LGE, LBel l o, l uv80ss, LG-D331AR"
"LGE, LG AKA, aka, LG-H778"
"LGE, LG AKA, aka, LG-H779"
"LGE, LG AKA, aka, LG-H788"
"LGE, LG AKA, aka, LG-H788SG"
"LGE, LG AKA, aka, LG-H788TR"
"LGE, LG AKA, aka, LG-H788n"
"LGE, LG Bel l o l l, v10, LG-X150"
"LGE, LG Bel l o l l, v10, LG-X155"
"LGE, LG Bel l o l l, v10, LG-X165g"
"LGE, LG Bel l o l l, v10, LG-X170g"
"LGE, LG Cl ass, c100n, LG-F620K"
"LGE, LG Cl ass, c100n, LG-F620L"
"LGE, LG Cl ass, c100n, LG-F620S"
"LGE, LG Connect 4G, cayman, LG-MS840"

supported device.txt

"LGE, LG DOUBLEPLAY, lgc729, LG-C729"
 "LGE, LG Destiny, y50, LGL21G"
 "LGE, LG Enlighten, VS700, LG-VS700"
 "LGE, LG Enlighten, VS700, LG-VS700PP"
 "LGE, LG Escape2, c70n, LG-H443"
 "LGE, LG Escape2, c70n, LG-H445"
 "LGE, LG Esteem, MS910, LG-MS910"
 "LGE, LG F570S, yg, LG-F570S"
 "LGE, LG F70, f70, LGL31L"
 "LGE, LG F70, f70n, LG-D315"
 "LGE, LG F70, f70n, LG-D315I "
 "LGE, LG F70, f70n, LG-F370K"
 "LGE, LG F70, f70n, LG-F370L"
 "LGE, LG F70, f70n, LG-F370S"
 "LGE, LG G Flex, zee, LG-D950"
 "LGE, LG G Flex, zee, LG-D950G"
 "LGE, LG G Flex, zee, LG-D951"
 "LGE, LG G Flex, zee, LG-D955"
 "LGE, LG G Flex, zee, LG-D956"
 "LGE, LG G Flex, zee, LG-D958"
 "LGE, LG G Flex, zee, LG-D959"
 "LGE, LG G Flex, zee, LG-F340K"
 "LGE, LG G Flex, zee, LG-F340L"
 "LGE, LG G Flex, zee, LG-F340S"
 "LGE, LG G Flex, zee, LG-LS995"
 "LGE, LG G Flex, zee, LGL23"
 "LGE, LG G Flex2, z2, LG-F510K"
 "LGE, LG G Flex2, z2, LG-F510L"
 "LGE, LG G Flex2, z2, LG-F510S"
 "LGE, LG G Flex2, z2, LG-H950"
 "LGE, LG G Flex2, z2, LG-H955"
 "LGE, LG G Flex2, z2, LG-H959"
 "LGE, LG G Flex2, z2, LGAS995"
 "LGE, LG G Flex2, z2, LGLS996"
 "LGE, LG G Flex2, z2, LGUS995"
 "LGE, LG G Pad 8.0 LTE, elite, LG-P490L"
 "LGE, LG G Pad 8.3, awifi, LG-V500"
 "LGE, LG G Pad 8.3 Google Play Edition, palman, LG-V510"
 "LGE, LG G Pad 8.3 LTE, altev, VK810 4G"
 "LGE, LG G Pad 8.3 homeBoy, awifi 070u, LG-V507L"
 "LGE, LG G Pad F 8.0, elite, LG-V495"
 "LGE, LG G Pad F 8.0, elite, LG-V499"
 "LGE, LG G Pad F7.0, elite, LGLK430"
 "LGE, LG G Pad F\xe2\x84\xa2 8.0, elite, LG-AK495"
 "LGE, LG G Pad F\xe2\x84\xa2 8.0, elite, LG-UK495"
 "LGE, LG G Pad F\xe2\x84\xa2 8.0, elite, LG-V496"
 "LGE, LG G Pad II 10.1 FHD, tifi, LG-V940"
 "LGE, LG G Pad X 8.3, altev2, VK815"
 "LGE, LG G Pad\xe2\x84\xa2 II 8.0LTE, elite, LG-V497"
 "LGE, LG G Stylo, g4stylusc, LGLS770"
 "LGE, LG G Stylo, g4stylusdsn, LG-H630"
 "LGE, LG G Stylo, g4stylusn, LG-H631"
 "LGE, LG G Stylo, g4stylusn, LG-H631MX"
 "LGE, LG G Stylo, g4stylusn, LG-H635"
 "LGE, LG G Stylo, g4stylusn, LG-H635A"
 "LGE, LG G Stylo, g4stylusn, LG-H636"
 "LGE, LG G Stylo, g4stylusn, LGMS631"
 "LGE, LG G Vista, b2l, LG-D631"
 "LGE, LG G Vista 2, p1v, LG-H740"
 "LGE, LG G2, g2, LG-D800"
 "LGE, LG G2, g2, LG-D801"
 "LGE, LG G2, g2, LG-D802"
 "LGE, LG G2, g2, LG-D802T"

supported device.txt

"LGE, LG G2, g2, LG-D802TR"
"LGE, LG G2, g2, LG-D803"
"LGE, LG G2, g2, LG-D805"
"LGE, LG G2, g2, LG-D806"
"LGE, LG G2, g2, LG-F320K"
"LGE, LG G2, g2, LG-F320L"
"LGE, LG G2, g2, LG-F320S"
"LGE, LG G2, g2, LG-LS980"
"LGE, LG G2, g2, VS980 4G"
"LGE, LG G3, g3, AS985"
"LGE, LG G3, g3, LG-AS990"
"LGE, LG G3, g3, LG-D850"
"LGE, LG G3, g3, LG-D851"
"LGE, LG G3, g3, LG-D852"
"LGE, LG G3, g3, LG-D852G"
"LGE, LG G3, g3, LG-D855"
"LGE, LG G3, g3, LG-D856"
"LGE, LG G3, g3, LG-D857"
"LGE, LG G3, g3, LG-D858"
"LGE, LG G3, g3, LG-D858HK"
"LGE, LG G3, g3, LG-D859"
"LGE, LG G3, g3, LG-F400K"
"LGE, LG G3, g3, LG-F400L"
"LGE, LG G3, g3, LG-F400S"
"LGE, LG G3, g3, LGL24"
"LGE, LG G3, g3, LGLS990"
"LGE, LG G3, g3, LGUS990"
"LGE, LG G3, g3, LGV31"
"LGE, LG G3, g3, VS985 4G"
"LGE, LG G3 A, ti gers, LG-F410S"
"LGE, LG G3 Cat. 6, ti ger6, LG-F460K"
"LGE, LG G3 Cat. 6, ti ger6, LG-F460L"
"LGE, LG G3 Cat. 6, ti ger6, LG-F460S"
"LGE, LG G4, p1, AS986"
"LGE, LG G4, p1, LG-AS811"
"LGE, LG G4, p1, LG-AS991"
"LGE, LG G4, p1, LG-F500K"
"LGE, LG G4, p1, LG-F500L"
"LGE, LG G4, p1, LG-F500S"
"LGE, LG G4, p1, LG-H810"
"LGE, LG G4, p1, LG-H811"
"LGE, LG G4, p1, LG-H812"
"LGE, LG G4, p1, LG-H815"
"LGE, LG G4, p1, LG-H818"
"LGE, LG G4, p1, LG-H819"
"LGE, LG G4, p1, LGLS991"
"LGE, LG G4, p1, LGUS991"
"LGE, LG G4, p1, LGV32"
"LGE, LG G4, p1, VS986"
"LGE, LG G4 Beat, p1bdsn, LG-H736"
"LGE, LG G4 Beat, p1bssn, LG-H735"
"LGE, LG G4 Styl us, mp1s3gds, LG-H540"
"LGE, LG G4 Styl us, mp1s3gss, LG-H542"
"LGE, LG G4c, c90, LG-H525"
"LGE, LG G4c, c90n, LG-H525n"
"LGE, LG G4s, p1bds3g, LG-H734"
"LGE, LG Gx, omega, LG-F310L"
"LGE, LG Gx, omegar, LG-F310LR"
"LGE, LG Joy, y30, LG-H220"
"LGE, LG Joy, y30dsf, LG-H222"
"LGE, LG Joy, y30f, LG-H221"
"LGE, LG Joy, y30f, LG-H221AR"
"LGE, LG L39C, l4i i _cdma, LGL39C"

supported device.txt

"LGE, LG L80 Dual , w6ds, LG-D380"
"LGE, LG L80 Dual , w6ds, LG-D385"
"LGE, LG L80 Single, w6, LG-D370"
"LGE, LG L80 Single, w6, LG-D373"
"LGE, LG L80 Single, w6, LG-D375"
"LGE, LG L80 Single, w6, LG-D375AR"
"LGE, LG LEON\\„\¢ LTE, c50, LG-H345"
"LGE, LG Leon, my50, LG-H320"
"LGE, LG Leon, my50ds, LG-H324"
"LGE, LG Leon, my50ds, LG-H326"
"LGE, LG Leon 4G LTE, c50, LG-H340"
"LGE, LG Leon 4G LTE, c50, LG-H340AR"
"LGE, LG Leon 4G LTE, c50, LG-H340GT"
"LGE, LG Leon 4G LTE, c50, LG-H343"
"LGE, LG Leon 4G LTE, c50, LGMS345"
"LGE, LG Leon 4G LTE, c50ds, LG-H342"
"LGE, LG Leon 4G LTE, c50n, LG-H340n"
"LGE, LG Leon TV, my50ds, LG-H326"
"LGE, LG Logos, c70, LGUS550"
"LGE, LG Lucid, cayman, VS840 4G"
"LGE, LG Lucid, cayman, VS840PP"
"LGE, LG Lucid 2, I1v, VS870 4G"
"LGE, LG Lucid 3, x5, VS876"
"LGE, LG Mach\\„\¢, I 2s, LG-LS860"
"LGE, LG Magna, my90, LG-H500"
"LGE, LG Magna, my90ds, LG-H502"
"LGE, LG Magna LTE, mc90, LG-H520"
"LGE, LG Max, v10, LG-X155"
"LGE, LG Max, v10, LG-X160"
"LGE, LG Max, v10, LG-X165g"
"LGE, LG Motion 4G, I0, LG-MS770"
"LGE, LG OPTIMUS M+, m3_mpcs_us, LG-MS695"
"LGE, LG OPTIMUS ZIP, Igl 75c, LGL75C"
"LGE, LG Optimus 3D, cosmopolitan, LG-P920"
"LGE, LG Optimus 3D, cosmopolitan, LG-P925g"
"LGE, LG Optimus 3D, cosmopolitan, LG-SU760"
"LGE, LG Optimus ELITE\\„\¢, m3s, LG-VM696"
"LGE, LG Optimus Elite, m3s, LG Optimus Elite"
"LGE, LG Optimus Elite, m3s, LG-LS696"
"LGE, LG Optimus F3Q, fx3q, LG-D520"
"LGE, LG Optimus F7, fx1, LG-AS780"
"LGE, LG Optimus F7, fx1, LG-LG870"
"LGE, LG Optimus F7, fx1, LG-US780"
"LGE, LG Optimus G, geeb, LG-E970"
"LGE, LG Optimus G, geeb, LG-E971"
"LGE, LG Optimus G, geeb, LG-E973"
"LGE, LG Optimus G, geehdc, L-01E"
"LGE, LG Optimus G, geehdc, LGL21"
"LGE, LG Optimus G, geehrc, LG-E975"
"LGE, LG Optimus G, geehrc, LG-E975K"
"LGE, LG Optimus G, geehrc, LG-E975T"
"LGE, LG Optimus G, geehrc, LG-E976"
"LGE, LG Optimus G, geehrc, LG-E977"
"LGE, LG Optimus G, geehrc, LG-E987"
"LGE, LG Optimus G, geehrc, LG-F180K"
"LGE, LG Optimus G, geehrc, LG-F180S"
"LGE, LG Optimus G, geehrc4g, LG-F180L"
"LGE, LG Optimus G, geehrc4g, LG-LS970"
"LGE, LG Optimus G Pro, geefhdc, LG-E980"
"LGE, LG Optimus G Pro, geefhdc, LG-E980h"
"LGE, LG Optimus G Pro, geefhdc, LG-E981h"
"LGE, LG Optimus G Pro, geefhdc, LG-E986"
"LGE, LG Optimus G Pro, geefhdc, LG-E988"

supported device.txt

"LGE, LG Opti mus G Pro, geefhd, LG-E989"
 "LGE, LG Opti mus G Pro, geefhd, LG-F240K"
 "LGE, LG Opti mus G Pro, geefhd, LG-F240S"
 "LGE, LG Opti mus G Pro, geefhd4g, LG-F240L"
 "LGE, LG Opti mus HUB, uni va_222-01, LG-E510"
 "LGE, LG Opti mus HUB, uni va_arb-xx, LG-E510"
 "LGE, LG Opti mus HUB, uni va_ci s-xxx, LG-E510"
 "LGE, LG Opti mus HUB, uni va_esa-xx, LG-E510"
 "LGE, LG Opti mus HUB, uni va_eur-xx, LG-E510"
 "LGE, LG Opti mus HUB, uni va_open-eu, LG-E510"
 "LGE, LG Opti mus HUB, uni va_tur-xx, LG-E510"
 "LGE, LG Opti mus L111, v1, LG-E410"
 "LGE, LG Opti mus L111, v1, LG-E410B"
 "LGE, LG Opti mus L111, v1, LG-E410c"
 "LGE, LG Opti mus L111, v1, LG-E410f"
 "LGE, LG Opti mus L111, v1, LG-E410g"
 "LGE, LG Opti mus L111, v1, LG-E410i "
 "LGE, LG Opti mus L111, v1, LG-E411f"
 "LGE, LG Opti mus L111, v1, LG-E411g"
 "LGE, LG Opti mus L111, v1ds, LG-E415f"
 "LGE, LG Opti mus L111, v1ds, LG-E415g"
 "LGE, LG Opti mus L111, v1ds, LG-E420"
 "LGE, LG Opti mus L111, v1ds, LG-E420f"
 "LGE, LG Opti mus L111, v1ts, LG-E475f"
 "LGE, LG Opti mus L3, e0, LG-E400"
 "LGE, LG Opti mus L3, e0, LG-E400R"
 "LGE, LG Opti mus L3, e0, LG-E400b"
 "LGE, LG Opti mus L3, e0, LG-E400f"
 "LGE, LG Opti mus L3, e0, LG-E400g"
 "LGE, LG Opti mus L3, e0, LG-L38C"
 "LGE, LG Opti mus L3, e0, LGL35G"
 "LGE, LG Opti mus L3, e0_open_eur, LG-E400"
 "LGE, LG Opti mus L3 Dual, e1, LG-E405"
 "LGE, LG Opti mus L3 Dual, e1, LG-E405f"
 "LGE, LG Opti mus L3 II, vee3ds, LG-E435"
 "LGE, LG Opti mus L3 II, vee3ds, LG-E435f"
 "LGE, LG Opti mus L3 II, vee3ds, LG-E435g"
 "LGE, LG Opti mus L3 II, vee3ds, LG-E435k"
 "LGE, LG Opti mus L3 II, vee3e, LG-E425"
 "LGE, LG Opti mus L3 II, vee3e, LG-E425c"
 "LGE, LG Opti mus L3 II, vee3e, LG-E425f"
 "LGE, LG Opti mus L3 II, vee3e, LG-E425g"
 "LGE, LG Opti mus L3 II, vee3e, LG-E425j "
 "LGE, LG Opti mus L3 II, vee3e, LG-E430"
 "LGE, LG Opti mus L3 II, vee3e, LG-E431g"
 "LGE, LG Opti mus L4 II, vee4ss, LG-E440"
 "LGE, LG Opti mus L4 II, vee4ss, LG-E440f"
 "LGE, LG Opti mus L4 II, vee4ss, LG-E440g"
 "LGE, LG Opti mus L4 II, vee4ss, LG-E465f"
 "LGE, LG Opti mus L4 II, vee4ss, LG-E465g"
 "LGE, LG Opti mus L4 II Dual, vee4ds, LG-E445"
 "LGE, LG Opti mus L4 II Dual, vee4ds, LG-E467f"
 "LGE, LG Opti mus L4 II Tri, vee4ts, LG-E470f"
 "LGE, LG Opti mus L5 Dual, m4ds, LG-E615"
 "LGE, LG Opti mus L5 Dual, m4ds, LG-E615f"
 "LGE, LG Opti mus L5 II, vee5ds, LG-E455"
 "LGE, LG Opti mus L5 II, vee5ds, LG-E455f"
 "LGE, LG Opti mus L5 II, vee5ds, LG-E455g"
 "LGE, LG Opti mus L5 II, vee5nfc, LG-E460"
 "LGE, LG Opti mus L5 II, vee5nfc, LG-E460f"
 "LGE, LG Opti mus L5 II, vee5ss, LG-E450"
 "LGE, LG Opti mus L5 II, vee5ss, LG-E450B"
 "LGE, LG Opti mus L5 II, vee5ss, LG-E450f"

supported device.txt

"LGE, LG Opti mus L5 II, vee5ss, LG-E450g"
 "LGE, LG Opti mus L5 II, vee5ss, LG-E450j"
 "LGE, LG Opti mus L5 II, vee5ss, LG-E451g"
 "LGE, LG Opti mus L5 II, vee5ss, LG-E460"
 "LGE, LG Opti mus L7, u0, LG-P700"
 "LGE, LG Opti mus L7, u0, LG-P705"
 "LGE, LG Opti mus L7, u0, LG-P705f"
 "LGE, LG Opti mus L7, u0, LG-P705g"
 "LGE, LG Opti mus L7, u0, LG-P708g"
 "LGE, LG Opti mus L7, u0, LG-T280"
 "LGE, LG Opti mus L7, u0, LGL96G"
 "LGE, LG Opti mus L7, vee7ds, LG-P715"
 "LGE, LG Opti mus L7 II, vee7e, LG-P710"
 "LGE, LG Opti mus L7 II, vee7e, LG-P712"
 "LGE, LG Opti mus L7 II, vee7e, LG-P713"
 "LGE, LG Opti mus L7 II, vee7e, LG-P713G0"
 "LGE, LG Opti mus L7 II, vee7e, LG-P713TR"
 "LGE, LG Opti mus L7 II, vee7e, LG-P714"
 "LGE, LG Opti mus L70, w5, LG-D321"
 "LGE, LG Opti mus L70, w5, LGMS323"
 "LGE, LG Opti mus L71 I, vee7ds, LG-P715"
 "LGE, LG Opti mus L71 I, vee7ds, LG-P716"
 "LGE, LG Opti mus L9, u2, LG-D700"
 "LGE, LG Opti mus L9, u2, LG-P760"
 "LGE, LG Opti mus L9, u2, LG-P765"
 "LGE, LG Opti mus L9, u2, LG-P768"
 "LGE, LG Opti mus L9, u2, LG-P769"
 "LGE, LG Opti mus L9, u2, LG-P778"
 "LGE, LG Opti mus L9, u2, LGMS769"
 "LGE, LG Opti mus L9 (NFC), u2, LG-P760"
 "LGE, LG Opti mus L9 II, I9i i, LG-D605"
 "LGE, LG Opti mus LTE Tag, cayman, LG-AS840"
 "LGE, LG Opti mus LTE Tag, cayman, LG-F120K"
 "LGE, LG Opti mus LTE Tag, cayman, LG-F120L"
 "LGE, LG Opti mus LTE Tag, cayman, LG-F120S"
 "LGE, LG Opti mus LTE Tag, I ge_120_kt, LG-F120K"
 "LGE, LG Opti mus LTE Tag, I ge_120_skt, LG-F120S"
 "LGE, LG Opti mus LTE3, fx1sk, LG-F260S"
 "LGE, LG Opti mus One, thunderg, LG-P500"
 "LGE, LG Opti mus One, thunderg, LG-P500h"
 "LGE, LG Opti mus One, thunderg, LG-P503"
 "LGE, LG Opti mus One, thunderg, LG-P504"
 "LGE, LG Opti mus One, thunderg, LG-P505"
 "LGE, LG Opti mus One, thunderg, LG-P505CH"
 "LGE, LG Opti mus One, thunderg, LG-P505R"
 "LGE, LG Opti mus One, thunderg, LG-P506"
 "LGE, LG Opti mus One, thunderg, LG-P509"
 "LGE, LG Opti mus Regard, I O, LG-LW770"
 "LGE, LG Opti mus Sel ect, u0_cdma, LG-AS730"
 "LGE, LG Opti mus Zone 2, w3c, VS415PP"
 "LGE, LG Pecan, pecan, LG-P350"
 "LGE, LG Pecan, pecan, LG-P350f"
 "LGE, LG Pecan, pecan, LG-P350g"
 "LGE, LG Power, y50c, LGL22C"
 "LGE, LG Pri me II, v10, LG-X170fTV"
 "LGE, LG Pri me II, v10, LG-X170g"
 "LGE, LG Pri me Pl us 4G, mc90ds, LG-H522"
 "LGE, LG Revol uti on, bryce, VS910 4G"
 "LGE, LG SUNSET, c50, LGL33L"
 "LGE, LG Spectrum, VS920, VS920 4G"
 "LGE, LG Spi ri t, my70, LG-H420"
 "LGE, LG Spi ri t 4G LTE, c70n, LG-H440n"
 "LGE, LG Spi ri t LTE, c70, LG-H440"

supported device.txt

"LGE, LG Spirit LTE, c70, LG-H440AR"
"LGE, LG Thrill 4G, cosmopolitan, LG-P925"
"LGE, LG Tribute 2\Xe2\x84\xa2, c50, LGLS665"
"LGE, LG Venice, u0_cdma, LG-LG730"
"LGE, LG Viper 4G LTE, cayman, LG-LS840"
"LGE, LG Volt, my70ds, LG-H422"
"LGE, LG Volt, x5, LGLS740"
"LGE, LG Volt 4G, c70ds, LG-H442"
"LGE, LG Volt II, c90nas, LGLS751"
"LGE, LG Volt LTE, c70w, LG-F540K"
"LGE, LG Volt LTE, c70w, LG-F540L"
"LGE, LG Volt LTE, c70w, LG-F540S"
"LGE, LG Watch Urbane, bass, LG Watch Urbane"
"LGE, LG Wine Smart, cf, LG-H410"
"LGE, LG Wine Smart Jazz, cf, LG-F610S"
"LGE, LG optimus LTE2, d1lkt, LG-F160K"
"LGE, LG optimus LTE2, d1lsk, LG-F160S"
"LGE, LG optimus LTE2, d1lu, LG-F160L"
"LGE, LG optimus LTE2, d1lu, LG-F160LV"
"LGE, LG optimus it L-05D, l_dcm, L-05D"
"LGE, LG optimus it L-05E, L05E, L-05E"
"LGE, LG-AS876, x5, AS876"
"LGE, LG-D150, w35, LG-D150"
"LGE, LG-D157f, w35ds, LG-D157F"
"LGE, LG-E985T, gvarfhd, LG-E985"
"LGE, LG-E985T, gvarfhd, LG-E985T"
"LGE, LGL22, g2, LGL22"
"LGE, Marquee, L-07C, L-07C"
"LGE, Marquee, LG855, LG-LG855"
"LGE, Marquee, LS855, LG-LS855"
"LGE, Marquee, bproj_CIS-xxx, LG-P970"
"LGE, My touch 4G, e739, LG-E739"
"LGE, Nexus 4, mako, Nexus 4"
"LGE, Nexus 5, hammerhead, Nexus 5"
"LGE, Nexus 5X, bullhead, Nexus 5X"
"LGE, Optimus Black, bproj_208-01, LG-P970"
"LGE, Optimus EX, x2, LG-SU880"
"LGE, Optimus LTE, l1a, LG-P870"
"LGE, Optimus 2, as680, LG-AS680"
"LGE, Optimus 2X, p990, LG-P990"
"LGE, Optimus 2X, p990, LG-P990H"
"LGE, Optimus 2X, p990, LG-P990h"
"LGE, Optimus 2X, p990_262-xx, LG-P990"
"LGE, Optimus 2X, p990_CIS-xxx, LG-P990"
"LGE, Optimus 2X, p990_EUR-xx, LG-P990"
"LGE, Optimus 2X, p990hN, LG-P990hN"
"LGE, Optimus 2X, p999, LG-P999"
"LGE, Optimus 2X, star, LG-P990"
"LGE, Optimus 2X, star, LG-SU660"
"LGE, Optimus 2X, star_450-05, LG-SU660"
"LGE, Optimus 2X, su660, LG-SU660"
"LGE, Optimus 3D, cosmo_450-05, LG-SU760"
"LGE, Optimus 3D, cosmo_EUR-XXX, LG-P920"
"LGE, Optimus 3D, cosmo_MEA-XXX, LG-P920"
"LGE, Optimus 3D, p920, LG-P920"
"LGE, Optimus 3D, p920, LG-P920h"
"LGE, Optimus 3D, su760, LG-SU760"
"LGE, Optimus 3D Cube, cx2, LG-SU870"
"LGE, Optimus 3D MAX, cx2, LG-P720"
"LGE, Optimus 3D MAX, cx2, LG-P720h"
"LGE, Optimus 3D MAX, cx2, LG-P725"
"LGE, Optimus 3D MAX, cx2, LG-SU870"
"LGE, Optimus 4X HD, x3, LG-P880"

supported device.txt

"LGE, Opti mus 4X HD, x3, LG-P880g"
 "LGE, Opti mus Bi g, j usti n, LG-LU6800"
 "LGE, Opti mus Bi g, l u6800, LG-LU6800"
 "LGE, Opti mus Bl ack, LGL85C, LGL85C"
 "LGE, Opti mus Bl ack, bl ack, LG-KU5900"
 "LGE, Opti mus Bl ack, bl ackg, LG-P970"
 "LGE, Opti mus Bl ack, bl ackg, LG-P970h"
 "LGE, Opti mus Bl ack, bproj _214-03, LG-P970"
 "LGE, Opti mus Bl ack, bproj _262-XXX, LG-P970"
 "LGE, Opti mus Bl ack, bproj _302-220, LG-P970g"
 "LGE, Opti mus Bl ack, bproj _334-020, LG-P970h"
 "LGE, Opti mus Bl ack, bproj _724-xxx, LG-P970h"
 "LGE, Opti mus Bl ack, bproj _ARE-XXX, LG-P970"
 "LGE, Opti mus Bl ack, bproj _EUR-XXX, LG-P970"
 "LGE, Opti mus Bl ack, bproj _sea-xxx, LG-P970"
 "LGE, Opti mus Bl ack, ku5900, LG-KU5900"
 "LGE, Opti mus Bl ack, l gp970, LG-P970"
 "LGE, Opti mus Bl ack, l gp970, LG-P970g"
 "LGE, Opti mus Bl ack, l gp970, LG-P970h"
 "LGE, Opti mus Chat, hazel , LG-C550"
 "LGE, Opti mus Chat, hazel , LG-C555"
 "LGE, Opti mus Core, u0_cdma, LGL86C"
 "LGE, Opti mus EX, x2, l S11LG"
 "LGE, Opti mus EX, x2_450-05, LG-SU880"
 "LGE, Opti mus Exceed 2, w5c, LG-VS450PP"
 "LGE, Opti mus F3, fx3, LG-LS720"
 "LGE, Opti mus F3, fx3, LG-P655H"
 "LGE, Opti mus F3, fx3, LG-P655K"
 "LGE, Opti mus F3, fx3, LG-P659"
 "LGE, Opti mus F3, fx3, LG-P659H"
 "LGE, Opti mus F3, fx3, LGL25L"
 "LGE, Opti mus F3, fx3, LGMS659"
 "LGE, Opti mus F5, l 1e, LG-P870h"
 "LGE, Opti mus F5, l 1e, LG-P875"
 "LGE, Opti mus F5, l 1e, LG-P875h"
 "LGE, Opti mus F5, l 1v, AS870 4G"
 "LGE, Opti mus F6, f6, LG-D500"
 "LGE, Opti mus F6, f6, LG-D505"
 "LGE, Opti mus F6, f6, LGMS500"
 "LGE, Opti mus Fuel , w3c, LGL34C"
 "LGE, Opti mus G Pro, geevl 04e, L-04E"
 "LGE, Opti mus GJ, geehdc, LG-E975w"
 "LGE, Opti mus GK, gvfhdc, LG-F220K"
 "LGE, Opti mus Hub, l gc800, LG-C800"
 "LGE, Opti mus Hub, l gc800g, LG-C800G"
 "LGE, Opti mus Hub, uni va_214-04, LG-E510"
 "LGE, Opti mus Hub, uni va_724-05, LG-E510f"
 "LGE, Opti mus Hub, uni va_730-01, LG-E510g"
 "LGE, Opti mus Hub, uni va_730-03, LG-E510g"
 "LGE, Opti mus Hub, uni va_740-01, LG-E510g"
 "LGE, Opti mus Hub, uni va_cl r-br, LG-E510f"
 "LGE, Opti mus Hub, uni va_ctm-xxx, LG-E510g"
 "LGE, Opti mus Hub, uni va_ent-cl , LG-E510g"
 "LGE, Opti mus Hub, uni va_open-br, LG-E510f"
 "LGE, Opti mus Hub, uni va_open-de, LG-E510"
 "LGE, Opti mus Hub, uni va_ssv-xxx, LG-E510g"
 "LGE, Opti mus Hub, uni va_tcl -mx, LG-E510f"
 "LGE, Opti mus Hub, uni va_tlf-es, LG-E510"
 "LGE, Opti mus Hub, uni va_ufn-mx, LG-E510g"
 "LGE, Opti mus Hub, uni va_usc-mx, LG-E510g"
 "LGE, Opti mus Hub, uni va_viv-br, LG-E510f"
 "LGE, Opti mus L40, w3, LG-D160"
 "LGE, Opti mus L40, w3, LG-D165"

supported device.txt

"LGE, Opti mus L40, w3, LG-D165AR"
"LGE, Opti mus L40, w3ds, LG-D170"
"LGE, Opti mus L40, w3ds, LG-D175f"
"LGE, Opti mus L40, w3ts, LG-D180f"
"LGE, Opti mus L5, m4, LG-E610"
"LGE, Opti mus L5, m4, LG-E610v"
"LGE, Opti mus L5, m4, LG-E612"
"LGE, Opti mus L5, m4, LG-E612f"
"LGE, Opti mus L5, m4, LG-E612g"
"LGE, Opti mus L5, m4, LG-E617G"
"LGE, Opti mus L5, m4, LG-L40G"
"LGE, Opti mus L711, vee7ds, LG-P716"
"LGE, Opti mus LI FE, l1_dcm, L-02E"
"LGE, Opti mus LTE, i _dcm, L-01D"
"LGE, Opti mus LTE, i _skt, LG-SU640"
"LGE, Opti mus LTE, i _u, LG-LU6200"
"LGE, Opti mus LTE, i proj, LG-P936"
"LGE, Opti mus LTE, l gp930, LG-P930"
"LGE, Opti mus LTE, l gp935, LG-P935"
"LGE, Opti mus Mach, LU3000, LG-LU3000"
"LGE, Opti mus Mach, hub, LG-LU3000"
"LGE, Opti mus Mach, l u3000, LG-LU3000"
"LGE, Opti mus Net, gel ato_302-610, LG-P690b"
"LGE, Opti mus Net, gel ato_ci s-xx, LG-P690"
"LGE, Opti mus Net, gel ato_sea-xx, LG-P690"
"LGE, Opti mus Net, l gl 45c, LGL45C"
"LGE, Opti mus Net Dual, gel atods_are-xxx, LG-P698"
"LGE, Opti mus Net Dual, gel atods_ci s-xxx, LG-P698"
"LGE, Opti mus Net Dual, gel atods_i nd-xxx, LG-P698"
"LGE, Opti mus Net Dual, gel atods_open-br, LG-P698f"
"LGE, Opti mus Net Dual, gel atods_sea-xxx, LG-P698"
"LGE, Opti mus One, ku3700, LG-KU3700"
"LGE, Opti mus One, l u3700, LG-LU3700"
"LGE, Opti mus One, su370, LG-SU370"
"LGE, Opti mus One, thunder_kor-05, LG-SU370"
"LGE, Opti mus One, thunder_kor-08, LG-KU3700"
"LGE, Opti mus One, thunder_kor-08, LG-LU3700"
"LGE, Opti mus One, thunderc, LG-CX670"
"LGE, Opti mus One, thunderc, LG-LW690"
"LGE, Opti mus One, thunderc, LG-MS690"
"LGE, Opti mus One, thunderc, LG-US670"
"LGE, Opti mus One, thunderc, LS670"
"LGE, Opti mus One, thunderc, VM670"
"LGE, Opti mus One, thunderc, Vortex"
"LGE, Opti mus One, thunderc, thunderc"
"LGE, Opti mus PAD LTE, express, LG-LU8300"
"LGE, Opti mus Pad, l 06c, L-06C"
"LGE, Opti mus Pad, v900, LG-V900"
"LGE, Opti mus Pad, v900asi a, LG-V900"
"LGE, Opti mus Pad, v901ar, LG-V901"
"LGE, Opti mus Pad, v901kr, LG-V901"
"LGE, Opti mus Pad, v901tr, LG-V901"
"LGE, Opti mus Pad, v905r, LG-V905R"
"LGE, Opti mus Pad, v909, LG-V909"
"LGE, Opti mus Pad, v909mkt, LG-V909"
"LGE, Opti mus Pl us, m3_acg_us, LG-AS695"
"LGE, Opti mus Pro, muscat, LG-C660"
"LGE, Opti mus Pro, muscat, LG-C660R"
"LGE, Opti mus Pro, muscat, LG-C660h"
"LGE, Opti mus Q, l gl 55c, LGL55C"
"LGE, Opti mus Q2, bssq, LG-LU6500"
"LGE, Opti mus Q2, bssq_450-06, LG-LU6500"
"LGE, Opti mus SI i der, VM701, LG-VM701"

supported device.txt

"LGE, Opti mus Sol , vi ctor, LG-E730"
"LGE, Opti mus Sol , vi ctor, LG-E730f"
"LGE, Opti mus Spi ri t, gel ato_505-01, LG-P690f"
"LGE, Opti mus Spi ri t, gel ato_eur-xx, LG-P690"
"LGE, Opti mus Vu, 325, LG-F100L"
"LGE, Opti mus Vu, batman, LG-F100L"
"LGE, Opti mus Vu, batman, LG-F100S"
"LGE, Opti mus Vu, batman_dcm, L-06DJOJO"
"LGE, Opti mus Vu, batman_l gu, LG-F100L"
"LGE, Opti mus Vu, batman_skt, LG-F100S"
"LGE, Opti mus Vu, l ge_325_skt, LG-F100S"
"LGE, Opti mus Vu, vu10, LG-P895"
"LGE, Opti mus Vu, vu10, LG-P895qb"
"LGE, Opti mus Vu2, vu2kt, LG-F200K"
"LGE, Opti mus Vu2, vu2sk, LG-F200S"
"LGE, Opti mus Vu2, vu2u, LG-F200L"
"LGE, Opti mus Vu2, vu2u, LG-F200LS"
"LGE, Opti mus Vu: , batman_dcm, L-06D"
"LGE, Opti mus Z, su950, SU950"
"LGE, Opti mus Zone, e0v, LG-VS410PP"
"LGE, Opti mus chat, el i ni , L-04C"
"LGE, PRADA 3. 0, p2, L-02D"
"LGE, PRADA 3. 0, p2, LG-KU5400"
"LGE, PRADA 3. 0, p2, LG-LU5400"
"LGE, PRADA 3. 0, p2, LG-P940"
"LGE, PRADA 3. 0, p2, LG-P940h"
"LGE, PRADA 3. 0, p2, LG-SU540"
"LGE, PecanV, pecanV, LG-P355"
"LGE, SH950C-CM, stb_catv_cnmuhd, SH950C-CM"
"LGE, Shi ne Pl us wi th Googl e, al ohag, LG-C710h"
"LGE, Smart Di os V8700, SE_TF, ref_SCTF"
"LGE, Spectrum, i _vzw, VS920 4G"
"LGE, Spectrum 2, d11v, VS930 4G"
"LGE, Spi ri t 4G, l 1m, LG-MS870"
"LGE, Spl endor, u0_cdma, LG-US730"
"LGE, Spray, e2j ps, 402LG"
"LGE, Swi ft, swi ft, GT540"
"LGE, Swi ft, swi ft, GT540G0"
"LGE, Swi ft, swi ft, GT540R"
"LGE, Swi ft, swi ft, GT540f"
"LGE, TBD, aka, LG-F520K"
"LGE, Thri l l 4G, cosmo_310-410, LG-P925"
"LGE, Thri l l 4G, p925, LG-P925"
"LGE, V10, ppl us, LG-F600K"
"LGE, V10, ppl us, LG-F600L"
"LGE, V10, ppl us, LG-F600S"
"LGE, V10, ppl us, LG-H900"
"LGE, V10, ppl us, LG-H901"
"LGE, V10, ppl us, LG-H960"
"LGE, V10, ppl us, LG-H961N"
"LGE, V10, ppl us, LG-H962"
"LGE, V10, ppl us, LG-H968"
"LGE, V10, ppl us, VS990"
"LGE, VU3, vu3, LG-F300K"
"LGE, VU3, vu3, LG-F300L"
"LGE, VU3, vu3, LG-F300S"
"LGE, Wi ne Smart, cf, LGS01"
"LGE, Wi ne Smart, vfp, LG-D486"
"LGE, Wi ne Smart, vfp, LG-F480K"
"LGE, Wi ne Smart, vfp, LG-F480L"
"LGE, Wi ne Smart, vfp, LG-F480S"
"LGE, Y25, y25, LGL15G"
"LGE, Y25, y25c, LGL16C"

supported device.txt

"LGU+, LAP250U, hg2, LAP250U"
"LGU+, ST940I -UP, tvq2, ST940I -UP"
"LGU+, WA-U420D, WA-U420D, WA-U420D"
"LGUplus, TV G, smartbox, TI 320-DU"
"LIAONING YIYATONG, DI SNEY_Tablet_PC, DI SNEY_Tablet_PC, DS2310-70LP"
"LIAONING YIYATONG, IRULU_MID, IRULU_MID, X10"
"LINSAY, LINSAY F-7HD2CORE / F-7HD4CORE / F-10HD2CORE /F-10XHD4CORE, F-7HD2CORE, LINSAY F-7HD2CORE/F-7HD4CORE/F-10HD2CORE/F-10XHD4CORE"
"LT, LT610, LT610, LT610"
"LT, W2, EG606_YE, W2"
"LUVU, LUVU 001, Luvo_001, Luvo 001"
"LUVU, LUVU-001L, LUVU-001L, LUVU 001L"
"LUXYA, LUXYA MID704DC Tablet / Bittmore Tab770, MY7317P, MID704DC"
"Lanix, I LIUM L1000, I lium_L1000, I LIUM L1000"
"Lanix, I LIUM L1000, I lium_L1000, I lium_L1000"
"Lanix, I LIUM L1000, I lium_L900, I LIUM L900"
"Lanix, I LIUM L820, I lium_L820, I lium L820"
"Lanix, I LIUM L950, I lium_L950, I LIUM L950"
"Lanix, I LIUM L950, I lium_L950, I lium_L950"
"Lanix, I LIUM PAD E10Si, i Li um_Pad_E10Si_1, I LIUM PAD E10Si "
"Lanix, I LIUM S670, I lium_S670, I LIUM S670"
"Lanix, I LIUM X110, I LIUM_X110, I LIUM X110"
"Lanix, I lium L1100, I LIUM_L1100, I LIUM L1100"
"Lanix, I lium X200, I lium_X200, I lium X200"
"Lanix, I lium_S130, I lium_S130, I lium S130"
"Lanix, I lium_S130, I lium_S130, I lium_S130"
"Lanix, I lium_S520, I lium_S520, I LIUM S520"
"Lanix, X400, I lium_X400, I LIUM X400"
"Lanix, i lium_S106, I lium_S106, I lium S106"
"Lava, Pi xel V1, Pi xel V1_sprout, Pi xel V1"
"Lava, XOLO LT900, LT900, LT900"
"Lazer, Lazer MD1005 Tablet, MD1005, MD1005"
"Lazer, Lazer MY1306P, MY1306P, MY1306P"
"Lazer, Lazer X4508, X4508, X4508"
"Lazer, MI D9526CM, MI D9526CM, S952"
"Lazer, MW-7615P, MW-7615P, MW-7615P"
"Lazer, MW6617, MW6617, MW6617"
"Le Pan, Le Pan TC1010, FG6A-LP, Le Pan TC1010"
"Le Pan, Le Pan TC1020, FG6Q, Le Pan TC1020"
"Le Pan, Le Pan TC802A, UY8, Le Pan TC802A"
"LeTV, Le X507, X3_HK, Le X507"
"LeTV, Le1, Le1, x600"
"LeTV, Letv Super TV X3-55 Pro, L553AN_US, X3-55 Pro"
"LeTV, Letv x600, x600, X600"
"Lechpol , FLOW, Kruger_Matz_FLOW, FLOW"
"Lechpol , Kruger_Matz_FLOW2, Kruger_Matz_FLOW2, FLOW2"
"Lenovo, , 18382AU, ThinkPad Tablet"
"Lenovo, , A1_07, A1_07"
"Lenovo, , A2109A, IdeaTabA2109A"
"Lenovo, , A2207A-H, IdeaTabA2207A-H"
"Lenovo, , A278t, Lenovo A278t"
"Lenovo, , A288t, Lenovo A288t"
"Lenovo, , A298t, Lenovo A298t"
"Lenovo, , A30t, A30t"
"Lenovo, , A530_msm7627a_al ps, Lenovo A530"
"Lenovo, , A560e_msm7627a, LNV-Lenovo_A560e"
"Lenovo, , A580, Lenovo A580"
"Lenovo, , A600e_msm8625, LNV-Lenovo A600e"
"Lenovo, , A60plus, Lenovo A60+ "
"Lenovo, , A630, Lenovo A630"
"Lenovo, , A660, Lenovo A660"
"Lenovo, , A668t, Lenovo A668t"
"Lenovo, , A690, Lenovo A690"

supported device.txt

"Lenovo, , A700e, Lenovo A700e"
"Lenovo, , A710e_msm7627a, Lenovo A710e"
"Lenovo, , A780_msm7627a, Lenovo A780"
"Lenovo, , A789, Lenovo A789"
"Lenovo, , A798t, Lenovo A798t"
"Lenovo, , A800, Lenovo A800"
"Lenovo, , Android, Lenovo A60+ "
"Lenovo, , K1, K1 "
"Lenovo, , K2110A-F, IdeaTab K2110A-F "
"Lenovo, , LI FETAB_S9512, LI FETAB_S9512 "
"Lenovo, , Lenovo_S2, Lenovo S2-38AH0 "
"Lenovo, , MD_LI FETAB_P9516, MD_LI FETAB_P9516 "
"Lenovo, , P700i, Lenovo P700i "
"Lenovo, , P770, Lenovo P770 "
"Lenovo, , S2005A-H, S2005A-H "
"Lenovo, , S2109A, IdeaTabS2109A-F "
"Lenovo, , S560, Lenovo S560 "
"Lenovo, , S880i, Lenovo S880i "
"Lenovo, , S890, Lenovo S890 "
"Lenovo, , S899t, Lenovo S899t "
"Lenovo, , S920_ROW, Lenovo S920 "
"Lenovo, , S920_ROW, Lenovo S920_ROW "
"Lenovo, , SmartTabII7, SmartTabII7 "
"Lenovo, , T702T, A66t "
"Lenovo, , a2_3g_data, IdeaTab A2107A-H "
"Lenovo, , a2_wi fi, IdeaTab A2107A-F "
"Lenovo, , a2_wi fi_row, IdeaTab A2107A-F "
"Lenovo, , a326, Lenovo A326 "
"Lenovo, , a360, Lenovo A360 "
"Lenovo, , a370, Lenovo A370 "
"Lenovo, , a500plus, Lenovo A500+ "
"Lenovo, , a520_gray, Lenovo A520GRAY "
"Lenovo, , a59wg, Lenovo A500 "
"Lenovo, , a59wg, Lenovo A500+ "
"Lenovo, , a60_campus, Lenovo A60 "
"Lenovo, , a60i d_tel, Lenovo A60 "
"Lenovo, , a60os, Lenovo A60 "
"Lenovo, , a60tw, Lenovo A60 "
"Lenovo, , a65, Lenovo A65 "
"Lenovo, , a65_ph_i d_vn, Lenovo A65 "
"Lenovo, , a65cu, Lenovo A65 "
"Lenovo, , amazon_w, Lenovo A1-32AB0 "
"Lenovo, , apollo_td, Lenovo S2-38AT0 "
"Lenovo, , apollo_wg, Lenovo S2-38AH0 "
"Lenovo, , apollohd_w, Lenovo K2 "
"Lenovo, , apollozero_w, Lenovo S760 "
"Lenovo, , aruba, Lenovo A765e "
"Lenovo, , austin, Lenovo A300 "
"Lenovo, , ideatv_S31, ideatv S31 "
"Lenovo, , lenovo13_td, Lenovo A366t "
"Lenovo, , lenovo15_td_i cs, Lenovo A698t "
"Lenovo, , lenovo73_cu, Lenovo A60 "
"Lenovo, , lenovo73_gb, Lenovo A520 "
"Lenovo, , lenovo73_gb, Lenovo P70 "
"Lenovo, , lenovo75_a2_att_i cs, A2107A-H "
"Lenovo, , lenovo75_a2_i cs, IdeaTab A2107A-H "
"Lenovo, , lenovo75_cu_gb, Lenovo A750 "
"Lenovo, , lenovo75_cu_i cs, Lenovo A750 "
"Lenovo, , mfl d_pr2, Lenovo K800 "
"Lenovo, , mi_350, Spi ce Mi -350 "
"Lenovo, , msm7627_ea95, Lenovo A390e "
"Lenovo, , msm7627_surf, A68e "
"Lenovo, , msm7627_surf, Lenovo A68e "

supported device.txt

"Lenovo, , msm7627a, LNV-Lenovo A790e"
 "Lenovo, , msm7627a_ha99, Lenovo A780"
 "Lenovo, , msm8660_surf, I deaTab S2007A-F"
 "Lenovo, , msm8660_surf, I deaTab S2007A-H"
 "Lenovo, , msm8660_surf, I deaTab S2010A-D"
 "Lenovo, , msm8660_surf, I deaTab S2010A-F"
 "Lenovo, , msm8660_surf, I deaTab S2010A-H"
 "Lenovo, , msm8960, I deaTabS2110AF"
 "Lenovo, , msm8960, I deaTabS2110AH"
 "Lenovo, , msm8960, SmartTab I 10"
 "Lenovo, , p700, Lenovo P700"
 "Lenovo, , p700_ph, Lenovo P700"
 "Lenovo, , s880, Lenovo S880"
 "Lenovo, , s880_row, Lenovo S880"
 "Lenovo, , sanpaolo, I deaTabV2007A"
 "Lenovo, , santi ago, I deaTabV2010A"
 "Lenovo, , santi ago, I deaTabV2010A-W"
 "Lenovo, , si cily, Lenovo S696"
 "Lenovo, , stuttgart_row, Lenovo K860"
 "Lenovo, , ventana, K1"
 "Lenovo, 32A3 40A3 43A3 49A3, uzi, LenovoTV 32A3"
 "Lenovo, ""55E82, 49E82, 50U3A, 58U3A, 70UD30A, 60UD30A, 80UD30A, 65UR30A"" , sun, AQUOS 50U3A"
 "Lenovo, ""55E82, 49E82, 50U3A, 58U3A, 70UD30A, 60UD30A, 80UD30A, 65UR30A"" , sun, AQUOS 65UR30A"
 "Lenovo, ""55E82, 49E82, 50U3A, 58U3A, 70UD30A, 60UD30A, 80UD30A, 65UR30A"" , sun, AQUOS 70UD30A"
 "Lenovo, ""55E82, 49E82, 50U3A, 58U3A, 70UD30A, 60UD30A, 80UD30A, 65UR30A"" , sun, AQUOS 70UG30A"
 "Lenovo, ""55E82, 49E82, 50U3A, 58U3A, 70UD30A, 60UD30A, 80UD30A, 65UR30A"" , sun, AQUOS 70XU30A"
 "Lenovo, ""55E82, 49E82, 50U3A, 58U3A, 70UD30A, 60UD30A, 80UD30A, 65UR30A"" , sun, LenovoTV 49E82"
 "Lenovo, ""55E82, 49E82, 50U3A, 58U3A, 70UD30A, 60UD30A, 80UD30A, 65UR30A"" , sun, LenovoTV 55E82"
 "Lenovo, 60K72, i deatv_K72, i deatv K72"
 "Lenovo, A10, A10, I deaPadA10"
 "Lenovo, A1000, A1000F, I deaTabA1000-F"
 "Lenovo, A1000-G, A1000G, I deaTabA1000-G"
 "Lenovo, A1000L, A1000LF, I deaTabA1000L-F"
 "Lenovo, A208t, A208t, Lenovo A208t"
 "Lenovo, A2107A, A2107A-H, A2107A-H"
 "Lenovo, A218t, A218t, Lenovo A218t"
 "Lenovo, A269, A269, Lenovo A269"
 "Lenovo, A269i, A269i, Lenovo A269i "
 "Lenovo, A278t, A278t, Lenovo A278t"
 "Lenovo, A3000, A3000, Lenovo A3000-H"
 "Lenovo, A305E, A305e, LNV-Lenovo A305e"
 "Lenovo, A305E, A305e, Lenovo A305e"
 "Lenovo, A308t, A308t, Lenovo A308t"
 "Lenovo, A318t, A318t, Lenovo A318t"
 "Lenovo, A369, A369, Lenovo A369"
 "Lenovo, A369i, A369i, Lenovo A369i "
 "Lenovo, A370e, A370e, LNV-Lenovo A370e"
 "Lenovo, A375e, A375e, LNV-Lenovo A375e"
 "Lenovo, A376, A376, Lenovo A376"
 "Lenovo, A378t, A378t, Lenovo A378t"
 "Lenovo, A390, A390, Lenovo A390_ROW"
 "Lenovo, A390t, A390t, Lenovo A390t"
 "Lenovo, A398t, A398t, Lenovo A398t"
 "Lenovo, A516, A516, Lenovo A516"
 "Lenovo, A516, A516_ROW, Lenovo A516"
 "Lenovo, A630, A630e, LNV-Lenovo A630e"
 "Lenovo, A656, A656, Lenovo A656"

supported device.txt

"Lenovo, A658T, A658t, Lenovo A658t"
"Lenovo, A670t, A670t, Lenovo A670t"
"Lenovo, A678t, A678t, Lenovo A678t"
"Lenovo, A706, armani , Lenovo A706"
"Lenovo, A706_ROW, armani _row, Lenovo A706_ROW"
"Lenovo, A720e, andorrap, Lenovo A720e"
"Lenovo, A750e, athenae, Lenovo A750e"
"Lenovo, A760, audi , Lenovo A760"
"Lenovo, A766, A766, Lenovo A766"
"Lenovo, A770e, athenaep, Lenovo A770e"
"Lenovo, A820, A820, Lenovo A820"
"Lenovo, A820e, andorra, Lenovo A820e"
"Lenovo, A830, A830, Lenovo A830"
"Lenovo, A850, A850, Lenovo A850"
"Lenovo, A850, A850_ROW, Lenovo A850"
"Lenovo, A860e, artini , Lenovo A860e"
"Lenovo, B6000-F, B6000, Lenovo B6000-F"
"Lenovo, B6000-H, B6000, Lenovo B6000-H"
"Lenovo, B6000-HV, B6000, Lenovo B6000-HV"
"Lenovo, B8000-F, B8000, Lenovo B8000-F"
"Lenovo, B8000-H, B8000, Lenovo B8000-H"
"Lenovo, E4002, E4002, MEDI ON E4002"
"Lenovo, EveryPad, A3000, EveryPad"
"Lenovo, EveryPad, A3000, I deaTab A3000-F"
"Lenovo, I deaTV, msm8660_surf, i deatv K91"
"Lenovo, I deaTab A1000, A1000LF, LenovoA1000L-F"
"Lenovo, I deaTab A1010, A1010T, I deaTabA1010-T"
"Lenovo, I deaTab A1020, A1020T, I deaTabA1020-T"
"Lenovo, I deaTab A3000, A3000, I deaTab A3000-H"
"Lenovo, I deaTab A3000, A3000, Vodafone Smart Tab III 7"
"Lenovo, I deaTab A5000, A5000E, I deaTabA5000-E"
"Lenovo, I deaTab S6000, S6000, I deaTab S6000-F"
"Lenovo, I deaTab S6000, S6000, I deaTab S6000-H"
"Lenovo, I deaTab S6000, S6000, Vodafone Smart Tab III 10"
"Lenovo, Indi go, Indi go, Thi nkPad Tabl et"
"Lenovo, K1, K1, K1"
"Lenovo, K800, K800, Lenovo K800"
"Lenovo, K900, K900, Lenovo K900"
"Lenovo, K900, K900_ROW, Lenovo K900_ROW"
"Lenovo, LI FETAB E10310, LI FETAB_E10310, LI FETAB_E10310"
"Lenovo, LI FETAB E7310, LI FETAB_E7310, LI FETAB_E7310"
"Lenovo, LI FETAB E7310, LI FETAB_E7310, LI FETAB_E7312"
"Lenovo, Lenovo, A708t, Lenovo A708t"
"Lenovo, Lenovo, A880, Lenovo A880"
"Lenovo, Lenovo TAB 2 A7-30HC, A7-30HC, Lenovo TAB 2 A7-30HC"
"Lenovo, Lenovo X2, X2-AP, Lenovo X2-AP"
"Lenovo, Lenovo A1900, A1900, Lenovo A1900"
"Lenovo, Lenovo A2105, Lenovo_A2105, Lenovo_A2105"
"Lenovo, Lenovo A228t, A228t, Lenovo A228t"
"Lenovo, Lenovo A238t, A238t, Lenovo A238t"
"Lenovo, Lenovo A2580, A2580, Lenovo A2580"
"Lenovo, Lenovo A2800, A2800-d, Lenovo A2800-d"
"Lenovo, Lenovo A2860, A2860, Lenovo A2860"
"Lenovo, Lenovo A300t, A300t, Lenovo A300t"
"Lenovo, Lenovo A316, A316, Lenovo A316"
"Lenovo, Lenovo A316i , A316i , Lenovo A316i "
"Lenovo, Lenovo A319, A319, Lenovo A319"
"Lenovo, Lenovo A320t, A320t, Lenovo A320t"
"Lenovo, Lenovo A328, A328, Lenovo A328"
"Lenovo, Lenovo A328t, A328t, Lenovo A328t"
"Lenovo, Lenovo A3300, A3300-GV, LenovoA3300-GV"
"Lenovo, Lenovo A3300, A3300-H, LenovoA3300-H"
"Lenovo, Lenovo A3300, A3300-HV, LenovoA3300-HV"

supported device.txt

"Lenovo, Lenovo A3300, A3300-T, Lenovo A3300-T"
"Lenovo, Lenovo A3300-GV, A3300-GV, LenovoA3300-GV"
"Lenovo, Lenovo A3300-HV, A3300-HV, Lenovo A3300-HV"
"Lenovo, Lenovo A330e, A330e, Lenovo A330e"
"Lenovo, Lenovo A338t, A338t, Lenovo A338t"
"Lenovo, Lenovo A3500, A3500, Lenovo A3500"
"Lenovo, Lenovo A3500, A3500HV, Lenovo A3500-HV"
"Lenovo, Lenovo A3500-F, A3500F, EveryPad2"
"Lenovo, Lenovo A3500-F, A3500F, Lenovo A3500-F"
"Lenovo, Lenovo A3500-FL, A3500FL, Lenovo A3500-FL"
"Lenovo, Lenovo A3500-H, A3500H, Lenovo A3500-H"
"Lenovo, Lenovo A355e, A355e, Lenovo A355e"
"Lenovo, Lenovo A358t, A358t, Lenovo A358t"
"Lenovo, Lenovo A3600-D, A3600-d, Lenovo A3600-d"
"Lenovo, Lenovo A3600u, A3600u, Lenovo A3600u"
"Lenovo, Lenovo A360e, A360e, Lenovo A360e"
"Lenovo, Lenovo A360t, A360t, Lenovo A360t"
"Lenovo, Lenovo A368t, A368t, Lenovo A368t"
"Lenovo, Lenovo A3800-D, A3800-d, Lenovo A3800-d"
"Lenovo, Lenovo A380e, A380e, LNV-Lenovo A380e"
"Lenovo, Lenovo A380t, A380t, Lenovo A380t"
"Lenovo, Lenovo A385e, A385e, LNV-Lenovo A385e"
"Lenovo, Lenovo A388t, A388t, Lenovo A388t"
"Lenovo, Lenovo A390, A390, Lenovo A390"
"Lenovo, Lenovo A3900, pxa1L88H2, Lenovo A3900"
"Lenovo, Lenovo A395e, A395e, LNV-Lenovo A395e"
"Lenovo, Lenovo A396, A396, Lenovo A396"
"Lenovo, Lenovo A396, A396_TY, Lenovo A396_TY"
"Lenovo, Lenovo A398t+, A398tp, Lenovo A398t+ "
"Lenovo, Lenovo A399, Ai ken, Lenovo A399"
"Lenovo, Lenovo A5000, A5000, Lenovo A5000"
"Lenovo, Lenovo A505e, A505e, LNV-Lenovo A505e"
"Lenovo, Lenovo A516, A516_ROW, Lenovo A516"
"Lenovo, Lenovo A526, A526, Lenovo A526"
"Lenovo, Lenovo A529, A529, Lenovo A529"
"Lenovo, Lenovo A536, A536, Lenovo A536"
"Lenovo, Lenovo A5500, A5500, Lenovo A5500"
"Lenovo, Lenovo A5500-F, A5500-F, Lenovo A5500-F"
"Lenovo, Lenovo A5500-H, A5500-H, Lenovo A5500-H"
"Lenovo, Lenovo A5500-HV, A5500-HV, Lenovo A5500-HV"
"Lenovo, Lenovo A560, A560_msm8212, Lenovo A560"
"Lenovo, Lenovo A560, A560_msm8610, LNV-Lenovo A560"
"Lenovo, Lenovo A5800-D, A5800-D, Lenovo A5800-D"
"Lenovo, Lenovo A588t, LenovoA588t, LenovoA588t"
"Lenovo, Lenovo A6000, Kraft-A6000, Lenovo A6000"
"Lenovo, Lenovo A6000-I, Kraft-A6000-I, Lenovo A6000-I "
"Lenovo, Lenovo A606, A606, Lenovo A606"
"Lenovo, Lenovo A616, A616, Lenovo A616"
"Lenovo, Lenovo A628t, A628t, Lenovo A628t"
"Lenovo, Lenovo A680, A680, Lenovo A680"
"Lenovo, Lenovo A680, A680, Lenovo A680_ROW"
"Lenovo, Lenovo A6800, A6800, Lenovo A6800"
"Lenovo, Lenovo A688t, A688t, Lenovo A688t"
"Lenovo, Lenovo A690e, A690e, LNV-Lenovo A690e"
"Lenovo, Lenovo A7-30GC, A7-30GC, Lenovo TAB 2 A7-30GC"
"Lenovo, Lenovo A7-30H, A7-30H, Lenovo TAB 2 A7-30D"
"Lenovo, Lenovo A7-30H, A7-30H, Lenovo TAB 2 A7-30H"
"Lenovo, Lenovo A7-60HC, A760HC, Lenovo A7-60HC"
"Lenovo, Lenovo A7000, A7000-a, Lenovo A7000-a"
"Lenovo, Lenovo A7600, A7600, Lenovo A7600"
"Lenovo, Lenovo A7600, ai ocmcc_ttp, Lenovo A7600-m"
"Lenovo, Lenovo A7600, ai ocu_wtftp, Lenovo A7600"
"Lenovo, Lenovo A7600-F, A7600-F, Lenovo A7600-F"

supported device.txt

"Lenovo, Lenovo A7600-H, A7600-H, Lenovo A7600-H"
"Lenovo, Lenovo A7600-HV, A7600-HV, Lenovo A7600-HV"
"Lenovo, Lenovo A768t, ai rpl ayt, Lenovo A768t"
"Lenovo, Lenovo A780e, A780e, LNV-Lenovo A780e"
"Lenovo, Lenovo A785e, A785e, LNV-Lenovo A785e"
"Lenovo, Lenovo A788t, A788t, Lenovo A788t"
"Lenovo, Lenovo A8-50, A8-50L, Lenovo TAB 2 A8-50L"
"Lenovo, Lenovo A8-50, A8-50LC, Lenovo 2 A8-50LC"
"Lenovo, Lenovo A8-50, A8-50LC, Lenovo TAB 2 A8-50LC"
"Lenovo, Lenovo A805e, ai rpl ayep, Lenovo A805e"
"Lenovo, Lenovo A806, A806, Lenovo A806"
"Lenovo, Lenovo A808t, A808t, Lenovo A808t"
"Lenovo, Lenovo A808t-i , A808t-i , Lenovo A808t-i "
"Lenovo, Lenovo A816, ai rpl ayw, Lenovo A5100"
"Lenovo, Lenovo A816, ai rpl ayw, Lenovo A816"
"Lenovo, Lenovo A820t, A820t, Lenovo A820t"
"Lenovo, Lenovo A828, A858, Lenovo A858"
"Lenovo, Lenovo A828t, A828t, Lenovo A828t"
"Lenovo, Lenovo A850, A850, Lenovo A850"
"Lenovo, Lenovo A850+, A850p, Lenovo A850+ "
"Lenovo, Lenovo A858t, A858t, Lenovo A858t"
"Lenovo, Lenovo A859, A859_ROW, Lenovo A859"
"Lenovo, Lenovo A889, A889, Lenovo A889"
"Lenovo, Lenovo A890e, ai rbuse, Lenovo A890e"
"Lenovo, Lenovo A916, A916, Lenovo A916"
"Lenovo, Lenovo A936, A936, Lenovo A936"
"Lenovo, Lenovo A938t, A938t, Lenovo A938t"
"Lenovo, Lenovo B8080, B8080, Lenovo B8080-F"
"Lenovo, Lenovo B8080-H, B8080, Lenovo B8080-H"
"Lenovo, Lenovo B8080-HV, B8080, Lenovo B8080-HV"
"Lenovo, Lenovo K30-E, Kraft-E, Lenovo K30-E"
"Lenovo, Lenovo K30-T, Kraft-T, Lenovo K30-T"
"Lenovo, Lenovo K30-TM, Kraft-TM, Lenovo K30-TM"
"Lenovo, Lenovo K30-W, Kraft-W, Lenovo K30-W"
"Lenovo, Lenovo K50, K50-t5, Lenovo K50-t5"
"Lenovo, Lenovo K50, ai o_3m_otfp, Lenovo K50-t3s"
"Lenovo, Lenovo K50, ai o_otfp, Lenovo K50-T5"
"Lenovo, Lenovo K50, ai o_otfp, Lenovo K50-t5"
"Lenovo, Lenovo K80M, K80M, Lenovo K80M"
"Lenovo, Lenovo K860, stuttgart, Lenovo K860"
"Lenovo, Lenovo K860i , K860i , Lenovo K860i "
"Lenovo, Lenovo K910, ki ton, Lenovo K910"
"Lenovo, Lenovo K910L, K910L, Lenovo K910L"
"Lenovo, Lenovo K910e, ki tone, LNV-Lenovo K910e"
"Lenovo, Lenovo K910e, ki tone, Lenovo K910e"
"Lenovo, Lenovo K920/VI BE Z2, ki ngdom_row, Lenovo K920"
"Lenovo, Lenovo K920/VI BE Z2 Pro, ki ngdomt, Lenovo K920"
"Lenovo, Lenovo N300, Li ndos2, Lenovo N300"
"Lenovo, Lenovo N308, SmartAI 0, Lenovo N308"
"Lenovo, Lenovo P70, P70-A, Lenovo P70-A"
"Lenovo, Lenovo P70, P70-t, Lenovo P70-t"
"Lenovo, Lenovo P780, P780, Lenovo P780"
"Lenovo, Lenovo P90, P90, Lenovo P90"
"Lenovo, Lenovo S580, S580, Lenovo S580"
"Lenovo, Lenovo S60, si sl eyl r, Lenovo S60-a"
"Lenovo, Lenovo S60, si sl eyl t, Lenovo S60-t"
"Lenovo, Lenovo S60, si sl eyl w, Lenovo S60-w"
"Lenovo, Lenovo S650, S650, Lenovo S650"
"Lenovo, Lenovo S650_ROW, S650_ROW, Lenovo S650"
"Lenovo, Lenovo S658t, S658t, Lenovo S658t"
"Lenovo, Lenovo S660, S660, Lenovo S660"
"Lenovo, Lenovo S668t, S668t, Lenovo S668t"
"Lenovo, Lenovo S810t, shell t, Lenovo S810t"

supported device.txt

"Lenovo, Lenovo S820, S820, Lenovo S820"
"Lenovo, Lenovo S820, S820_AMX_ROW, Lenovo S820"
"Lenovo, Lenovo S850, S850, Lenovo S850"
"Lenovo, Lenovo S850t, S850t, Lenovo S850t"
"Lenovo, Lenovo S856, shellamx, Lenovo S856"
"Lenovo, Lenovo S856, shellr, Lenovo S856"
"Lenovo, Lenovo S856, shellr_s, Lenovo S856"
"Lenovo, Lenovo S856, shellw, Lenovo S856"
"Lenovo, Lenovo S858t, Selected, Lenovo S858t"
"Lenovo, Lenovo S860, S860, Lenovo S860"
"Lenovo, Lenovo S860e, shell e, Lenovo S860e"
"Lenovo, Lenovo S898t+, S898tp, Lenovo S898t+ "
"Lenovo, Lenovo S90, si sl eye, Lenovo S90-e "
"Lenovo, Lenovo S90-A, si sl eyr, Lenovo S90-A "
"Lenovo, Lenovo S90-T, si sl eyt, Lenovo S90-t "
"Lenovo, Lenovo S90-U, si sl eyw, Lenovo S90-u "
"Lenovo, Lenovo S920, S920, Lenovo S920 "
"Lenovo, Lenovo S930, S930, Lenovo S930 "
"Lenovo, Lenovo S930_ROW, S930_ROW, Lenovo S930 "
"Lenovo, Lenovo S938t, S938t, Lenovo S938t "
"Lenovo, Lenovo S939, S939, Lenovo S939 "
"Lenovo, Lenovo S960, S960, Lenovo S960 "
"Lenovo, Lenovo S960, S960_AMX_ROW, Lenovo S960 "
"Lenovo, Lenovo S968t, S968t, Lenovo S968t "
"Lenovo, Lenovo TAB 2 A10, A10-70F, Lenovo TAB 2 A10-70F "
"Lenovo, Lenovo TAB 2 A10, A10-70L, Lenovo TAB 2 A10-70L "
"Lenovo, Lenovo TAB 2 A10, A10-70LC, Lenovo TAB 2 A10-70LC "
"Lenovo, Lenovo TAB 2 A7-10F, Tab2A7-10F, Tab2A7-10F "
"Lenovo, Lenovo TAB 2 A7-20F, Tab2A7-20F, Tab2A7-20F "
"Lenovo, Lenovo TAB 2 A7-30F, A7-30F, Lenovo TAB 2 A7-30F "
"Lenovo, Lenovo TAB 2 A7-30HC, A7-30HC, Lenovo 2 A7-30HC "
"Lenovo, Lenovo TAB 2 A7-30HC, A7-30HC, Lenovo TAB 2 A7-30HC "
"Lenovo, Lenovo TAB 2 A7-30TC, A7-30TC, Lenovo 2 A7-30TC "
"Lenovo, Lenovo TAB 2 A8-50F, A8-50F, Lenovo 2 A8-50F "
"Lenovo, Lenovo TAB 2 A8-50F, A8-50F, Lenovo TAB 2 A8-50F "
"Lenovo, Lenovo TAB A10-80HC, A10_80HC, TAB A10-80HC "
"Lenovo, Lenovo TAB S8-50F, S8-50F, Lenovo TAB S8-50F "
"Lenovo, Lenovo TAB S8-50L, S8-50L, Lenovo TAB S8-50L "
"Lenovo, Lenovo TAB S8-50LC, S8-50LC, Lenovo S8-50LC "
"Lenovo, Lenovo TAB S8-50LC, S8-50LC, Lenovo TAB S8-50LC "
"Lenovo, Lenovo X2, X2-EU, Lenovo X2-EU "
"Lenovo, Lenovo X2 Pro, s7, Lenovo X2Pt5 "
"Lenovo, Lenovo X2 Pro, s7, VI BE X2Pt5 "
"Lenovo, Lenovo X2-CU/VI BE X2, X2-CU, Lenovo X2-CU "
"Lenovo, Lenovo X2-T0/VI BE X2, X2-T0, Lenovo X2-T0 "
"Lenovo, Lenovo X2-TR/VI BE X2, X2-TR, Lenovo X2-TR "
"Lenovo, Lenovo YOGA Tablet Pro-1050L/Yoga Tablet 2, YT2, YOGA Tablet 2-1050L "
"Lenovo, Lenovo YOGA Tablet Pro-1050LC/Yoga Tablet 2, YT2, YOGA Tablet 2-1050LC "
"Lenovo, Lenovo YOGA Tablet Pro-1380F/Yoga Tablet 2 Pro, YT2, YOGA Tablet 2 Pro-1380F "
"Lenovo, Lenovo YOGA Tablet Pro-1380L/Yoga Tablet 2 Pro, YT2, YOGA Tablet 2 Pro-1380L "
"Lenovo, Lenovo YOGA Tablet Pro-830L/Yoga Tablet 2, YT2, YOGA Tablet 2-830L "
"Lenovo, Lenovo YOGA Tablet Pro-830LC/Yoga Tablet 2, YT2, YOGA Tablet 2-830LC "
"Lenovo, Lenovo YogaTablet2 -1050F, YT2, YOGA Tablet 2-1050F "
"Lenovo, Lenovo YogaTbal et2-830F, YT2, YOGA Tablet 2-830F "
"Lenovo, Lenovo Z2, z2r, Lenovo Z2 "
"Lenovo, Lenovo Z2, z2t, Lenovo Z2 "
"Lenovo, Lenovo Z2w, z2w, Lenovo Z2w "
"Lenovo, Lenovo Z90/VI BE Shot, zoom_fdd, Lenovo Z90 "
"Lenovo, Lenovo Z90/VI BE Shot, zoom_fdd, Lenovo Z90-7 "
"Lenovo, LenovoTAB2 A7-30DC, A7-30HC, Lenovo TAB 2 A7-30DC "
"Lenovo, LenovoTV 40S9; LenovoTV 50S9; AQUOS 40U1; AQUOS 50U1\xef\xbc\x9bAQUOS 58U1;
AQUOS 60LX765A, jazz, AQUOS 58U1 "
"Lenovo, LenovoTV 40S9; LenovoTV 50S9; AQUOS 40U1; AQUOS 50U1\xef\xbc\x9bAQUOS 58U1;

supported device.txt

AQUOS 60LX765A, jazz, AQUOS 60LX765A"
"Lenovo, LenovoTV 40S9; LenovoTV 50S9; AQUOS 40U1; AQUOS 50U1\xef\xbc\x9bAQUOS 58U1;
AQUOS 60LX765A, jazz, AQUOS 60UE20A"
"Lenovo, LenovoTV 40S9; LenovoTV 50S9; AQUOS 40U1; AQUOS 50U1\xef\xbc\x9bAQUOS 58U1;
AQUOS 60LX765A, jazz, LenovoTV 40S9"
"Lenovo, LenovoTV 40S9; LenovoTV 50S9; AQUOS 40U1; AQUOS 50U1\xef\xbc\x9bAQUOS 58U1;
AQUOS 60LX765A, jazz, LenovoTV 58S9"
"Lenovo, LenovoTV 50S52; AQUOS LCD-50S1A, bumblebee, AQUOS 50S1"
"Lenovo, LenovoTV 50S52; AQUOS LCD-50S1A, bumblebee, LenovoTV 50S52"
"Lenovo, Lenovo S960, S960_ROW, Lenovo S960"
"Lenovo, P780, P780, Lenovo P780"
"Lenovo, P780, P780_ROW, Lenovo P780"
"Lenovo, P780, P780_ROW, Lenovo P780_ROW"
"Lenovo, S5000, S5000, Lenovo S5000-F"
"Lenovo, S5000, S5000, Lenovo S5000-H"
"Lenovo, S6000L, S6000L, Lenovo S6000L-F"
"Lenovo, S61, ideatv_S61, ideatv S61"
"Lenovo, S680, seoul, Lenovo S680"
"Lenovo, S686, Alaska, Lenovo S686"
"Lenovo, S720, S720, Lenovo S720"
"Lenovo, S750, S750, Lenovo S750"
"Lenovo, S820, S820, Lenovo S820"
"Lenovo, S820, S820_ROW, Lenovo S820"
"Lenovo, S820, S820_ROW, Lenovo S820_ROW"
"Lenovo, S820e, appleee, Lenovo S820e"
"Lenovo, S850e, si chuan, Lenovo S850e"
"Lenovo, S868, S868t, Lenovo S868t"
"Lenovo, S870e, S870e, LNV-Lenovo S870e"
"Lenovo, S870e, S870e, Lenovo S870e"
"Lenovo, S898t, S898t, Lenovo S898t"
"Lenovo, S90-L, si sl eyr_amx, Lenovo S90-L"
"Lenovo, S920, S920, Lenovo S920"
"Lenovo, S960, S960, Lenovo S960"
"Lenovo, ThinkVision28, ThinkVision28, ThinkVision28"
"Lenovo, ideatv S52, ideatv_S52, ideatv S52"
"Lenovo, ideatvK82 60LX750A 52LX750A 46LX750A 60LX850A 70LX850A
80LX850A, ideatv_K82, ideatv K82"
"Lexibook, Fluo, MFC145FR1, MFC145FR1"
"Lexibook, Fluo XL, MFC191FR2, MFC191FR2"
"Lexibook, Fluo XL Premium Edition, MFC510FR1, MFC510FR1"
"Lexibook, MFC191, MFC191, S952"
"Lexibook, Playroid, Lbox500, LBOX500"
"LifeWatch, ""LifeWatch V , FGL-00004"" , hp6577_cts, LifeWatch V"
"LinkNet, Smart Box HD, SH940C-LN, SH940C-LN"
"Linsto, WEBPAD1002, Linsto, WEBPAD1002"
"Logic Instrument, FieldBook E1, FieldBook_E1, FieldBook_E1"
"Logicom, E350, E350, E350"
"Logicom, E400, E400, E400"
"Logicom, L-EMENT TAB 1040, generic, L-EMENT_TAB1040"
"Logicom, L-EMENT TAB 741, LEMENTTAB741, L-EMENT 741"
"Logicom, L-EMENT TAB 742, LEMENTTAB742, L-EMENT 742"
"Logicom, L-EMENT350, L-EMENT350, L-EMENT350"
"Logicom, L-EMENT400, LEMENT400, L-EMENT 400"
"Logicom, L-EMENT500, L-EMENT500L, L-EMENT500L"
"Logicom, L-EMENT550, L-EMENT550, L-EMENT550"
"Logicom, L-EMENT_TAB1040_BT, generic, L-EMENT_TAB1040_BT"
"Logicom, L-ITE402, L-ITE402, L-ITE 402"
"Logicom, L-ITE552, L-ITE552, L-ITE 552"
"Logicom, L-IXIR TAB 1041, generic, LIXIR1041"
"Logicom, L-IXIR TAB 701 3G, TAB701, L-IXIR TAB 701 3G"
"Logicom, L-IXIR TAB 840, L-IXIR_TAB_840, L-IXIR_TAB_840"
"Logicom, LEMENT TAB 740, LEMENTTAB740, L-EMENT 740"
"Logicom, LEMENTTAB901, LEMENTTAB901, LEMENT_TAB901"

supported device.txt

"Logi com, LOGI COM E1052GP, E1052GP, E1052GP"
"Logi com, LOGI COM E852GP, E852GP, E852GP"
"Logi com, Logi com S450, S450, S450"
"Logi com, Logi com S504, S504, Connect 5"
"Logi com, Logi com S504, S504, S504"
"Logi com, S1052, S1052, S1052"
"Logi com, S732, rk3026, S732"
"Logi com, S7842, S7842, S7842"
"Logi com, S952, S952, S952"
"Logi tech, Revue, ka, Revue"
"Lumi gon, T2, msm7630_fw8911, T2"
"Lumi gon, T2 HD, T2HD, T2HD"
"MAD CATZ, Mad Catz M. O. J. O. , moj o, Mad Catz M. O. J. O. "
"MG Series, Any 302, TR10CS1_15, TR10CS1"
"MG Series, Any 302, TR10CS2_3, TR10CS2"
"MG series, Any 302, TR10CS2_2, TR10CS2"
"MG series, Any 303, TR10CD2_2, TR10CD2"
"MG series, Any 303, TR10CD2_3, TR10CD2"
"MPman, MPDC1006, MPDC1006, MPDC1006"
"MPman, MPDC706, MPDC706, MPDC706"
"MSI , Pri mo73, N71J, Pri mo73"
"MSI , Pri mo76, N728, Pri mo76"
"MSI , Pri mo81, N821, Pri mo 81"
"MSI , Pri mo81, N821, Pri mo81"
"MSI , Pri mo81, Pri mo81, Pri mo81"
"MTC, MTC 982, MTC_982, MTC 982"
"MTC, Vodafone Smart mi ni , Vodafone_875, MTC 970H"
"MTN, MTN-5982C3, MTN-TBW5982C3, MTN-TBW5982C3"
"MTN, MTN-8978P, MTN-8978P, MTN-8978P"
"MTN, MTN-S620, MTN-S620, MTN-S620"
"MTN, MTN-S720i , MTN-S720i , MTN-S720i "
"MTN Group, MTN Steppa 2 LTE, Steppa2, MTN Steppa 2 LTE"
"MTN Group, Sm@rt Mi ni S630, MTN-S630, MTN-S630"
"MTN-E70, MTN-E70, MTN-E70, MTN-E70"
"MTT, Master, Master, M. T. T. Master"
"MTT, Smart Fun, SmartFun, M. T. T. Smart Fun"
"Mach Speed, xtreme, X_treme_Pl ay_Tab, X-treme Pl ay Tab"
"MachSpeed, MachSpeed Tri o Steal th_10 Tablet, D_10AL, Tri o Steal th_10"
"MachSpeed, MachSpeed Tri o Steal th_8 Tablet, D_8AL, Tri o Steal th_8"
"MachSpeed, MachSpeed Tri o Steal th_9 Tablet, D_9AL, Tri o Steal th_9"
"MachSpeed, MachSpeed Tri oSteal th-7, Tri oSteal th-7, Tri oSteal th-7"
"MachSpeed, STR-9. 6-Tabl et, STR_96_Tabl et, STR-9. 6-Tabl et"
"Mad Catz, Mad Catz M. O. J. O. , moj o, Mad Catz M. O. J. O. "
"Marshall , Marshall London, KB-1501, London"
"Mecer, 101P51C, 101P51C, 101P51C"
"Mecer, 800P31C, 800P31C, 800P31C"
"Mecer, TEI 11011, TEI 11011MST, TEI 11011MST"
"Medi on, LI FETAB E10316, LI FETAB_E10316, BOSCH_E10316"
"Medi on, LI FETAB E10316, LI FETAB_E10316, LI FETAB_E10316"
"Medi on, LI FETAB E10320, LI FETAB_E10320, LI FETAB_E10320"
"Medi on, LI FETAB E10320, LI FETAB_E10320, MI CROSTAR_E10319"
"Medi on, LI FETAB E7313, LI FETAB_E7313, LI FETAB_E7313"
"Medi on, LI FETAB E7316, LI FETAB_E7316, LI FETAB_E7316"
"Medi on, LI FETAB E7316, LI FETAB_E7316, LI FETAB_S7316"
"Medi on, LI FETAB E732X, LI FETAB_E732X, LI FETAB_E732X"
"Medi on, LI FETAB P891X, Li fetab_p891x, LI FETAB_P891X"
"Medi on, LI FETAB S1033X, LI FETAB_S1033X, LI FETAB_S1033X"
"Medi on, LI FETAB S1034X, Li fetab_s1034x, LI FETAB_S1034X"
"Medi on, LI FETAB S785X, LI FETAB_S785X, LI FETAB_S785X"
"Medi on, LI FETAB S831X, LI FETAB_S831X, LI FETAB_S831X"
"Medi on, Li fetab P9514, LI FETAB_P9514, LI FETAB_P9514"
"Medi on, MEDI ON E4502, E4502, MEDI ON E4502"
"Medi on, P4501, P4501, P4501"

supported device.txt

"Medion, mi crostar E10319, E10319, E10319"
"MegaFon, MFLogi n3T, MFLogi n3T, MFLogi n3T"
"MegaFon, MFLogi nPh, MFLogi nPh, MFLogi nPh"
"MegaFon, MS4B, Vi per_LTE, ALCATEL ONE TOUCH 7030R"
"MegaFon, MS4B, Vi per_LTE, ALCATEL ONE TOUCH 7030Y"
"MegaFon, MS4B, Vi per_LTE, MS4B"
"MegaFon, MegaFon Logi n 3, MFLogi n3, MegaFon Logi n 3"
"MegaFon, MegaFon MT3A, MT3A, MT3A"
"Megahouse, CP-D403, CP-D403, CP-D403"
"Mei tu, Mei tu M4, M4, Mei tu M4"
"Memorex, MTAB-09541AB, MTAB-09541AB, MTAB-09541AB"
"Memorex, Memorex MTAB-07530A, MTAB-07530A, MTAB-07530A"
"Mexico SEP tender, TR10CS1, TR10CS1_7, TR10CS1"
"Mexico SEP tender, TR10CS1, TR10CS1_8, TR10CS1"
"Mi cromax, A110, s9081, Mi cromax A110"
"Mi cromax, A111, A111, A111"
"Mi cromax, A116, A116, A116"
"Mi cromax, A240, A240, A240"
"Mi cromax, A27, A27, A27"
"Mi cromax, A44, ti nnoes13_s7050, A44"
"Mi cromax, A45, ti nnoes73_s8030_2g, A45"
"Mi cromax, A50, kpt73_gb, Mi cromax A50"
"Mi cromax, A54, A54, A54"
"Mi cromax, A56, A56, Mi cromax A56"
"Mi cromax, A57, A57, A57"
"Mi cromax, A57, A57, Mi cromax A57"
"Mi cromax, A72, A72, Mi cromax A72"
"Mi cromax, A73, A73, A73"
"Mi cromax, A73, A73, Mi cromax A73"
"Mi cromax, A75, A75, A75"
"Mi cromax, A78, Mi cromax, A78"
"Mi cromax, A84, A84, A84"
"Mi cromax, A87, A87, A87"
"Mi cromax, A87, A87, Mi cromax A87"
"Mi cromax, A88, A88, A88"
"Mi cromax, A89, A89, A89"
"Mi cromax, A91, A91, A91"
"Mi cromax, A91, A91, Mi cromax A91"
"Mi cromax, BOLT, A068, A068"
"Mi cromax, BOLT, A069, Mi cromax A069"
"Mi cromax, BOLT, A24, Mi cromax A24"
"Mi cromax, BOLT, A34, Mi cromax A34"
"Mi cromax, BOLT, A67, Mi cromax A67"
"Mi cromax, BOLT, A69, Mi cromax A69"
"Mi cromax, BOLT, A69_I N, Mi cromax A69"
"Mi cromax, Bol t, A066, Mi cromax A066"
"Mi cromax, Bol t, A067, Mi cromax A067"
"Mi cromax, Bol t, AD4500, Mi cromax AD4500"
"Mi cromax, Bol t, D321, Mi cromax D321"
"Mi cromax, Bol t, Q335, Mi cromax Q335"
"Mi cromax, CANVAS 2 COLOURS, A120, Mi cromax A120"
"Mi cromax, CANVAS 2 PLUS, A110Q, A110Q"
"Mi cromax, CANVAS 2 PLUS, s9086b, Mi cromax A110Q"
"Mi cromax, CANVAS 4, A210, A210"
"Mi cromax, CANVAS 4, s9111b, A210"
"Mi cromax, CANVAS BEAT, A114R, Mi cromax A114R"
"Mi cromax, CANVAS BLAZE, MT500, MT500"
"Mi cromax, CANVAS DOODLE 3, Mi cromaxA102, Mi cromax A102"
"Mi cromax, CANVAS DUET, AE90, Mi cromax AE90"
"Mi cromax, CANVAS DUET 2, EG111, Mi cromax EG111"
"Mi cromax, CANVAS ELANZA 2, A121, Mi cromax A121"
"Mi cromax, CANVAS ENGAGE, A091, Mi cromax A091"
"Mi cromax, CANVAS ENTI CE, A105, Mi cromax A105"

supported device.txt

"Mi cromax, CANVAS GOLD, A300, Mi cromax A300"
 "Mi cromax, CANVAS KNIGHT, A350, Mi cromax A350"
 "Mi cromax, CANVAS KNIGHT, s9320ae, Mi cromax A350"
 "Mi cromax, CANVAS MAGNUS, s9203, Mi cromax A117"
 "Mi cromax, CANVAS POWER, A96, Mi cromax A96"
 "Mi cromax, CANVAS TUBE, A118R, Mi cromax A118R"
 "Mi cromax, CANVAS TURBO, A250, A250"
 "Mi cromax, CANVAS TURBO, s9311, A250"
 "Mi cromax, CANVAS TURBO MINI, s8513a, Mi cromax A200"
 "Mi cromax, CANVAS UNITE 2, A106, Mi cromax A106"
 "Mi cromax, Canvas 4+, A315, Mi cromax A315"
 "Mi cromax, Canvas A1, AQ4501_sprout, Mi cromax AQ4501"
 "Mi cromax, Canvas A1, AQ4502_sprout, Mi cromax AQ4502"
 "Mi cromax, Canvas Doodle4, Q391, Mi cromax Q391"
 "Mi cromax, Canvas Fire, A093, Mi cromax A093"
 "Mi cromax, Canvas Fire, A104, Mi cromax A104"
 "Mi cromax, Canvas Fire4, A107, Mi cromax A107"
 "Mi cromax, Canvas HD Plus, A190, Mi cromax A190"
 "Mi cromax, Canvas Juice2, AQ5001, Mi cromax AQ5001"
 "Mi cromax, Canvas Knight Cameo, A290, Mi cromax A290"
 "Mi cromax, Canvas Knight2, KNIGHT2, Mi cromax E471"
 "Mi cromax, Canvas L, A108, Mi cromax A108"
 "Mi cromax, Canvas Nitro, A310, Mi cromax A310"
 "Mi cromax, Canvas Nitro, A311, Mi cromax A311"
 "Mi cromax, Canvas Nitro2, E311, Mi cromax E311"
 "Mi cromax, Canvas Pep, Q371, Mi cromax Q371"
 "Mi cromax, Canvas Play, Q355, Mi cromax Q355"
 "Mi cromax, Canvas Selfie, A255, Mi cromax A255"
 "Mi cromax, Canvas Selfie Lens, Q345, Mi cromax Q345"
 "Mi cromax, Canvas Spark, Q380, Mi cromax Q380"
 "Mi cromax, Canvas Tab, P480, Mi cromax P480"
 "Mi cromax, Canvas Tab, P480, P480"
 "Mi cromax, Canvas Tab, P690, Mi cromax P690"
 "Mi cromax, Canvas XL2, A109, Mi cromax A109"
 "Mi cromax, Canvas Xpress, A99, Mi cromax A99"
 "Mi cromax, Canvas tab, P470, P470"
 "Mi cromax, Canvas tab, P666, Mi cromax P666"
 "Mi cromax, MI CROMAX MAD, A94, Mi cromax A94"
 "Mi cromax, MI CROMAX UNITE, A092, Mi cromax A092"
 "Mi cromax, Mi cromax Bolt, A064, Mi cromax A064"
 "Mi cromax, Mi cromax Bolt, A065, Mi cromax A065"
 "Mi cromax, Mi cromax Bolt, A082, Mi cromax A082"
 "Mi cromax, P275, P275, P275"
 "Mi cromax, P300, crane-M701C_mmx, P300"
 "Mi cromax, Unite3, Q372, Mi cromax Q372"
 "Mi i A, Mi i A, TA10CA1_2, TA10CA1"
 "Mi i A, Mi i A MT-733G, MT-733G, MT-733G"
 "Mi nt, M4, M4, M4"
 "Mi nt, M5, MI NT-M5, M5"
 "Mi to, A10, A10_sprout, MI TO_A10"
 "Mobi Wi re, Cygnus, Cygnus45, Cygnus"
 "Mobi Wi re, Cygnus, Cygnus45, Cygnus45"
 "Mobi cel l , Ai r, Mobi cel _Ai r, Ai r"
 "Mobi cel l , CHERRY, CHERRY, CHERRY"
 "Mobi cel l , ECHO, ECHO, ECHO"
 "Mobi cel l , HERO X, HERO_X, HERO_X"
 "Mobi cel l , METRO2, METRO2, MOBI CEL METRO2"
 "Mobi cel l , Matri x, Matri x, Matri x"
 "Mobi cel l , Mobi cel , Soni c, Soni c"
 "Mobi cel l , Mobi cel , Venus, Venus"
 "Mobi cel l , ONYX, ONYX, ONYX"
 "Mobi cel l , Samba, Samba, Samba"
 "Mobi l y, MDB342X, qnbml , MDB342X"

supported device.txt

"Mobi stel , Cynus F9 4G, Cynus_F9_4G, Cynus_F9_4G"
"Mobi wi re, Ahi ga, Ahi ga, Ahi ga"
"Mobi wi re, Cygnus mi ni , Cygnus mi ni , Cygnus mi ni "
"Mobi wi re, Cygnus mi ni , Cygnus mi ni , Cygnus mi ni "
"Mobi wi re, Pegasus, Pegasus, Pegasus"
"Mobi wi re, S4040, S4040, S4040"
"Mobi wi re, Tel enor SmartPI us, Tel enor SmartPI us, Tel enor_SmartPI us"
"Mobi wi re, VSN V. 45, up06_h26_v45, V. 45"
"Modecom, FreeTAB 10. 1 Si l ver, si l ver, FreeTAB 10. 1 Si l ver"
"Modecom, Xi no Z46 X4+, xi no_z46, Xi no Z46 X4+ "
"Mohu, MH-CHANNELS, MH-CHANNELS, MH-CHANNELS"
"Monster, Monster M10, M10, M10"
"Motorol a, , A853, Mi l estone"
"Motorol a, , ArgonSpi n, XT550"
"Motorol a, , Graham, MZ505"
"Motorol a, , TAHI TI , MT620"
"Motorol a, , Tri umph, MOTWX435KT"
"Motorol a, , XT311, XT311"
"Motorol a, , XT316, XT316"
"Motorol a, , XT317, XT317"
"Motorol a, , XT319, XT319"
"Motorol a, , XT530, XT530"
"Motorol a, , XT531, XT531"
"Motorol a, , XT532, XT532"
"Motorol a, , argonspi n_umts, XT550"
"Motorol a, , cdma_kronos, MB612"
"Motorol a, , cdma_pax, XT603"
"Motorol a, , cdma_sol ana, MI LESTONE3"
"Motorol a, , cdma_spyder, DROI D RAZR"
"Motorol a, , cdma_spyder, I S12M"
"Motorol a, , cdma_spyder, Motorol a RAZR MAXX"
"Motorol a, , cdma_targa, DROI D BI ONI C"
"Motorol a, , cg_ti ta2, XT800+ "
"Motorol a, , choi , XT711"
"Motorol a, , chol es, XT701"
"Motorol a, , desti no, i 867"
"Motorol a, , domi noq_umts, XT316"
"Motorol a, , edi son, MB865"
"Motorol a, , edi son, ME865"
"Motorol a, , fawnri dge, i 940"
"Motorol a, , fl emi ng, MZ607"
"Motorol a, , fl emi ng, MZ608"
"Motorol a, , fl emi ng, MZ609"
"Motorol a, , fl emi ng, XOOM 2 ME"
"Motorol a, , graham_wi fi , MZ505"
"Motorol a, , i DEN, Motorol a_i 1"
"Motorol a, , morr, MB200"
"Motorol a, , pasteur, MZ616"
"Motorol a, , pasteur, MZ617"
"Motorol a, , pasteur, XOOM 2"
"Motorol a, , qi l i n, XT806"
"Motorol a, , scorpi on_mi ni _u, XT905"
"Motorol a, , smq_u, XT905"
"Motorol a, , swordfi sh, XT882"
"Motorol a, , ti nq_umts, XT560"
"Motorol a, , ttu_skt, XT800W"
"Motorol a, , umts_begoni a, MB610"
"Motorol a, , umts_begoni a, MB611"
"Motorol a, , umts_el way, MB632"
"Motorol a, , umts_el way, ME632"
"Motorol a, , umts_hubbl e, MZ605"
"Motorol a, , umts_kobe, MB520"
"Motorol a, , umts_l ucky, A1680"

supported device.txt

"Motorol a , , umts_sage, MB508"
"Motorol a , , umts_sol ana, ME863"
"Motorol a , , umts_sol ana, XT860"
"Motorol a , , umts_spyder, XT910"
"Motorol a , , umts_spyder, XT910K"
"Motorol a , , umts_spyder, XT910S"
"Motorol a , , umts_venus2, XT610"
"Motorol a , , wi fi _hubbl e, MZ604"
"Motorol a , , zepp, MB501"
"Motorol a, Atri x, ol ympus, MB860"
"Motorol a, Atri x, ol ympus, MB861"
"Motorol a, Atri x, ol ympus, ME860"
"Motorol a, Atri x HD, qi nara, MB886"
"Motorol a, Backfl i p, motus, MB300"
"Motorol a, Backfl i p, motus, ME600"
"Motorol a, CLI Q, morri son, MB200"
"Motorol a, CLI Q, morri son, morri son"
"Motorol a, Charm, umts_basi l , MB502"
"Motorol a, Ci trus, cdma_ci ena, WX442"
"Motorol a, Ci trus, cdma_ci ena, WX445"
"Motorol a, Ci trus, cdma_ci ena, XT301"
"Motorol a, Cl i q-XT, zeppel i n, MB501"
"Motorol a, Cl i q-XT, zeppel i n, ME501"
"Motorol a, DROI D RAZR HD, vanqui sh, DROI D RAZR HD"
"Motorol a, DROI D RAZR HD, vanqui sh_u, RAZR HD"
"Motorol a, DROI D RAZR HD, vanqui sh_u, XT925"
"Motorol a, DROI D RAZR M, scorpi on_mi ni , XT907"
"Motorol a, DROI D RAZR i , smi , XT890"
"Motorol a, DROI D Turbo, quark, XT1250"
"Motorol a, DROI D Turbo, quark, XT1254"
"Motorol a, DROI D4, cdma_maserati , DROI D4"
"Motorol a, Defy, umts_j ordan, MB525"
"Motorol a, Defy, umts_j ordan, MB526"
"Motorol a, Defy, umts_j ordan, ME525"
"Motorol a, Defy, umts_j ordan, ME525+ "
"Motorol a, Defy, umts_j ordan, unknown"
"Motorol a, Defy Mi ni , Ti nBoost, XT320"
"Motorol a, Defy Mi ni , Ti nBoost, XT321"
"Motorol a, Defy Mi ni , ti nboost_umts, XT320"
"Motorol a, Defy Mi ni , ti nboost_umts, XT321"
"Motorol a, Defy Pro, XT560, XT560"
"Motorol a, Devour, cal gary, Devour"
"Motorol a, Devour, cal gary, cal gary"
"Motorol a, Droi d, mi l er, A854"
"Motorol a, Droi d, shol es, Droi d"
"Motorol a, Droi d, umts_shol es, A853"
"Motorol a, Droi d, umts_shol es, Mi l estone"
"Motorol a, Droi d, umts_shol es, XT701"
"Motorol a, Droi d, umts_shol es, XT702"
"Motorol a, Droi d, umts_shol es, XT720"
"Motorol a, Droi d, umts_shol es, umts"
"Motorol a, Droi d 3, cdma_sol ana, DROI D3"
"Motorol a, Droi d 4, cdma_maserati , DROI D4"
"Motorol a, Droi d Bi oni c, cdma_targa, DROI D BI ONI C"
"Motorol a, Droi d I I , cdma_droi d2, A955"
"Motorol a, Droi d I I , cdma_droi d2, DROI D2"
"Motorol a, Droi d I I , cdma_droi d2we, DROI D2 GLOBAL"
"Motorol a, Droi d MAXX, obake-maxx, XT1080"
"Motorol a, Droi d Mi ni , obakem, XT1030"
"Motorol a, Droi d Pro, cdma_venus2, DROI D PRO"
"Motorol a, Droi d Pro, cdma_venus2, DROI D Pro"
"Motorol a, Droi d Pro, cdma_venus2, Mi l estone PLUS"
"Motorol a, Droi d Pro, cdma_venus2, XT610"

supported device.txt

"Motorola, Droid RAZR, umts_spyder, XT910"
 "Motorola, Droid Razr M, scorpion_mini_t, 201M"
 "Motorola, Droid Ultra, obake, XT1080"
 "Motorola, Droid X, cdma_shadow, DROIDX"
 "Motorola, Droid X, cdma_shadow, MB810"
 "Motorola, Droid X, cdma_shadow, ME811"
 "Motorola, Droid X, cdma_shadow, Milestone X"
 "Motorola, Droid X, cdma_shadow, MotoX"
 "Motorola, Droid X2, daytona, DROID X2"
 "Motorola, Droid X2, daytona, Milestone X2"
 "Motorola, Electrify M, solstice, XT901"
 "Motorola, Flipout, umts_ruth, MB511"
 "Motorola, Flipout, umts_ruth, ME511"
 "Motorola, Flipout, umts_ruth, MotoMB511"
 "Motorola, Glam XT800, titanium, XT800"
 "Motorola, Iron Rock, umts_iron, XT627"
 "Motorola, MOTO E, condor_cdma, XT1019"
 "Motorola, MOTO E, condor_cdma, XT830C"
 "Motorola, MOTO E, condor_umts, XT1021"
 "Motorola, MOTO E, condor_umts, XT1023"
 "Motorola, MOTO E, condor_umtsds, XT1022"
 "Motorola, MOTO E, otus, MotoE2"
 "Motorola, MOTO E, otus, XT0000"
 "Motorola, MOTO E, otus_ds, MotoE2"
 "Motorola, MOTO E, otus_ds, XT1021"
 "Motorola, MOTO E, surnia_cdma, XT1526"
 "Motorola, MOTO E, surnia_uds, MotoE2(4G-LTE)"
 "Motorola, MOTO E, surnia_udstv, MotoE2(4G-LTE)"
 "Motorola, MOTO E, surnia_umts, MotoE2(4G-LTE)"
 "Motorola, MOTO G, falcon_umts, XT1002"
 "Motorola, MOTO G, falcon_umts, XT1003"
 "Motorola, MOTO G, falcon_umts, XT1032"
 "Motorola, MOTO G, osprey_udstv, MotoG3"
 "Motorola, MOTO G, peregrine, XT1039"
 "Motorola, MOTO G, peregrine, XT1042"
 "Motorola, MOTO G, peregrine, XT1045"
 "Motorola, MOTO G, thea, XT1072"
 "Motorola, MOTO G, thea_umtsds, XT1063"
 "Motorola, MOTO G, thea_umtsds, XT1078"
 "Motorola, MOTO G, titan_umts, XT1063"
 "Motorola, MOTO G, titan_umts, XT1064"
 "Motorola, MOTO G, titan_umtsds, XT1068"
 "Motorola, MOTO G, titan_umtsds, titan_nibr_ds"
 "Motorola, MOTO G LTE, peregrine, XT1039"
 "Motorola, MOTO G LTE, peregrine, XT1040"
 "Motorola, MOTO G LTE, peregrine, XT1045"
 "Motorola, MOTO G w/4G LTE, peregrine, XT1039"
 "Motorola, MOTO G w/4G LTE, peregrine, XT1040"
 "Motorola, MOTO X, ghost, XT1053"
 "Motorola, MOTO X, ghost, XT1058"
 "Motorola, MOTO X, victara, XT1092"
 "Motorola, MOTO X, victara, XT1093"
 "Motorola, MOTO X, victara, XT1094"
 "Motorola, MOTO X, victara, XT1095"
 "Motorola, MOTO X, victara, XT1096"
 "Motorola, MOTO X, victara, XT1097"
 "Motorola, MOTOROLA ELECTRIFY 2, cdma_yangtze, XT881"
 "Motorola, MOTOROLA RAZR HD, vanquish_u, RAZR HD"
 "Motorola, MOTOROLA RAZR M, smq_t, 201M"
 "Motorola, MOTOROLA RAZR i, smi, XT890"
 "Motorola, Master Touch, umts_primus, XT621"
 "Motorola, Milestone2, umts_milestone2, A953"
 "Motorola, Milestone2, umts_milestone2, ME722"

supported device.txt

"Motorola, Milestone2, umts_milestone2, MotoA953"
"Motorola, Moto 360, minnow, Moto 360"
"Motorola, Moto 360 (2nd Gen), carp, Moto 360"
"Motorola, Moto 360 (2nd Gen), smelt, Moto 360"
"Motorola, Moto Defy XT, XT535, XT535"
"Motorola, Moto Defy XT, ti nboostplus_cdma, XT555C"
"Motorola, Moto Defy XT, ti nboostplus_cdma, XT556"
"Motorola, Moto Defy XT, ti nboostplus_cdma, XT557"
"Motorola, Moto Defy XT, ti nboostplus_ums, XT535"
"Motorola, Moto E, condor_cdma, XT1019"
"Motorola, Moto E, condor_udstv, XT1025"
"Motorola, Moto E, condor_ums, XT1021"
"Motorola, Moto E, condor_ums, XT1023"
"Motorola, Moto E, condor_umsds, XT1022"
"Motorola, Moto E, otus, MotoE2"
"Motorola, Moto E, surnia_cdma, MotoE2(4G-LTE)"
"Motorola, Moto E, surnia_cdma, XT1526"
"Motorola, Moto E, surnia_cdma, XT1528"
"Motorola, Moto E, surnia_cdma, XT15280"
"Motorola, Moto E, surnia_uds, MotoE2(4G-LTE)"
"Motorola, Moto E, surnia_ums, MotoE2(4G-LTE)"
"Motorola, Moto G, falcon_cdma, XT1028"
"Motorola, Moto G, falcon_cdma, XT1031"
"Motorola, Moto G, falcon_cdma, XT937C"
"Motorola, Moto G, falcon_ums, XT1008"
"Motorola, Moto G, falcon_ums, XT1032"
"Motorola, Moto G, falcon_ums, XT1034"
"Motorola, Moto G, falcon_ums, XT939G"
"Motorola, Moto G, falcon_umsds, XT1033"
"Motorola, Moto G, osprey_cdma, MotoG3"
"Motorola, Moto G, osprey_u2, MotoG3"
"Motorola, Moto G, osprey_ud2, MotoG3"
"Motorola, Moto G, osprey_uds, MotoG3"
"Motorola, Moto G, osprey_ums, MotoG3"
"Motorola, Moto G, theads, XT1079"
"Motorola, Moto G, titan_udstv, XT1069"
"Motorola, Moto G, titan_udstv, titan_retbr_dstv"
"Motorola, Moto G, titan_ums, XT1064"
"Motorola, Moto G, titan_umsds, XT1068"
"Motorola, Moto G Google Play edition, falcon_ums, XT1032"
"Motorola, Moto G w/ 4G LTE, peregrine, XT1045"
"Motorola, Moto G w/4G LTE, peregrine, XT1040"
"Motorola, Moto MAXX, quark_ums, XT1225"
"Motorola, Moto Turbo, quark_ums, XT1225"
"Motorola, Moto X, ghost, XT1049"
"Motorola, Moto X, ghost, XT1050"
"Motorola, Moto X, ghost, XT1052"
"Motorola, Moto X, ghost, XT1053"
"Motorola, Moto X, ghost, XT1055"
"Motorola, Moto X, ghost, XT1056"
"Motorola, Moto X, ghost, XT1058"
"Motorola, Moto X, ghost, XT1060"
"Motorola, Moto X, victara, XT1085"
"Motorola, Moto X, victara, XT1097"
"Motorola, Moto X, victara, XT1098"
"Motorola, Moto X Style, clark, XT1572"
"Motorola, Moto X Style, clark, XT1575"
"Motorola, Motoluxe, XT611, XT611"
"Motorola, Motoluxe, XT615, XT615"
"Motorola, Motoluxe, XT682, XT682"
"Motorola, Motoluxe, ironmax_ums, XT615"
"Motorola, Motoluxe, ironmax_ums, XT685"
"Motorola, Motoluxe, ironmaxct_cdma, Motorola MOT-XT681"

supported device.txt

"Motorola, Motoluxe, ironmaxtv_umts, XT687"
 "Motorola, Motoluxe, umts_ironrock, XT626"
 "Motorola, Motoluxe, umts_ironrock, XT627"
 "Motorola, Motorola, sholest, Milestone XT720"
 "Motorola, Motorola, sholest, Motorola XT720"
 "Motorola, Motorola, sholest, XT720"
 "Motorola, Motorola Atrix HD, qinara, MB886"
 "Motorola, Motorola Master Touch, umts_primus, XT621"
 "Motorola, Motorola Master Touch XT621, umts_primus, XT621"
 "Motorola, Motorola Photon, asanti_c, XT897"
 "Motorola, Motorola Photon, asanti_c, XT897S"
 "Motorola, Motorola RAZR HD, vanquish, DROID RAZR HD"
 "Motorola, Motorola RAZR M, smq, XT907"
 "Motorola, Motorola Razr V, umts_yangtze, XT885"
 "Motorola, Motorola Razr V, umts_yangtze, XT886"
 "Motorola, Motorola XOOM 2, flaming, MZ609"
 "Motorola, Motorola XOOM 2, pasteur, MZ617"
 "Motorola, Motosmart, XT389, XT389"
 "Motorola, Motosmart, XT390, XT390"
 "Motorola, Motosmart, argonmini_umts, XT389"
 "Motorola, Motosmart, argonmini_umts, XT390"
 "Motorola, Motosmart, siliconsmart_umts, XT303"
 "Motorola, Motosmart, siliconsmart_umts, XT305"
 "Motorola, Nexus 6, shamu, Nexus 6"
 "Motorola, Opus One, rubicon, Motorola Titanium"
 "Motorola, Opus One, rubicon, Titanium"
 "Motorola, Photon 4G, sunfire, ISW11M"
 "Motorola, Photon 4G, sunfire, MB855"
 "Motorola, Photon 4G, sunfire, Motorola Electrify"
 "Motorola, Quench XT3, XT502, Motorola-XT502"
 "Motorola, RAZR D1, hawk35_umts, XT914"
 "Motorola, RAZR D1, hawk35_umts, XT915"
 "Motorola, RAZR D1, hawk35_umts, XT916"
 "Motorola, RAZR D1, hawk35_umts, XT918"
 "Motorola, RAZR D3, hawk40_umts, XT919"
 "Motorola, RAZR D3, hawk40_umts, XT920"
 "Motorola, Spice, sesame, XT300"
 "Motorola, XOOM, stinson, Xoom"
 "Motorola, XOOM, umts_everest, MZ601"
 "Motorola, XOOM, umts_hubble, MZ601"
 "Motorola, XOOM, umts_hubble, MZ605"
 "Motorola, XOOM, wifi_hubble, MZ604"
 "Motorola, XOOM, wifi_hubble, MZ606"
 "Motorola, XOOM, wilmington, Xoom"
 "Motorola, XT605, umts_jorian, XT605"
 "Motorola, XT627, umts_ironrock, XT627"
 "Motorola Solutions, Moto E, surnia_umts, MotoE2(4G-LTE)"
 "Motorola Solutions, TC55CH, TC55CH, TC55CH"
 "Motorola Solutions Inc., TC55, TC55, TC55"
 "Motorola Solutions Inc., TC55CH, TC55CH, TC55CH"
 "Moxee Technologies, X1, X1, X1"
 "Moxee Technologies, X10, X10, X10"
 "Moxee Technologies, X100, X100, X100"
 "Multilaser, M7s Dual Core, NB116_NB117_NB118, M7s Dual ML03"
 "Multilaser, M7s Quad Core, astar-ococci, ML01-M7S-Quad-Core"
 "Multilaser, MS50, MS50, MS50"
 "Multilaser, Ms5, MTL-MS5, MS5"
 "Multilaser, Ms6, MS6, MS6"
 "MyGo, GoTab GBT10, GBT10, GoTab_GBT10"
 "Myphone, UNO, UNO_sprout, MyPhone UNO"
 "NAXA, NAXA NID-7011, NID-7011, NID-7011"
 "NAXA, NID_7010, NID_7010, NID_7010"
 "NCREDIBLE, NV8-HD, NV8-HD, NV8"

supported device.txt

"NEC, 101T \xe3\x80\x80MEDIAS, NEC-101, NEC-101T"
"NEC, AGT10, AGT10, N8730-411"
"NEC, AGT10, AGT10, N8730-41101"
"NEC, AGT10, AGT10, N8730-41102"
"NEC, CASIO G\`zOne Commando 4G LTE, C811, C811 4G"
"NEC, Casio G\`zOne Commando, C771, C771"
"NEC, Disney Mobile on docomoN-03E, N-03E, N-03E"
"NEC, G\`zOne IS11CA, IS11CA, IS11CA"
"NEC, G\`zOne TYPE-L CAL21, CAL21, CAL21"
"NEC, G\xe2\x80\x99zOne CA-201L, CA201L, CA-201L"
"NEC, LaVieTab PC-TE508BAW, TE508BAW, PC-TE508BAW"
"NEC, LaVieTab PC-TE508S1W/LaVieTab PC-TE508S1L, PC-TE508S1_nec, LaVieTab PC-TE508S1"
"NEC, LaVieTab PC-TE510S1L, PC-TE510S1_nec, LaVieTab PC-TE510S1"
"NEC, LifeTouch B, LTB013, D000-000013-101"
"NEC, LifeTouch B, LTB018, D000-000018-001"
"NEC, LifeTouch B, LTB018, D000-000018-002"
"NEC, LifeTouch B, LTB018, D000-000018-003"
"NEC, LifeTouch B, LTB018, D000-000018-004"
"NEC, LifeTouch B, LTB018, D000-000018-101"
"NEC, LifeTouch B, LTB018, D000-000018-102"
"NEC, LifeTouch B, LTB018, D000-000018-104"
"NEC, LifeTouch B, LTB019G, D000-000019-002"
"NEC, LifeTouch B, LTB019W, D000-000019-001"
"NEC, LifeTouch B, LTB028, LTB-HS"
"NEC, LifeTouch L, D000000023, LT-TLA"
"NEC, LifeTouch L, D000000035, NEC-STR"
"NEC, LifeTouch L, D000000039, NEC-STR"
"NEC, LifeTouch L, LTTLA16, LT-TLA"
"NEC, LifeTouch L, LTTLA32, LT-TLA"
"NEC, LifeTouch Note, D000000010N, D000-000010-N"
"NEC, LifeTouch Note, D000000011N, D000-000011-N"
"NEC, LifeTouch Note, LTNA7, LT-NA7"
"NEC, LifeTouch Note, LTNA7F, LT-NA7F"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-B01"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-B02"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-C01"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-K01"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-R01"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-R02"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-R03"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-R04"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-S00"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-S01"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-S05"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-S25"
"NEC, LifeTouch S, LifeTouch_D1, D000-000001-S85"
"NEC, LifeTouch S, LifeTouch_D7, D000-000007-D01"
"NEC, LifeTouch W, LT-W1_1, D000-000002-W01"
"NEC, LifeTouch W, LT-W1_2, D000-000002-W02"
"NEC, LifeTouch W, LifeTouch_W1, D000-000002-001"
"NEC, MEDIAS X N-06E, N-06E, N-06E"
"NEC, MEDIAS BR IS11N, IS11N, IS11N"
"NEC, MEDIAS CH 101N, 101N, 101N"
"NEC, MEDIAS ES N-05D, N-05D, N-05D"
"NEC, MEDIAS LTE N-04D, N-04D, N-04D"
"NEC, MEDIAS N-04C, N-04C, N-04C"
"NEC, MEDIAS NE-202, NE-202, NE-202"
"NEC, MEDIAS NEC-101S, MAGNUM, NEC-101S"
"NEC, MEDIAS NEC-101S, NEC-101, NEC-101S"
"NEC, MEDIAS NEC-102, NEC-102, NEC-102"
"NEC, MEDIAS PP N-01D, N-01D, N-01D"
"NEC, MEDIAS TAB N-06D, N-06D, N-06D"
"NEC, MEDIAS TAB UL N-08D, N-08D, N-08D"

supported device.txt

"NEC, MEDIAS U N-02E, N-02E, N-02E"
"NEC, MEDIAS U NE-103T, NE-103, NE-103T"
"NEC, MEDIAS W N-05E, N-05E, N-05E"
"NEC, MEDIAS WP N-06C, N-06C, N-06C"
"NEC, MEDIAS X N-04E, N-04E, N-04E"
"NEC, MEDIAS X N-07D, N-07D, N-07D"
"NEC, NE-201, NE-201, NEC-NE-201A1A"
"NEC, NEC909e, NEC909e, NEC909e"
"NEC, PC- TS507N1S, PC-TS507N1S, LaVi eTab PC-TS507N1S"
"NEC, PC-508T1W, 508T1W, PC-TS508T1W"
"NEC, PC-708T1W, 708T1W, PC-TS708T1W"
"NEC, PC-TE307N1W, PC-TE307N1W, PC-TE307N1W"
"NEC, PC-TE510N1B, LaVi eTab, LaVi eTab PC-TE510N1B"
"NESO, NESO N810 i 7, N810_i 7_1, N810 i 7"
"NGM, Forward_Pri me, Forward_Pri me, Forward_Pri me"
"NGM, Infi ni ty, Infi ni ty, Infi ni ty"
"NGM, NGM_Dynami c_Styl o, NGM_Dynami c_Styl o, NGM_Dynami c_Styl o"
"NGM Italia SRL, Danami c Now, Dynami cNow, Now"
"NGM Italia SRL, Dynami c Raci ng 3, NGM_Dynami c_Raci ng_3, Dynami c Raci ng 3"
"NGM Italia SRL, Endurance, ForwardEndurance, ForwardEndurance"
"NGM Italia SRL, ForwardZero, ForwardZero, ForwardZero"
"NGM Italia SRL, LI FE, Li fe, Li fe"
"NGM Italia SRL, M500, NGM_M500, NGM M500"
"NGM Italia SRL, M502, M502, M502"
"NGM Italia SRL, NGM Youcol or E400, E400, E400"
"NGM Italia SRL, NGM Youcol or E501, E501, E501"
"NGM Italia SRL, NGM Youcol or E505, E505, E505"
"NGM Italia SRL, NGM Youcol or E506, E506, E506"
"NGM Italia SRL, NGM Youcol or E507, E507, E507"
"NGM Italia SRL, P503, NGM_P503, NGM P503"
"NGM Italia SRL, Ruby, ForwardRuby, Forward Ruby"
"NGM Italia SRL, Ruby, ForwardRuby, ForwardRuby"
"NVi di a, SHI ELD Androi d TV, foster, SHI ELD Androi d TV"
"NVi di a, SHI ELD Androi d TV, foster, SHI ELD Consol e"
"NVi di a, SHI ELD Tabl et, shi el dtabl et, SHI ELD Tabl et"
"NVi di a, Shi el d, roth, SHI ELD"
"NVi di a, TegraNote, tegrannot e, Tegra Note 7"
"NVi di a, TegraNote, tegrannot e, TegraNote-P1640"
"NVi di a, TegraNote, tegrannot e, TegraNote-Premi um"
"NVi di a, TegraNote, tegrannot e7c, Tegra Note 7"
"NanoTech, Nuvol a NP-1, nuvol a, Nuvol a NP-1"
"Ncredi bl e, Ncredi bl e NV8, NV8, NV8"
"Netgear, NeoTVPri me, NeoTV, GTV100"
"Nexi an, Nexi an j ourney one, Mi 438S_sprout, Mi 438S"
"Next Learni ng, Nexttab N3, N3, N3"
"Nextbook, M-MP7NB3G, 7_Pi us_HD3G, M-MP7NB3G"
"Nextbook, NX700QC, nxm7100I vd_wm, NX700QC"
"Nextbook, NX785QC, nxm865I vd_wm, NX785QC"
"Nextbook, NX785QC8G, NXM865FD, NX785QC8G"
"Nextbook, NXA101LTE116, NXA101LTE116, NXA101LTE116"
"Nextbook, NXA116QC164, NXA116QC164, NXA116QC164"
"Nextbook, NXA8LTE116, NXA8LTE116, NXA8LTE116"
"Nextbook, NXA8QC116, NXA8QC116, NXA8QC116"
"Nextel , V. 35, up11_vsn_h1_si ngl e, Nextel V. 35"
"Nextel , V. 45, H26-VSN, NI I Nextel "
"Nextel , V. 45, H26-VSN, V. 45"
"Ni kon, COOLPI X, S800c, COOLPI X S800c"
"Ni kon, COOLPI X S810c, s810c, COOLPI X S810c"
"Nobi s, NB07, NB07, NB07"
"Nobi s, NB1022, RCT6203W46, NB1022"
"Nobi s, NB7022S, NB7022S, NB7022S"
"Nobi s, NB7850S, NB7850S, NB7850S"
"Nobi s, Nobi s NB09, M9025, NB09"

supported device.txt

"Noble, NBX-T1014N, TA10CA2, TA10CA2"
"Noble, NBX-T7014, E270BSA, NBX-T7014"
"Nokia, N1, Nokia_N1, N1"
"Nubia, NX401, NX40X, NX401"
"Nubia, NX501, NX501, NX501"
"Nubia, NX503A, NX503A, NX503A"
"Nuvision, TM101A530L, TM101A530L, TM101A530L"
"Nuvision, TM1088, fiber-wifi bt, CT1000"
"Nuvision, TM1088, fiber-wifi bt, Endeavour101"
"Nuvision, TM1088, fiber-wifi bt, TM1088"
"Nuvision, TM1088, fiber-wifi bt, WEBPAD1002"
"Nuvision, TM785M3, TM785M3, TM785M3"
"Nuvision, TM800A510L, TM800A, TM800A510L"
"Nyx mobile, NOBA, NOBA, NOBA"
"OPPO, N1, N1, N1"
"OPPO, N1T, N1T, N1T"
"OPPO, N1W, N1W, N1W"
"OPPO, R1001, R1001, R1001"
"OPPO, R2001, R2001, R2001"
"OPPO, R2010, R2010, R2010"
"OPPO, R2017, R2017, R2017"
"OPPO, R6007, R6007, R6007"
"OPPO, R7007, R7007, R7007"
"OPPO, R8001, R8001, R8001"
"OPPO, R8006, R8006, R8006"
"OPPO, R8007, R8007, R8007"
"OPPO, R815, R815, R815"
"OPPO, R819, R819, R819"
"OPPO, R821, R821, R821"
"OPPO, R827, R827, R827"
"OPPO, R827T, R827T, R827T"
"OPPO, R829, R829, R829"
"OPPO, R829T, R829T, R829T"
"OPPO, R830, R830, R830"
"OPPO, R830S, R830S, R830S"
"OPPO, R831, R831, R831"
"OPPO, R831L, R831L, R831L"
"OPPO, R831S, R831S, R831S"
"OPPO, R831T, R831T, R831T"
"OPPO, R850, R850, R850"
"OPPO, U707, U707, U707"
"OPPO, U708, U708, U708"
"OPPO, X9006, X9006, X9006"
"OPPO, X9007, X9007, X9007"
"OPPO, X9070, X9070, X9070"
"OPPO, X9076, X9076, X9076"
"OPPO, X9077, X9077, X9077"
"OPPO, X909, FIND5, X909"
"Odys, ODYS_UNO_X10, UNO_X10, UNO_X10"
"Odys, ODYS_UNO_X8, UNO_X8, UNO_X8"
"Olive Oil, OliveOil_Model_3, wecct3, CT3"
"Olivetti, Graphos_A10, Graphos_A10, Graphos_A10"
"Olivetti, OP110, OP110, OP110"
"OnePlus, OnePlus_One, A0001, A0001"
"OnePlus, OnePlus_One, A0001, One"
"OpenPeak, , CIUS-7, CIUS-7"
"OpenPeak, , CIUS-7-AT, CIUS-7-AT"
"OpenPeak, , cius, cius"
"Oppo, 1100, 1100, 1100"
"Oppo, 1105, 1105, 1105"
"Oppo, 1107, 1107, 1107"
"Oppo, 1206, 1206, 1206"
"Oppo, 3000, 3000, 3000"

supported device.txt

"Oppo, 3001, Mi rror3, 3001"
"Oppo, 3005, 3005, 3005"
"Oppo, 3006, Mi rror3, 3006"
"Oppo, 3007, 3007, 3007"
"Oppo, 3008, 3008, 3008"
"Oppo, A11, A11, A11"
"Oppo, A11f, A11, A11f"
"Oppo, A11t, A11, A11t"
"Oppo, A13t, A31t, A31t"
"Oppo, A31, A31t, A31"
"Oppo, A31c, A31c, A31c"
"Oppo, A31u, A31u, A31u"
"Oppo, A51, A51, A51"
"Oppo, A51f, A51, A51f"
"Oppo, A51fa, A51, A51f"
"Oppo, A51kc, A51kc, A51kc"
"Oppo, A51w, A51, A51w"
"Oppo, Fi nd 5, FI ND5, X909"
"Oppo, N1, N1, N1"
"Oppo, N1 mi mi , N1mi ni , N5111"
"Oppo, N1 mi mi , N1mi ni , N5116"
"Oppo, N1T, N1T, N1T"
"Oppo, N3, N3, N5206"
"Oppo, N3, N3, N5207"
"Oppo, N3, N3, N5209"
"Oppo, N5110, N5110, N5110"
"Oppo, N5117, N5117, N5117"
"Oppo, OPP0 1201, 1201, 1201"
"Oppo, OPP0 A11w, A11w, A11w"
"Oppo, OPP0 Fi nd5, FI ND5, X909"
"Oppo, OPP0 Fi nd5, FI ND5, X909T"
"Oppo, OPP0 UI i ke2, UI i ke2, U705T"
"Oppo, R1001, OPP072_13076, R1001"
"Oppo, R1001, R1001, R1001"
"Oppo, R1011, R1011, R1011"
"Oppo, R1011w, R1011, R1011"
"Oppo, R5, R5, R8106"
"Oppo, R5, R5, R8107"
"Oppo, R5, R5, R8109"
"Oppo, R6006, R3, R6006"
"Oppo, R7, R7, R7"
"Oppo, R7 Li te, R7f, R7kf"
"Oppo, R7 PI us, R7PI us, R7PI us"
"Oppo, R7005, R3, R7005"
"Oppo, R7PI ust, R7PI us, R7PI ust"
"Oppo, R7c, R7c, R7c"
"Oppo, R7f, R7f, R7f"
"Oppo, R7g, R7f, R7g"
"Oppo, R7kc, R7kc, R7kc"
"Oppo, R7kf, R7f, R7kf"
"Oppo, R7kt, R7, R7kt"
"Oppo, R7s, R7s, R7s"
"Oppo, R7sf, R7sm, R7sf"
"Oppo, R7sfg, R7sf, R7sf"
"Oppo, R7sm, R7sm, R7sm"
"Oppo, R7st, R7s, R7st"
"Oppo, R7t, R7, R7t"
"Oppo, R8000, R1S, R8000"
"Oppo, R809T, R809T, R809T"
"Oppo, R8106, R5, R8106"
"Oppo, R815, R815, R815"
"Oppo, R815T, R815T, R815T"
"Oppo, R815W, R815W, R815W"

supported device.txt

"Oppo, R819, R819, R819"
"Oppo, R819T, R819T, R819T"
"Oppo, R820, R820, R820"
"Oppo, R8200, R1C, R8200"
"Oppo, R8201, R1x, R8201"
"Oppo, R8205, R1C, R8205"
"Oppo, R8206, R1x, R8206"
"Oppo, R8207, R1C, R8207"
"Oppo, R821, R821, R821"
"Oppo, R821T, R821T, R821T"
"Oppo, R823T, R823T, R823T"
"Oppo, R827, R827, R827"
"Oppo, R831, R831, R831"
"Oppo, R831, R831T, R831T"
"Oppo, R831K, R831K, R831K"
"Oppo, R833T, OPP082_13067, R833T"
"Oppo, U3, U3, U3"
"Oppo, U707, U707, U707"
"Oppo, U707T, U707T, U707T"
"Oppo, UI i ke2, U705W, U705W"
"Oppo, X9000, X9000, X9000"
"Oppo, X9077, FI ND7, X9077"
"Oppo, X909, FI ND5, X909"
"Oppo, X909, X909, X909"
"Oppo, X909, X909T, X909T"
"Opti con, H-27, H-27, H-27"
"Orange, Luno, Luno, Luno"
"Orange, NOS Roya, AI to45, NOS Roya"
"Orange, Nura2, m823_orange, Nura 2"
"Orange, Orange Nura, M812, Orange Nura"
"Orange, Orange Ri se 30, Pi xi 3-4, Orange Ri se 30"
"Orange, Orange Roya, AI to45, Orange Roya"
"Orange, Orange Zi l o, Orange_Zi l o, Zi l o"
"Orange, i dol S, Di abl o_LTE, Orange Ni va"
"Orbi c, R370H, R370H, R370L"
"PC Smart, PTSG0B8, PTSG0B8, PC_Smart_PTSG0B8"
"POC, POC2, CBL7509MM, POC2"
"Panasoni c, , H580VT_A, JT-H580VT"
"Panasoni c, , H581VT_A, JT-H581VT"
"Panasoni c, , P-08D, P-08D"
"Panasoni c, , I aputa, P-07C"
"Panasoni c, 003P, pana1, 003P"
"Panasoni c, 101P, pana2_2s, 101P"
"Panasoni c, 102P, pana2_4s, 102P"
"Panasoni c, 48AX600C, mst918_4G, 48AX600C"
"Panasoni c, 55AX600C, mst918_4k2k, 55AX600C"
"Panasoni c, AS650C, AS650C, AS650C"
"Panasoni c, AX600C, AX600C, AX600C"
"Panasoni c, AI tus 18, AI tus18, AI tus 18"
"Panasoni c, AI tus 24, AI tus24, AI tus 24"
"Panasoni c, Boukenkun-reci ever, VW_RCBKK1, VW_RCBKK1"
"Panasoni c, EB-4063-X, EB-4063-X, EB-4063-X"
"Panasoni c, ELUGA, pana2_4o, dL1"
"Panasoni c, ELUGA P, P-03E, P-03E"
"Panasoni c, ELUGA Power, P-07D, P-07D"
"Panasoni c, ELUGA U, ELUGA_U, Panasoni c ELUGA U"
"Panasoni c, ELUGA U2, ELUGA_U2, Panasoni c ELUGA U2"
"Panasoni c, ELUGA V, P-06D, P-06D"
"Panasoni c, ELUGA X, P-02E, P-02E"
"Panasoni c, ELUGA dL1, pana2_4v, Panasoni c_dL1"
"Panasoni c, Eco11 v2, Eco11v2, Eco11 v2"
"Panasoni c, Eco9 v1, Eco, Eco9 v1"
"Panasoni c, Eco9 v2, Ecov2, Eco9 v2"

supported device.txt

"Panasoni c, Elite 11, Elite11, Elite"
"Panasoni c, Elite 11, Elite11, Elite 11"
"Panasoni c, Elite 12, Elite12, Elite"
"Panasoni c, Elite 16, Elite16, Elite"
"Panasoni c, Elite 18, Elite18, Elite"
"Panasoni c, FZ-A1, toughpad, FZ-A1B"
"Panasoni c, FZ-B2, fz_b2bb, FZ-B2B"
"Panasoni c, FZ-X1, FZ-X1, FZ-X1"
"Panasoni c, FZ-X1, FZ-X1VU, FZ-X1"
"Panasoni c, FZ-X1, FZ-X1VUC, FZ-X1"
"Panasoni c, HDPSEB v2, HDPSEBv2, HD PSEB v2"
"Panasoni c, JT-B1, B1, JT-B1"
"Panasoni c, KX-PRXA10, KX-PRXA10, Panasoni c KX-PRXA10"
"Panasoni c, KX-PRXA15, KX-PRXA15, Panasoni c KX-PRXA15"
"Panasoni c, LUMI X CM1, DMC-CM1, DMC-CM1"
"Panasoni c, P-01D, pana2_1, P-01D"
"Panasoni c, P-02D, pana2_2, P-02D"
"Panasoni c, P-04D, pana2_4d, P-04D"
"Panasoni c, P-05D, pana2_4a, P-05D"
"Panasoni c, P-07C, pana1, P-07C"
"Panasoni c, Panasoni c ELUGA A, ELUGA_A, Panasoni c ELUGA A"
"Panasoni c, Panasoni c ELUGA I, ELUGA_I, Panasoni c ELUGA I"
"Panasoni c, Panasoni c ELUGA L 4G, ELUGA_L_4G, Panasoni c ELUGA L 4G"
"Panasoni c, Panasoni c ELUGA S, ELUGA_S, Panasoni c ELUGA S"
"Panasoni c, Panasoni c ELUGA S Mi ni, ELUGA_S_Mi ni, Panasoni c ELUGA S Mi ni "
"Panasoni c, Panasoni c El uga Z, ELUGA_Z, Panasoni c ELUGA Z"
"Panasoni c, Panasoni c P11, P11, Panasoni c P11"
"Panasoni c, Panasoni c P31, P31, Panasoni c P31"
"Panasoni c, Panasoni c P41, P41, Panasoni c P41"
"Panasoni c, Panasoni c P41 HD, P41HD, Panasoni c P41HD"
"Panasoni c, Panasoni c P51, P51, Panasoni c P51"
"Panasoni c, Panasoni c P55, P55, Panasoni c P55"
"Panasoni c, Panasoni c P55 Novo, P55_Novo, Panasoni c P55 Novo"
"Panasoni c, Panasoni c P61, P61, Panasoni c P61"
"Panasoni c, Panasoni c P61, P61, Panasoni c_P61"
"Panasoni c, Panasoni c P81, P81, Panasoni c P81"
"Panasoni c, Panasoni c T11, T11, Panasoni c T11"
"Panasoni c, Panasoni c T21, T21, Panasoni c T21"
"Panasoni c, Panasoni c T31, T31, Panasoni c T31"
"Panasoni c, Panasoni c T33, T33, Panasoni c T33"
"Panasoni c, Panasoni c T40, T40, Panasoni c T40"
"Panasoni c, Panasoni c T41, T41, Panasoni c T41"
"Panasoni c, Panasoni c T9, T9, Panasoni c T9"
"Panasoni c, SDU, SDU, SDU"
"Panasoni c, SM17, SM17, Smart Moni tor 17"
"Panasoni c, SV-ME1000, K1, Panasoni c SV-ME1000"
"Panasoni c, SmartTVBox, C01AS, SMARTTVBOX"
"Panasoni c, TAB-A01, TAB-A01, TAB-A01-SD"
"Panasoni c, UN-MT300, A1, Panasoni c UN-MT300"
"Panasoni c, UN-W700, F1, Panasoni c UN-W700"
"Panasoni c, VHS v2, VHS, Vi deo Handset"
"Panasoni c, VTSH v1, VTSHv1, VTSH v1"
"Pantech, ADR910L, ADR910L, ADR910L"
"Pantech, ADR930L, ADR930L, ADR930L"
"Pantech, AT1, at1, IM-T100K"
"Pantech, Apache, ADR8995, ADR8995"
"Pantech, Burst, presto, PantechP9070"
"Pantech, Crossover, moon, PantechP8000"
"Pantech, EF33S, ef33s, IM-A760S"
"Pantech, EF34K, ef34k, IM-A770K"
"Pantech, EF35L, ef35l, IM-A780L"
"Pantech, El ement, pororo, PantechP4100"
"Pantech, Fl ex, oscar, PantechP8010"

supported device.txt

"Pantech, IM-810K, ef40k, IM-A810K"
"Pantech, IM-840SP, IM-A840SP, IM-A840SP"
"Pantech, IM-A730S, ef30s, IM-A730S"
"Pantech, IM-A740S, ef31s, IM-A740S"
"Pantech, IM-A760S, ef33s, IM-A760S"
"Pantech, IM-A770K, ef34k, IM-A770K"
"Pantech, IM-A775C, ef34c, IM-A775C"
"Pantech, IM-A780L, ef35l, IM-A780L"
"Pantech, IM-A800S, ef39s, IM-A800S"
"Pantech, IM-A810K, ef40k, IM-A810K"
"Pantech, IM-A810S, ef40s, IM-A810S"
"Pantech, IM-A830K, ef45k, IM-A830K"
"Pantech, IM-A830KE, ef45kv, IM-A830KE"
"Pantech, IM-A830L, ef46l, IM-A830L"
"Pantech, IM-A830S, ef47s, IM-A830S"
"Pantech, IM-A840S, IM-A840S, IM-A840S"
"Pantech, IM-A850K, ef49k, IM-A850K"
"Pantech, IM-A850L, ef50l, IM-A850L"
"Pantech, IM-A850S, ef48s, IM-A850S"
"Pantech, IM-A860K, ef51k, IM-A860K"
"Pantech, IM-A860L, ef51l, IM-A860L"
"Pantech, IM-A860S, ef51s, IM-A860S"
"Pantech, IM-A870K, ef52k, IM-A870K"
"Pantech, IM-A870L, ef52l, IM-A870L"
"Pantech, IM-A870S, ef52s, IM-A870S"
"Pantech, IM-A880S, EF56S, IM-A880S"
"Pantech, IM-A910K, ef63k, IM-A910K"
"Pantech, IM-A910L, ef63l, IM-A910L"
"Pantech, IM-A910S, ef63s, IM-A910S"
"Pantech, IM-A920S, ef65s, IM-A920S"
"Pantech, I zar, sp33k, SKY IM-A630K"
"Pantech, MI RACH_J, mi rachj, I S01PT"
"Pantech, MI RACH_J, mi rachj, I S11PT"
"Pantech, Mi rach, ef13l, IM-A690L"
"Pantech, Mi rach, ef13s, IM-A690S"
"Pantech, Mi rach A, ef32k, IM-A750K"
"Pantech, P9090, magnus, PantechP9090"
"Pantech, PLANET, mi ni, PLANET"
"Pantech, PTL21, maruko, PTL21"
"Pantech, Pocket, mi ni, PantechP9060"
"Pantech, SI RI US \xce\xbb1, j masai, I S06"
"Pantech, Si ri us, ef10s, SKY IM-A600S"
"Pantech, VEGA RACER, ef34k, IM-A770K"
"Pantech, VEGA RACER, ef35l, IM-A780L"
"Pantech, VEGA Secret Note, EF59K, IM-A890K"
"Pantech, VEGA Secret Note, EF59L, IM-A890L"
"Pantech, VEGA Secret Note, EF59S, IM-A890S"
"Pantech, VEGA Secret UP, EF60S, IM-A900S"
"Pantech, VEGA Secret UP, EF61K, IM-A900K"
"Pantech, VEGA Secret UP, EF62L, IM-A900L"
"Pantech, VEGA Secret UP, ef60s, IM-A900S"
"Pantech, VEGA Secret UP, ef61k, IM-A900K"
"Pantech, VEGA Secret UP, ef62l, IM-A900L"
"Pantech, Vega, ef12s, SKY IM-A650S"
"Pantech, Vega LTE M, ef65l, IM-A820L"
"Pantech, Vega X, ef14l, IM-A720L"
"Pantech, Vega X, ef18k, IM-A710K"
"Pantech, ef14l v, ef14l v, IM-A725L"
"Partner, OT-310, OT-310, OT-310"
"Pegatron, , Duke3G, Android Tablet PC"
"Pegatron, , DukeWi fi, Android Tablet PC"
"Pegatron, , TabletPC, Android Tablet PC"
"Pegatron, Maxi IQ, Maxi IQ, Maxi IQ"

supported device.txt

"Pegatron, Oli pad, OP111, chagal I "
"Pegatron, chagal I , chagal I , Chagal I 10.1 Wi Fi "
"Pegatron, chagal I , chagal I , E-Tab 4G"
"Pegatron, chagal I , chagal I , chagal I "
"Phi l i ps, , Phi l i ps_GGC3, SA3CNT"
"Phi l i ps, , Phi l i ps_PI 5000, Phi l i ps_PI 5000"
"Phi l i ps, , SA2CNTxx, Phi l i ps GoGear Connect"
"Phi l i ps, 4K & Full HD Slim LED TV powered by
Androi d\xe2\x84\xa2, phi l i ps_MT5593FHT_EU, QM152E"
"Phi l i ps, 4K UHD Razor Slim LED TV powered by Androi d\xe2\x84\xa2, QV151E, QV151E"
"Phi l i ps, HMP8100/93, HMP8100_ATV_93, HMP8100_ATV_93"
"Phi l i ps, HMP8100/98, HMP8100_ATV, HMP8100_ATV_I NT"
"Phi l i ps, PHP-S221C4AFD, MMD_WW, G3SMNTS22"
"Phi l i ps, PHP-S231C4AFD, G3SMNTS23, G3SMNTS23"
"Phi l i ps, PI 2000, PI 2000, PI 2000"
"Phi l i ps, PI 2010, PI 2010, PI 2010"
"Phi l i ps, PI 2011, PI 2011, PI 2011"
"Phi l i ps, PI 3100/51, PI 3100_51, PI 3100"
"Phi l i ps, PI 3100/58, PI 3100_58, PI 3100"
"Phi l i ps, PI 3100/93, PI 3100_93, PI 3100-93"
"Phi l i ps, PI 3100/98, PI 3100_98, PI 3100"
"Phi l i ps, PI 3100Z3/93, PI 3100Z3_93, PI 3100Z3_93"
"Phi l i ps, PI 3105, PI 3105, PI 3105"
"Phi l i ps, PI 3106, PI 3106, PI 3106"
"Phi l i ps, PI 3110, PI 3110, PI 3110"
"Phi l i ps, PI 3205G, PI 3205G_93, PI 3205G"
"Phi l i ps, PI 3210G, PI 3210G, PI 3210G"
"Phi l i ps, PI 3900, T7p_Duo_93, PI 3900-93"
"Phi l i ps, PI 3900/51, PI 3900_51, PI 3900"
"Phi l i ps, PI 3900/58, PI 3900_58, PI 3900"
"Phi l i ps, PI 3900/98, PI 3900_98, PI 3900"
"Phi l i ps, PI 3910, PI 3910, PI 3910"
"Phi l i ps, PI 4010G, PI 4010G, PI 4010G"
"Phi l i ps, PI 7100/93, PI 7100_93, PI 7100_93"
"Phi l i ps, Phi l i ps Androi d 2014, phi l i pstv, AND1E"
"Phi l i ps, Phi l i ps S308, Phi l i ps_S308, Phi l i ps S308"
"Phi l i ps, Phi l i ps V387, V387, Phi l i ps V387"
"Phi l i ps, Phi l i ps W8510, Topaz, Phi l i ps W8510"
"Phi l i ps, Phi l i ps_W3500, Phi l i ps_W3500, Phi l i ps_W3500"
"Phi l i ps, Phi l ps S398, Phi l i ps_S398, Phi l i ps S398"
"Phi l i ps, S221C3A, MMD_WW, G2SMNT"
"Phi l i ps, T8 PI 7000, Tabl et_8, PI 7000"
"Phi l i ps, W337, W337, W337"
"Phi l i ps, W3568, Phi l i ps_W3568, Phi l i ps W3568"
"Phi l i ps, W3620, W3620, W3620"
"Phi l i ps, W6500, Phi l i ps_W6500_A, W6500"
"Phi l i ps, W6610, Marathon, Phi l i ps W6610"
"Phi l i ps, W6620, W6620, W6620"
"Phi l i ps, W8555, Pri de, Phi l i ps W8555"
"Pi oneer, PI ONEER R1, RCK8726Y703H, R1"
"Pi ai si o, G320, G320, G320"
"Pi ai si o, Hi ve V 3G, mg978, Hi ve V 3G"
"Pi ai si o, Hi ve V 3G, mr978, Hi ve V 3G"
"Pi ai si o, ""Rai nbow I I 3G 8""""""", mr801, Rai nbow I I 3G"
"Pi ai si o, ""Rubi k I I 10""""""", q102, Rubi k 10.1 I I "
"Pi ai si o, Turbo-X_epsi l on, Turbo-X_epsi l on, Turbo-X_epsi l on"
"Pi ai si o, Turbo-X_pi _4G, Turbo-X_pi _4G, Turbo-X_pi _4G"
"Pi ai si o, I amda, Turbo-X_I amda, Turbo-X I amda"
"Pi us4, Q-Touch, Q-Touch, Q-Touch"
"Pol ari s, pol ari s Androi d_X7, pol ari s-Condroi d_X7, Condroi d_X7"
"Pol aroi d, A6, A6, A6"
"Pol aroi d, A9x/PTAB935x, A9xPTAB935x, A9x/PTAB935x"
"Pol aroi d, I nfi ni te, MI D1324, MI D 1324"

supported device.txt

"Pol aroi d, MI D4X07, RCT6773W22, MI D4X07"
"Pol aroi d, MI D4X10, RCT6203W46, MI D4X10"
"Pol aroi d, P10/Q10/PTAB1040/PTAB1041, pq10-Pol aroi d, P10/Q10/PTAB1040/PTAB1041"
"Pol aroi d, P1001, P1001, P1001"
"Pol aroi d, P7/Q7/PTAB740/PTAB741, pq7-Pol aroi d, P7/Q7/PTAB740/PTAB741"
"Pol aroi d, P791, P791, P791"
"Pol aroi d, P9/Q9/PTAB940/PTAB941, pq9-Pol aroi d, P9/Q9/PTAB940/PTAB941"
"Pol aroi d, P901, P901, P901"
"Pol aroi d, POLAR01 D A7_PTAB735, A7_PTAB735, HS-7DTB39"
"Pol aroi d, PR05023PW, up06_h25_pol aroi d, PR05023PW"
"Pol aroi d, PR05043, PR05043, PR05043"
"Pol aroi d, PTAB1051-PTAB1055, RCT6203W46, PTAB1051_PTAB1055"
"Pol aroi d, Pol aroi d A/S10, wi ng-AS10, A/S10"
"Pol aroi d, Pol aroi d A/S7, wi ng-AS7, A/S7"
"Pol aroi d, Pol aroi d A/S8, wi ng-AS8, A/S8"
"Pol aroi d, Pol aroi d A7X_PTAB735X, PTAB735X, A7X_PTAB735X"
"Pol aroi d, Pol aroi d K7, PTAB782, K7/PTAB782"
"Pol aroi d, Pol aroi d L9, L9, L9"
"Pol aroi d, Pol aroi d MI D1028, MI D1028, MI D1028"
"Pol aroi d, Pol aroi d P900, P900, P900/Q900"
"Pol aroi d, Pol aroi d PTAB751, STJR76, PTAB751"
"Pol aroi d, Pol aroi d V7, nucl ear-M7021, V7"
"Posi ti vo, Posi ti vo AB7, YPY_AB7D, YPY_AB7D"
"Posi ti vo, Posi ti vo AB7D, YPY_AB7DC, YPY_AB7DC"
"Posi ti vo, Posi ti vo BGH Y200, T710, Posi ti vo BGH Y200"
"Posi ti vo, Posi ti vo BGH Y210, Y210, Posi ti vo BGH Y210"
"Posi ti vo, Posi ti vo BGH Y400, Y400, Y400"
"Posi ti vo, Posi ti vo Mi ni , mi ni , Posi ti vo Mi ni "
"Posi ti vo, Posi ti vo Mi ni , mi ni , Posi ti vo Mi ni TE"
"Posi ti vo, Posi ti vo OCTA, OCTA, OCTA"
"Posi ti vo, Posi ti vo S380, S380, S380"
"Posi ti vo, Posi ti vo S450, S450, S450"
"Posi ti vo, Posi ti vo S550, S550, S550"
"Posi ti vo, Posi ti vo SX1000, SX1000, Posi ti vo SX1000"
"Posi ti vo, Posi ti vo T1060, t1060, T1060"
"Posi ti vo, Posi ti vo T1060, t1060, T1060B"
"Posi ti vo, Posi ti vo T1060, t1060, T1060C"
"Posi ti vo, Posi ti vo T701 TV, T701, T701"
"Posi ti vo, Posi ti vo T705, T705, T705"
"Posi ti vo, Posi ti vo T705, T705, T705/T708"
"Posi ti vo, Posi ti vo T705, T705, T705K"
"Posi ti vo, Posi ti vo T710, T710, Posi ti vo T710"
"Posi ti vo, Posi ti vo T750, t750, Posi ti vo T750"
"Posi ti vo, Posi ti vo X400, X400, X400"
"Posi ti vo, Posi ti vo YPY AB7, YPY_AB7, Posi ti vo Ypy AB7E"
"Posi ti vo, Posi ti vo YPY AB7, YPY_AB7, Posi ti vo Ypy AB7EC"
"Posi ti vo, Posi ti vo YPY7 3G, TB07FTA, Posi ti vo Ypy 7 - TB07FTA"
"Posi ti vo, Posi ti vo YPY7 3G, TB07FTA, Ypy 7 - TB07FTA"
"Posi ti vo, Posi ti vo YPY7 3G, YPY_07FTA, YPY_07FTA"
"Posi ti vo, Posi ti vo YPY7 wi fi , TB07STA, Posi ti vo Ypy 7 - TB07STA"
"Posi ti vo, Posi ti vo YPY7 wi fi , TB07STA, Ypy 7 - TB07STA"
"Posi ti vo, Posi ti vo YPY7 wi fi , YPY_07STA, YPY_07STA"
"Posi ti vo, Posi ti vo Ypy 07FTB, YPY_07FTB, POSI TI VO TABLET YPY 07FTB PM BEL\xc3\x89M"
"Posi ti vo, Posi ti vo Ypy 07FTB, YPY_07FTB, YPY_07FTB"
"Posi ti vo, Posi ti vo Ypy 07FTBF, YPY_07FTBF, YPY_07FTBF"
"Posi ti vo, Posi ti vo Ypy 07STB, YPY_07STB, YPY_07STB"
"Posi ti vo, Posi ti vo Ypy 07STBF, YPY_07STBF, YPY_07STBF"
"Posi ti vo, Posi ti vo Ypy 10FTB, YPY_10FTB, YPY_10FTB"
"Posi ti vo, Posi ti vo Ypy 10FTBF, YPY_10FTBF, YPY_10FTBF"
"Posi ti vo, Posi ti vo Ypy 10STB, YPY_10STB, YPY_10STB"
"Posi ti vo, Posi ti vo Ypy 10STBF, YPY_10STBF, YPY_10STBF"
"Posi ti vo, Posi ti vo Ypy AB10, YPY_AB10D, YPY_AB10D"
"Posi ti vo, Posi ti vo Ypy AB10D, YPY_AB10DC, YPY_AB10DC"

supported device.txt

"Posi ti vo, Posi ti vo Ypy AB10E, YPY_AB10EC, Posi ti vo Ypy AB10EC"
"Posi ti vo, Posi ti vo Ypy AB10H, YPY_AB10H, Posi ti vo Ypy AB10H"
"Posi ti vo, Posi ti vo Ypy AB10i, Ypy_AB10i, Ypy AB10i "
"Posi ti vo, Posi ti vo Ypy AB7F, YPY_AB7F, Posi ti vo Ypy AB7F"
"Posi ti vo, Posi ti vo Ypy L700, YPY_L700, Posi ti vo Ypy L700"
"Posi ti vo, Posi ti vo Ypy L700, YPY_L700, Posi ti vo Ypy L700 Ed. Especi al "
"Posi ti vo, Posi ti vo Ypy L700, YPY_L700, Posi ti vo Ypy L700+ "
"Posi ti vo, Posi ti vo Ypy S350p, YPY_S350, YPY_S350_PLUS"
"Posi ti vo, Posi ti vo Ypy S405, YPY_S405, YPY_S405"
"Posi ti vo, Posi ti vo Ypy TQ7, YPY_TQ7, YPY_TQ7"
"Posi ti vo, Posi ti vo mi ni I, mi ni_i, Posi ti vo BGH Y300"
"Posi ti vo, Posi ti vo mi ni I, mi ni_i, Posi ti vo Mi ni I "
"Posi ti vo, Quantum Go, Q1, Quantum Go"
"Posi ti vo, Quantum Go, Q2, Quantum Go"
"Posi ti vo, S440, S440, S440"
"Posi ti vo, S480, S480, S480"
"Posi ti vo, YPY_10_3G, YPY_10FTA, YPY_10FTA"
"Posi ti vo, YPY_S400, YPY_S400, YPY_S400"
"Posi ti vo, Ypy, T701_AR, L701_TV"
"Posi ti vo, Ypy, YPY_L700, Posi ti vo BGH Ypy L700"
"Posi ti vo, Ypy AB10DP, YPY_AB10DP, YPY_AB10DP"
"Posi ti vo, Ypy AB10E, YPY_AB10E, Posi ti vo Ypy AB10E"
"Posi ti vo, Ypy AB7K, YPY_AB7K, YPY_AB7K"
"Posi ti vo, Ypy Ki ds, YPY_L700, Posi ti vo BGH Ypy L700 Ki ds"
"Posi ti vo, Ypy Ki ds, YPY_L700, Posi ti vo Ypy L700 Ki ds"
"Posi ti vo, Ypy Ki ds, YPY_L700, Posi ti vo Ypy L700+ Ki ds"
"Posi ti vo, Ypy L1000, YPY_L1000, Posi ti vo Ypy L1000"
"Posi ti vo, Ypy L1000, YPY_L1000, Posi ti vo Ypy L1000F"
"Posi ti vo, Ypy L1050, YPY_L1050, Posi ti vo Ypy L1050"
"Posi ti vo, Ypy L1050, YPY_L1050, Posi ti vo Ypy L1050F"
"Posi ti vo, Ypy L1050E, YPY_L1050E, Posi ti vo Ypy L1050E"
"Posi ti vo, Ypy Mi ni, mi ni, Posi ti vo BGH Mi ni "
"Posi ti vo, Ypy S350, YPY_S350, YPY_S350"
"Posi ti vo, Ypy S450, YPY_S450, YPY_S450"
"Posi ti vo, Ypy S460, YPY_S460, YPY_S460"
"Posi ti vo, Ypy S500, YPY_S500, YPY_S500"
"Presti ge, ELI TE10Q, El i te10Q, El i te10Q"
"Presti ge, ELI TE7Q, El i te7Q, El i te7Q"
"Presti ge, ELI TE8Q, ELI TE8Q, ELI TE8Q"
"Presti ge, ELI TE8QS, El i te8QS, El i te8QS"
"Presti ge, ELI TE9Q, ELI TE9Q, ELI TE9Q"
"Presti ge, PR07DS, PR07DS, PR07DS"
"Presti ge, PR08D, PR08D, PR08D"
"Presti ge, PR09D, PR09D, PR09D"
"Presti ge, Presti ge 7G, Presti ge-7G, Presti ge 7G"
"Presti ge, Presti ge PR010D, PR010D, PR010D"
"Presti gi o, GV7790, GV7790, GV7790"
"Presti gi o, Grace X3, PSP3455DU0, PSP3455DU0"
"Presti gi o, Grace X5, PSP5470DU0, PSP5470DU0"
"Presti gi o, Grace X7, PSP7505DU0, PSP7505DU0"
"Presti gi o, Mul ti Pad Thunder 7.0i, g01p, PMT3377_Wi "
"Presti gi o, Mul ti Pad Wi ze 3037 3G, PMT3038_3G, PMT3037_3G"
"Presti gi o, Mul ti Pad Wi ze 3038 3G, PMT3038_3G, PMT3038_3G"
"Presti gi o, Mul ti Phone 5453 DU0, PSP5453DU0, PSP5453DU0"
"Presti gi o, Mul ti Phone 5455 DU0, PSP5455DU0, PSP5455DU0"
"Presti gi o, Mul ti Phone 5504 DU0, PSP5504DU0, PSP5504DU0"
"Presti gi o, Mul ti Phone 5505 DU0, PSP5505DU0, PSP5505DU0"
"Presti gi o, Mul ti Phone 5517 DU0, PSP5517DU0, PSP5517DU0"
"Presti gi o, Mul ti phone 5508 DU0, PSP5508DU0, PSP5508DU0"
"Presti gi o, Muze A3, PSP3452DU0, PSP3452DU0"
"Presti gi o, PMT3008_Wi, PMT3008_Wi_C, PMT3008_Wi_C"
"Presti gi o, PMT3011_3G, PMT3011_3G, PMT3011_3G"
"Presti gi o, PMT3021_3G, PMT3011_3G, PMT3021_3G"

supported device.txt

"Prestigio, PMT3031_3G, PMT3011_3G, PMT3031_3G"
"Prestigio, PMT3047_3G, PMT3047_3G, PMT3047_3G"
"Prestigio, PMT3057_3G, PMT3057_3G, PMT3057_3G"
"Prestigio, PMT3067_3G, PMT3057_3G, PMT3067_3G"
"Prestigio, PMT3087_3G, PMT3057_3G, PMT3087_3G"
"Prestigio, PMT3177_3G, PMT3177_3G, PMT3177_3G"
"Prestigio, PMT3277_3G, PMT3277_3G, PMT3277_3G"
"Prestigio, PMT3287_3G, PMT3287_3G, PMT3287_3G"
"Prestigio, PMT3677_Wi, PMT3677, PMT3677_Wi "
"Prestigio, PMT5001_3G, PMT5001_3G, PMT5001_3G"
"Prestigio, PMT5002_Wi, PMT5002_Wi, PMT5002_Wi "
"Prestigio, PMT5008_3G, PMT5008_3G, PMT5008_3G"
"Prestigio, PMT5011_3G, PMT5001_3G, PMT5011_3G"
"Prestigio, PMT5018_3G, PMT5008_3G, PMT5018_3G"
"Prestigio, PMT5021_3G, PMT5001_3G, PMT5021_3G"
"Prestigio, PMT5287_4G, PMT5287_4G, PMT5287_4G"
"Prestigio, PMT5487_3G, PMT5487_3G, PMT5487_3G"
"Prestigio, PMT5777_3G, PMT5777_3G, PMT5777_3G"
"Prestigio, PMT5887_3G, PMT5887_3G, PMT5887_3G"
"Prestigio, PMT7008_4G, PMT7008_4G, PMT7008_4G"
"Prestigio, PMT7177_3G, PMT7177_3G, PMT7177_3G"
"Prestigio, PMT7287_3G, PMT7287_3G, PMT7287_3G"
"Prestigio, PMT7787_3G, PMT7787_3G, PMT7787_3G"
"Prestigio, PSP3404DUO, PSP3404DUO, PSP3404DUO"
"Prestigio, PSP3405DUO, PSP3405DUO, PSP3405DUO"
"Prestigio, PSP3450DUO, PSP3450DUO, PSP3450DUO"
"Prestigio, PSP3456DUO, PSP3456DUO, PSP3456DUO"
"Prestigio, PSP3502DUO, PSP3502DUO, PSP3502DUO"
"Prestigio, PSP3503DUO, PSP3503DUO, PSP3503DUO"
"Prestigio, PSP3505DUO, PSP3503DUO, PSP3505DUO"
"Prestigio, PSP3530DUO, DW53B01G, PSP3530DUO"
"Prestigio, PSP3531DUO, DW53B01G, PSP3531DUO"
"Prestigio, PSP5047DUO, MT6589, PSP5047DUO"
"Prestigio, PSP5454DUO, PSP5454DUO, PSP5454DUO"
"Prestigio, PSP5457DUO, MT6572, PSP5457DUO"
"Prestigio, PSP5507DUO, PSP5507DUO, PSP5507DUO"
"Prestigio, PSP5550DUO, PSP5550DUO, PSP5550DUO"
"Prestigio, Prestigio Grace, PSP7557, PSP7557"
"Prestigio, Prestigio Multi Pad Wi ze 3009, PMT3009_Wi_C, PMT3009_Wi_C"
"Prestigio, Prestigio Multi Pad Wi ze 3017, PMT3017_Wi, PMT3017_Wi "
"Prestigio, Prestigio Multi Pad Wi ze 3018, PMT3018_Wi, PMT3018_Wi "
"Prestigio, Prestigio PMT5587_Wi, AML8726-MXS, PMT5587_Wi "
"Prestigio, Prestigio PMT5877C, PMT5877C, PMT5877C"
"Prestigio, Prestigio PMT7077_3G, PMT7077_3G, PMT7077_3G"
"Prestigio, Prestigio PMT7287C3G, PMT7287C3G, PMT7287C3G"
"Prestigio, Prestigio PSP5307DUO, PSP5307DUO, PSP5307DUO"
"Prestigio, Prestigio WI ZE A3, PSP3453DUO, PSP3453DUO"
"Proscan, PLT1065G, PLT1065G, PLT1065G"
"Proscan, PLT1077G(1GB/8GB), PLT1077G, PLT1077G"
"Proscan, PLT1077G_16G, PLT1077G_16G, PLT1077G_16G"
"Proscan, PLT7100G, PLT7100G, PLT7100G"
"Proscan, PLT7109G, PLT7109G, PLT7109G"
"Proscan, PLT7130G, PLT7130G, PLT7130G"
"Proscan, PLT7602G, PLT7602G, PLT7602G"
"Proscan, PLT7649G, PLT7649G, PLT7649G"
"Proscan, PLT7803G, PLT7803G, PLT7803G"
"Proscan, PLT7804G, PLT7804G, PLT7804G"
"Proscan, PLT8802G, PLT8802G, PLT8802G"
"Proscan, PLT9602G, PLT9602G, PLT9602G"
"Proscan, PLT9606G, PLT9606G, PLT9606G"
"Proscan, PLT9609G, PLT9609G, PLT9609G"
"Proscan, PLT9649G, PLT9649G, PLT9649G"
"Proscan, PLT9650G, PLT9650G, PLT9650G"

supported device.txt

"Proscan, PROSCAN PLT8235G Tablet, MID807_K, PLT8235G"
"QLA, C600, GBC_bravo, C600"
"QMobi le, E8, GBL5805QM, E8"
"QMobi le, LT700, GBL7325QM, LT700"
"QMobi le, Qmobi le L20, L20, QMobi le L20"
"QMobi le, X75, WBW5613QM, X75"
"QMobi le, Z10, Z10, QMobi le Z10"
"Q00Q, Q00QV3, Q00Q, Q00Q"
"Qi li ve, Q. 3778, Q3778, Q. 3778"
"Qi li ve, Qi li ve W55, W55, W55"
"Quanta, , Ni rvana_Tablet, Ni rvana_Tablet"
"Quanta, , i nfi ni ty_g, INFINI TY G NK2"
"Quanta, , nk1, IGS-1000"
"Quanta, , nk1, TA1013"
"Quanta, , ventana, NK1_111018_002_HC"
"Quanta, , ventana, Q10"
"Quanta, CT2200, CT2200, CT2200"
"Quanta, FT103, FT103, FT103"
"Quanta, True Beyond 4G, a17, TRUE BEYOND 4G"
"Quanta, VSD220, VSD220, VSD220"
"RAI NBOW, WI KO, s5501, RAI NBOW"
"RCA, 10 Vi ki ng Pro, RCT6303W87DK, RCT6303W87DK"
"RCA, 11 Maven Pro, RCT6213W87DK, RCT6213W87DK"
"RCA, 7 Voyager II, RCT6773W22B, RCT6773W22B"
"RCA, BNT-710, BNT-710, BNT-710"
"RCA, Pro10 Edi ti on II, RCT6203W46L, RCT6203W46L"
"RCA, RCA DAA730R / RCA DAA738R, MD7081, DAA730R"
"RCA, RCA DAA730R / RCA DAA738R, MD7081, DAA738R"
"RCA, RCA RCS13101T, RCS13101T, RCS13101T"
"RCA, RCA RCT6077W2, RCT6077W2, RCT6077W2"
"RCA, RCA RCT6077W22, RCT6077W22, RCT6077W22"
"RCA, RCA RCT6272W23, RCT6272W23, RCT6272W23"
"RCA, RCA RCT6378W2, RCT6378W2, RCT6378W2"
"RCA, RCA RCT6691W3, RCT6691W3, RCT6691W3"
"RCA, RCT6002W46, RCT6002W46, RCT6002W46"
"RCA, RCT6103W46, RCT6103W46, RCT6103W46"
"RCA, RCT6203W46, RCT6203W46, RCT6203W46"
"RCA, RCT6273W26, RCT6273W26, RCT6273W26"
"RCA, RCT6293W23, RCT6293W23, RCT6293W23"
"RCA, RCT6573W23, RCT6573W23, RCT6573W23"
"RCA, RCT6672W23, RCT6672W23, RCT6672W23"
"RCA, RCT6773W22, RCT6773W22, RCT6773W22"
"RCA, RCT6773W42B, RCT6773W42B, RCT6773W42B"
"REACH, Q882, Q882, Q882"
"Razer, Forge TV, pearl yn, Forge"
"Revtel , R45, Revel _R45, R45"
"Royal tek, FGAD, FGAD, FGAD"
"SAKAI SI O, SAKAI SI O FP-U320-711-WI FI , U320-WF, FP-U320-711-WI FI "
"SAKAI SI O, SAKAI SI O FP-U320-711-WWAN, U320-3G, FP-U320-711-WWAN"
"SELECLI NE, MI D7526CM, MI D7526CM, NI D_7010"
"SELECLI NE, MI D_9526CM, MI D_9526CM, S952"
"SENSEIT, SENSEIT L301, SENSEIT-L301, SENSEIT L301"
"SFR, SFR-G8800, stb_dvb_sfr, SFR-G8800"
"SFR, STARADDI CT 4, staraddi ct4, STARADDI CT 4"
"SFR, Star Shi ne II, up11_sfr_mensa, STARSHI NE II "
"SFR, Star Trail 5, STARTRAI L5, STARTRAI L5"
"SFR, Star Trail 6, STARTRAI L6, STARTRAI L6"
"SFR, Star Trail III, mobi wi re_startrail3, StarTrail III"
"SK Broadband, B tv smart, BHX-S100, BHX-S100"
"SK Broadband, B tv smart, BKO-S200, BKO-S200"
"SK Tel esys, , K4, SK-S170"
"SK Tel esys, , msm8255_k5, SK-S150"
"SK Tel esys, , qsd8250_s1, SK-S100"

supported device.txt

"SK Tel esys, AN200, AN200, AN200"
"SK Tel esys, Fly, htt77_i cs2, Fly"
"SK Tel esys, ITP-E410W, wi l l ow, ITP-E410W"
"SK Tel esys, ITP-R208W, rk30sdk, ITP-R208W"
"SK Tel esys, Ice-Phone Forever, z262_wvga_mge, Ice-Phone Forever"
"SK Tel esys, K2401, K2401, S201"
"SK Tel esys, S150, msm8255_k5, S150"
"SK Tel esys, T720, T720, Cl ear"
"SK Tel esys, UTA200, htt75_nand_6628_i cs, UTA200"
"SK Tel esys, i cube-830, i cube-830, i cube-830"
"SKnetworks, EG68BE, EG668BE, EG668"
"SKnetworks, EG978TW, EG978TW, EG978"
"SKnetworks, EG980, eg980tw, EG980"
"SKnetworks, WA966, u966e_2, WA966"
"SKnetworks, WA978, u978e_1, WA978"
"SMARTAB, SMARTAB ST700, ST700, ST700"
"SOSMART, SOSMART T5, SOSMART_T5, SOSMART_T5"
"STOREX, eZee\ Tab7Q11-M, Tab7Q11, Tab7Q11"
"STOREX, eZee\ xe2\x80\x99Tab7D14-S, STOREX7526, NI D_7010"
"Sal ti l l o, CF10, CF10, CF10"
"Samsung, , GT-I 5510M, GT-I 5510M"
"Samsung, , GT-I 5510T, GT-I 5510T"
"Samsung, , GT-I 5800L, GT-I 5800L"
"Samsung, , GT-N7000B, GT-N7000B"
"Samsung, , GT-P7300B, GT-P7300B"
"Samsung, , GT-P7320T, GT-P7320T"
"Samsung, , GT-P7500M, GT-P7500M"
"Samsung, , GT-P7500R, GT-P7500R"
"Samsung, , GT-P7500V, GT-P7500V"
"Samsung, , GT-S5698, GT-S5698"
"Samsung, , GT-S5820, GT-S5820"
"Samsung, , GT-S5830V, GT-S5830V"
"Samsung, , SCH-I 339, SCH-I 339"
"Samsung, , SCH-I 405U, SCH-I 405U"
"Samsung, , SCH-I 509U, SCH-I 509U"
"Samsung, , SCH-I 519, SCH-I 519"
"Samsung, , SCH-I 559, SCH-I 559"
"Samsung, , SCH-I 559, SCH-i 559"
"Samsung, , SCH-I 639, SCH-I 639"
"Samsung, , SCH-I 659, SCH-I 659"
"Samsung, , SCH-I 699, SCH-I 699"
"Samsung, , SCH-I 779, SCH-I 779"
"Samsung, , SCH-I 919U, SCH-I 919U"
"Samsung, , SCH-W899, SCH-W899"
"Samsung, , SCH-W999, SCH-W999"
"Samsung, , SCH-i 809, SCH-i 809"
"Samsung, , SCH-i 919, SCH-i 919"
"Samsung, , SGH-I 987, SGH-I 987"
"Samsung, , SGH_T939, Behol d I I "
"Samsung, , SHV-E150S, SHV-E150S"
"Samsung, , SHW-M115S, SHW-M115S"
"Samsung, , SHW-M135K, SHW-M135K"
"Samsung, , SHW-M135L, SHW-M135L"
"Samsung, , SHW-M340D, SHW-M340D"
"Samsung, , SHW-M340K, SHW-M340K"
"Samsung, , SHW-M460D, SHW-M460D"
"Samsung, , amazi ngtrf, SGH-S730G"
"Samsung, , aruba3gchn, GT-I 8262D"
"Samsung, , espressorfcmcc, GT-P3108"
"Samsung, , gd1l tektt, EK-KC120K"
"Samsung, , godi val tevw, SCH-I 425"
"Samsung, , i roncmcc, GT-B9388"
"Samsung, , m0grandectc, SCH-W2013"

supported device.txt

"Samsung, , m0grandectc, SCH-W9913"
"Samsung, , p4noterfskt, SHW-M480S"
"Samsung, , stunnerl tespr, SPH-L500"
"Samsung, , superi orchn, GT-I 9260"
"Samsung, Absol ute, GT-B9120, GT-B9120"
"Samsung, Accl ai m, SCH-R880, SCH-R880"
"Samsung, Admi re, SCH-R720, SCH-R720"
"Samsung, Amazi ng, amazi ngtrf, SGH-S730M"
"Samsung, Baffi n, baffi nl tel gt, SHV-E270L"
"Samsung, Capti vate Gl i de, SGH-I 927, SAMSUNG-SGH-I 927"
"Samsung, Capti vate Gl i de, SGH-I 927, SGH-I 927"
"Samsung, Chi na Tel ecom, kyl evecctc, SCH-I 699I "
"Samsung, Conquer, SPH-D600, SPH-D600"
"Samsung, Doubl eTi me, SGH-I 857, SAMSUNG-SGH-I 857"
"Samsung, Droï d Charge, SCH-I 510, SCH-I 510"
"Samsung, Europa, GT-I 5500B, GT-I 5500B"
"Samsung, Europa, GT-I 5500L, GT-I 5500L"
"Samsung, Europa, GT-I 5500M, GT-I 5500M"
"Samsung, Europa, GT-I 5503T, GT-I 5503T"
"Samsung, Europa, GT-I 5510L, GT-I 5510L"
"Samsung, Exhi bi t, SGH-T759, SGH-T759"
"Samsung, GALAXY Camera, gd1, EK-GC100"
"Samsung, Gal axy (Chi na), GT-B9062, GT-B9062"
"Samsung, Gal axy 070, hendri x, YP-GI 2"
"Samsung, Gal axy A, archer, SHW-M100S"
"Samsung, Gal axy A, archer, archer"
"Samsung, Gal axy A3, a33g, SM-A300H"
"Samsung, Gal axy A3, a3l te, SM-A300F"
"Samsung, Gal axy A3, a3l te, SM-A300M"
"Samsung, Gal axy A3, a3l te, SM-A300XZ"
"Samsung, Gal axy A3, a3l te, SM-A300YZ"
"Samsung, Gal axy A3, a3l techn, SM-A3000"
"Samsung, Gal axy A3, a3l techn, SM-A300X"
"Samsung, Gal axy A3, a3l tectc, SM-A3009"
"Samsung, Gal axy A3, a3l tedd, SM-A300G"
"Samsung, Gal axy A3, a3l tesl k, SM-A300F"
"Samsung, Gal axy A3, a3l tezh, SM-A3000"
"Samsung, Gal axy A3, a3l tezt, SM-A300YZ"
"Samsung, Gal axy A3, a3ul te, SM-A300FU"
"Samsung, Gal axy A3, a3ul te, SM-A300XU"
"Samsung, Gal axy A3, a3ul te, SM-A300Y"
"Samsung, Gal axy A5, a53g, SM-A500H"
"Samsung, Gal axy A5, a5l te, SM-A500F"
"Samsung, Gal axy A5, a5l te, SM-A500G"
"Samsung, Gal axy A5, a5l te, SM-A500M"
"Samsung, Gal axy A5, a5l te, SM-A500XZ"
"Samsung, Gal axy A5, a5l techn, SM-A5000"
"Samsung, Gal axy A5, a5l techn, SM-A500X"
"Samsung, Gal axy A5, a5l tectc, SM-A5009"
"Samsung, Gal axy A5, a5l tezh, SM-A5000"
"Samsung, Gal axy A5, a5l tezt, SM-A500YZ"
"Samsung, Gal axy A5, a5ul te, SM-A500FU"
"Samsung, Gal axy A5, a5ul te, SM-A500Y"
"Samsung, Gal axy A5, a5ul tektt, SM-A500K"
"Samsung, Gal axy A5, a5ul tel gt, SM-A500L"
"Samsung, Gal axy A5, a5ul teskt, SM-A500F1"
"Samsung, Gal axy A5, a5ul teskt, SM-A500S"
"Samsung, Gal axy A7, a73g, SM-A700H"
"Samsung, Gal axy A7, a7al te, SM-A700F"
"Samsung, Gal axy A7, a7l te, SM-A700FD"
"Samsung, Gal axy A7, a7l te, SM-A700X"
"Samsung, Gal axy A7, a7l techn, SM-A7000"
"Samsung, Gal axy A7, a7l techn, SM-A700YD"

supported device.txt

"Samsung, Gal axy A7, a7l tectc, SM-A7009"
 "Samsung, Gal axy A7, a7l tektt, SM-A700K"
 "Samsung, Gal axy A7, a7l tel gt, SM-A700L"
 "Samsung, Gal axy A7, a7l teskt, SM-A700S"
 "Samsung, Gal axy A8, a8el te, SM-A800F"
 "Samsung, Gal axy A8, a8el te, SM-A800YZ"
 "Samsung, Gal axy A8, a8el teskt, SM-A800S"
 "Samsung, Gal axy A8, a8hpl te, SM-A800I "
 "Samsung, Gal axy A8, a8l techn, SM-A8000"
 "Samsung, Gal axy A8, a8l techn, SM-A800X"
 "Samsung, Gal axy Ace, GT-S5830, GT-S5830"
 "Samsung, Gal axy Ace, GT-S5830B, GT-S5830B"
 "Samsung, Gal axy Ace, GT-S5830C, GT-S5830C"
 "Samsung, Gal axy Ace, GT-S5830D, GT-S5830D"
 "Samsung, Gal axy Ace, GT-S5830F, GT-S5830F"
 "Samsung, Gal axy Ace, GT-S5830G, GT-S5830G"
 "Samsung, Gal axy Ace, GT-S5830L, GT-S5830L"
 "Samsung, Gal axy Ace, GT-S5830M, GT-S5830M"
 "Samsung, Gal axy Ace, GT-S5830T, GT-S5830T"
 "Samsung, Gal axy Ace, GT-S5830i , GT-S5830i "
 "Samsung, Gal axy Ace, GT-S5831i , GT-S5831i "
 "Samsung, Gal axy Ace, GT-S5838, GT-S5838"
 "Samsung, Gal axy Ace, GT-S5839i , GT-S5839i "
 "Samsung, Gal axy Ace, GT-S6358, GT-S6358"
 "Samsung, Gal axy Ace, SCH-I 619, SCH-I 619"
 "Samsung, Gal axy Ace, SHW-M240S, SHW-M240S"
 "Samsung, Gal axy Ace, heat3gou, SM-G310R5"
 "Samsung, Gal axy Ace, heatl te, SM-G357M"
 "Samsung, Gal axy Ace 4, vi val tods5m, SM-G313HU"
 "Samsung, Gal axy Ace 4, vi val tods5m, SM-G313HY"
 "Samsung, Gal axy Ace 4, vi val tods5m, SM-G313M"
 "Samsung, Gal axy Ace 4, vi val tods5m, SM-G313MY"
 "Samsung, Gal axy Ace 4 Li te, vi val to3g, SM-G313U"
 "Samsung, Gal axy Ace Advance, GT-S6800, GT-S6800"
 "Samsung, Gal axy Ace Duos, GT-S6352, GT-S6352"
 "Samsung, Gal axy Ace Duos, GT-S6802, GT-S6802"
 "Samsung, Gal axy Ace Duos, GT-S6802B, GT-S6802B"
 "Samsung, Gal axy Ace Duos, SCH-I 579, SCH-i 579"
 "Samsung, Gal axy Ace Duos, SCH-I 589, SCH-I 589"
 "Samsung, Gal axy Ace Duos, SCH-I 589, SCH-i 589"
 "Samsung, Gal axy Ace Duos, SCH-i 579, SCH-i 579"
 "Samsung, Gal axy Ace Duos, SCH-i 589, SCH-i 589"
 "Samsung, Gal axy Ace Pl us, GT-S7500, GT-S7500"
 "Samsung, Gal axy Ace Pl us, GT-S7500L, GT-S7500L"
 "Samsung, Gal axy Ace Pl us, GT-S7500T, GT-S7500T"
 "Samsung, Gal axy Ace Pl us, GT-S7500W, GT-S7500W"
 "Samsung, Gal axy Ace Pl us, GT-S7508, GT-S7508"
 "Samsung, Gal axy Ace Q, SGH-I 827D, SGH-I 827D"
 "Samsung, Gal axy Ace Styl e, heat3gtfnvzw, SM-S765C"
 "Samsung, Gal axy Ace Styl e, heat3gtfnvzw, SM-S766C"
 "Samsung, Gal axy Ace Styl e, heatnfc3g, SM-G310HN"
 "Samsung, Gal axy Ace Styl e, heatql te, SM-G357FZ"
 "Samsung, Gal axy Ace2, GT-I 8160, GT-I 8160"
 "Samsung, Gal axy Ace2, GT-I 8160L, GT-I 8160L"
 "Samsung, Gal axy Ace2, GT-I 8160P, GT-I 8160P"
 "Samsung, Gal axy Ace2 X, kyl essopen, GT-S7560"
 "Samsung, Gal axy Ace2 X, kyl essopen, GT-S7560M"
 "Samsung, Gal axy Ace3, l ogan, GT-S7270"
 "Samsung, Gal axy Ace3, l ogan, GT-S7270L"
 "Samsung, Gal axy Ace3, l ogan, SCH-I 679"
 "Samsung, Gal axy Ace3, l ogan3gcmcc, GT-S7278"
 "Samsung, Gal axy Ace3, l ogands, GT-S7272"
 "Samsung, Gal axy Ace3, l oganl te, GT-S7275"

supported device.txt

"Samsung, Gal axy Ace3, Ioganrel te, GT-S7275B"
 "Samsung, Gal axy Ace3, Ioganrel te, GT-S7275R"
 "Samsung, Gal axy Ace3, Ioganrel te, GT-S7275T"
 "Samsung, Gal axy Ace3, Ioganrel te, GT-S7275Y"
 "Samsung, Gal axy Ace3 Duos, Ioganl i te3g, GT-S7272C"
 "Samsung, Gal axy Ace3 Duos, Ioganu3gcmcc, GT-S7278U"
 "Samsung, Gal axy Ace3 Duos TV, Iogandsdtv, GT-S7273T"
 "Samsung, Gal axy Ace4, vi val to3g, SM-G313ML"
 "Samsung, Gal axy Ace4, vi val to3mve3g, SM-G316H"
 "Samsung, Gal axy Ace4, vi val to5mve3g, SM-G316HU"
 "Samsung, Gal axy Ace4, vi val to5mve3g, SM-G316M"
 "Samsung, Gal axy Ace4, vi val to5mve3g, SM-G316MY"
 "Samsung, Gal axy Ace4, vi val tol te, SM-G313F"
 "Samsung, Gal axy Ace4, vi val tol te, SM-G313MU"
 "Samsung, Gal axy Ace4, vi val tonfc3g, SM-G313HN"
 "Samsung, Gal axy Ace4 Li te, vi val to, SM-G3139D"
 "Samsung, Gal axy Ace4 Li te, vi val to3g, SM-G313H"
 "Samsung, Gal axy Ace4 Li te, vi val to3mve3gl tn, SM-G316U"
 "Samsung, Gal axy Ace4 Li te, vi val to3mveml 3g, SM-G318H"
 "Samsung, Gal axy Ace4 Li te, vi val to3mveml 3g, SM-G318ML"
 "Samsung, Gal axy Ace4 Li te, vi val to3mveml 3gsea, SM-G318HZ"
 "Samsung, Gal axy Ace4 Li te, vi val to3mveml 3gsea, SM-G318MZ"
 "Samsung, Gal axy Ace4 Neo, vi val to3mve3gl tn, SM-G316ML"
 "Samsung, Gal axy Admi re, SCH-R820, SCH-R820"
 "Samsung, Gal axy Admi re 2, goghcric, SCH-R830C"
 "Samsung, Gal axy Al pha, sl te, SM-G850F"
 "Samsung, Gal axy Al pha, sl te, SM-G850FQ"
 "Samsung, Gal axy Al pha, sl te, SM-G850M"
 "Samsung, Gal axy Al pha, sl te, SM-G850X"
 "Samsung, Gal axy Al pha, sl te, SM-G850Y"
 "Samsung, Gal axy Al pha, sl teatt, SAMSUNG-SM-G850A"
 "Samsung, Gal axy Al pha, sl tecan, SM-G850W"
 "Samsung, Gal axy Al pha, sl techn, SM-G8508S"
 "Samsung, Gal axy Al pha, sl tektt, SM-G850K"
 "Samsung, Gal axy Al pha, sl tel gt, SM-G850L"
 "Samsung, Gal axy Al pha, sl teskt, SM-G850S"
 "Samsung, Gal axy Amp, kyl eatt, SAMSUNG-SGH-I 407"
 "Samsung, Gal axy Apol lo, GT-I 5800, GT-I 5800"
 "Samsung, Gal axy Apol lo, GT-I 5800, GT-I 5800L"
 "Samsung, Gal axy Apol lo, GT-I 5800D, GT-I 5800D"
 "Samsung, Gal axy Apol lo, GT-I 5801, GT-I 5801"
 "Samsung, Gal axy Appeal, SGH-I 827, SAMSUNG-SGH-I 827"
 "Samsung, Gal axy Attai n, SCH-R920, SCH-R920"
 "Samsung, Gal axy Avant, afyonl tetmo, SM-G386T"
 "Samsung, Gal axy Axi om, i nfi ni teusc, SCH-R830"
 "Samsung, Gal axy Beam, GT-I 8250, GT-I 8250"
 "Samsung, Gal axy Beam, GT-I 8530, GT-I 8530"
 "Samsung, Gal axy Camera, gd1, EK-GC100"
 "Samsung, Gal axy Camera, gd1att, SAMSUNG-EK-GC100"
 "Samsung, Gal axy Camera, gd1can, EK-GC100"
 "Samsung, Gal axy Camera, gd1ktt, EK-KC100K"
 "Samsung, Gal axy Camera, gd1l tel gt, EK-KC120L"
 "Samsung, Gal axy Camera, gd1l teskt, EK-KC120S"
 "Samsung, Gal axy Camera, gd1l tevw, EK-GC120"
 "Samsung, Gal axy Camera, gd1skt, EK-KC100S"
 "Samsung, Gal axy Camera, gd1wi fi, EK-GC110"
 "Samsung, Gal axy Camera, gd1wi fi any, EK-GC110"
 "Samsung, Gal axy Camera, uOl te, EK-GN100"
 "Samsung, Gal axy Camera, uOl te, EK-GN120"
 "Samsung, Gal axy Camera 2, sf2wi fi, EK-GC200"
 "Samsung, Gal axy Centura, amazi ng3gtrf, SCH-S738C"
 "Samsung, Gal axy Chat, zani n, GT-B5330"
 "Samsung, Gal axy Chat, zani n, GT-B5330B"

supported device.txt

"Samsung, Gal axy Chat, zani n, GT-B5330L"
 "Samsung, Gal axy Core, afyonl teMetroPCS, SM-G386T1"
 "Samsung, Gal axy Core, afyonl tecan, SM-G386W"
 "Samsung, Gal axy Core, arubasl i m, GT-I 8262"
 "Samsung, Gal axy Core, arubasl i mss, GT-I 8260"
 "Samsung, Gal axy Core, arubasl i mss, GT-I 8260L"
 "Samsung, Gal axy Core 2, kanas, SM-G355H"
 "Samsung, Gal axy Core Advance, cane3g, GT-I 8580"
 "Samsung, Gal axy Core Advance, cane3gskt, SHW-M570S"
 "Samsung, Gal axy Core LTE, afyonl te, SM-G386F"
 "Samsung, Gal axy Core LTE, cs03l te, SM-G3518"
 "Samsung, Gal axy Core Li te, vi ctorl te, SM-G3586V"
 "Samsung, Gal axy Core Li te, vi ctorl te, SM-G3589W"
 "Samsung, Gal axy Core Max, kl eosl te, SM-G5108"
 "Samsung, Gal axy Core Max Duos, kl eosl te, SM-G5108Q"
 "Samsung, Gal axy Core Pl us, cs02, SM-G350"
 "Samsung, Gal axy Core Pl us, cs023g, SM-G3502"
 "Samsung, Gal axy Core Pl us, cs02ve3g, SM-G3502L"
 "Samsung, Gal axy Core Pl us, cs02ve3gdtv, SM-G3502T"
 "Samsung, Gal axy Core Pl us, cs02ve3gss, SM-G350L"
 "Samsung, Gal axy Core Pl us, cs02ve3gss, SM-G350M"
 "Samsung, Gal axy Core Pri me, core33g, SM-G360H"
 "Samsung, Gal axy Core Pri me, core33g, SM-G360HU"
 "Samsung, Gal axy Core Pri me, corepri mel te, SM-G360F"
 "Samsung, Gal axy Core Pri me, corepri mel te, SM-G360FY"
 "Samsung, Gal axy Core Pri me, corepri mel te, SM-G360M"
 "Samsung, Gal axy Core Pri me, corepri mel teai o, SAMSUNG-SM-G360AZ"
 "Samsung, Gal axy Core Pri me, corepri mel tel ra, SM-G360R6"
 "Samsung, Gal axy Core Pri me, corepri mel tespr, SM-G360P"
 "Samsung, Gal axy Core Pri me, corepri mel tetfnvzw, SM-S820L"
 "Samsung, Gal axy Core Pri me, corepri mel tevzw, SM-G360V"
 "Samsung, Gal axy Core Pri me, corepri meve3g, SM-G361H"
 "Samsung, Gal axy Core Pri me, corepri meve3g, SM-G361HU"
 "Samsung, Gal axy Core Pri me, corepri mel te, SM-G361F"
 "Samsung, Gal axy Core Pri me, corepri mel te, SM-G361M"
 "Samsung, Gal axy Core Pri me, cpri mel temtr, SM-G360T1"
 "Samsung, Gal axy Core Pri me, cpri mel tetmo, SM-G360T"
 "Samsung, Gal axy Core Pri me, rossal te, SM-G3606"
 "Samsung, Gal axy Core Pri me, rossal te, SM-G3608"
 "Samsung, Gal axy Core Pri me, rossal tectc, SM-G3609"
 "Samsung, Gal axy Core Pri me, rossal texsa, SM-G360GY"
 "Samsung, Gal axy Core Safe, arubasl i mss, GT-I 8260E"
 "Samsung, Gal axy Core Safe, arubasl i mss, SHW-M580D"
 "Samsung, Gal axy Core Safe, arubasl i mss, SHW-M585D"
 "Samsung, Gal axy Core2, kanas, SM-G355H"
 "Samsung, Gal axy Core2, kanas, SM-G355HQ"
 "Samsung, Gal axy Core2, kanas, SM-G355M"
 "Samsung, Gal axy Core2, kanas3g, SM-G3556D"
 "Samsung, Gal axy Core2, kanas3gcmcc, SM-G3558"
 "Samsung, Gal axy Core2, kanas3gctc, SM-G3559"
 "Samsung, Gal axy Core2, kanas3gnfc, SM-G355HN"
 "Samsung, Gal axy Di scover, amazi ng3gcric, SCH-R740C"
 "Samsung, Gal axy Di scover, amazi ngtrfcd, SCH-S735C"
 "Samsung, Gal axy Duos, aruba3gcmcc, GT-I 8268"
 "Samsung, Gal axy E5, e53g, SM-E500H"
 "Samsung, Gal axy E5, e5l te, SM-E500F"
 "Samsung, Gal axy E5, e5l te, SM-E500M"
 "Samsung, Gal axy E5, e5l tetfnvzw, SM-S978L"
 "Samsung, Gal axy E5, e5l tetw, SM-E500YZ"
 "Samsung, Gal axy E7, e73g, SM-E700H"
 "Samsung, Gal axy E7, e7l te, SM-E700F"
 "Samsung, Gal axy E7, e7l te, SM-E700M"
 "Samsung, Gal axy E7, e7l techn, SM-E7000"

supported device.txt

"Samsung, Gal axy E7, e7I tectc, SM-E7009"
"Samsung, Gal axy E7, e7I tehktw, SM-E7000"
"Samsung, Gal axy Europa, GT-I 5500, GT-I 5500"
"Samsung, Gal axy Europa, GT-I 5503, GT-I 5503"
"Samsung, Gal axy Europa, GT-I 5508, GT-I 5508"
"Samsung, Gal axy Europa, GT-I 5510, GT-I 5510"
"Samsung, Gal axy Exhi bi t, codi naMetroPCS, SGH-T599N"
"Samsung, Gal axy Exhi bi t, codi natmo, SGH-T599"
"Samsung, Gal axy Exhi bi t, codi navi d, SGH-T599V"
"Samsung, Gal axy Exhi bi t2, SGH-T679, SGH-T679"
"Samsung, Gal axy Exhi l arate, SGH-I 577, SAMSUNG-SGH-I 577"
"Samsung, Gal axy Express, expressatt, SAMSUNG-SGH-I 437"
"Samsung, Gal axy Express, expressatt, SAMSUNG-SGH-I 437P"
"Samsung, Gal axy Express, expressl te, GT-I 8730"
"Samsung, Gal axy Express, expressl te, GT-I 8730T"
"Samsung, Gal axy Express, expresszi gl teatt, SAMSUNG-SGH-I 437Z"
"Samsung, Gal axy Express2, wi l coxl te, SM-G3815"
"Samsung, Gal axy Fame, SCH-I 629, SCH-I 629"
"Samsung, Gal axy Fame, nevi s, GT-S6810"
"Samsung, Gal axy Fame, nevi s, GT-S6810B"
"Samsung, Gal axy Fame, nevi s, GT-S6810E"
"Samsung, Gal axy Fame, nevi s, GT-S6810L"
"Samsung, Gal axy Fame, nevi s3g, GT-S6812i "
"Samsung, Gal axy Fame, nevi s3gcmcc, GT-S6818"
"Samsung, Gal axy Fame, nevi s3gcmcc, GT-S6818V"
"Samsung, Gal axy Fame, nevi sds, GT-S6812"
"Samsung, Gal axy Fame, nevi sds, GT-S6812B"
"Samsung, Gal axy Fame, nevi snvess, GT-S6790N"
"Samsung, Gal axy Fame, nevi sp, GT-S6810M"
"Samsung, Gal axy Fame, nevi sp, GT-S6810P"
"Samsung, Gal axy Fame, nevi svess, GT-S6790"
"Samsung, Gal axy Fame, nevi svess, GT-S6790E"
"Samsung, Gal axy Fame, nevi svess, GT-S6790L"
"Samsung, Gal axy Fame, nevi sw, GT-S6812C"
"Samsung, Gal axy Fame Li te Duos, nevi sw, GT-S6792L"
"Samsung, Gal axy Fi t, GT-S5670, GT-S5670"
"Samsung, Gal axy Fi t, GT-S5670B, GT-S5670B"
"Samsung, Gal axy Fi t, GT-S5670L, GT-S5670L"
"Samsung, Gal axy Fol der, novel 3gskt, SM-G155S"
"Samsung, Gal axy Fol der, novel l tektt, SM-G150NK"
"Samsung, Gal axy Fol der, novel l tekx, SM-G150NO"
"Samsung, Gal axy Fol der, novel l tel gt, SM-G150NL"
"Samsung, Gal axy Fol der, novel l teskt, SM-G150NS"
"Samsung, Gal axy Fresh, kyl evess, GT-S7390"
"Samsung, Gal axy Fresh, kyl evess, GT-S7390E"
"Samsung, Gal axy Fresh, kyl evess, GT-S7390G"
"Samsung, Gal axy Gi o, GT-S5660, GT-S5660"
"Samsung, Gal axy Gi o, GT-S5660B, GT-S5660B"
"Samsung, Gal axy Gi o, GT-S5660L, GT-S5660L"
"Samsung, Gal axy Gi o, GT-S5660M, GT-S5660M"
"Samsung, Gal axy Gi o, GT-S5660V, GT-S5660V"
"Samsung, Gal axy Gi o, SCH-i 569, SCH-i 569"
"Samsung, Gal axy Gi o, SHW-M290K, SHW-M290K"
"Samsung, Gal axy Gi o, SHW-M290S, SHW-M290S"
"Samsung, Gal axy Gol den, ks02I te, GT-I 9230"
"Samsung, Gal axy Gol den, ks02I te, GT-I 9235"
"Samsung, Gal axy Gol den, ks02I tektt, SHV-E400K"
"Samsung, Gal axy Gol den, ks02I teskt, SHV-E400S"
"Samsung, Gal axy Gol den 2, patekl te, SM-W2015"
"Samsung, Gal axy Grand, baffi n3gduosctc, SCH-I 879"
"Samsung, Gal axy Grand, baffi ncmcc, GT-I 9128"
"Samsung, Gal axy Grand, baffi ncmcc, GT-I 9128V"
"Samsung, Gal axy Grand, baffi nl tektt, SHV-E270K"

supported device.txt

"Samsung, Gal axy Grand, baffi nl teskt, SHV-E270S"
 "Samsung, Gal axy Grand, baffi nrd, GT-I 9118"
 "Samsung, Gal axy Grand, baffi nss, GT-I 9080E"
 "Samsung, Gal axy Grand, baffi nss, GT-I 9080L"
 "Samsung, Gal axy Grand, baffi nvekt, SHV-E275K"
 "Samsung, Gal axy Grand, baffi nveskt, SHV-E275S"
 "Samsung, Gal axy Grand, baffi nvtd3g, GT-I 9128E"
 "Samsung, Gal axy Grand, baffi nvtd3g, GT-I 9128I "
 "Samsung, Gal axy Grand Duos, baffi n, GT-I 9082"
 "Samsung, Gal axy Grand Duos, baffi n, GT-I 9082L"
 "Samsung, Gal axy Grand Max, grandmax3g, SM-G7202"
 "Samsung, Gal axy Grand Max, grandmaxl techn, SM-G7200"
 "Samsung, Gal axy Grand Max, grandmaxl techn, SM-G720AX"
 "Samsung, Gal axy Grand Neo, baffi nl i te, GT-I 9060"
 "Samsung, Gal axy Grand Neo, baffi nl i te, GT-I 9060L"
 "Samsung, Gal axy Grand Neo, baffi nl i te, GT-I 9082C"
 "Samsung, Gal axy Grand Neo, baffi nl i tedtv, GT-I 9063T"
 "Samsung, Gal axy Grand Neo, baffi nq3g, GT-I 9168"
 "Samsung, Gal axy Grand Neo, baffi nq3g, GT-I 9168I "
 "Samsung, Gal axy Grand Neo Plus, grandneove3g, GT-I 9060C"
 "Samsung, Gal axy Grand Neo Plus, grandneove3g, GT-I 9060I "
 "Samsung, Gal axy Grand Neo Plus, grandneove3g, GT-I 9060M"
 "Samsung, Gal axy Grand Neo+, baffi nq3gduosctc, SCH-I 879E"
 "Samsung, Gal axy Grand Pri me, fortuna3g, SM-G530H"
 "Samsung, Gal axy Grand Pri me, fortuna3gdtv, SM-G530BT"
 "Samsung, Gal axy Grand Pri me, fortunale, SM-G5306W"
 "Samsung, Gal axy Grand Pri me, fortunale, SM-G5308W"
 "Samsung, Gal axy Grand Pri me, fortunale, SM-G530F"
 "Samsung, Gal axy Grand Pri me, fortunale, SM-G530M"
 "Samsung, Gal axy Grand Pri me, fortunale tectc, SM-G5309W"
 "Samsung, Gal axy Grand Pri me, fortunale tezh, SM-G5308W"
 "Samsung, Gal axy Grand Pri me, fortunale tezt, SM-G530MU"
 "Samsung, Gal axy Grand Pri me, fortunale tezt, SM-G530Y"
 "Samsung, Gal axy Grand Pri me, gpri mel teacg, SM-G530R7"
 "Samsung, Gal axy Grand Pri me, gpri mel teacg, gpri mel teacg"
 "Samsung, Gal axy Grand Pri me, gpri mel tecan, SM-G530W"
 "Samsung, Gal axy Grand Pri me, gpri mel temtr, SM-G530T1"
 "Samsung, Gal axy Grand Pri me, gpri mel tespr, SM-G530P"
 "Samsung, Gal axy Grand Pri me, gpri mel tetfnvzw, SM-S920L"
 "Samsung, Gal axy Grand Pri me, gpri mel tetmo, SM-G530T"
 "Samsung, Gal axy Grand Pri me, gpri mel teusc, SM-G530R4"
 "Samsung, Gal axy Grand Pri me, grandpri mel te, SM-G530FZ"
 "Samsung, Gal axy Grand Pri me, grandpri mel teai o, SAMSUNG-SM-G530AZ"
 "Samsung, Gal axy Grand Pri me, grandpri meve3g, SM-G531H"
 "Samsung, Gal axy Grand Pri me, grandpri meve3gdtv, SM-G531BT"
 "Samsung, Gal axy Grand Pri me, grandpri mel te, SM-G531F"
 "Samsung, Gal axy Grand Pri me, grandpri mel tel tn, SM-G531M"
 "Samsung, Gal axy Grand Pri me, grandpri mel tezt, SM-G531Y"
 "Samsung, Gal axy Grand duos, baffi n, GT-I 9082i "
 "Samsung, Gal axy Grand-Max, grandmaxl tekx, SM-G720N0"
 "Samsung, Gal axy Grand2, ms013g, SM-G7102"
 "Samsung, Gal axy Grand2, ms013g, SM-G7106"
 "Samsung, Gal axy Grand2, ms013g, SM-G7108"
 "Samsung, Gal axy Grand2, ms013g, SM-G7109"
 "Samsung, Gal axy Grand2, ms013gdtv, SM-G7102T"
 "Samsung, Gal axy Grand2, ms013gss, SM-G710"
 "Samsung, Gal axy Grand2, ms01l te, SM-G7105"
 "Samsung, Gal axy Grand2, ms01l te, SM-G7105H"
 "Samsung, Gal axy Grand2, ms01l te, SM-G7105L"
 "Samsung, Gal axy Grand2, ms01l tektt, SM-G710K"
 "Samsung, Gal axy Grand2, ms01l tel gt, SM-G710L"
 "Samsung, Gal axy Grand2, ms01l teskt, SM-G710S"
 "Samsung, Gal axy I ndul ge, SCH-R910, SCH-R910"

supported device.txt

"Samsung, Gal axy Indul ge, SCH-R915, SCH-R915"
 "Samsung, Gal axy Infi ni te, i nfi ni te3gduosctc, SCH-I 759"
 "Samsung, Gal axy J, hl tej s01tw, SGH-N075T"
 "Samsung, Gal axy J1, j 13g, SM-J100H"
 "Samsung, Gal axy J1, j 13g, SM-J100ML"
 "Samsung, Gal axy J1, j 13gtfnvzw, SM-S777C"
 "Samsung, Gal axy J1, j 1l te, SM-J100F"
 "Samsung, Gal axy J1, j 1l te, SM-J100G"
 "Samsung, Gal axy J1, j 1l te, SM-J100M"
 "Samsung, Gal axy J1, j 1nl te, SM-J100FN"
 "Samsung, Gal axy J1, j 1nl te, SM-J100MU"
 "Samsung, Gal axy J1, j 1nl te, SM-J100Y"
 "Samsung, Gal axy J1, j 1ql tevzw, SM-J100VPP"
 "Samsung, Gal axy J1 Ace, j 1acel te, SM-J110F"
 "Samsung, Gal axy J1 Ace, j 1acel te, SM-J110G"
 "Samsung, Gal axy J1 Ace, j 1acel tel tn, SM-J110M"
 "Samsung, Gal axy J1 Ace, j 1pop3g, SM-J110H"
 "Samsung, Gal axy J1 Ace, j 1pop3g, SM-J110L"
 "Samsung, Gal axy J2, j 23g, SM-J200H"
 "Samsung, Gal axy J2, j 2l te, SM-J200F"
 "Samsung, Gal axy J2, j 2l te, SM-J200G"
 "Samsung, Gal axy J2, j 2l te, SM-J200GU"
 "Samsung, Gal axy J2, j 2l te, SM-J200M"
 "Samsung, Gal axy J2, j 2l te, SM-J200Y"
 "Samsung, Gal axy J2, j 2l tedtv, SM-J200BT"
 "Samsung, Gal axy J5, j 53g, SM-J500H"
 "Samsung, Gal axy J5, j 5l te, SM-J5007"
 "Samsung, Gal axy J5, j 5l te, SM-J500F"
 "Samsung, Gal axy J5, j 5l te, SM-J500G"
 "Samsung, Gal axy J5, j 5l te, SM-J500M"
 "Samsung, Gal axy J5, j 5l techn, SM-J5008"
 "Samsung, Gal axy J5, j 5l tekx, SM-J500N0"
 "Samsung, Gal axy J5, j 5nl te, SM-J500FN"
 "Samsung, Gal axy J5, j 5yl te, SM-J500Y"
 "Samsung, Gal axy J7, j 7e3g, SM-J700H"
 "Samsung, Gal axy J7, j 7el te, SM-J700F"
 "Samsung, Gal axy J7, j 7el te, SM-J700M"
 "Samsung, Gal axy J7, j 7l techn, SM-J7008"
 "Samsung, Gal axy K, SHW-M130K, SHW-M130K"
 "Samsung, Gal axy K Zoom, m2a3g, SM-C111"
 "Samsung, Gal axy K Zoom, m2a3g, SM-C111M"
 "Samsung, Gal axy K Zoom, m2al te, SM-C115"
 "Samsung, Gal axy K Zoom, m2al te, SM-C115M"
 "Samsung, Gal axy K Zoom, m2al tecan, SM-C115W"
 "Samsung, Gal axy K Zoom, m2al tel gt, SM-C115L"
 "Samsung, Gal axy M Pro2, l ucas, GT-B7810"
 "Samsung, Gal axy M Styl e, SHW-M340L, SHW-M340L"
 "Samsung, Gal axy M Styl e, SHW-M340S, SHW-M340S"
 "Samsung, Gal axy M Styl e, vastoi cmcc, GT-I 8258"
 "Samsung, Gal axy Mega 2, mega23g, SM-G750H"
 "Samsung, Gal axy Mega 5. 8, crater, GT-I 9152"
 "Samsung, Gal axy Mega 5. 8, crater3gctc, SCH-P709"
 "Samsung, Gal axy Mega 5. 8, craterss, GT-I 9150"
 "Samsung, Gal axy Mega 5. 8, cratertd3g, GT-I 9158"
 "Samsung, Gal axy Mega 6. 3, mel i us3g, GT-I 9200"
 "Samsung, Gal axy Mega 6. 3, mel i us3g, GT-I 9208"
 "Samsung, Gal axy Mega 6. 3, mel i us3gduosctc, SCH-P729"
 "Samsung, Gal axy Mega 6. 3, mel i usl te, GT-I 9205"
 "Samsung, Gal axy Mega 6. 3, mel i usl teMetroPCS, SGH-M819N"
 "Samsung, Gal axy Mega 6. 3, mel i usl teatt, SAMSUNG-SGH-I 527"
 "Samsung, Gal axy Mega 6. 3, mel i usl tecan, SGH-I 527M"
 "Samsung, Gal axy Mega 6. 3, mel i usl tektt, SHV-E310K"
 "Samsung, Gal axy Mega 6. 3, mel i usl tel gt, SHV-E310L"

supported device.txt

"Samsung, Gal axy Mega 6.3, melius teskt, SHV-E310S"
 "Samsung, Gal axy Mega 6.3, melius tespr, SPH-L600"
 "Samsung, Gal axy Mega 6.3, melius teusc, SCH-R960"
 "Samsung, Gal axy Mega Plus, craterq3g, GT-I9152P"
 "Samsung, Gal axy Mega Plus, craterq3g, GT-I9158P"
 "Samsung, Gal axy Mega Plus, megaplus te, GT-I9158V"
 "Samsung, Gal axy Mega2, mega2 te, SM-G750F"
 "Samsung, Gal axy Mega2, mega2 teatt, SAMSUNG-SM-G750A"
 "Samsung, Gal axy Mega2, vasta3g, SM-G750H"
 "Samsung, Gal axy Mega2, vastal te, SM-G7508Q"
 "Samsung, Gal axy Mega2, vastal tezh, SM-G7508Q"
 "Samsung, Gal axy Mini, GT-S5570, GT-S5570"
 "Samsung, Gal axy Mini, GT-S5570B, GT-S5570B"
 "Samsung, Gal axy Mini, GT-S5570I, GT-S5570I"
 "Samsung, Gal axy Mini, GT-S5570L, GT-S5570L"
 "Samsung, Gal axy Mini, GT-S5578, GT-S5578"
 "Samsung, Gal axy Mini, SGH-T499, SGH-T499"
 "Samsung, Gal axy Mini, SGH-T499V, SGH-T499V"
 "Samsung, Gal axy Mini, SGH-T499Y, SGH-T499Y"
 "Samsung, Gal axy Mini2, GT-S6500, GT-S6500"
 "Samsung, Gal axy Mini2, GT-S6500D, GT-S6500D"
 "Samsung, Gal axy Mini2, GT-S6500L, GT-S6500L"
 "Samsung, Gal axy Mini2, GT-S6500T, GT-S6500T"
 "Samsung, Gal axy Music, ivoryss, GT-S6010"
 "Samsung, Gal axy Music, ivoryss, GT-S6010L"
 "Samsung, Gal axy Music Duos, ivory, GT-S6012"
 "Samsung, Gal axy Music Duos, ivory, GT-S6012B"
 "Samsung, Gal axy NX, uote, EK-GN120"
 "Samsung, Gal axy NX, uote, EK-GN120A"
 "Samsung, Gal axy NX, uote, EK-GN120A"
 "Samsung, Gal axy Neo, SHW-M220L, SHW-M220L"
 "Samsung, Gal axy Nexus, maguro, Gal axy Nexus"
 "Samsung, Gal axy Nexus, maguro, Gal axy X"
 "Samsung, Gal axy Nexus, toro, Gal axy Nexus"
 "Samsung, Gal axy Nexus, toroplus, Gal axy Nexus"
 "Samsung, Gal axy Note, GT-I9220, GT-I9220"
 "Samsung, Gal axy Note, GT-I9228, GT-I9228"
 "Samsung, Gal axy Note, GT-N7000, GT-N7000"
 "Samsung, Gal axy Note, GT-N7005, GT-N7005"
 "Samsung, Gal axy Note, SC-05D, SC-05D"
 "Samsung, Gal axy Note, SCH-i889, SCH-i889"
 "Samsung, Gal axy Note, SGH-I717, SAMSUNG-SGH-I717"
 "Samsung, Gal axy Note, SGH-I717, SGH-I717"
 "Samsung, Gal axy Note, SGH-I717D, SGH-I717D"
 "Samsung, Gal axy Note, SGH-I717M, SGH-I717M"
 "Samsung, Gal axy Note, SGH-I717R, SGH-I717R"
 "Samsung, Gal axy Note, SGH-T879, SGH-T879"
 "Samsung, Gal axy Note, SHV-E160K, SHV-E160K"
 "Samsung, Gal axy Note, SHV-E160L, SHV-E160L"
 "Samsung, Gal axy Note, SHV-E160S, SHV-E160S"
 "Samsung, Gal axy Note 10.1, I t033g, SM-P601"
 "Samsung, Gal axy Note 10.1, I t033g, SM-P602"
 "Samsung, Gal axy Note 10.1, I t03I tektt, SM-P605K"
 "Samsung, Gal axy Note 10.1, I t03I tel gt, SM-P605L"
 "Samsung, Gal axy Note 10.1, I t03I teskt, SM-P605S"
 "Samsung, Gal axy Note 10.1, p4notel te, GT-N8020"
 "Samsung, Gal axy Note 10.1, p4notel tektt, SHV-E230K"
 "Samsung, Gal axy Note 10.1, p4notel tel gt, SHV-E230L"
 "Samsung, Gal axy Note 10.1, p4notel teskt, SHV-E230S"
 "Samsung, Gal axy Note 10.1, p4notel tespr, SPH-P600"
 "Samsung, Gal axy Note 10.1, p4notel teusc, SCH-I925U"
 "Samsung, Gal axy Note 10.1, p4notel tevwz, SCH-I925"
 "Samsung, Gal axy Note 10.1, p4noterf, GT-N8000"

supported device.txt

"Samsung, Gal axy Note 10. 1, p4noterf, GT-N8005"
 "Samsung, Gal axy Note 10. 1, p4noterfktt, SHW-M480K"
 "Samsung, Gal axy Note 10. 1, p4notewi fi , GT-N8013"
 "Samsung, Gal axy Note 10. 1, p4notewi fi 43241any, SHW-M486W"
 "Samsung, Gal axy Note 10. 1, p4notewi fi any, SHW-M480W"
 "Samsung, Gal axy Note 10. 1, p4notewi fi ktt, SHW-M485W"
 "Samsung, Gal axy Note 10. 1, p4notewi fi ww, GT-N8010"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t033g, SM-P601"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t03l te, SM-P605"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t03l te, SM-P605M"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t03l tetmo, SM-P607T"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t03l tevw, SM-P605V"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t03wi fi , SM-P600"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t03wi fi kx, SM-P600"
 "Samsung, Gal axy Note 10. 1 2014 Edi ti on, l t03wi fi ue, SM-P600"
 "Samsung, Gal axy Note 8, konal teatt, SAMSUNG-SGH-I 467"
 "Samsung, Gal axy Note 8. 0, kona3g, GT-N5100"
 "Samsung, Gal axy Note 8. 0, kona3g, GT-N5105"
 "Samsung, Gal axy Note 8. 0, konal te, GT-N5120"
 "Samsung, Gal axy Note 8. 0, konal tecan, SGH-I 467M"
 "Samsung, Gal axy Note 8. 0, konawi fi , GT-N5110"
 "Samsung, Gal axy Note 8. 0, konawi fi any, SHW-M500W"
 "Samsung, Gal axy Note Edge, SCL24, SCL24"
 "Samsung, Gal axy Note Edge, tbel tektt, SM-N915K"
 "Samsung, Gal axy Note Edge, tbel tel gt, SM-N915L"
 "Samsung, Gal axy Note Edge, tbel teskt, SM-N915S"
 "Samsung, Gal axy Note Edge, tbl te, SM-N9150"
 "Samsung, Gal axy Note Edge, tbl te, SM-N915F"
 "Samsung, Gal axy Note Edge, tbl te, SM-N915FY"
 "Samsung, Gal axy Note Edge, tbl te, SM-N915G"
 "Samsung, Gal axy Note Edge, tbl te, SM-N915X"
 "Samsung, Gal axy Note Edge, tbl teatt, SAMSUNG-SM-N915A"
 "Samsung, Gal axy Note Edge, tbl tecan, SM-N915W8"
 "Samsung, Gal axy Note Edge, tbl techn, SM-N9150"
 "Samsung, Gal axy Note Edge, tbl tespr, SM-N915P"
 "Samsung, Gal axy Note Edge, tbl tetmo, SM-N915T"
 "Samsung, Gal axy Note Edge, tbl tetmo, SM-N915T3"
 "Samsung, Gal axy Note Edge, tbl teusc, SM-N915R4"
 "Samsung, Gal axy Note Edge, tbl tevw, SM-N915V"
 "Samsung, Gal axy Note l l , t0l teatt, SAMSUNG-SGH-I 317"
 "Samsung, Gal axy Note Pro 12. 2, v1a3g, SM-P901"
 "Samsung, Gal axy Note Pro 12. 2, v1awi fi , SM-P900"
 "Samsung, Gal axy Note Pro 12. 2, v1awi fi kx, SM-P900"
 "Samsung, Gal axy Note Pro 12. 2, vi ennal te, SM-P905"
 "Samsung, Gal axy Note Pro 12. 2, vi ennal te, SM-P905M"
 "Samsung, Gal axy Note Pro 12. 2, vi ennal teatt, SAMSUNG-SM-P907A"
 "Samsung, Gal axy Note Pro 12. 2, vi ennal tekx, SM-P905FO"
 "Samsung, Gal axy Note Pro 12. 2, vi ennal tevw, SM-P905V"
 "Samsung, Gal axy Note2, SC-02E, SC-02E"
 "Samsung, Gal axy Note2, t03g, GT-N7100"
 "Samsung, Gal axy Note2, t03g, GT-N7100T"
 "Samsung, Gal axy Note2, t03gchn, GT-N7100"
 "Samsung, Gal axy Note2, t03gchnduos, GT-N7102"
 "Samsung, Gal axy Note2, t03gchnduos, GT-N7102i "
 "Samsung, Gal axy Note2, t03gcmcc, GT-N7108"
 "Samsung, Gal axy Note2, t03gctc, SCH-N719"
 "Samsung, Gal axy Note2, t03gcuduos, GT-N7102"
 "Samsung, Gal axy Note2, t03gcuduos, GT-N7102i "
 "Samsung, Gal axy Note2, t0l te, GT-N7105"
 "Samsung, Gal axy Note2, t0l te, GT-N7105T"
 "Samsung, Gal axy Note2, t0l teatt, SAMSUNG-SGH-I 317"
 "Samsung, Gal axy Note2, t0l tecan, SGH-I 317M"
 "Samsung, Gal axy Note2, t0l tecan, SGH-T889V"

supported device.txt

"Samsung, Gal axy Note2, t0l tecmcc, GT-N7108D"
"Samsung, Gal axy Note2, t0l tedcm, SC-02E"
"Samsung, Gal axy Note2, t0l tektt, SHV-E250K"
"Samsung, Gal axy Note2, t0l tel gt, SHV-E250L"
"Samsung, Gal axy Note2, t0l teskt, SHV-E250S"
"Samsung, Gal axy Note2, t0l tespr, SPH-L900"
"Samsung, Gal axy Note2, t0l tetmo, SGH-T889"
"Samsung, Gal axy Note2, t0l teusc, SCH-R950"
"Samsung, Gal axy Note2, t0l tevzw, SCH-I 605"
"Samsung, Gal axy Note3, SC-02F, SC-02F"
"Samsung, Gal axy Note3, SCL22, SCL22"
"Samsung, Gal axy Note3, ha3g, SM-N900"
"Samsung, Gal axy Note3, ha3g, SM-N9000Q"
"Samsung, Gal axy Note3, hl te, SM-N9005"
"Samsung, Gal axy Note3, hl te, SM-N9006"
"Samsung, Gal axy Note3, hl te, SM-N9007"
"Samsung, Gal axy Note3, hl te, SM-N9008V"
"Samsung, Gal axy Note3, hl te, SM-N9009"
"Samsung, Gal axy Note3, hl te, SM-N900U"
"Samsung, Gal axy Note3, hl teatt, SAMSUNG-SM-N900A"
"Samsung, Gal axy Note3, hl tecan, SM-N900W8"
"Samsung, Gal axy Note3, hl tektt, SM-N900K"
"Samsung, Gal axy Note3, hl tel gt, SM-N900L"
"Samsung, Gal axy Note3, hl teskt, SM-N900S"
"Samsung, Gal axy Note3, hl tespr, SM-N900P"
"Samsung, Gal axy Note3, hl tetmo, SM-N900T"
"Samsung, Gal axy Note3, hl teusc, SM-N900R4"
"Samsung, Gal axy Note3, hl tevzw, SM-N900V"
"Samsung, Gal axy Note3, htdl te, SM-N9007"
"Samsung, Gal axy Note3 Duos, hl te, SM-N9002"
"Samsung, Gal axy Note3 Duos, hl te, SM-N9008"
"Samsung, Gal axy Note3 Neo, frescol tektt, SM-N750K"
"Samsung, Gal axy Note3 Neo, frescol tel gt, SM-N750L"
"Samsung, Gal axy Note3 Neo, frescol teskt, SM-N750S"
"Samsung, Gal axy Note3 Neo, hl 3g, SM-N750"
"Samsung, Gal axy Note3 Neo, hl 3g, SM-N7500Q"
"Samsung, Gal axy Note3 Neo, hl 3gds, SM-N7502"
"Samsung, Gal axy Note3 Neo, hl l te, SM-N7505"
"Samsung, Gal axy Note3 Neo, hl l te, SM-N7505L"
"Samsung, Gal axy Note3 Neo, hl l te, SM-N7507"
"Samsung, Gal axy Note4, tre3cal tektt, SM-N916K"
"Samsung, Gal axy Note4, tre3cal tel gt, SM-N916L"
"Samsung, Gal axy Note4, tre3cal teskt, SM-N916S"
"Samsung, Gal axy Note4, tre3g, SM-N910H"
"Samsung, Gal axy Note4, trel te, SM-N910C"
"Samsung, Gal axy Note4, trel tektt, SM-N910K"
"Samsung, Gal axy Note4, trel tel gt, SM-N910L"
"Samsung, Gal axy Note4, trel teskt, SM-N910S"
"Samsung, Gal axy Note4, trhpl te, SM-N910U"
"Samsung, Gal axy Note4, trl te, SM-N910F"
"Samsung, Gal axy Note4, trl te, SM-N910G"
"Samsung, Gal axy Note4, trl te, SM-N910X"
"Samsung, Gal axy Note4, trl teatt, SAMSUNG-SM-N910A"
"Samsung, Gal axy Note4, trl teatt, SM-N910F"
"Samsung, Gal axy Note4, trl tecan, SM-N910W8"
"Samsung, Gal axy Note4, trl techn, SM-N9100"
"Samsung, Gal axy Note4, trl techn, SM-N9106W"
"Samsung, Gal axy Note4, trl techn, SM-N9108V"
"Samsung, Gal axy Note4, trl techn, SM-N9109W"
"Samsung, Gal axy Note4, trl technzh, SM-N9100"
"Samsung, Gal axy Note4, trl tespr, SM-N910P"
"Samsung, Gal axy Note4, trl tetmo, SM-N910T"
"Samsung, Gal axy Note4, trl tetmo, SM-N910T2"

supported device.txt

"Samsung, Gal axy Note4, trl tetmo, SM-N910T3"
 "Samsung, Gal axy Note4, trl teusc, SM-N910R4"
 "Samsung, Gal axy Note4, trl tevw, SM-N910V"
 "Samsung, Gal axy Note5, nobl el te, SM-N9208"
 "Samsung, Gal axy Note5, nobl el te, SM-N920C"
 "Samsung, Gal axy Note5, nobl el te, SM-N920F"
 "Samsung, Gal axy Note5, nobl el te, SM-N920G"
 "Samsung, Gal axy Note5, nobl el te, SM-N920I "
 "Samsung, Gal axy Note5, nobl el te, SM-N920X"
 "Samsung, Gal axy Note5, nobl el teatt, SAMSUNG-SM-N920A"
 "Samsung, Gal axy Note5, nobl el tebmc, SM-N920W8"
 "Samsung, Gal axy Note5, nobl el techn, SM-N9200"
 "Samsung, Gal axy Note5, nobl el tecmcc, SM-N9208"
 "Samsung, Gal axy Note5, nobl el tehk, SM-N9200"
 "Samsung, Gal axy Note5, nobl el tektt, SM-N920K"
 "Samsung, Gal axy Note5, nobl el tel gt, SM-N920L"
 "Samsung, Gal axy Note5, nobl el teskt, SM-N920S"
 "Samsung, Gal axy Note5, nobl el tespr, SM-N920P"
 "Samsung, Gal axy Note5, nobl el tetmo, SM-N920T"
 "Samsung, Gal axy Note5, nobl el teusc, SM-N920R4"
 "Samsung, Gal axy Note5, nobl el tevw, SM-N920V"
 "Samsung, Gal axy On5, o5l te, SM-G550FY"
 "Samsung, Gal axy On7, o7l te, SM-G600FY"
 "Samsung, Gal axy Pl ayer, YP-GB70, YP-GB70"
 "Samsung, Gal axy Pl ayer 3. 6, YP-GS1, YP-GS1"
 "Samsung, Gal axy Pl ayer 4, YP-GB1, YP-GB1"
 "Samsung, Gal axy Pl ayer 4. 0, YP-G1, YP-G1"
 "Samsung, Gal axy Pl ayer 4. 2, YP-G1 1, YP-G1 1"
 "Samsung, Gal axy Pl ayer 5, YP-G70, YP-G70"
 "Samsung, Gal axy Pl ayer 5. 8, harri son, YP-GP1"
 "Samsung, Gal axy Pl ayer 5. 8, harri sonkrktt, YP-GP1"
 "Samsung, Gal axy Pl ayer 5. 8, harri sonkrl gt, YP-GP1"
 "Samsung, Gal axy Pl ayer 50, YP-G50, YP-G50"
 "Samsung, Gal axy Pocket, GT-S5300, GT-S5300"
 "Samsung, Gal axy Pocket, GT-S5300B, GT-S5300B"
 "Samsung, Gal axy Pocket, GT-S5300L, GT-S5300L"
 "Samsung, Gal axy Pocket, GT-S5302, GT-S5302"
 "Samsung, Gal axy Pocket, GT-S5302B, GT-S5302B"
 "Samsung, Gal axy Pocket, cori pl us, GT-S5301"
 "Samsung, Gal axy Pocket, cori pl usds, GT-S5303"
 "Samsung, Gal axy Pocket Neo, corsi ca, GT-S5312"
 "Samsung, Gal axy Pocket Neo, corsi ca, GT-S5312B"
 "Samsung, Gal axy Pocket Neo, corsi ca, GT-S5312L"
 "Samsung, Gal axy Pocket Neo, corsi cass, GT-S5310"
 "Samsung, Gal axy Pocket Neo, corsi cass, GT-S5310B"
 "Samsung, Gal axy Pocket Neo, corsi cass, GT-S5310E"
 "Samsung, Gal axy Pocket Neo, corsi cass, GT-S5310G"
 "Samsung, Gal axy Pocket Neo, corsi cass, GT-S5310L"
 "Samsung, Gal axy Pocket Neo, corsi cass, GT-S5310T"
 "Samsung, Gal axy Pocket Neo, corsi cave3g, GT-S5310I "
 "Samsung, Gal axy Pocket Neo, corsi cave3g, GT-S5310N"
 "Samsung, Gal axy Pocket Neo, corsi caveds3gvj , GT-S5312C"
 "Samsung, Gal axy Pocket Neo, corsi caveds3gvj , GT-S5312M"
 "Samsung, Gal axy Pocket Neo, d2ai o, SAMSUNG-SGH-I 747Z"
 "Samsung, Gal axy Pocket Pl us, cori pl us, GT-S5301"
 "Samsung, Gal axy Pocket Pl us, cori pl us, GT-S5301B"
 "Samsung, Gal axy Pocket Pl us, cori pl us, GT-S5301L"
 "Samsung, Gal axy Pocket SS, corsi cave3g, GT-S5310C"
 "Samsung, Gal axy Pocket SS, corsi cave3g, GT-S5310M"
 "Samsung, Gal axy Pocket2, pocket23g, SM-G110B"
 "Samsung, Gal axy Pocket2, pocket23g, SM-G110M"
 "Samsung, Gal axy Pocket2, pocket2ss3g, SM-G110H"
 "Samsung, Gal axy Pop, superi orl teskt, SHV-E220S"

supported device.txt

"Samsung, Gal axy Pop (CDMA), SCH-i 559, SCH-i 559"
 "Samsung, Gal axy Precedent, SCH-M828C, SCH-M828C"
 "Samsung, Gal axy Premier, superior, GT-I 9260"
 "Samsung, Gal axy Premier, superiormcc, GT-I 9268"
 "Samsung, Gal axy Prevail, SPH-M820, SPH-M820-BST"
 "Samsung, Gal axy Prevail 2, raybst, SPH-M840"
 "Samsung, Gal axy Pro, GT-B7510, GT-B7510"
 "Samsung, Gal axy Pro, GT-B7510B, GT-B7510B"
 "Samsung, Gal axy Pro, GT-B7510L, GT-B7510L"
 "Samsung, Gal axy Proclaim, SCH-S720C, SCH-S720C"
 "Samsung, Gal axy Q, SGH-T589, SGH-T589"
 "Samsung, Gal axy Q, SGH-T589R, SGH-T589R"
 "Samsung, Gal axy Q, SGH-T589W, SGH-T589W"
 "Samsung, Gal axy R-Style, jaguark, SHV-E170K"
 "Samsung, Gal axy R-Style, jaguarl, SHV-E170L"
 "Samsung, Gal axy R-Style, jaguars, SHV-E170S"
 "Samsung, Gal axy Reverb, iconvmu, SPH-M950"
 "Samsung, Gal axy Round, flteskt, SM-G910S"
 "Samsung, Gal axy Rugby, comanchean, SGH-I 547C"
 "Samsung, Gal axy Rugby Pro, comancheatt, SAMSUNG-SGH-I 547"
 "Samsung, Gal axy Rush, prevail 2spr, SPH-M830"
 "Samsung, Gal axy S, GT-I 9000, GT-I 9000"
 "Samsung, Gal axy S, GT-I 9000B, GT-I 9000B"
 "Samsung, Gal axy S, GT-I 9000M, GT-I 9000M"
 "Samsung, Gal axy S, GT-I 9000T, GT-I 9000T"
 "Samsung, Gal axy S, GT-I 9003, GT-I 9003"
 "Samsung, Gal axy S, GT-I 9003L, GT-I 9003L"
 "Samsung, Gal axy S, GT-I 9008L, GT-I 9008L"
 "Samsung, Gal axy S, GT-I 9010, GT-I 9010"
 "Samsung, Gal axy S, GT-I 9018, GT-I 9018"
 "Samsung, Gal axy S, GT-I 9050, GT-I 9050"
 "Samsung, Gal axy S, SC-02B, SC-02B"
 "Samsung, Gal axy S, SCH-I 500, SCH-I 500"
 "Samsung, Gal axy S, SCH-S950C, SCH-S950C"
 "Samsung, Gal axy S, SCH-i 909, SCH-i 909"
 "Samsung, Gal axy S, SGH-I 897, SAMSUNG-SGH-I 897"
 "Samsung, Gal axy S, SGH-T959V, SGH-T959V"
 "Samsung, Gal axy S, SGH-T959W, SGH-T959W"
 "Samsung, Gal axy S, SHW-M110S, SHW-M110S"
 "Samsung, Gal axy S, SHW-M190S, SHW-M190S"
 "Samsung, Gal axy S, SPH-D700, SPH-D700"
 "Samsung, Gal axy S, Loganl te, GT-S7275"
 "Samsung, Gal axy S Advance, GT-I 9070, GT-I 9070"
 "Samsung, Gal axy S Advance, GT-I 9070P, GT-I 9070P"
 "Samsung, Gal axy S Aviator, SCH-R930, SCH-R930"
 "Samsung, Gal axy S Blaze, SGH-T769, SGH-T769"
 "Samsung, Gal axy S BlazeQ, apexqtm, SGH-T699"
 "Samsung, Gal axy S Captivate, SGH-I 896, SAMSUNG-SGH-I 896"
 "Samsung, Gal axy S Captivate, SGH-I 896, SGH-I 896"
 "Samsung, Gal axy S Continuum, SCH-I 400, SCH-I 400"
 "Samsung, Gal axy S DUOS, kyl eopen, GT-S7562"
 "Samsung, Gal axy S DUOS, kyl eopen, GT-S7562L"
 "Samsung, Gal axy S Duos, kyl echn, GT-S7562"
 "Samsung, Gal axy S Duos, kyl eopen, GT-S7562"
 "Samsung, Gal axy S Duos, kyl etdcmcc, GT-S7568"
 "Samsung, Gal axy S Duos2, kyl eprods, GT-S7582"
 "Samsung, Gal axy S Duos2, kyl eprods, GT-S7582L"
 "Samsung, Gal axy S Duos3, vi val to3gvn, SM-G313HZ"
 "Samsung, Gal axy S Epic, SPH-D700, SPH-D700"
 "Samsung, Gal axy S Fascinate, SGH-T959P, SGH-T959P"
 "Samsung, Gal axy S Glide, SGH-I 927R, SAMSUNG-SGH-I 927R"
 "Samsung, Gal axy S Lightray, SCH-R940, SCH-R940"
 "Samsung, Gal axy S Plus, GT-I 9001, GT-I 9001"

supported device.txt

"Samsung, Gal axy S Stratosphere, SCH-I 405, SCH-I 405"
 "Samsung, Gal axy S Vi brant, SGH-T959, SGH-T959"
 "Samsung, Gal axy S Vi brant, SGH-T959D, SGH-T959D"
 "Samsung, Gal axy S duos, kyl ei chn, GT-S7566"
 "Samsung, Gal axy S2, GT-I 9100, GT-I 9100"
 "Samsung, Gal axy S2, GT-I 9100M, GT-I 9100M"
 "Samsung, Gal axy S2, GT-I 9100P, GT-I 9100P"
 "Samsung, Gal axy S2, GT-I 9100T, GT-I 9100T"
 "Samsung, Gal axy S2, GT-I 9103, GT-I 9103"
 "Samsung, Gal axy S2, GT-I 9108, GT-I 9108"
 "Samsung, Gal axy S2, GT-I 9210T, GT-I 9210T"
 "Samsung, Gal axy S2, SC-02C, SC-02C"
 "Samsung, Gal axy S2, SCH-R760X, SCH-R760X"
 "Samsung, Gal axy S2, SGH-I 777, SAMSUNG-SGH-I 777"
 "Samsung, Gal axy S2, SGH-S959G, SGH-S959G"
 "Samsung, Gal axy S2, SGH-T989, SGH-T989"
 "Samsung, Gal axy S2, SHV-E110S, SHV-E110S"
 "Samsung, Gal axy S2, SHW-M250K, SHW-M250K"
 "Samsung, Gal axy S2, SHW-M250L, SHW-M250L"
 "Samsung, Gal axy S2, SHW-M250S, SHW-M250S"
 "Samsung, Gal axy S2, t1cmcc, GT-I 9108"
 "Samsung, Gal axy S2 Duos, SCH-i 929, SCH-i 929"
 "Samsung, Gal axy S2 Duos TV, Iogandsdtv, GT-S7273T"
 "Samsung, Gal axy S2 Epi c, SCH-R760, SCH-R760"
 "Samsung, Gal axy S2 Epi c, SPH-D710, SPH-D710"
 "Samsung, Gal axy S2 Epi c, SPH-D710BST, SPH-D710BST"
 "Samsung, Gal axy S2 Epi c, SPH-D710VMUB, SPH-D710VMUB"
 "Samsung, Gal axy S2 HD LTE, SGH-I 757M, SGH-I 757M"
 "Samsung, Gal axy S2 HD LTE, SHV-E120K, SHV-E120K"
 "Samsung, Gal axy S2 HD LTE, SHV-E120L, SHV-E120L"
 "Samsung, Gal axy S2 HD LTE, SHV-E120S, SHV-E120S"
 "Samsung, Gal axy S2 LTE, GT-I 9210, GT-I 9210"
 "Samsung, Gal axy S2 LTE, SC-03D, SC-03D"
 "Samsung, Gal axy S2 LTE, SGH-I 727R, SGH-I 727R"
 "Samsung, Gal axy S2 Pl us, GT-I 9100G, GT-I 9100G"
 "Samsung, Gal axy S2 Pl us, s2ve, GT-I 9105"
 "Samsung, Gal axy S2 Pl us, s2vep, GT-I 9105P"
 "Samsung, Gal axy S2 Skyrocket, SGH-I 727, SAMSUNG-SGH-I 727"
 "Samsung, Gal axy S2 Skyrocket, SGH-I 727, SGH-I 727"
 "Samsung, Gal axy S2 Wi max, I SW11SC, I SW11SC"
 "Samsung, Gal axy S2 X, SGH-T989D, SGH-T989D"
 "Samsung, Gal axy S3, SC-03E, SC-03E"
 "Samsung, Gal axy S3, c1att, SGH-I 748"
 "Samsung, Gal axy S3, c1ktt, SHV-E210K"
 "Samsung, Gal axy S3, c1l gt, SHV-E210L"
 "Samsung, Gal axy S3, c1skt, SHV-E210S"
 "Samsung, Gal axy S3, d2att, SAMSUNG-SGH-I 747"
 "Samsung, Gal axy S3, d2can, SGH-I 747M"
 "Samsung, Gal axy S3, d2can, SGH-T999V"
 "Samsung, Gal axy S3, d2cri, SCH-R530C"
 "Samsung, Gal axy S3, d2dcm, Gravi ty"
 "Samsung, Gal axy S3, d2dcm, SC-06D"
 "Samsung, Gal axy S3, d2I teMetroPCS, SGH-T999N"
 "Samsung, Gal axy S3, d2I terefreshspr, SPH-L710T"
 "Samsung, Gal axy S3, d2I tetmo, SGH-T999L"
 "Samsung, Gal axy S3, d2mtr, SCH-R530M"
 "Samsung, Gal axy S3, d2spi, SCH-L710"
 "Samsung, Gal axy S3, d2spr, SPH-L710"
 "Samsung, Gal axy S3, d2tfnspr, SCH-S960L"
 "Samsung, Gal axy S3, d2tfnvzw, SCH-S968C"
 "Samsung, Gal axy S3, d2tmo, SGH-T999"
 "Samsung, Gal axy S3, d2usc, SCH-R530U"
 "Samsung, Gal axy S3, d2vmu, SPH-L710"

supported device.txt

"Samsung, Gal axy S3, d2vzw, SCH-I 535"
 "Samsung, Gal axy S3, d2vzw, SCH-I 535PP"
 "Samsung, Gal axy S3, d2xar, SCH-R530X"
 "Samsung, Gal axy S3, m0, GT-I 9300"
 "Samsung, Gal axy S3, m0, GT-I 9300T"
 "Samsung, Gal axy S3, m0apt, SCH-I 939"
 "Samsung, Gal axy S3, m0chn, GT-I 9300"
 "Samsung, Gal axy S3, m0cmcc, GT-I 9308"
 "Samsung, Gal axy S3, m0ctc, SCH-I 939"
 "Samsung, Gal axy S3, m0ctcduos, SCH-I 939D"
 "Samsung, Gal axy S3, m0skt, SHW-M440S"
 "Samsung, Gal axy S3, m3, GT-I 9305"
 "Samsung, Gal axy S3, m3, GT-I 9305N"
 "Samsung, Gal axy S3, m3, GT-I 9305T"
 "Samsung, Gal axy S3, m3dcm, Gravi tyQuad"
 "Samsung, Gal axy S3, m3dcm, SC-03E"
 "Samsung, Gal axy S3 Duos, arubasl i m, GT-I 8262B"
 "Samsung, Gal axy S3 Mi ni , gol den, GT-I 8190"
 "Samsung, Gal axy S3 Mi ni , gol den, GT-I 8190L"
 "Samsung, Gal axy S3 Mi ni , gol den, GT-I 8190N"
 "Samsung, Gal axy S3 Mi ni , gol den, GT-I 8190T"
 "Samsung, Gal axy S3 Mi ni , gol denl teatt, SAMSUNG-SM-G730A"
 "Samsung, Gal axy S3 Mi ni , gol denl tebmc, SM-G730W8"
 "Samsung, Gal axy S3 Mi ni , gol denl tevw, SM-G730V"
 "Samsung, Gal axy S3 Mi ni , gol denve3g, GT-I 8200L"
 "Samsung, Gal axy S3 Mi ni Val ue Edi ti on, gol denve3g, GT-I 8200N"
 "Samsung, Gal axy S3 Mi ni Val ue Edi ti on, gol denvess3g, GT-I 8200"
 "Samsung, Gal axy S3 Mi ni Val ue Edi ti on, gol denvess3g, GT-I 8200Q"
 "Samsung, Gal axy S3 Neo, s3ve3g, GT-I 9300I "
 "Samsung, Gal axy S3 Neo, s3ve3g, GT-I 9301I "
 "Samsung, Gal axy S3 Neo, s3ve3g, GT-I 9301Q"
 "Samsung, Gal axy S3 Neo, s3ve3gdd, GT-I 9300I "
 "Samsung, Gal axy S3 Neo, s3ve3gds, GT-I 9300I "
 "Samsung, Gal axy S3 Neo, s3ve3gdsdd, GT-I 9300I "
 "Samsung, Gal axy S3 Neo Pl us, s3ve3g, GT-I 9300I "
 "Samsung, Gal axy S3 Neo Pl us, s3ve3g, GT-I 9308I "
 "Samsung, Gal axy S3 Progre, SCL21, SCL21"
 "Samsung, Gal axy S3 SI m, wi l coxds, SM-G3812B"
 "Samsung, Gal axy S4, SC-04E, SC-04E"
 "Samsung, Gal axy S4, j a3g, GT-I 9500"
 "Samsung, Gal axy S4, j a3gduosctc, SCH-I 959"
 "Samsung, Gal axy S4, j al tektt, SHV-E300K"
 "Samsung, Gal axy S4, j al tel gt, SHV-E300L"
 "Samsung, Gal axy S4, j al teskt, SHV-E300S"
 "Samsung, Gal axy S4, j fl te, GT-I 9505"
 "Samsung, Gal axy S4, j fl te, GT-I 9508"
 "Samsung, Gal axy S4, j fl te, GT-I 9508C"
 "Samsung, Gal axy S4, j fl teai o, SAMSUNG-SGH-I 337Z"
 "Samsung, Gal axy S4, j fl teatt, SAMSUNG-SGH-I 337"
 "Samsung, Gal axy S4, j fl tecan, SGH-I 337M"
 "Samsung, Gal axy S4, j fl tecan, SGH-M919V"
 "Samsung, Gal axy S4, j fl tecri , SCH-R970C"
 "Samsung, Gal axy S4, j fl tecsp, SCH-R970X"
 "Samsung, Gal axy S4, j fl tel ra, SCH-I 545L"
 "Samsung, Gal axy S4, j fl terefreshspr, SPH-L720T"
 "Samsung, Gal axy S4, j fl tespr, SPH-L720"
 "Samsung, Gal axy S4, j fl tetfnatt, SM-S975L"
 "Samsung, Gal axy S4, j fl tetfntmo, SGH-S970G"
 "Samsung, Gal axy S4, j fl tetmo, SGH-M919"
 "Samsung, Gal axy S4, j fl teusc, SCH-R970"
 "Samsung, Gal axy S4, j fl tevw, SCH-I 545"
 "Samsung, Gal axy S4, j ftdd, GT-I 9507"
 "Samsung, Gal axy S4, j ftdd, GT-I 9507V"

supported device.txt

"Samsung, Gal axy S4, j fvel te, GT-I 9515"
"Samsung, Gal axy S4, j fvel te, GT-I 9515L"
"Samsung, Gal axy S4, j fwi fi , GT-I 9505X"
"Samsung, Gal axy S4, j sgl te, GT-I 9508V"
"Samsung, Gal axy S4, ks01l te, GT-I 9506"
"Samsung, Gal axy S4, ks01l tektt, SHV-E330K"
"Samsung, Gal axy S4, ks01l tel gt, SHV-E330L"
"Samsung, Gal axy S4 Acti ve, j acti vel te, GT-I 9295"
"Samsung, Gal axy S4 Acti ve, j acti vel teatt, SAMSUNG-SGH-I 537"
"Samsung, Gal axy S4 Acti ve, j acti vel teatt, SGH-I 537"
"Samsung, Gal axy S4 Acti ve, j acti vel teskt, SHV-E470S"
"Samsung, Gal axy S4 Duos, j a3gchnduos, GT-I 9502"
"Samsung, Gal axy S4 Googl e Pl ay Edi ti on, j gedl te, GT-I 9505G"
"Samsung, Gal axy S4 LTE-A, ks01l teskt, SHV-E330S"
"Samsung, Gal axy S4 Mi ni , serrano3g, GT-I 9190"
"Samsung, Gal axy S4 Mi ni , serranods, GT-I 9192"
"Samsung, Gal axy S4 Mi ni , serranol te, GT-I 9195"
"Samsung, Gal axy S4 Mi ni , serranol te, GT-I 9195L"
"Samsung, Gal axy S4 Mi ni , serranol te, GT-I 9195T"
"Samsung, Gal axy S4 Mi ni , serranol te, GT-I 9195X"
"Samsung, Gal axy S4 Mi ni , serranol te, GT-I 9197"
"Samsung, Gal axy S4 Mi ni , serranol tebmc, SGH-I 257M"
"Samsung, Gal axy S4 Mi ni , serranol tektt, SHV-E370K"
"Samsung, Gal axy S4 Mi ni , serranol tekx, SHV-E370D"
"Samsung, Gal axy S4 Mi ni , serranol tel ra, SCH-I 435L"
"Samsung, Gal axy S4 Mi ni , serranol tespr, SPH-L520"
"Samsung, Gal axy S4 Mi ni , serranol teusc, SCH-R890"
"Samsung, Gal axy S4 Mi ni , serranol tevzw, SCH-I 435"
"Samsung, Gal axy S4 Mi ni , serranove3g, GT-I 9192I "
"Samsung, Gal axy S4 Mi ni , serranovel te, GT-I 9195I "
"Samsung, Gal axy S4 Mi ni , serranovel teatt, SAMSUNG-SGH-I 257"
"Samsung, Gal axy S4 Zoom, mproj ect3g, SM-C101"
"Samsung, Gal axy S4 Zoom, mproj ectl teatt, SAMSUNG-SM-C105A"
"Samsung, Gal axy S4 Zoom, mproj ectl tel gt, SM-C105L"
"Samsung, Gal axy S4 Zoom, mproj ectl teskt, SM-C105S"
"Samsung, Gal axy S4 Zoom, mproj ectql te, SM-C105"
"Samsung, Gal axy S5, SCL23, SCL23"
"Samsung, Gal axy S5, k3g, SM-G900H"
"Samsung, Gal axy S5, kl te, SM-G9008W"
"Samsung, Gal axy S5, kl te, SM-G9009W"
"Samsung, Gal axy S5, kl te, SM-G900F"
"Samsung, Gal axy S5, kl te, SM-G900FQ"
"Samsung, Gal axy S5, kl te, SM-G900I "
"Samsung, Gal axy S5, kl te, SM-G900M"
"Samsung, Gal axy S5, kl te, SM-G900MD"
"Samsung, Gal axy S5, kl teMetroPCS, SM-G900T1"
"Samsung, Gal axy S5, kl teMetroPCS, SM-G900T4"
"Samsung, Gal axy S5, kl teacg, SM-G900R7"
"Samsung, Gal axy S5, kl teai o, SAMSUNG-SM-G900AZ"
"Samsung, Gal axy S5, kl teatt, SAMSUNG-SM-G900A"
"Samsung, Gal axy S5, kl tecan, SM-G900W8"
"Samsung, Gal axy S5, kl teduoszn, SM-G9006W"
"Samsung, Gal axy S5, kl tektt, SM-G900K"
"Samsung, Gal axy S5, kl tel gt, SM-G900L"
"Samsung, Gal axy S5, kl tel ra, SM-G900R6"
"Samsung, Gal axy S5, kl teskt, SM-G900S"
"Samsung, Gal axy S5, kl tespr, SM-G900P"
"Samsung, Gal axy S5, kl tetmo, SM-G900T"
"Samsung, Gal axy S5, kl tetmo, SM-G900T3"
"Samsung, Gal axy S5, kl teusc, SM-G900R4"
"Samsung, Gal axy S5, kl tevzw, SM-G900V"
"Samsung, Gal axy S5, kwi fi , SM-G900X"
"Samsung, Gal axy S5, l enti sl tektt, SM-G906K"

supported device.txt

"Samsung, Gal axy S5, lenti sl tel gt, SM-G906L"
 "Samsung, Gal axy S5, lenti sl teskt, SM-G906S"
 "Samsung, Gal axy S5 Acti ve, kl teacti ve, SM-G870F"
 "Samsung, Gal axy S5 Acti ve, kl teattacti ve, SAMSUNG-SM-G870A"
 "Samsung, Gal axy S5 Acti ve, kl tecanacti ve, SM-G870W"
 "Samsung, Gal axy S5 Dual SIM, kl te, SM-G900FD"
 "Samsung, Gal axy S5 Googl e Pl ay Edi ti on, kgedl te, SM-G900FG"
 "Samsung, Gal axy S5 K Sport, kl tesprsports, SM-G860P"
 "Samsung, Gal axy S5 LTE-A, kccat6, SM-G901F"
 "Samsung, Gal axy S5 Mi ni , kmi ni 3g, SM-G800H"
 "Samsung, Gal axy S5 Mi ni , kmi ni l te, SM-G800F"
 "Samsung, Gal axy S5 Mi ni , kmi ni l te, SM-G800Y"
 "Samsung, Gal axy S5 Mi ni , kmi ni l teusc, SM-G800R4"
 "Samsung, Gal axy S5 Neo, s5neol te, SM-G903F"
 "Samsung, Gal axy S5 Neo, s5neol te, SM-G903M"
 "Samsung, Gal axy S5 mi ni , kmi ni 3g, SM-G800HQ"
 "Samsung, Gal axy S5 mi ni , kmi ni l te, SM-G800M"
 "Samsung, Gal axy S5 mi ni , kmi ni l teatt, SAMSUNG-SM-G800A"
 "Samsung, Gal axy S5 mi ni , kmi ni wi fi , SM-G800X"
 "Samsung, Gal axy S5 mi ni LTE, kmi ni l te, SM-G800Y"
 "Samsung, Gal axy S6, zerofl te, SM-G920F"
 "Samsung, Gal axy S6, zerofl te, SM-G920I "
 "Samsung, Gal axy S6, zerofl te, SM-G920X"
 "Samsung, Gal axy S6, zerofl teacg, SM-G920R7"
 "Samsung, Gal axy S6, zerofl teai o, SAMSUNG-SM-G920AZ"
 "Samsung, Gal axy S6, zerofl teatt, SAMSUNG-SM-G920A"
 "Samsung, Gal axy S6, zerofl tebmc, SM-G920W8"
 "Samsung, Gal axy S6, zerofl techn, SM-G9200"
 "Samsung, Gal axy S6, zerofl techn, SM-G9208"
 "Samsung, Gal axy S6, zerofl tectc, SM-G9209"
 "Samsung, Gal axy S6, zerofl tektt, SM-G920K"
 "Samsung, Gal axy S6, zerofl tel gt, SM-G920L"
 "Samsung, Gal axy S6, zerofl tel ra, SM-G920R6"
 "Samsung, Gal axy S6, zerofl temtr, SM-G920T1"
 "Samsung, Gal axy S6, zerofl teskt, SM-G920S"
 "Samsung, Gal axy S6, zerofl tespr, SM-G920P"
 "Samsung, Gal axy S6, zerofl tetfnvzw, SM-S906L"
 "Samsung, Gal axy S6, zerofl tetmo, SM-G920T"
 "Samsung, Gal axy S6, zerofl teusc, SM-G920R4"
 "Samsung, Gal axy S6, zerofl tevzw, SM-G920V"
 "Samsung, Gal axy S6 Acti ve, mari nel teatt, SAMSUNG-SM-G890A"
 "Samsung, Gal axy S6 Edge, 404SC, 404SC"
 "Samsung, Gal axy S6 Edge, SCV31, SCV31"
 "Samsung, Gal axy S6 Edge, zerol te, SM-G925F"
 "Samsung, Gal axy S6 Edge, zerol te, SM-G925I "
 "Samsung, Gal axy S6 Edge, zerol te, SM-G925X"
 "Samsung, Gal axy S6 Edge, zerol teacg, SM-G925R7"
 "Samsung, Gal axy S6 Edge, zerol teatt, SAMSUNG-SM-G925A"
 "Samsung, Gal axy S6 Edge, zerol tebmc, SM-G925W8"
 "Samsung, Gal axy S6 Edge, zerol techn, SM-G9250"
 "Samsung, Gal axy S6 Edge, zerol tektt, SM-G925K"
 "Samsung, Gal axy S6 Edge, zerol tel gt, SM-G925L"
 "Samsung, Gal axy S6 Edge, zerol tel ra, SM-G925R6"
 "Samsung, Gal axy S6 Edge, zerol teskt, SM-G925S"
 "Samsung, Gal axy S6 Edge, zerol tespr, SM-G925P"
 "Samsung, Gal axy S6 Edge, zerol tetmo, SM-G925T"
 "Samsung, Gal axy S6 Edge, zerol teusc, SM-G925R4"
 "Samsung, Gal axy S6 Edge, zerol tevzw, SM-G925V"
 "Samsung, Gal axy S6 Edge+, zenl te, SM-G9287"
 "Samsung, Gal axy S6 Edge+, zenl te, SM-G9287C"
 "Samsung, Gal axy S6 Edge+, zenl te, SM-G928C"
 "Samsung, Gal axy S6 Edge+, zenl te, SM-G928F"
 "Samsung, Gal axy S6 Edge+, zenl te, SM-G928G"

supported device.txt

"Samsung, Gal axy S6 Edge+, zenl te, SM-G928I"
 "Samsung, Gal axy S6 Edge+, zenl te, SM-G928X"
 "Samsung, Gal axy S6 Edge+, zenl teatt, SAMSUNG-SM-G928A"
 "Samsung, Gal axy S6 Edge+, zenl tebmc, SM-G928W8"
 "Samsung, Gal axy S6 Edge+, zenl techn, SM-G9280"
 "Samsung, Gal axy S6 Edge+, zenl tektt, SM-G928K"
 "Samsung, Gal axy S6 Edge+, zenl tekx, SM-G928N0"
 "Samsung, Gal axy S6 Edge+, zenl tel gt, SM-G928L"
 "Samsung, Gal axy S6 Edge+, zenl teskt, SM-G928S"
 "Samsung, Gal axy S6 Edge+, zenl tespr, SM-G928P"
 "Samsung, Gal axy S6 Edge+, zenl tetmo, SM-G928T"
 "Samsung, Gal axy S6 Edge+, zenl tevw, SM-G928V"
 "Samsung, Gal axy Spi ca, GT-I 5700, GT-I 5700"
 "Samsung, Gal axy Spi ca, GT-I 5700, GT-I 5700L"
 "Samsung, Gal axy Spi ca, GT-I 5700, GT-I 5700R"
 "Samsung, Gal axy Spi ca, GT-I 5700L, GT-I 5700L"
 "Samsung, Gal axy Spi ca, spi ca, GT-I 5700"
 "Samsung, Gal axy Spi ca, spi ca, GT-I 5700L"
 "Samsung, Gal axy Spi ca, spi ca, GT-I 5700R"
 "Samsung, Gal axy Spi ca, spi ca, GT-i 5700"
 "Samsung, Gal axy Star, mi nt, GT-S5282"
 "Samsung, Gal axy Star, mi ntss, GT-S5280"
 "Samsung, Gal axy Star Pl us, l ogran2g, GT-S7262"
 "Samsung, Gal axy Star Tri os, mi ntts, GT-S5283B"
 "Samsung, Gal axy Star2 Pl us, hi ggs2g, SM-G350E"
 "Samsung, Gal axy Stel l ar, j aspervzw, SCH-I 200"
 "Samsung, Gal axy Stel l ar, j aspervzw, SCH-I 200PP"
 "Samsung, Gal axy Style Duos, aruba3gduosctc, SCH-I 829"
 "Samsung, Gal axy Tab, GT-P1000, GT-P1000"
 "Samsung, Gal axy Tab, GT-P1000L, GT-P1000L"
 "Samsung, Gal axy Tab, GT-P1000M, GT-P1000M"
 "Samsung, Gal axy Tab, GT-P1000N, GT-P1000N"
 "Samsung, Gal axy Tab, GT-P1000R, GT-P1000R"
 "Samsung, Gal axy Tab, GT-P1000T, GT-P1000T"
 "Samsung, Gal axy Tab, GT-P1010, GT-P1010"
 "Samsung, Gal axy Tab, GT-P1013, GT-P1013"
 "Samsung, Gal axy Tab, SC-01C, SC-01C"
 "Samsung, Gal axy Tab, SCH-I 800, SCH-I 800"
 "Samsung, Gal axy Tab, SGH-T849, SGH-T849"
 "Samsung, Gal axy Tab, SHW-M180K, SHW-M180K"
 "Samsung, Gal axy Tab, SHW-M180L, SHW-M180L"
 "Samsung, Gal axy Tab, SHW-M180S, SHW-M180S"
 "Samsung, Gal axy Tab, SHW-M180W, SHW-M180W"
 "Samsung, Gal axy Tab, SMT-i 9100, SMT-i 9100"
 "Samsung, Gal axy Tab 10. 1, GT-P7500, GT-P7500"
 "Samsung, Gal axy Tab 10. 1, GT-P7500D, GT-P7500D"
 "Samsung, Gal axy Tab 10. 1, GT-P7503, GT-P7503"
 "Samsung, Gal axy Tab 10. 1, GT-P7510, GT-P7510"
 "Samsung, Gal axy Tab 10. 1, SC-01D, SC-01D"
 "Samsung, Gal axy Tab 10. 1, SCH-I 905, SCH-I 905"
 "Samsung, Gal axy Tab 10. 1, SGH-T859, SGH-T859"
 "Samsung, Gal axy Tab 10. 1, SHW-M300W, SHW-M300W"
 "Samsung, Gal axy Tab 10. 1, SHW-M380K, SHW-M380K"
 "Samsung, Gal axy Tab 10. 1, SHW-M380S, SHW-M380S"
 "Samsung, Gal axy Tab 10. 1, SHW-M380W, SHW-M380W"
 "Samsung, Gal axy Tab 10. 1 N, GT-P7501, GT-P7501"
 "Samsung, Gal axy Tab 10. 1 N, GT-P7511, GT-P7511"
 "Samsung, Gal axy Tab 10. 1 v, p3, GT-P7100"
 "Samsung, Gal axy Tab 3V 7. 0, goyave3g5M, SM-T116NY"
 "Samsung, Gal axy Tab 4 8. 0, mi l l etwi Fi , SM-T330X"
 "Samsung, Gal axy Tab 4 8. 0, mi l l etwi Fi kx, SM-T330"
 "Samsung, Gal axy Tab 4 Acti ve, rubensl te, SM-T365"
 "Samsung, Gal axy Tab 4 Acti ve, rubensl te, SM-T365Y"

supported device.txt

"Samsung, Gal axy Tab 7. 0, SPH-P100, SPH-P100"
 "Samsung, Gal axy Tab 7. 0 Pl us, GT-P6200, GT-P6200"
 "Samsung, Gal axy Tab 7. 0 Pl us, GT-P6200L, GT-P6200L"
 "Samsung, Gal axy Tab 7. 0 Pl us, GT-P6201, GT-P6201"
 "Samsung, Gal axy Tab 7. 0 Pl us, GT-P6210, GT-P6210"
 "Samsung, Gal axy Tab 7. 0 Pl us, GT-P6211, GT-P6211"
 "Samsung, Gal axy Tab 7. 0 Pl us, SC-02D, SC-02D"
 "Samsung, Gal axy Tab 7. 0 Pl us, SGH-T869, SGH-T869"
 "Samsung, Gal axy Tab 7. 0 Pl us, SHW-M430W, SHW-M430W"
 "Samsung, Gal axy Tab 7. 7, GT-P6800, GT-P6800"
 "Samsung, Gal axy Tab 7. 7, GT-P6810, GT-P6810"
 "Samsung, Gal axy Tab 7. 7, SCH-I 815, SCH-I 815"
 "Samsung, Gal axy Tab 7. 7 Pl us, SC-01E, SC-01E"
 "Samsung, Gal axy Tab 8. 9, GT-P7300, GT-P7300"
 "Samsung, Gal axy Tab 8. 9, GT-P7310, GT-P7310"
 "Samsung, Gal axy Tab 8. 9, GT-P7320, GT-P7320"
 "Samsung, Gal axy Tab 8. 9, SCH-P739, SCH-P739"
 "Samsung, Gal axy Tab 8. 9, SGH-I 957, SAMSUNG-SGH-I 957"
 "Samsung, Gal axy Tab 8. 9, SGH-I 957D, SAMSUNG-SGH-I 957D"
 "Samsung, Gal axy Tab 8. 9, SGH-I 957D, SGH-I 957D"
 "Samsung, Gal axy Tab 8. 9, SGH-I 957M, SAMSUNG-SGH-I 957M"
 "Samsung, Gal axy Tab 8. 9, SGH-I 957M, SGH-I 957M"
 "Samsung, Gal axy Tab 8. 9, SGH-I 957R, SAMSUNG-SGH-I 957R"
 "Samsung, Gal axy Tab 8. 9, SGH-I 957R, SGH-I 957R"
 "Samsung, Gal axy Tab 8. 9, SHV-E140K, SHV-E140K"
 "Samsung, Gal axy Tab 8. 9, SHV-E140L, SHV-E140L"
 "Samsung, Gal axy Tab 8. 9, SHV-E140S, SHV-E140S"
 "Samsung, Gal axy Tab 8. 9, SHW-M305W, SHW-M305W"
 "Samsung, Gal axy Tab A 8. 0, gt58l te, SM-T355"
 "Samsung, Gal axy Tab A 8. 0, gt58l te, SM-T355Y"
 "Samsung, Gal axy Tab A 8. 0, gt58l techn, SM-T355C"
 "Samsung, Gal axy Tab A 8. 0, gt58l tetmo, SM-T357T"
 "Samsung, Gal axy Tab A 8. 0, gt58wi fi , SM-T350"
 "Samsung, Gal axy Tab A 8. 0, gt58wi fi , SM-T350X"
 "Samsung, Gal axy Tab A 8. 0, gt58wi fi chn, SM-T350"
 "Samsung, Gal axy Tab A 8. 0, gt58wi fi chn, SM-T350X"
 "Samsung, Gal axy Tab A 8. 0, gt5note8l te, SM-P355"
 "Samsung, Gal axy Tab A 8. 0, gt5note8l te, SM-P355M"
 "Samsung, Gal axy Tab A 8. 0, gt5note8l techn, SM-P355C"
 "Samsung, Gal axy Tab A 8. 0, gt5note8l techn, SM-P355Y"
 "Samsung, Gal axy Tab A 8. 0, gt5note8wi fi , SM-P350"
 "Samsung, Gal axy Tab A 8. 0, gt5note8wi fi chn, SM-P350"
 "Samsung, Gal axy Tab A 9. 7, gt510l te, SM-T555"
 "Samsung, Gal axy Tab A 9. 7, gt510l techn, SM-T555C"
 "Samsung, Gal axy Tab A 9. 7, gt510wi fi , SM-T550"
 "Samsung, Gal axy Tab A 9. 7, gt510wi fi , SM-T550X"
 "Samsung, Gal axy Tab A 9. 7, gt510wi fi chn, SM-T550"
 "Samsung, Gal axy Tab A 9. 7, gt510wi fi chn, SM-T550X"
 "Samsung, Gal axy Tab A 9. 7, gt5note10l te, SM-P555"
 "Samsung, Gal axy Tab A 9. 7, gt5note10l te, SM-P555M"
 "Samsung, Gal axy Tab A 9. 7, gt5note10l techn, SM-P555C"
 "Samsung, Gal axy Tab A 9. 7, gt5note10l tehktw, SM-P555Y"
 "Samsung, Gal axy Tab A 9. 7, gt5note10l tektt, SM-P555K"
 "Samsung, Gal axy Tab A 9. 7, gt5note10l tel gt, SM-P555L"
 "Samsung, Gal axy Tab A 9. 7, gt5note10l teskt, SM-P555S"
 "Samsung, Gal axy Tab A 9. 7, gt5note10wi fi , SM-P550"
 "Samsung, Gal axy Tab A 9. 7, gt5note10wi fi chn, SM-P550"
 "Samsung, Gal axy Tab A S 8. 0, gt58l tebmc, SM-T357W"
 "Samsung, Gal axy Tab E 9. 6, gtel 3g, SM-T561"
 "Samsung, Gal axy Tab E 9. 6, gtel 3g, SM-T561M"
 "Samsung, Gal axy Tab E 9. 6, gtel 3g, SM-T561Y"
 "Samsung, Gal axy Tab E 9. 6, gtel 3g, SM-T562"
 "Samsung, Gal axy Tab E 9. 6, gtel l tevzw, SM-T567V"

supported device.txt

"Samsung, Gal axy Tab E 9. 6, gtel wi fi , SM-T560"
 "Samsung, Gal axy Tab E 9. 6, gtel wi fi ue, SM-T560NU"
 "Samsung, Gal axy Tab Plus 7. 0, goyave3gsea, SM-T116BU"
 "Samsung, Gal axy Tab Pro 10. 1, pi cassol te, SM-T525"
 "Samsung, Gal axy Tab Pro 10. 1, pi cassowi fi , SM-T520"
 "Samsung, Gal axy Tab Pro 10. 1 Chef Col l ecti on, pi cassowi fi cc, SM-T520CC"
 "Samsung, Gal axy Tab Pro 12. 2, v2l te, SM-T905"
 "Samsung, Gal axy Tab Pro 12. 2, v2wi fi , SM-T900"
 "Samsung, Gal axy Tab Pro 12. 2, v2wi fi , SM-T900X"
 "Samsung, Gal axy Tab Pro 8. 4, mondri anl te, SM-T325"
 "Samsung, Gal axy Tab Pro 8. 4, mondri anwi fi , SM-T320"
 "Samsung, Gal axy Tab Pro 8. 4, mondri anwi fi , SM-T320X"
 "Samsung, Gal axy Tab Pro 8. 4, mondri anwi fi kx, SM-T320"
 "Samsung, Gal axy Tab Pro 8. 4, mondri anwi fi ue, SM-T320"
 "Samsung, Gal axy Tab Pro 8. 4, mondri anwi fi ue, SM-T320NU"
 "Samsung, Gal axy Tab Q, q7, SM-T2519"
 "Samsung, Gal axy Tab S 10. 5, chagal l wi fi , SM-T800"
 "Samsung, Gal axy Tab S 8. 4, SC-03G, SC-03G"
 "Samsung, Gal axy Tab S 8. 4, kl i mtl te, SM-T705"
 "Samsung, Gal axy Tab S 8. 4, kl i mtl te, SM-T705C"
 "Samsung, Gal axy Tab S 8. 4, kl i mtl te, SM-T705Y"
 "Samsung, Gal axy Tab S 8. 4, kl i mtl tevzw, SM-T707V"
 "Samsung, Gal axy Tab S 8. 4, kl i mtwi fi , SM-T700"
 "Samsung, Gal axy Tab S2 8. 0, gts210l te, SM-T815"
 "Samsung, Gal axy Tab S2 8. 0, gts28l te, SM-T715"
 "Samsung, Gal axy Tab S2 8. 0, gts28l te, SM-T715Y"
 "Samsung, Gal axy Tab S2 8. 0, gts28l techn, SM-T715C"
 "Samsung, Gal axy Tab S2 8. 0, gts28l tekx, SM-T715N0"
 "Samsung, Gal axy Tab S2 8. 0, gts28wi fi , SM-T710"
 "Samsung, Gal axy Tab S2 8. 0, gts28wi fi , SM-T710X"
 "Samsung, Gal axy Tab S2 8. 0, gts28wi fi chn, SM-T710"
 "Samsung, Gal axy Tab S2 9. 7, gts210l te, SM-T815C"
 "Samsung, Gal axy Tab S2 9. 7, gts210l te, SM-T815Y"
 "Samsung, Gal axy Tab S2 9. 7, gts210l te, SM-T817"
 "Samsung, Gal axy Tab S2 9. 7, gts210l teatt, SAMSUNG-SM-T817A"
 "Samsung, Gal axy Tab S2 9. 7, gts210l tecan, SM-T817W"
 "Samsung, Gal axy Tab S2 9. 7, gts210l tekx, SM-T815N0"
 "Samsung, Gal axy Tab S2 9. 7, gts210l tespr, SM-T817P"
 "Samsung, Gal axy Tab S2 9. 7, gts210l tetmo, SM-T817T"
 "Samsung, Gal axy Tab S2 9. 7, gts210l teusc, SM-T817R4"
 "Samsung, Gal axy Tab S2 9. 7, gts210l tevzw, SM-T817V"
 "Samsung, Gal axy Tab S2 9. 7, gts210wi fi , SM-T810"
 "Samsung, Gal axy Tab S2 9. 7, gts210wi fi , SM-T810X"
 "Samsung, Gal axy Tab2 10. 1, espresso10att, SAMSUNG-SGH-I 497"
 "Samsung, Gal axy Tab2 10. 1, espresso10can, SGH-I 497"
 "Samsung, Gal axy Tab2 10. 1, espresso10rf, GT-P5100"
 "Samsung, Gal axy Tab2 10. 1, espresso10spr, SPH-P500"
 "Samsung, Gal axy Tab2 10. 1, espresso10tmo, SGH-T779"
 "Samsung, Gal axy Tab2 10. 1, espresso10vzw, SCH-I 915"
 "Samsung, Gal axy Tab2 10. 1, espresso10wi fi , GT-P5110"
 "Samsung, Gal axy Tab2 10. 1, espresso10wi fi , GT-P5113"
 "Samsung, Gal axy Tab2 7. 0, espressorf, GT-P3100"
 "Samsung, Gal axy Tab2 7. 0, espressorf, GT-P3100B"
 "Samsung, Gal axy Tab2 7. 0, espressorf, GT-P3105"
 "Samsung, Gal axy Tab2 7. 0, espressovzw, SCH-I 705"
 "Samsung, Gal axy Tab2 7. 0, espressovzw, SCH-i 705"
 "Samsung, Gal axy Tab2 7. 0, espressowi fi , GT-P3110"
 "Samsung, Gal axy Tab2 7. 0, espressowi fi , GT-P3113"
 "Samsung, Gal axy Tab3, l t01wi fi kx, SM-T310"
 "Samsung, Gal axy Tab3 10. 1, santos103g, GT-P5200"
 "Samsung, Gal axy Tab3 10. 1, santos10l te, GT-P5220"
 "Samsung, Gal axy Tab3 10. 1, santos10wi fi , GT-P5210"
 "Samsung, Gal axy Tab3 10. 1, santos10wi fi , GT-P5210XD1"

supported device.txt

"Samsung, Gal axy Tab3 7. 0, l t023g, SM-T211"
 "Samsung, Gal axy Tab3 7. 0, l t023g, SM-T212"
 "Samsung, Gal axy Tab3 7. 0, l t023gdtv, SM-T211M"
 "Samsung, Gal axy Tab3 7. 0, l t02l te, SM-T215"
 "Samsung, Gal axy Tab3 7. 0, l t02l teatt, SAMSUNG-SM-T217A"
 "Samsung, Gal axy Tab3 7. 0, l t02l tespr, SM-T217S"
 "Samsung, Gal axy Tab3 7. 0, l t02l tetmo, SM-T217T"
 "Samsung, Gal axy Tab3 7. 0, l t02wi fi , SM-T210"
 "Samsung, Gal axy Tab3 7. 0, l t02wi fi , SM-T210R"
 "Samsung, Gal axy Tab3 7. 0, l t02wi fi l gt, SM-T210L"
 "Samsung, Gal axy Tab3 8. 0, l t013g, SM-T311"
 "Samsung, Gal axy Tab3 8. 0, l t013g, SM-T312"
 "Samsung, Gal axy Tab3 8. 0, l t01l te, SM-T315"
 "Samsung, Gal axy Tab3 8. 0, l t01l te, SM-T315T"
 "Samsung, Gal axy Tab3 8. 0, l t01wi fi , SM-T310"
 "Samsung, Gal axy Tab3 8. 0, l t01wi fi , SM-T310X"
 "Samsung, Gal axy Tab3 8. 0, l t02l duwi fi , SM-T210X"
 "Samsung, Gal axy Tab3 Ki ds, l t02ki dswi fi , SM-T2105"
 "Samsung, Gal axy Tab3 Li te, goya3g, SM-T111"
 "Samsung, Gal axy Tab3 Li te, goya3g, SM-T111M"
 "Samsung, Gal axy Tab3 Li te, goyawi fi , SM-T110"
 "Samsung, Gal axy Tab3 Li te 7. 0, fortunave3g, SM-G530H"
 "Samsung, Gal axy Tab3 Li te 7. 0, goyave3g, SM-T116NQ"
 "Samsung, Gal axy Tab3 Li te 7. 0, goyavewi fi , SM-T113"
 "Samsung, Gal axy Tab3 VE 7. 0, goyave3g, SM-T116"
 "Samsung, Gal axy Tab3V 7. 0, goyave3gsea, SM-T116NU"
 "Samsung, Gal axy Tab3V 7. 0, goyavewi fi xtc, SM-T113NU"
 "Samsung, Gal axy Tab4, mati ssewi fi googl e, SM-T530NN"
 "Samsung, Gal axy Tab4 10. 0, mati sse3g, SM-T531"
 "Samsung, Gal axy Tab4 10. 0, mati ssel te, SM-T535"
 "Samsung, Gal axy Tab4 10. 0, mati ssel teatt, SAMSUNG-SM-T537A"
 "Samsung, Gal axy Tab4 10. 0, mati ssel teusc, SM-T537R4"
 "Samsung, Gal axy Tab4 10. 0, mati ssel tevw, SM-T537V"
 "Samsung, Gal axy Tab4 10. 1, mati ssevefi fi , SM-T533"
 "Samsung, Gal axy Tab4 10. 1, mati ssewi fi , SM-T530"
 "Samsung, Gal axy Tab4 10. 1, mati ssewi fi , SM-T530X"
 "Samsung, Gal axy Tab4 10. 1, mati ssewi fi kx, SM-T530"
 "Samsung, Gal axy Tab4 10. 1, mati ssewi fi ue, SM-T530NU"
 "Samsung, Gal axy Tab4 7. 0, 403SC, 403SC"
 "Samsung, Gal axy Tab4 7. 0, degas3g, SM-T231"
 "Samsung, Gal axy Tab4 7. 0, degas3g, SM-T232"
 "Samsung, Gal axy Tab4 7. 0, degasl te, SM-T235"
 "Samsung, Gal axy Tab4 7. 0, degasl te, SM-T235Y"
 "Samsung, Gal axy Tab4 7. 0, degasl tespr, SM-T237P"
 "Samsung, Gal axy Tab4 7. 0, degasl tevw, SM-T237V"
 "Samsung, Gal axy Tab4 7. 0, degasvel te, SM-T239"
 "Samsung, Gal axy Tab4 7. 0, degasvel te, SM-T2397"
 "Samsung, Gal axy Tab4 7. 0, degasvel te, SM-T239M"
 "Samsung, Gal axy Tab4 7. 0, degasvel techn, SM-T239C"
 "Samsung, Gal axy Tab4 7. 0, degaswi fi , SM-T230"
 "Samsung, Gal axy Tab4 7. 0, degaswi fi , SM-T230NY"
 "Samsung, Gal axy Tab4 7. 0, degaswi fi , SM-T230X"
 "Samsung, Gal axy Tab4 7. 0, degaswi fi bmwzc, SM-T230NY"
 "Samsung, Gal axy Tab4 7. 0, degaswi fi dtv, SM-T230NT"
 "Samsung, Gal axy Tab4 7. 0, degaswi fi openbnn, SM-T230NU"
 "Samsung, Gal axy Tab4 7. 0, degaswi fi ue, SM-T230NU"
 "Samsung, Gal axy Tab4 8. 0, mi l l et3g, SM-T331"
 "Samsung, Gal axy Tab4 8. 0, mi l l etl te, SM-T335"
 "Samsung, Gal axy Tab4 8. 0, mi l l etl teatt, SAMSUNG-SM-T337A"
 "Samsung, Gal axy Tab4 8. 0, mi l l etl tektt, SM-T335K"
 "Samsung, Gal axy Tab4 8. 0, mi l l etl tel gt, SM-T335L"
 "Samsung, Gal axy Tab4 8. 0, mi l l etl tetmo, SM-T337T"
 "Samsung, Gal axy Tab4 8. 0, mi l l etl tevw, SM-T337V"

supported device.txt

"Samsung, Gal axy Tab4 8. 0, mi l l etwi fi , SM-T330"
 "Samsung, Gal axy Tab4 8. 0, mi l l etwi fi ue, SM-T330NU"
 "Samsung, Gal axy Tab4 Acti ve, rubensl te, SM-T365"
 "Samsung, Gal axy Tab4 Acti ve, rubensl te, SM-T365M"
 "Samsung, Gal axy Tab4 Acti ve, rubensl tekx, SM-T365F0"
 "Samsung, Gal axy Tab4 Acti ve, rubenswi fi , SM-T360"
 "Samsung, Gal axy Tab4 Acti ve, rubenswi fi chn, SM-T360"
 "Samsung, Gal axy Tab4 Nook 10. 1, mati ssewi fi openbnn, SM-T530NU"
 "Samsung, Gal axy TabS 10. 5, SCT21, SCT21"
 "Samsung, Gal axy TabS 10. 5, chagal l hl tektt, SM-T805K"
 "Samsung, Gal axy TabS 10. 5, chagal l hl tel gt, SM-T805L"
 "Samsung, Gal axy TabS 10. 5, chagal l hl teskt, SM-T805S"
 "Samsung, Gal axy TabS 10. 5, chagal l l te, SM-T805"
 "Samsung, Gal axy TabS 10. 5, chagal l l te, SM-T805M"
 "Samsung, Gal axy TabS 10. 5, chagal l l te, SM-T805Y"
 "Samsung, Gal axy TabS 10. 5, chagal l l te, SM-T807"
 "Samsung, Gal axy TabS 10. 5, chagal l l teatt, SAMSUNG-SM-T807A"
 "Samsung, Gal axy TabS 10. 5, chagal l l tecan, SM-T805W"
 "Samsung, Gal axy TabS 10. 5, chagal l l tespr, SM-T807P"
 "Samsung, Gal axy TabS 10. 5, chagal l l tetmo, SM-T807T"
 "Samsung, Gal axy TabS 10. 5, chagal l l teusc, SM-T807R4"
 "Samsung, Gal axy TabS 10. 5, chagal l l tevzw, SM-T807V"
 "Samsung, Gal axy TabS 10. 5, chagal l wi fi , SM-T800"
 "Samsung, Gal axy TabS 10. 5, chagal l wi fi , SM-T800X"
 "Samsung, Gal axy TabS 10. 5, chagal l wi fi kx, SM-T800"
 "Samsung, Gal axy TabS 8. 4, kl i mtl te, SM-T705"
 "Samsung, Gal axy TabS 8. 4, kl i mtl te, SM-T705M"
 "Samsung, Gal axy TabS 8. 4, kl i mtl teatt, SAMSUNG-SM-T707A"
 "Samsung, Gal axy TabS 8. 4, kl i mtl tecan, SM-T705W"
 "Samsung, Gal axy TabS 8. 4, kl i mtwi fi , SM-T700"
 "Samsung, Gal axy TabS 8. 4, kl i mtwi fi kx, SM-T700"
 "Samsung, Gal axy Tap Pro 10. 1, pi cassol te, SM-T525"
 "Samsung, Gal axy Tap Pro 8. 4, mondri anwi fi , SM-T320"
 "Samsung, Gal axy Trend, kyl eve, GT-S7392"
 "Samsung, Gal axy Trend, kyl eve, GT-S7392L"
 "Samsung, Gal axy Trend, kyl eve3gcmcc, GT-S7568I "
 "Samsung, Gal axy Trend Duos, kyl ei chn, GT-S7562i "
 "Samsung, Gal axy Trend Duos, kyl epl uschn, GT-S7572"
 "Samsung, Gal axy Trend Duos, kyl eve, GT-S7390"
 "Samsung, Gal axy Trend Duos, kyl eve, GT-S7392"
 "Samsung, Gal axy Trend Duos, kyl eve, GT-S7562C"
 "Samsung, Gal axy Trend Li te, kyl evess, GT-S7390"
 "Samsung, Gal axy Trend Li te, kyl evess, GT-S7390L"
 "Samsung, Gal axy Trend Pl us, kyl epro, GT-S7580"
 "Samsung, Gal axy Trend Pl us, kyl epro, GT-S7580E"
 "Samsung, Gal axy Trend Pl us, kyl epro, GT-S7580L"
 "Samsung, Gal axy Trend Pl us, kyl epro, GT-S7583T"
 "Samsung, Gal axy Trend2, garda3gcmcc, GT-S7898"
 "Samsung, Gal axy Trend2, gardave3gcmcc, GT-S7898I "
 "Samsung, Gal axy Trend2, kyl epl usctc, SCH-I 739"
 "Samsung, Gal axy Trend3, cs023g, SM-G3502U"
 "Samsung, Gal axy Trend3, cs02cmcc, SM-G3508"
 "Samsung, Gal axy Trend3, cs02ctc, SM-G3509"
 "Samsung, Gal axy Trend3, cs02ve, SM-G3508I "
 "Samsung, Gal axy Trend3, cs02ve3g, SM-G3502C"
 "Samsung, Gal axy Trend3, cs02ve3g, SM-G3502I "
 "Samsung, Gal axy Trend3, cs02ve3g, SM-G3508J"
 "Samsung, Gal axy Trend3, cs02ve3g, SM-G3509I "
 "Samsung, Gal axy U, SHW-M130L, SHW-M130L"
 "Samsung, Gal axy Vi ctory, goghspr, SPH-L300"
 "Samsung, Gal axy Vi ctory, goghvmu, SPH-L300"
 "Samsung, Gal axy W, GT-I 8150, GT-I 8150"
 "Samsung, Gal axy W, GT-I 8150B, GT-I 8150B"

supported device.txt

"Samsung, Gal axy W, GT-I 8150T, GT-I 8150T"
 "Samsung, Gal axy W, SGH-T679M, SGH-T679M"
 "Samsung, Gal axy W, q7l teskt, SM-T255S"
 "Samsung, Gal axy Wi n, del os3gcmcc, GT-I 8558"
 "Samsung, Gal axy Wi n, del os3gduosctc, SCH-I 869"
 "Samsung, Gal axy Wi n, del os3geur, GT-I 8552"
 "Samsung, Gal axy Wi n, del os3geur, GT-I 8552B"
 "Samsung, Gal axy Wi n, del os3gss, GT-I 8550E"
 "Samsung, Gal axy Wi n, del osl tel gt, SHV-E500L"
 "Samsung, Gal axy Wi n, del osl teskt, SHV-E500S"
 "Samsung, Gal axy Wi n Duos, del os3gchn, GT-I 8552"
 "Samsung, Gal axy Wi n Pro, wi l cox3g, SM-G3818"
 "Samsung, Gal axy Wi n Pro, wi l coxctc, SM-G3819"
 "Samsung, Gal axy Wi n Pro, wi l coxctc, SM-G3819D"
 "Samsung, Gal axy Wi n Pro, wi l coxds, SM-G3812"
 "Samsung, Gal axy Wi n2, corepri mel tedtv, SM-G360BT"
 "Samsung, Gal axy Xcover, GT-S5690, GT-S5690"
 "Samsung, Gal axy Xcover, GT-S5690L, GT-S5690L"
 "Samsung, Gal axy Xcover, GT-S5690M, GT-S5690M"
 "Samsung, Gal axy Xcover, GT-S5690R, GT-S5690R"
 "Samsung, Gal axy Xcover2, skomer, GT-S7710"
 "Samsung, Gal axy Xcover2, skomer, GT-S7710L"
 "Samsung, Gal axy Xcover3, xcover3l te, SM-G388F"
 "Samsung, Gal axy Y, GT-S5360, GT-S5360"
 "Samsung, Gal axy Y, GT-S5360B, GT-S5360B"
 "Samsung, Gal axy Y, GT-S5360L, GT-S5360L"
 "Samsung, Gal axy Y, GT-S5360T, GT-S5360T"
 "Samsung, Gal axy Y, GT-S5363, GT-S5363"
 "Samsung, Gal axy Y, GT-S5368, GT-S5368"
 "Samsung, Gal axy Y, GT-S5369, GT-S5369"
 "Samsung, Gal axy Y, SCH-I 509, SCH-I 509"
 "Samsung, Gal axy Y, SCH-i 509, SCH-i 509"
 "Samsung, Gal axy Y Duos, GT-S6102, GT-S6102"
 "Samsung, Gal axy Y Duos, GT-S6102B, GT-S6102B"
 "Samsung, Gal axy Y Duos, GT-S6102E, GT-S6102E"
 "Samsung, Gal axy Y Pl us, cori pl usds, GT-S5303"
 "Samsung, Gal axy Y Pl us, cori pl usds, GT-S5303B"
 "Samsung, Gal axy Y Pop, GT-S6108, GT-S6108"
 "Samsung, Gal axy Y Pro, GT-B5510, GT-B5510"
 "Samsung, Gal axy Y Pro, GT-B5510B, GT-B5510B"
 "Samsung, Gal axy Y Pro, GT-B5510L, GT-B5510L"
 "Samsung, Gal axy Y Pro Duos, GT-B5512, GT-B5512"
 "Samsung, Gal axy Y Pro Duos, GT-B5512B, GT-B5512B"
 "Samsung, Gal axy Y TV, GT-S5367, GT-S5367"
 "Samsung, Gal axy Young, roy, GT-S6312"
 "Samsung, Gal axy Young, roydtv, GT-S6313T"
 "Samsung, Gal axy Young, royss, GT-S6310"
 "Samsung, Gal axy Young, royss, GT-S6310B"
 "Samsung, Gal axy Young, royss, GT-S6310L"
 "Samsung, Gal axy Young, royss, GT-S6310T"
 "Samsung, Gal axy Young, royssdtv, GT-S6313T"
 "Samsung, Gal axy Young, royssnfc, GT-S6310N"
 "Samsung, Gal axy Young2, young23g, SM-G130H"
 "Samsung, Gal axy Young2, young23g, SM-G130M"
 "Samsung, Gal axy Young2, young23g, SM-G130U"
 "Samsung, Gal axy Young2, young23gdtv, SM-G130BT"
 "Samsung, Gal axy Young2, young2ds2g, SM-G130E"
 "Samsung, Gal axy Young2, young2nfc3g, SM-G130HN"
 "Samsung, Gal axy Young2 Pro, young2ve3g, SM-G130BU"
 "Samsung, Gal axy pl ayer 70 Pl us, YP-GB70D, YP-GB70D"
 "Samsung, Gal axy wi n, del os3gss, GT-I 8550L"
 "Samsung, Garda, gardal teMetroPCS, SGH-T399N"
 "Samsung, Gear Li ve, sprat, Gear Li ve"

supported device.txt

"Samsung, Gem, SCH-I 100, SCH-I 100"
"Samsung, Hennessy, hennessy3gduosctc, SCH-W789"
"Samsung, Homesync, spcwi fi , GT-B9150"
"Samsung, IceTouch, gokey, YP-GH1"
"Samsung, I I I usi on, SCH-I 110, SCH-I 110"
"Samsung, Infuse, SGH-I 997, SAMSUNG-SGH-I 997"
"Samsung, Infuse, SGH-I 997R, SAMSUNG-SGH-I 997R"
"Samsung, Moment, SPH-M900, SPH-M900"
"Samsung, Montbl anc, montbl anc3gctc, SM-W2014"
"Samsung, Nexus 10, manta, Nexus 10"
"Samsung, Nexus S, crespo, Nexus S"
"Samsung, Nexus S, crespo4g, Nexus S 4G"
"Samsung, ProXpress M4580, fi ber-athena, samsung-pri nter-tablet"
"Samsung, Repl eni sh, SPH-M580, SPH-M580"
"Samsung, Repl eni sh, SPH-M580BST, SPH-M580BST"
"Samsung, Repp, SCH-R680, SCH-R680"
"Samsung, Roy VE DTV, royssvedtv, GT-S6293T"
"Samsung, Roy VE DTV, royvedtv, GT-S6293T"
"Samsung, Rugby Smart, SGH-I 847, SAMSUNG-SGH-I 847"
"Samsung, SC-01F, SC-01F, SC-01F"
"Samsung, SC-01G, SC-01G, SC-01G"
"Samsung, SC-02G, SC-02G, SC-02G"
"Samsung, SC-04F, SC-04F, SC-04F"
"Samsung, SC-04G, SC-04G, SC-04G"
"Samsung, SC-05G, SC-05G, SC-05G"
"Samsung, SM-G9198, phi l i ppe l techn, SM-G9198"
"Samsung, Samsung Gal axy S4, j fl teMetroPCS, SGH-M919N"
"Samsung, Samsung Gal axy S4 Zoom, mprojectl tektt, SM-C105K"
"Samsung, Samsung Gal axy Stratosphere2, aegi s2vzw, SCH-I 415"
"Samsung, Samsung Garda, gardal tetmo, SGH-T399"
"Samsung, Samsung Homesync, spcwi fi , GT-B9150"
"Samsung, Samsung Homesync, spcwi fi any, GT-B9150"
"Samsung, Si deki ck, SGH-T839, SGH-T839"
"Samsung, Transfi x, SCH-R730, SCH-R730"
"Samsung, Transform, SPH-M920, SPH-M920"
"Samsung, Transform UI tra, SPH-M930, SPH-M930"
"Samsung, Transform UI tra, SPH-M930BST, SPH-M930BST"
"Samsung, Vi nsQ, SPH-M910, SPH-M910"
"Samsung, Vi nsQ(M910) , SPH-M910, SPH-M910"
"Samsung, ol l eh, i k1, SMT-E5015"
"Sanyo, 55CE6139M1, CEM1, CEM1"
"Sanyo, Benesse, 31TL04, 31TL04"
"Sanyo, Benesse, 40TL04, 40TL04"
"Sanyo, Benesse, 41EA04, 41EA04"
"Sanyo, CEA1, CEA1, CEA1"
"Sanyo, CEA3, CEA3, CEA3"
"Sanyo, CEH1, CEH1, CEH1"
"Sanyo, CER2, CER2, CER2"
"Sanyo, CER3, CER3, CER3"
"Seemahal e Tel ecoms, ST5000, ST5000, ST5000"
"Sharp, , SH7218T, SH7218T"
"Sharp, , SH8268U, SH8268U"
"Sharp, , SH8288U, SH8288U"
"Sharp, , SH8298U, SH8298U"
"Sharp, , msm7627_surf, SH8118U"
"Sharp, 306SH, SG306SH, 306SH"
"Sharp, 401SH, SG401SH, 401SH"
"Sharp, A01SH, A01SH, A01SH"
"Sharp, ADS1, ADS1, SHARP-ADS1"
"Sharp, AQUOS CRYSTAL 2, SG403SH, 403SH"
"Sharp, AQUOS CRYSTAL X, SG402SH, 402SH"
"Sharp, AQUOS EVER SH-04G, SH-04G, SH-04G"
"Sharp, AQUOS K SHF31, SHF31, SHF31"

supported device.txt

"Sharp, AQUOS K SHF32, SHF32, SHF32"
"Sharp, AQUOS PAD SHT22, SHT22, SHT22"
"Sharp, AQUOS PAD SH-05G, SH-05G, SH-05G"
"Sharp, AQUOS PAD SH-06F, SH-06F, SH-06F"
"Sharp, AQUOS PAD SH-08E, SH-08E, SH-08E"
"Sharp, AQUOS PAD SHT21, SHT21, SHT21"
"Sharp, AQUOS PHONE SERIE SHL22, SHL22, SHL22"
"Sharp, AQUOS PHONE SERIE SHL23, SHL23, SHL23"
"Sharp, AQUOS PHONE SERIE mini SHL24, SHL24, SHL24"
"Sharp, AQUOS PHONE CL IS17SH, SHI 17, IS17SH"
"Sharp, AQUOS PHONE EX SH-02F, SH-02F, SH-02F"
"Sharp, AQUOS PHONE EX SH-04E, SH04E, SH-04E"
"Sharp, AQUOS PHONE IS11SH, SHI 11, IS11SH"
"Sharp, AQUOS PHONE IS12SH, SHI 12, IS12SH"
"Sharp, AQUOS PHONE IS13SH, SHI 13, IS13SH"
"Sharp, AQUOS PHONE IS14SH, SHI 14, IS14SH"
"Sharp, AQUOS PHONE SERIE ISW16SH, SHI 16, ISW16SH"
"Sharp, AQUOS PHONE SERIE SHL21, SHL21, SHL21"
"Sharp, AQUOS PHONE SH-01D, SH01D, SH-01D"
"Sharp, AQUOS PHONE SH-06D, SH06D, SH-06D"
"Sharp, AQUOS PHONE SH-12C, SH12C, SH-12C"
"Sharp, AQUOS PHONE SH90B, SH90B, SH90B"
"Sharp, AQUOS PHONE SL IS15SH, SHI 15, IS15SH"
"Sharp, AQUOS PHONE SoftBank 102SH II, SBM102SH2, SBM102SH2"
"Sharp, AQUOS PHONE SoftBank 006SH, SBM006SH, SBM006SH"
"Sharp, AQUOS PHONE SoftBank 102SH, SBM102SH, SBM102SH"
"Sharp, AQUOS PHONE SoftBank 103SH, SBM103SH, SBM103SH"
"Sharp, AQUOS PHONE SoftBank 104SH, SBM104SH, SBM104SH"
"Sharp, AQUOS PHONE THE HYBRID SoftBank 007SH, SBM007SH, SBM007SH"
"Sharp, AQUOS PHONE THE HYBRID SoftBank 007SH J, SBM007SHJ, SBM007SHJ"
"Sharp, AQUOS PHONE THE HYBRID SoftBank 101SH, SBM101SH, SBM101SH"
"Sharp, AQUOS PHONE THE PREMIUM SoftBank 009SH, SBM009SH, SBM009SH"
"Sharp, AQUOS PHONE WX05SH, WX05SH, WX05SH"
"Sharp, AQUOS PHONE Xx 206SH, SBM206SH, SBM206SH"
"Sharp, AQUOS PHONE Xx 302SH, SBM302SH, SBM302SH"
"Sharp, AQUOS PHONE Xx SoftBank 106SH, SBM106SH, SBM106SH"
"Sharp, AQUOS PHONE Xx mini 303SH, SBM303SH, SBM303SH"
"Sharp, AQUOS PHONE ZETA SH-01F, SH-01F, SH-01F"
"Sharp, AQUOS PHONE ZETA SH-02E, SH02E, SH-02E"
"Sharp, AQUOS PHONE ZETA SH-06E, SH-06E, SH-06E"
"Sharp, AQUOS PHONE ZETA SH-09D, SH09D, SH-09D"
"Sharp, AQUOS PHONE es WX04SH, WX04SH, WX04SH"
"Sharp, AQUOS PHONE f SH-13C, SH13C, SH-13C"
"Sharp, AQUOS PHONE si SH-01E, SH01E, SH-01E"
"Sharp, AQUOS PHONE si SH-07E, SH-07E, SH-07E"
"Sharp, AQUOS PHONE slider SH-02D, SH02D, SH-02D"
"Sharp, AQUOS PHONE ss 205SH, SBM205SH, SBM205SH"
"Sharp, AQUOS PHONE st SH-07D, SH07D, SH-07D"
"Sharp, AQUOS PHONE sv SH-10D, SH10D, SH-10D"
"Sharp, AQUOS SERIE SHL25, SHL25, SHL25"
"Sharp, AQUOS SERIE SHV32, SHV32, SHV32"
"Sharp, AQUOS SERIE mini SHV31, SHV31, SHV31"
"Sharp, AQUOS SH-M01, SH-M01, SH-M01"
"Sharp, AQUOS SH-M02, SH-M02, SH-M02"
"Sharp, AQUOS Xx, SG404SH, 404SH"
"Sharp, AQUOS Xx 304SH, SG304SH, 304SH"
"Sharp, AQUOS ZETA SH-01G, SH-01G, SH-01G"
"Sharp, AQUOS ZETA SH-01H, SH-01H, SH-01H"
"Sharp, AQUOS ZETA SH-03G, SH-03G, SH-03G"
"Sharp, AQUOS ZETA SH-04F, SH-04F, SH-04F"
"Sharp, AQUOS \xe3\x82\xb1\xe3\x83\xbc\xe3\x82\xbf\xe3\x82\xa4 SH-06G, SH-06G, SH-06G"
"Sharp, DMO09SH, DMO09SH, DMO09SH"
"Sharp, DMO10SH, DMO10SH, DMO10SH"

supported device.txt

"Sharp, DM011SH, DM011SH, DM011SH"
"Sharp, DM012SH, DM012SH, DM012SH"
"Sharp, DM013SH, DM013SH, DM013SH"
"Sharp, DM016SH, DM016SH, DM016SH"
"Sharp, Di sney Mobi le DM014SH, DM014SH, DM014SH"
"Sharp, Di sney Mobi le on docomo SH-02G, SH-02G, SH-02G"
"Sharp, Di sney Mobi le on docomo SH-05F, SH-05F, SH-05F"
"Sharp, EB-A71GJ, EB-A71GJ, EB-A71GJ"
"Sharp, EB-WX1GJ/EB-W51GJ, Gal apagos, EB-W51GJ"
"Sharp, EB-WX1GJ/EB-W51GJ, Gal apagos, EB-WX1GJ"
"Sharp, GALAPAGOS SoftBank 003SH, SBM003SH, SBM003SH"
"Sharp, GALAPAGOS SoftBank 005SH, SBM005SH, SBM005SH"
"Sharp, INFOBAR A01, SHX11, INFOBAR A01"
"Sharp, INFOBAR C01, SHX12, INFOBAR C01"
"Sharp, IS01, SHI 01, IS01"
"Sharp, IS03, SHI 03, IS03"
"Sharp, IS05, SHI 05, IS05"
"Sharp, LC-**UH30U, sharp_2k15_us_androi d, LC-Ux30US"
"Sharp, LC-42LE860H, LC-42LE860H, LC-42LE860H"
"Sharp, LC-42LE860M, LC-42LE860M, LC-42LE860M"
"Sharp, LC-50LE860H, LC-50LE860H, LC-50LE860H"
"Sharp, LC-50LE860M, LC-50LE860M, LC-50LE860M"
"Sharp, LC-50UE1H, LC-50UE1H, LC-50UE1H"
"Sharp, LC-50UE1M, LC-50UE1M, LC-50UE1M"
"Sharp, LC-55LE860H, LC-55LE860H, LC-55LE860H"
"Sharp, LC-55LE860M, LC-55LE860M, LC-55LE860M"
"Sharp, LC-58UE1H, LC-58UE1H, LC-58UE1H"
"Sharp, LC-58UE1M, LC-58UE1M, LC-58UE1M"
"Sharp, LC-A11A, a11a, LC-A11A"
"Sharp, LC-A1H, a1h, LC-A1H"
"Sharp, LC-LX565H, I x565h, LC-LX565H"
"Sharp, LC-S3H-01, I c_s3h01, LC-S3H-01"
"Sharp, LCD-LX460A, I x460a, LCD-LX460A"
"Sharp, LCD-LX560A, I x560a, LCD-LX560A"
"Sharp, LCD-LX565A, I x565ab, LCD-LX565A-B"
"Sharp, LCD-LX565A, msd818sharp, LCD-LX565A"
"Sharp, LCD-S3A-01, I cd_s3a01, LCD-S3A-01"
"Sharp, LCD-UF30A, I cd_uf30a, LCD-UF30A"
"Sharp, LCD-V3A, v3a, LCD-V3A"
"Sharp, LYNX 3D SH-03C, SH03C, SH-03C"
"Sharp, LYNX SH-10B, SH10B, SH-10B"
"Sharp, Medi a Tabl et, EB-L76G-B, EB-L76G-B"
"Sharp, PANTONE 5 SoftBank 107SH, SBM107SH, SBM107SH"
"Sharp, PANTONE 6 SoftBank 200SH, SBM200SH, SBM200SH"
"Sharp, Q-pot. Phone SH-04D, SH04D, SH-04D"
"Sharp, RW107, RW107, RW107"
"Sharp, SBM204SH, SBM204SH, SBM204SH"
"Sharp, SC-S01, scal I op, SC-S01"
"Sharp, SH-01E Vi vi enne Westwood, SH01EVW, SH-01EVW"
"Sharp, SH-01F DRAGON QUEST, SH-01FDQ, SH-01FDQ"
"Sharp, SH-03F, SH03F, SH-03F"
"Sharp, SH-05E, SH05E, SH-05E"
"Sharp, SH-06D NERV, SH06DNERV, SH-06DNERV"
"Sharp, SH80F, SH80F, SH80F"
"Sharp, SH8118U, msm7627, SH8118U"
"Sharp, SH8128U, msm7627, SH8128U"
"Sharp, SH8188U, SH8188U, SH8188U"
"Sharp, SH825wi, SH825Wi, SH825Wi "
"Sharp, SoftBank 007SH KT, SBM007SHK, SBM007SHK"
"Sharp, SoftBank 107SH B, SBM107SHB, SBM107SHB"
"Sharp, SoftBank 305SH, SG305SH, 305SH"
"Sharp, SoftBank AQUOS PHONE Xx 203SH, SBM203SH, SBM203SH"
"Sharp, Yahoo! Phone SoftBank 009SH Y, SBM009SHY, SBM009SHY"

supported device.txt

"Si AL, Bi c camera, Si 01BB, Si 01BB"
"Si AL, Si 01BE, Si 01BE, Si 01BE"
"Si co SmartPhone, SSR1-5-8M, GBC_bravo, SSR1-5-8M"
"Si co SmartPhone, SSR1-5-8M, GBC_bravo, si co pro"
"Si lent Circle, Bl ackphone 2, BP2, Bl ackphone 2"
"Si ragon, Si ragon SP-5000, SP-5000, Si ragon SP-5000"
"Smartab, STJR700, STJR700, STJR700"
"Smartab, Smartab SRF79, SRF79, SRF79"
"Smartab, Smartab STJR76, STJR76, STJR76"
"Smartfren, AD688G, AD688G, Smartfren Andromax AD688G"
"Smartfren, AD689G, AD689G, Smartfren Andromax AD689G"
"Smartfren, Andromax AD687G, AD687G, Andromax AD687G"
"Smartfren, Andromax C46B2G, HS8916QC, Andromax C46B2G"
"Smartfren, C2LEAD688G, C2LEAD688G, Smartfren Andromax AD688G"
"Smartfren, EG680, eg680, EG680"
"Smartfren, G36C1G, HS8916QC, Andromax G36C1G"
"Smartfren, G36C1H, G36C1H, Andromax G36C1H"
"Smartfren, I46D1G, HS8916QC, Andromax I46D1G"
"Smartfren, NC36B1G, HS8610QC, Smartfren Andromax NC36B1G"
"Smartfren, NEWAD688G, NEWAD688G, Smartfren Andromax AD688G"
"Smartfren, Smartfren Andromax AD682H, AD682H, Smartfren Andromax AD682H"
"Smartfren, Smartfren AndromaxNC36B1H, NC36B1H, Smartfren Andromax NC36B1H"
"Soni m, Ex-Handy 09, XP6700Z1, Ex-Handy 09"
"Soni m, Smart-Ex 01, XP7700Z1, Smart-Ex 01"
"Soni m, XP6, XP6700, XP6700"
"Soni m, XP7, XP7700, XP7700"
"Soni mtech, XP6, XP6700, Ex-Handy 209"
"Soni mtech, XP6, XP6700, XP6700"
"Soni mtech, XP7, XP7700, Smart-Ex 201"
"Soni mtech, XP7, XP7700, XP7700"
"Soni mtech, XP7, XP7700Z1, Smart-Ex 01"
"Soni mtech, XP7700Z1, XP7700Z1, Smart-Ex 01"
"Soni mtech, XP7705, XP7705, XP7700"
"Sony, , C5503, C5503"
"Sony, , C6616, C6616"
"Sony, , SGP312, SGP312"
"Sony, , ST21i , ST21i "
"Sony, , ST23i , ST23i "
"Sony, , ST26i , ST26i "
"Sony, , nbx02, Sony Tablet P"
"Sony, BRAVIA 2015, SVP-DTV15, BRAVIA 2015"
"Sony, BRAVIA 4K 2015, SVP-DTV15, BRAVIA 2015"
"Sony, BRAVIA 4K 2015, SVP-DTV15, BRAVIA 4K 2015"
"Sony, BRAVIA Smart Sti ck, NSZGU1, NSZ-GU1"
"Sony, Internet TV, asura, Internet TV"
"Sony, Internet TV, eagle, Internet TV Box"
"Sony, NSZGS7, NSZGS7, NSZ-GS7/GX70"
"Sony, NW-F800, i cx1227, WALKMAN"
"Sony, NW-F880 Seri es, i cx1237, WALKMAN"
"Sony, NW-Z1000, i cx1216, NW-Z1000Seri es"
"Sony, NW-ZX1, i cx1240, WALKMAN"
"Sony, NWZ-Z1000, i cx1216, NWZ-Z1000Seri es"
"Sony, SmartWatch 3, tetra, SmartWatch 3"
"Sony, Sony Ericsson Live wi th Wal kman, WT19a, WT19a"
"Sony, Sony Ericsson Live wi th Wal kman, WT19i , WT19i "
"Sony, Sony Smartphone Z Ul tra Google Pl ay edi ti on, C6806, C6806_GPe"
"Sony, Sony Tablet S, nbx03, Sony Tablet S"
"Sony, Tablet P, nbx02, Sony Tablet P"
"Sony, Tablet S, nbx03, Sony Tablet S"
"Sony, Xperi a E1 dual, D2114, D2114"
"Sony, Xperi a A, S0-04E, S0-04E"
"Sony, Xperi a A2, S0-04F, S0-04F"
"Sony, Xperi a A4, S0-04G, S0-04G"

supported device.txt

"Sony, Xperia C, C2304, C2304"
"Sony, Xperia C, C2305, C2305"
"Sony, Xperia C3, D2533, D2533"
"Sony, Xperia C3 Dual, D2502, D2502"
"Sony, Xperia C5 Ultra, E5506, E5506"
"Sony, Xperia C5 Ultra, E5553, E5553"
"Sony, Xperia C5 Ultra Dual, E5533, E5533"
"Sony, Xperia C5 Ultra Dual, E5563, E5563"
"Sony, Xperia E, C1504, C1504"
"Sony, Xperia E, C1505, C1505"
"Sony, Xperia E dual, C1604, C1604"
"Sony, Xperia E dual, C1605, C1605"
"Sony, Xperia E1, D2004, D2004"
"Sony, Xperia E1, D2005, D2005"
"Sony, Xperia E1, D2114, D2114"
"Sony, Xperia E1 Dual, D2104, D2104"
"Sony, Xperia E1 Dual, D2105, D2105"
"Sony, Xperia E1 dual, D2104, D2104"
"Sony, Xperia E1 dual, D2105, D2105"
"Sony, Xperia E3, D2202, D2202"
"Sony, Xperia E3, D2203, D2203"
"Sony, Xperia E3, D2206, D2206"
"Sony, Xperia E3, D2243, D2243"
"Sony, Xperia E3 Dual, D2212, D2212"
"Sony, Xperia E4g, E2053, E2053"
"Sony, Xperia E4g Dual, E2033, E2033"
"Sony, Xperia E4g Dual, E2043, E2043"
"Sony, Xperia Go, ST27a, ST27a"
"Sony, Xperia Go, ST27i, ST27i"
"Sony, Xperia J, ST26a, ST26a"
"Sony, Xperia J, ST26i, ST26i"
"Sony, Xperia J1 Compact, D5788, D5788"
"Sony, Xperia L, C2104, C2104"
"Sony, Xperia L, C2105, C2105"
"Sony, Xperia M, C1904, C1904"
"Sony, Xperia M, C1905, C1905"
"Sony, Xperia M dual, C2004, C2004"
"Sony, Xperia M dual, C2005, C2005"
"Sony, Xperia M2, D2303, D2303"
"Sony, Xperia M2, D2305, D2305"
"Sony, Xperia M2, D2306, D2306"
"Sony, Xperia M2 Aqua, D2403, D2403"
"Sony, Xperia M2 Aqua, D2406, D2406"
"Sony, Xperia M2 Dual, D2302, D2302"
"Sony, Xperia M2 dual, D2302, D2302"
"Sony, Xperia M5, E5603, E5603"
"Sony, Xperia M5, E5606, E5606"
"Sony, Xperia M5, E5653, E5653"
"Sony, Xperia M5 Dual, E5633, E5633"
"Sony, Xperia M5 Dual, E5643, E5643"
"Sony, Xperia M5 Dual, E5663, E5663"
"Sony, Xperia Mi ro, ST23i, ST23i"
"Sony, Xperia P, LT22i, LT22i"
"Sony, Xperia PLAY, R800a, R800a"
"Sony, Xperia PLAY, R800i, R800i"
"Sony, Xperia S, LT26i, LT26i"
"Sony, Xperia SL, LT26i, LT26i"
"Sony, Xperia SP, C5302, C5302"
"Sony, Xperia SP, C5303, C5303"
"Sony, Xperia SP, C5306, C5306"
"Sony, Xperia SP, M35h, M35h"
"Sony, Xperia SP, M35t, M35t"
"Sony, Xperia T, LT30a, LT30a"

supported device.txt

"Sony, Xperia T, LT30p, LT30p"
"Sony, Xperia T2 Ultra, D5303, D5303"
"Sony, Xperia T2 Ultra, D5306, D5306"
"Sony, Xperia T2 Ultra, D5316, D5316"
"Sony, Xperia T2 Ultra, D5316N, D5316N"
"Sony, Xperia T2 Ultra, D5322, D5322"
"Sony, Xperia T2 Ultra dual, D5322, D5322"
"Sony, Xperia T3, D5102, D5102"
"Sony, Xperia T3, D5103, D5103"
"Sony, Xperia T3, D5106, D5106"
"Sony, Xperia TX, LT29i, LT29i"
"Sony, Xperia Tablet S, txs03, SGPT12"
"Sony, Xperia Tablet S, txs03, SGPT13"
"Sony, Xperia Tablet Z, SGP311, SGP311"
"Sony, Xperia Tablet Z, SGP312, SGP312"
"Sony, Xperia Tablet Z, SGP321, SGP321"
"Sony, Xperia Tablet Z, SGP351, SGP351"
"Sony, Xperia Tipo, ST21i, ST21i"
"Sony, Xperia Tipo, ST21i 2, ST21i 2"
"Sony, Xperia U, ST25a, ST25a"
"Sony, Xperia U, ST25i, ST25i"
"Sony, Xperia V, LT25i, LT25i"
"Sony, Xperia Z, C6602, C6602"
"Sony, Xperia Z, C6603, C6603"
"Sony, Xperia Z, C6606, C6606"
"Sony, Xperia Z, C6616, C6616"
"Sony, Xperia Z, L36h, L36h"
"Sony, Xperia Z, S0-02E, S0-02E"
"Sony, Xperia Z Ultra, C6802, C6802"
"Sony, Xperia Z Ultra, C6806, C6806"
"Sony, Xperia Z Ultra, C6833, C6833"
"Sony, Xperia Z Ultra, C6843, C6843"
"Sony, Xperia Z Ultra, SGP412, SGP412"
"Sony, Xperia Z Ultra, S0L24, S0L24"
"Sony, Xperia Z Ultra, XL39h, XL39h"
"Sony, Xperia Z1, C6902, C6902"
"Sony, Xperia Z1, C6903, C6903"
"Sony, Xperia Z1, C6906, C6906"
"Sony, Xperia Z1, C6916, C6916"
"Sony, Xperia Z1, C6943, C6943"
"Sony, Xperia Z1, L39h, L39h"
"Sony, Xperia Z1, L39t, L39t"
"Sony, Xperia Z1, L39u, L39u"
"Sony, Xperia Z1, S0-01F, S0-01F"
"Sony, Xperia Z1, S0L23, S0L23"
"Sony, Xperia Z1 Compact, D5503, D5503"
"Sony, Xperia Z1 Compact, M51w, M51w"
"Sony, Xperia Z1F, S0-02F, S0-02F"
"Sony, Xperia Z2, D6502, D6502"
"Sony, Xperia Z2, D6503, D6503"
"Sony, Xperia Z2, D6543, D6543"
"Sony, Xperia Z2, S0-03F, S0-03F"
"Sony, Xperia Z2 Tablet, SGP511, SGP511"
"Sony, Xperia Z2 Tablet, SGP512, SGP512"
"Sony, Xperia Z2 Tablet, SGP521, SGP521"
"Sony, Xperia Z2 Tablet, SGP551, SGP551"
"Sony, Xperia Z2 Tablet, SGP561, SGP561"
"Sony, Xperia Z2 Tablet, S0-05F, S0-05F"
"Sony, Xperia Z2 Tablet, S0T21, S0T21"
"Sony, Xperia Z2a, D6563, D6563"
"Sony, Xperia Z3, 401S0, 401S0"
"Sony, Xperia Z3, D6603, D6603"
"Sony, Xperia Z3, D6616, D6616"

supported device.txt

"Sony, Xperi a Z3, D6643, D6643"
"Sony, Xperi a Z3, D6646, D6646"
"Sony, Xperi a Z3, D6653, D6653"
"Sony, Xperi a Z3, S0-01G, S0-01G"
"Sony, Xperi a Z3, SOL26, SOL26"
"Sony, Xperi a Z3, l eo, D6603"
"Sony, Xperi a Z3 Compact, D5803, D5803"
"Sony, Xperi a Z3 Compact, D5833, D5833"
"Sony, Xperi a Z3 Compact, S0-02G, S0-02G"
"Sony, Xperi a Z3 Dual , D6633, D6633"
"Sony, Xperi a Z3 Dual , D6683, D6683"
"Sony, Xperi a Z3 Tabl et Compact, SGP611, SGP611"
"Sony, Xperi a Z3 Tabl et Compact, SGP612, SGP612"
"Sony, Xperi a Z3 Tabl et Compact, SGP621, SGP621"
"Sony, Xperi a Z3 Tabl et Compact, SGP641, SGP641"
"Sony, Xperi a Z3+, E6553, E6553"
"Sony, Xperi a Z3+ Dual , E6533, E6533"
"Sony, Xperi a Z3v, D6708, D6708"
"Sony, Xperi a Z4, 402S0, 402S0"
"Sony, Xperi a Z4, S0-03G, S0-03G"
"Sony, Xperi a Z4, SOV31, SOV31"
"Sony, Xperi a Z4 Tabl et, SGP771, SGP771"
"Sony, Xperi a Z4 Tabl et, S0-05G, S0-05G"
"Sony, Xperi a Z4 Tabl et, S0T31, S0T31"
"Sony, Xperi a Z4 tabl et, SGP712, SGP712"
"Sony, Xperi a Z4v, E6508, E6508"
"Sony, Xperi a Z5, 501S0, 501S0"
"Sony, Xperi a Z5, E6603, E6603"
"Sony, Xperi a Z5, E6653, E6653"
"Sony, Xperi a Z5, S0-01H, S0-01H"
"Sony, Xperi a Z5, SOV32, SOV32"
"Sony, Xperi a Z5 Compact, E5803, E5803"
"Sony, Xperi a Z5 Compact, E5823, E5823"
"Sony, Xperi a Z5 dual , E6633, E6633"
"Sony, Xperi a Z5 dual , E6683, E6683"
"Sony, Xperi a ZL, C6502, C6502"
"Sony, Xperi a ZL, C6503, C6503"
"Sony, Xperi a ZL, C6506, C6506"
"Sony, Xperi a ZL, L35h, L35h"
"Sony, Xperi a ZL2, SOL25, SOL25"
"Sony, Xperi a ZR, C5306, C5306"
"Sony, Xperi a ZR, C5502, C5502"
"Sony, Xperi a ZR, C5503, C5503"
"Sony, Xperi a acro HD, S0-03D, S0-03D"
"Sony, Xperi a acro S, LT26w, LT26w"
"Sony, Xperi a acti ve, ST17i , ST17i "
"Sony, Xperi a arc S, LT18i , LT18i "
"Sony, Xperi a go, ST27i , ST27i "
"Sony, Xperi a i on, LT28h, LT28h"
"Sony, Xperi a i on, LT28i , LT28i "
"Sony, Xperi a mi ni pro, SK17a, SK17a"
"Sony, Xperi a mi ro, ST23a, ST23a"
"Sony, Xperi a mi ro, ST23i , ST23i "
"Sony, Xperi a neo L, MT25i , MT25i "
"Sony, Xperi a pro, MK16i , MK16i "
"Sony, Xperi a ray, ST18i , ST18i "
"Sony, Xperi a sol a, MT27i , MT27i "
"Sony, Xperi a ti po, ST21a, ST21a"
"Sony, Xperi a ti po dual , ST21a2, ST21a2"
"Sony, Xperi a\xe2\x84\xa2 C4, E5303, E5303"
"Sony, Xperi a\xe2\x84\xa2 C4, E5306, E5306"
"Sony, Xperi a\xe2\x84\xa2 C4, E5353, E5353"
"Sony, Xperi a\xe2\x84\xa2 C4 Dual , E5333, E5333"

supported device.txt

"Sony, Xperi a\xe2\x84\xa2 C4 Dual , E5343, E5343"
 "Sony, Xperi a\xe2\x84\xa2 C4 Dual , E5363, E5363"
 "Sony, Xperi a\xe2\x84\xa2 E4, E2104, E2104"
 "Sony, Xperi a\xe2\x84\xa2 E4, E2105, E2105"
 "Sony, Xperi a\xe2\x84\xa2 E4 Dual , E2115, E2115"
 "Sony, Xperi a\xe2\x84\xa2 E4 Dual , E2124, E2124"
 "Sony, Xperi a\xe2\x84\xa2 E4g, E2003, E2003"
 "Sony, Xperi a\xe2\x84\xa2 E4g, E2006, E2006"
 "Sony, Xperi a\xe2\x84\xa2 M4 Aqua, E2303, E2303"
 "Sony, Xperi a\xe2\x84\xa2 M4 Aqua, E2306, E2306"
 "Sony, Xperi a\xe2\x84\xa2 M4 Aqua, E2353, E2353"
 "Sony, Xperi a\xe2\x84\xa2 M4 Aqua Dual , E2312, E2312"
 "Sony, Xperi a\xe2\x84\xa2 M4 Aqua Dual , E2333, E2333"
 "Sony, Xperi a\xe2\x84\xa2 M4 Aqua Dual , E2363, E2363"
 "Sony Eri csson, , LT15a, LT15a"
 "Sony Eri csson, , LT18i , LT18i "
 "Sony Eri csson, , LT22i , LT22i "
 "Sony Eri csson, , LT26i , LT26i "
 "Sony Eri csson, , LT28h, LT28h"
 "Sony Eri csson, , LT28i , LT28i "
 "Sony Eri csson, , MK16a, MK16a"
 "Sony Eri csson, , MK16i , MK16i "
 "Sony Eri csson, , MT11i , MT11i "
 "Sony Eri csson, , MT15i , MT15i "
 "Sony Eri csson, , MT27i , MT27i "
 "Sony Eri csson, , R800x, R800x"
 "Sony Eri csson, , SK17i , SK17i "
 "Sony Eri csson, , ST15i , ST15i "
 "Sony Eri csson, , ST17i , ST17i "
 "Sony Eri csson, , ST18i , ST18i "
 "Sony Eri csson, , WT18i , WT18i "
 "Sony Eri csson, , WT19a, WT19a"
 "Sony Eri csson, , WT19i , WT19i "
 "Sony Eri csson, Li ve wi th Wal kman, WT19a, WT19a"
 "Sony Eri csson, Li ve wi th Wal kman, WT19i , WT19i "
 "Sony Eri csson, Li ve wi th Wal kman(TM), WT19a, WT19a"
 "Sony Eri csson, X10 Xperi a Mi ni , robyn, E10i "
 "Sony Eri csson, Xperi a A, S0-04E, S0-04E"
 "Sony Eri csson, Xperi a AX, S0-01E, S0-01E"
 "Sony Eri csson, Xperi a Acro, I S11S, I S11S"
 "Sony Eri csson, Xperi a Acro, S0-02C, S0-02C"
 "Sony Eri csson, Xperi a Arc, LT15i , LT15i "
 "Sony Eri csson, Xperi a Arc, S0-01C, S0-01C"
 "Sony Eri csson, Xperi a C, S39h, S39h"
 "Sony Eri csson, Xperi a GX, S0-04D, S0-04D"
 "Sony Eri csson, Xperi a Go, ST27a, ST27a"
 "Sony Eri csson, Xperi a Go, ST27i , ST27i "
 "Sony Eri csson, Xperi a J, ST26i , ST26i "
 "Sony Eri csson, Xperi a Neo, MT15i , MT15i "
 "Sony Eri csson, Xperi a P, LT22i , LT22i "
 "Sony Eri csson, Xperi a PLAY, R800a, R800a"
 "Sony Eri csson, Xperi a PLAY, R800at, R800at"
 "Sony Eri csson, Xperi a PLAY, R800i , R800i "
 "Sony Eri csson, Xperi a PLAY, R800x, R800x"
 "Sony Eri csson, Xperi a PLAY, S0-01D, S0-01D"
 "Sony Eri csson, Xperi a Pl ay, R800i , R800i "
 "Sony Eri csson, Xperi a Pl ay, Zeus, Zeus"
 "Sony Eri csson, Xperi a S, LT26i , LT26i "
 "Sony Eri csson, Xperi a S, S0-02D, S0-02D"
 "Sony Eri csson, Xperi a SL, LT26i i , LT26i i "
 "Sony Eri csson, Xperi a SP, M35c, M35c"
 "Sony Eri csson, Xperi a SX, S0-05D, S0-05D"
 "Sony Eri csson, Xperi a T, LT30a, LT30a"

supported device.txt

"Sony Ericsson, Xperia T, LT30at, LT30at"
 "Sony Ericsson, Xperia T, LT30p, LT30p"
 "Sony Ericsson, Xperia TX, LT29i, LT29i "
 "Sony Ericsson, Xperia Tablet Z, SGP311, SGP311"
 "Sony Ericsson, Xperia Tablet Z, SGP321, SGP321"
 "Sony Ericsson, Xperia Tablet Z, SGP341, SGP341"
 "Sony Ericsson, Xperia Tablet Z, S0-03E, S0-03E"
 "Sony Ericsson, Xperia U, ST25i, ST25i "
 "Sony Ericsson, Xperia UL, SOL22, SOL22"
 "Sony Ericsson, Xperia V, LT25c, LT25c"
 "Sony Ericsson, Xperia V, LT25i, LT25i "
 "Sony Ericsson, Xperia VL, SOL21, SOL21"
 "Sony Ericsson, Xperia X10, S0-01B, S0-01B"
 "Sony Ericsson, Xperia X10, SonyEricssonS0-01B, S0-01B"
 "Sony Ericsson, Xperia X10, SonyEricssonX10i v, X10i "
 "Sony Ericsson, Xperia X10, X10a, X10a"
 "Sony Ericsson, Xperia X10, X10i, X10i "
 "Sony Ericsson, Xperia X10 Mini, E10i, E10i "
 "Sony Ericsson, Xperia X10 Mini, SonyEricssonE10i, E10i "
 "Sony Ericsson, Xperia X10 Mini Pro, U20i, U20i "
 "Sony Ericsson, Xperia X10 mini, SonyEricssonE10a, E10a"
 "Sony Ericsson, Xperia X10 mini pro, SonyEricssonU20a, U20a"
 "Sony Ericsson, Xperia X8, E15i, E15i "
 "Sony Ericsson, Xperia Z, S0-02E, S0-02E"
 "Sony Ericsson, Xperia Z Ultra, C6806, C6806"
 "Sony Ericsson, Xperia Z1, C6903, C6903"
 "Sony Ericsson, Xperia Z1, C6906, C6906"
 "Sony Ericsson, Xperia Z1, C6943, C6943"
 "Sony Ericsson, Xperia acro HD, IS12S, IS12S"
 "Sony Ericsson, Xperia acro S, LT26w, LT26w"
 "Sony Ericsson, Xperia active, ST17i, ST17i "
 "Sony Ericsson, Xperia arc, LT15a, LT15a"
 "Sony Ericsson, Xperia arc, LT15i, LT15i "
 "Sony Ericsson, Xperia arc S, LT18a, LT18a"
 "Sony Ericsson, Xperia arc S, LT18i, LT18i "
 "Sony Ericsson, Xperia go, ST27i, ST27i "
 "Sony Ericsson, Xperia ion, LT28at, LT28at"
 "Sony Ericsson, Xperia ion, LT28h, LT28h"
 "Sony Ericsson, Xperia ion, LT28i, LT28i "
 "Sony Ericsson, Xperia Live, WT19a, WT19a"
 "Sony Ericsson, Xperia mini, S51SE, S51SE"
 "Sony Ericsson, Xperia mini, ST15a, ST15a"
 "Sony Ericsson, Xperia mini, ST15i, ST15i "
 "Sony Ericsson, Xperia mini pro, SK17a, SK17a"
 "Sony Ericsson, Xperia mini pro, SK17i, SK17i "
 "Sony Ericsson, Xperia miro, ST23i, ST23i "
 "Sony Ericsson, Xperia neo, MT15a, MT15a"
 "Sony Ericsson, Xperia neo, MT15i, MT15i "
 "Sony Ericsson, Xperia neo L, MT25i, MT25i "
 "Sony Ericsson, Xperia neo V, MT11a, MT11a"
 "Sony Ericsson, Xperia neo V, MT11i, MT11i "
 "Sony Ericsson, Xperia pro, MK16a, MK16a"
 "Sony Ericsson, Xperia pro, MK16i, MK16i "
 "Sony Ericsson, Xperia ray, S0-03C, S0-03C"
 "Sony Ericsson, Xperia ray, ST18a, ST18a"
 "Sony Ericsson, Xperia ray, ST18i, ST18i "
 "Sony Ericsson, Xperia sola, MT27i, MT27i "
 "Sony Ericsson, Xperia tipo, ST21i, ST21i "
 "Sony Ericsson, Xperia tipo dual, ST21i 2, ST21i 2"
 "Sophix_Digix, TAB-750_G, TAB-750_G, TAB-750_G"
 "Sourcing Creation, Connect 451, Connect451, Connect 451"
 "Sourcing Creation, Connect502, Connect502, Connect502"
 "Sourcing Creation, Connect502, MT502, Connect502"

supported device.txt

"Sourcing Creation, Connect551, Connect551, Connect551"
 "Sourcing Creation, ST1003S, T1882R, Smart_TAB_1003s"
 "Sourcing Creation, SmartTab_8004, T814, SmartTab_8004"
 "Sourcing Creation, Web\ Pad_1002_02, Webpad_1002_02, Webpad_1002_02"
 "Sourcing Creation, sp401, sp401, sp401"
 "Sourcing Creation, webpad_7005, MB709Q5, Webpad_7005"
 "Southern Telecom, A5, A5, A5"
 "Southern Telecom, ST13, ST13, ST13"
 "Southern Telecom, Smartab ST10, ST10, ST10/ST10x"
 "Southern Telecom, Smartab ST7, ST7, ST7/ST7x"
 "Southern Telecom, a4, a4, a4"
 "Spectralink, PIVOT 8741/8753, thor_6dq, 8741"
 "Spectralink, PIVOT 8741/8753, thor_6dq, 8753"
 "Spice, Dream Uno, Mi -498_sprout, Spice Mi -498"
 "Spice, Dream Uno, Mi -498_sprout, Spice Mi -498H"
 "Spice, Smart Flo Mi -449, SpiceMi 449, SpiceMi -449"
 "Spice, Smart Flo Mi -449, hongyu72_wet_j b3, SpiceMi -449"
 "Spice, Stellar Mi -438, Spice, MI -438"
 "Spice, Stellar Mi -506, SpiceMi 506, Spice Mi -506"
 "Storex, eZeeTab10D12-S, eZeeTab10D12-S, eZeeTab10D12-S"
 "Storex, eZeeTab7D15-M, eZeeTab7D15-M, eZeeTab7D15-M"
 "Sugar, Sugar, s9121, SUGAR"
 "Sumitomo Electric Networks, , dhe1100, Hi kari -i Frame/WDPF-703SE"
 "Symphony, Roar A50, Roar_A50_sprout, Roar_A50"
 "TA71CA5_JP, "" JP SA COUTO, S. A. _MG070A2T"" , TA71CA5_1, TA71CA5"
 "TCL, L55E6700UDS, movo_l a, movo_l a"
 "TCL, LE50UHDE5692G, movo, movo"
 "TCT (Alcatel) , , A556C, A556C"
 "TCT (Alcatel) , , A919_gsm, TCL A919"
 "TCT (Alcatel) , , ASB-D_T918, ASB-D T918"
 "TCT (Alcatel) , , B-Gri ffi nPI us_TD, ASB-D T918"
 "TCT (Alcatel) , , BASE_Vari a_gsm, BASE_Vari a"
 "TCT (Alcatel) , , E928_TD, TCL E928"
 "TCT (Alcatel) , , Gri ffi n_TD, TCL E928"
 "TCT (Alcatel) , , MOVE_gsm, MOVE"
 "TCT (Alcatel) , , MTC-962_gsm, MTC-962"
 "TCT (Alcatel) , , Martini , one touch 906"
 "TCT (Alcatel) , , MegaFon_SP-A10, MegaFon_SP-A10"
 "TCT (Alcatel) , , ONE_TOUCH_928D_gsm, ALCATEL ONE TOUCH 928D"
 "TCT (Alcatel) , , ONE_TOUCH_983A_gsm, ALCATEL_one_touch_983A"
 "TCT (Alcatel) , , ONE_TOUCH_983M_gsm, ONE TOUCH 983M"
 "TCT (Alcatel) , , OP070, OP070"
 "TCT (Alcatel) , , OT-906, ALCATEL_one_touch_906"
 "TCT (Alcatel) , , OT-906, ALCATEL_one_touch_906Y"
 "TCT (Alcatel) , , OT-913D, ALCATEL_one_touch_913D"
 "TCT (Alcatel) , , OT-976, ALCATEL_one_touch_976"
 "TCT (Alcatel) , , OT-978, ALCATEL_one_touch_978"
 "TCT (Alcatel) , , OT-979, ALCATEL_one_touch_979"
 "TCT (Alcatel) , , OT-979, ALCATEL_one_touch_979_Hel l oKi tty"
 "TCT (Alcatel) , , OT-980A_gsm, Alcatel OT-980A"
 "TCT (Alcatel) , , OT-980_gsm, Alcatel OT-980"
 "TCT (Alcatel) , , OT-980_gsm, Alcatel OT-980A"
 "TCT (Alcatel) , , OT-980_gsm, Alcatel OT-981A"
 "TCT (Alcatel) , , OT-981A_gsm, Alcatel OT-981A"
 "TCT (Alcatel) , , OT-981_gsm, Alcatel OT-981A"
 "TCT (Alcatel) , , OT_918_gsm, ALCATEL OT 918"
 "TCT (Alcatel) , , OT_919_Hel l oKi tty_gsm, ALCATEL OT 919 Hel l oKi tty"
 "TCT (Alcatel) , , OT_919_gsm, ALCATEL OT 919"
 "TCT (Alcatel) , , OT_990M_gsm, ALCATEL_OT_990M"
 "TCT (Alcatel) , , RASPG3201_umts, RASPG3201"
 "TCT (Alcatel) , , RPSPG3201_umts, RPSPG3201"
 "TCT (Alcatel) , , SmartIII4, Vodafone 975N"
 "TCT (Alcatel) , , T20, one touch T20"

supported device.txt

"TCT (Al catel) , , T60, onetouch T60"
 "TCT (Al catel) , , TCL-A909_A909_gsm, TCL A909"
 "TCT (Al catel) , , TCL-S806, TCL-S806"
 "TCT (Al catel) , , TCL_890D_gsm, TCL A890 2SIM"
 "TCT (Al catel) , , TCL_A510, TCL A510"
 "TCT (Al catel) , , TCL_A510, TCL_A510"
 "TCT (Al catel) , , TCL_A919_umts, TCL A919"
 "TCT (Al catel) , , TCL_A919_umts, TCL_W969"
 "TCT (Al catel) , , TCL_A966_gsm, TCL A966"
 "TCT (Al catel) , , TCL_A968, TCL A968"
 "TCT (Al catel) , , TCL_A980_gsm, TCL A980"
 "TCT (Al catel) , , TCL_A986_gsm, TCL A986"
 "TCT (Al catel) , , TCL_A988_gsm, TCL_A988"
 "TCT (Al catel) , , TCL_A998_gsm, TCL A998"
 "TCT (Al catel) , , TCL_C990_Plus_cdma, TCL C990+ "
 "TCT (Al catel) , , TCL_D515_cdma, TCL D515"
 "TCT (Al catel) , , TCL_D662_cdma, TCL D662"
 "TCT (Al catel) , , TCL_S800_GSM, TCL S800"
 "TCT (Al catel) , , TCL_W939_gsm, TCL_W939"
 "TCT (Al catel) , , TCL_W969_gsm, TCL W969"
 "TCT (Al catel) , , Vancouver_gsm, Vancouver_Orange"
 "TCT (Al catel) , , mercury, I-L1"
 "TCT (Al catel) , , move_2_gsm, move 2"
 "TCT (Al catel) , , msm7627_ffa, Al catel OT-980"
 "TCT (Al catel) , , msm7627_ffa, Al catel OT-980A"
 "TCT (Al catel) , , one_touch_890D_gsm, ALCATEL one touch 890D"
 "TCT (Al catel) , , one_touch_890_gsm, ALCATEL one_touch_890"
 "TCT (Al catel) , , one_touch_890_gsm, Vi p_Mi ni Droi d"
 "TCT (Al catel) , , one_touch_891_gsm, ALCATEL one_touch_891"
 "TCT (Al catel) , , one_touch_908A_gsm, ALCATEL one_touch_908A"
 "TCT (Al catel) , , one_touch_908F_gsm, ALCATEL one_touch_908F"
 "TCT (Al catel) , , one_touch_908F_gsm, ALCATEL one_touch_908F_Orange"
 "TCT (Al catel) , , one_touch_908F_gsm, Al catel one_touch_908F"
 "TCT (Al catel) , , one_touch_908F_gsm, Al catel one_touch_908F_Orange"
 "TCT (Al catel) , , one_touch_908M_gsm, ALCATEL one_touch_908M"
 "TCT (Al catel) , , one_touch_908S_gsm, ALCATEL one_touch_908S"
 "TCT (Al catel) , , one_touch_908_gsm, ALCATEL ONE TOUCH 908"
 "TCT (Al catel) , , one_touch_909A_gsm, ALCATEL one_touch_909A"
 "TCT (Al catel) , , one_touch_909B_cdma, ALCATEL one_touch_909B"
 "TCT (Al catel) , , one_touch_909B_cdma, USCC_ALCATEL one_touch_909B"
 "TCT (Al catel) , , one_touch_909S_gsm, ALCATEL one_touch_909S"
 "TCT (Al catel) , , one_touch_910A_gsm, ALCATEL one_touch_910A"
 "TCT (Al catel) , , one_touch_910_gsm, ALCATEL one_touch_910"
 "TCT (Al catel) , , one_touch_916A_gsm, ALCATEL ONE TOUCH 916A"
 "TCT (Al catel) , , one_touch_916D_gsm, ALCATEL ONE TOUCH 916D"
 "TCT (Al catel) , , one_touch_916_gsm, ALCATEL ONE TOUCH 916"
 "TCT (Al catel) , , one_touch_918M_gsm, ALCATEL ONE TOUCH 918M"
 "TCT (Al catel) , , one_touch_918M_umts, ALCATEL one_touch_918M"
 "TCT (Al catel) , , one_touch_918N_umts, ALCATEL one_touch_918N"
 "TCT (Al catel) , , one_touch_918_gsm, ALCATEL ONE TOUCH 918"
 "TCT (Al catel) , , one_touch_985_gsm, ALCATEL ONE TOUCH 985"
 "TCT (Al catel) , , one_touch_985_gsm, Tel enor Smart"
 "TCT (Al catel) , , one_touch_988_cdma, ALCATEL one_touch_988"
 "TCT (Al catel) , , one_touch_988_cdma, USCC_ALCATEL one_touch_988"
 "TCT (Al catel) , , one_touch_990A_gsm, ALCATEL ONE TOUCH 990A"
 "TCT (Al catel) , , one_touch_990A_gsm, ALCATEL one_touch_990A"
 "TCT (Al catel) , , one_touch_990C_cdma, ALCATEL one touch 990C"
 "TCT (Al catel) , , one_touch_990_gsm, ALCATEL ONE TOUCH 990"
 "TCT (Al catel) , , one_touch_990_gsm, Al catel one touch 990 Orange"
 "TCT (Al catel) , , one_touch_990_gsm, Tel enor OneTouch"
 "TCT (Al catel) , , one_touch_991S_gsm, ALCATEL ONE TOUCH 991S"
 "TCT (Al catel) , , one_touch_993D_gsm, ALCATEL ONE TOUCH 993D"
 "TCT (Al catel) , , one_touch_995A_gsm, ALCATEL one_touch_995A"

supported device.txt

"TCT (Al catel), , one_touch_995C_cdma, one touch 995C+"
"TCT (Al catel), , one_touch_996_gsm, Orange_infinity_996"
"TCT (Al catel), \t ALCATEL ONETOUCH PIXI 3 (4.5), PIXI 3_45_4G, 5017X"
"TCT (Al catel), 4013M, Pi xi 3-4, 4013M"
"TCT (Al catel), 4014A, Pi xi 3-4, 4014A"
"TCT (Al catel), 4014M, Pi xi 3-4, 4014M"
"TCT (Al catel), 5038D, SOUL45_GSM, 5038D"
"TCT (Al catel), 5042T, ALT045TMO, 5042T"
"TCT (Al catel), 5054A, Pop355, 5054A"
"TCT (Al catel), 5054D, Pop355, 5054D"
"TCT (Al catel), 5065A, Pop35, 5065A"
"TCT (Al catel), 5065D, Pop35, 5065D"
"TCT (Al catel), 5065X, Pop35, 5065X"
"TCT (Al catel), 6010A, Mi ata_3G, 6016A"
"TCT (Al catel), 6014X, Mi ata_3G, 6014X"
"TCT (Al catel), 6016D, Mi ata_3G, 6016D"
"TCT (Al catel), 6016E, Mi ata_3G, 6016E"
"TCT (Al catel), 6016X, Mi ata_3G, 6016X"
"TCT (Al catel), 6037B, Ecl i pse, 6037B"
"TCT (Al catel), 6037K, Ecl i pse, 6037K"
"TCT (Al catel), 6037Y, Ecl i pse, 6037Y"
"TCT (Al catel), 6039A, i dol 347, 6039A"
"TCT (Al catel), 6039H, i dol 347, 6039H"
"TCT (Al catel), 6039J, i dol 347, 6039J"
"TCT (Al catel), 6039K, i dol 347, 6039K"
"TCT (Al catel), 6039S, i dol 347, 6039S"
"TCT (Al catel), 6039Y, i dol 347, 6039Y"
"TCT (Al catel), 6042D, CROSSAPAC, 6042D"
"TCT (Al catel), 6043A, DI ABLOXPLUS, 6043A"
"TCT (Al catel), 6043D, DI ABLOXPLUS, 6043D"
"TCT (Al catel), 7040N, Yari s5TMO, 7040N"
"TCT (Al catel), 7040R, Yari s5TMO, 7040R"
"TCT (Al catel), 7040T, Yari s5TMO, 7040T"
"TCT (Al catel), 7045Y, RI 05, 7045Y"
"TCT (Al catel), 730U, Ri o5C, J730U"
"TCT (Al catel), 8030B, HER02, 8030B"
"TCT (Al catel), 8030B, HER02PLUS, 8030B"
"TCT (Al catel), 8030Y, HER02, 8030Y"
"TCT (Al catel), 8054, Pi xi 3-7, 8054"
"TCT (Al catel), 8055, Pi xi 3-7, 8055"
"TCT (Al catel), 8056, Pi xi 3-7, 8056"
"TCT (Al catel), 8057, Pi xi 3-7, 8057"
"TCT (Al catel), 8057, Pi xi 3-7, KR076"
"TCT (Al catel), 8070, Pi xi 3-8_Wi Fi, 8070"
"TCT (Al catel), 8079, Pi xi 3-10_Wi Fi, 8079"
"TCT (Al catel), 8080, Pi xi 3-10_Wi Fi, 8080"
"TCT (Al catel), 9002A, Pi xi 3-7_3G, 9002A"
"TCT (Al catel), 9002A, Pi xi 3-7_3G, ALCATEL ONE TOUCH 9002A"
"TCT (Al catel), 9002X, Pi xi 3-7_3G, 9002X"
"TCT (Al catel), 9005X, PI X08_3G, 9005X"
"TCT (Al catel), 9006W, Pi xi 2-7_4G_TMO, 9006W"
"TCT (Al catel), 9007X, Pi xi 3-7_4G_EE, 9007X"
"TCT (Al catel), 9020A, ti nt8_att, 9020A"
"TCT (Al catel), 9021A, Pop2-8_4G_Tel us, 9021A"
"TCT (Al catel), A520L, Al to4EVD0, A520L"
"TCT (Al catel), A521L, Al to4NA, A521L"
"TCT (Al catel), A846L, Al to5TF, A846L"
"TCT (Al catel), A851L, Vi per_gsm, Al catel 7030L"
"TCT (Al catel), A851L, Vi per_gsm, Al catel A851L"
"TCT (Al catel), ALCATEL 4015T, Yari s35_GSM, ALCATEL 4015T"
"TCT (Al catel), ALCATEL A564C, Yari s5NA, ALCATEL A564C"
"TCT (Al catel), ALCATEL A564R, Yari s5NA, ALCATEL A564R"
"TCT (Al catel), ALCATEL ONE TOUCH 4005D, Beetl e_Li te_Edge_GSM, ALCATEL ONE TOUCH 4005D"

supported device.txt

"TCT (Al catel), ALCATEL ONE TOUCH 4005D, Beetle_Lite_Edge_GSM, ALCATEL_ONE_TOUCH_4005D"
"TCT (Al catel), ALCATEL ONE TOUCH 4010X, Beetle_Lite_GSM, ALCATEL ONE TOUCH 4010A"
"TCT (Al catel), ALCATEL ONE TOUCH 4010X, Beetle_Lite_GSM, ALCATEL ONE TOUCH 4010D"
"TCT (Al catel), ALCATEL ONE TOUCH 4010X, Beetle_Lite_GSM, ALCATEL ONE TOUCH 4010E"
"TCT (Al catel), ALCATEL ONE TOUCH 4010X, Beetle_Lite_GSM, ALCATEL ONE TOUCH 4010X"
"TCT (Al catel), ALCATEL ONE TOUCH 4010X, Beetle_Lite_GSM, TCL_J210"
"TCT (Al catel), ALCATEL ONE TOUCH 4010X, Beetle_Lite_GSM, Telenor Smart 2"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, ALCATEL ONE TOUCH 4029A"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, ALCATEL ONE TOUCH 4030D"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, ALCATEL ONE TOUCH 4030E"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, ALCATEL ONE TOUCH 4030X"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, ALCATEL ONE TOUCH 4030Y"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, ALCATEL ONE TOUCH 4030Y_orange"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, Infinity POP"
"TCT (Al catel), ALCATEL ONE TOUCH 4030X, Beetle_GSM, Orange Runo"
"TCT (Al catel), ALCATEL ONE TOUCH 4037N, SOUL4NA, ALCATEL ONE TOUCH 4037N"
"TCT (Al catel), ALCATEL ONE TOUCH 4037N, SOUL4NA, ALCATEL ONE TOUCH 4037T"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL ONE TOUCH 5020A"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL ONE TOUCH 5020D"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL ONE TOUCH 5020E"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL ONE TOUCH 5020T"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL ONE TOUCH 5020W"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL ONE TOUCH 5020X"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL ONE TOUCH 5021E"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL_ONE_TOUCH_5020D_Orange"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, ALCATEL_ONE_TOUCH_5020X_Orange"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, AURUS III"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, MTC 972"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, Orange Ki vo"
"TCT (Al catel), ALCATEL ONE TOUCH 5020D, Megane_GSM, Telenor Smart Pro 2"
"TCT (Al catel), ALCATEL ONE TOUCH 5020N, Megane, ALCATEL ONE TOUCH 5020N"
"TCT (Al catel), ALCATEL ONE TOUCH 5035D, Camry_GSM, ALCATEL ONE TOUCH 5035A"
"TCT (Al catel), ALCATEL ONE TOUCH 5035D, Camry_GSM, ALCATEL ONE TOUCH 5035D"
"TCT (Al catel), ALCATEL ONE TOUCH 5035D, Camry_GSM, ALCATEL ONE TOUCH 5035E"
"TCT (Al catel), ALCATEL ONE TOUCH 5035D, Camry_GSM, ALCATEL ONE TOUCH 5035X"
"TCT (Al catel), ALCATEL ONE TOUCH 5035D, Camry_GSM, TCL J610"
"TCT (Al catel), ALCATEL ONE TOUCH 5035D, Camry_GSM, TCL S810"
"TCT (Al catel), ALCATEL ONE TOUCH 5036A, Yari sL_GSM, ALCATEL ONE TOUCH 5036A"
"TCT (Al catel), ALCATEL ONE TOUCH 5036D, Yari sL_GSM, ALCATEL ONE TOUCH 5036D"
"TCT (Al catel), ALCATEL ONE TOUCH 5036D, Yari sL_GSM, ONE TOUCH 5036X"
"TCT (Al catel), ALCATEL ONE TOUCH 5036F, Yari sL_GSM, ALCATEL ONE TOUCH 5036F"
"TCT (Al catel), ALCATEL ONE TOUCH 5036X, Yari sL_GSM, ALCATEL ONE TOUCH 5036X"
"TCT (Al catel), ALCATEL ONE TOUCH 5037E, Yari sL_GSM, ALCATEL ONE TOUCH 5037E"
"TCT (Al catel), ALCATEL ONE TOUCH 601, Tel sa, ALCATEL ONE TOUCH 6010"
"TCT (Al catel), ALCATEL ONE TOUCH 6010A, Tel sa, ALCATEL ONE TOUCH 6010A"
"TCT (Al catel), ALCATEL ONE TOUCH 6010D, Tel sa, ALCATEL ONE TOUCH 6010D"
"TCT (Al catel), ALCATEL ONE TOUCH 6010X, Tel sa, ALCATEL ONE TOUCH 6010"
"TCT (Al catel), ALCATEL ONE TOUCH 6010X, Tel sa, ALCATEL ONE TOUCH 6010D"
"TCT (Al catel), ALCATEL ONE TOUCH 6010X, Tel sa, ALCATEL ONE TOUCH 6010X"
"TCT (Al catel), ALCATEL ONE TOUCH 6010X, Tel sa, ALCATEL ONE TOUCH 6010X-orange"
"TCT (Al catel), ALCATEL ONE TOUCH 6010X, Tel sa, TCL S520"
"TCT (Al catel), ALCATEL ONE TOUCH 6030A, Di abl o, ALCATEL ONE TOUCH 6030A"
"TCT (Al catel), ALCATEL ONE TOUCH 6030D, Di abl o, ALCATEL ONE TOUCH 6030D"
"TCT (Al catel), ALCATEL ONE TOUCH 6030N, Di abl o, ALCATEL ONE TOUCH 6030N"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X, Di abl o, ALCATEL ONE TOUCH 6030A"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X, Di abl o, ALCATEL ONE TOUCH 6030D"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X, Di abl o, ALCATEL ONE TOUCH 6030X"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X, Di abl o, ALCATEL ONE TOUCH 6030X-orange"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X, Di abl o, ALCATEL_ONE_TOUCH_6030X_Orange"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X, Di abl o, Opti mus_San_Remoo"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X, Di abl o, TCL S820"
"TCT (Al catel), ALCATEL ONE TOUCH 6030X-orange, Di abl o, ALCATEL ONE TOUCH 6030X-orange"
"TCT (Al catel), ALCATEL ONE TOUCH 6032, Al pha, ALCATEL ONE TOUCH 6032"

supported device.txt

"TCT (Al catel), ALCATEL ONE TOUCH 6032A, Al pha, ALCATEL ONE TOUCH 6032A"
"TCT (Al catel), ALCATEL ONE TOUCH 6032X, Al pha, ALCATEL ONE TOUCH 6032X"
"TCT (Al catel), ALCATEL ONE TOUCH 6033A, Di abl oHD, ALCATEL ONE TOUCH 6033A"
"TCT (Al catel), ALCATEL ONE TOUCH 6033M, Di abl oHD, ALCATEL ONE TOUCH 6033M"
"TCT (Al catel), ALCATEL ONE TOUCH 6033X, Di abl oHD, ALCATEL ONE TOUCH 6033M"
"TCT (Al catel), ALCATEL ONE TOUCH 6033X, Di abl oHD, ALCATEL ONE TOUCH 6033X"
"TCT (Al catel), ALCATEL ONE TOUCH 6033X, Di abl oHD, TCL S850"
"TCT (Al catel), ALCATEL ONE TOUCH 6037B, Ecl i pse, ALCATEL ONE TOUCH 6037B"
"TCT (Al catel), ALCATEL ONE TOUCH 6040A, DI ABLOX, ALCATEL ONE TOUCH 6040A"
"TCT (Al catel), ALCATEL ONE TOUCH 6040D, DI ABLOX, ALCATEL ONE TOUCH 6040D"
"TCT (Al catel), ALCATEL ONE TOUCH 6040D, DI ABLOX, TCL S950"
"TCT (Al catel), ALCATEL ONE TOUCH 6040E, DI ABLOX, ALCATEL ONE TOUCH 6040E"
"TCT (Al catel), ALCATEL ONE TOUCH 6040X, DI ABLOX, ALCATEL ONE TOUCH 6040X"
"TCT (Al catel), ALCATEL ONE TOUCH 7024W, Rav4, ALCATEL ONE TOUCH 7024R"
"TCT (Al catel), ALCATEL ONE TOUCH 7024W, Rav4, ALCATEL ONE TOUCH 7024W"
"TCT (Al catel), ALCATEL ONE TOUCH 7024W, Rav4, ALCATEL ONE TOUCH FIERCE"
"TCT (Al catel), ALCATEL ONE TOUCH 7025D, Rav4, ALCATEL ONE TOUCH 7025D"
"TCT (Al catel), ALCATEL ONE TOUCH 7040A, YARI SXL, ALCATEL ONE TOUCH 7040A"
"TCT (Al catel), ALCATEL ONE TOUCH 7040D, YARI SXL, ALCATEL ONE TOUCH 7040D"
"TCT (Al catel), ALCATEL ONE TOUCH 7040E, YARI SXL, ALCATEL ONE TOUCH 7040E"
"TCT (Al catel), ALCATEL ONE TOUCH 7040K, YARI SXL, ALCATEL ONE TOUCH 7040K"
"TCT (Al catel), ALCATEL ONE TOUCH 7040X, YARI SXL, ALCATEL ONE TOUCH 7040X"
"TCT (Al catel), ALCATEL ONE TOUCH 7041D, YARI SXL, ALCATEL ONE TOUCH 7041D"
"TCT (Al catel), ALCATEL ONE TOUCH 7041X, YARI SXL, ALCATEL ONE TOUCH 7041X"
"TCT (Al catel), ALCATEL ONE TOUCH 7042A, YARI SXL, ALCATEL ONE TOUCH 7042A"
"TCT (Al catel), ALCATEL ONE TOUCH 7042D, YARI SXL, ALCATEL ONE TOUCH 7042D"
"TCT (Al catel), ALCATEL ONE TOUCH 7042E, YARI SXL, ALCATEL ONE TOUCH 7042E"
"TCT (Al catel), ALCATEL ONE TOUCH 7047D, YARI S_55, ALCATEL ONE TOUCH 7047D"
"TCT (Al catel), ALCATEL ONE TOUCH 7047E, YARI S_55, ALCATEL ONE TOUCH 7047E"
"TCT (Al catel), ALCATEL ONE TOUCH 7047X, YARI S_55, ALCATEL ONE TOUCH 7047X"
"TCT (Al catel), ALCATEL ONE TOUCH 8008D, Scri be5HD, ALCATEL ONE TOUCH 8008D"
"TCT (Al catel), ALCATEL ONE TOUCH 8008D, Scri be5HD, ALCATEL ONE TOUCH 8008X"
"TCT (Al catel), ALCATEL ONE TOUCH 8008D, Scri be5HD, Orange Infini ty 8008X"
"TCT (Al catel), ALCATEL ONE TOUCH 8020A, SCRI BEPRO, ALCATEL ONE TOUCH 8020A"
"TCT (Al catel), ALCATEL ONE TOUCH 8020D, SCRI BEPRO, ALCATEL ONE TOUCH 8020D"
"TCT (Al catel), ALCATEL ONE TOUCH 8020E, SCRI BEPRO, ALCATEL ONE TOUCH 8020E"
"TCT (Al catel), ALCATEL ONE TOUCH 8020X, SCRI BEPRO, ALCATEL ONE TOUCH 8020X"
"TCT (Al catel), ALCATEL ONE TOUCH 903, one_touch_903A_gsm, ALCATEL ONE TOUCH_903"
"TCT (Al catel), ALCATEL ONE TOUCH 903, one_touch_903A_gsm, ALCATEL_one_touch_903"
"TCT (Al catel), ALCATEL ONE TOUCH 903, one_touch_903D_gsm, ALCATEL ONE TOUCH 903D"
"TCT (Al catel), ALCATEL ONE TOUCH 903, one_touch_903_gsm, ALCATEL ONE TOUCH 903"
"TCT (Al catel), ALCATEL ONE TOUCH 903, one_touch_903_gsm, ALCATEL ONE TOUCH_903"
"TCT (Al catel), ALCATEL ONE TOUCH 903A, one_touch_903A_gsm, ALCATEL ONE TOUCH 903A"
"TCT (Al catel), ALCATEL ONE TOUCH 903D, one_touch_903D_gsm, ALCATEL ONE TOUCH 903D"
"TCT (Al catel), ALCATEL ONE TOUCH 918, one_touch_918_gsm, ALCATEL ONE TOUCH 918"
"TCT (Al catel), ALCATEL ONE TOUCH 918, one_touch_918_gsm, ALCATEL one touch 918"
"TCT (Al catel), ALCATEL ONE TOUCH 918, one_touch_918_gsm, ALCATEL_one_touch_918"
"TCT (Al catel), ALCATEL ONE TOUCH 918, one_touch_918_gsm, Al catel_one_touch_918_Orange"
"TCT (Al catel), ALCATEL ONE TOUCH 918A, one_touch_918A_gsm, ALCATEL ONE TOUCH 918A"
"TCT (Al catel), ALCATEL ONE TOUCH 918A, one_touch_918A_gsm, ALCATEL_one_touch_918A"
"TCT (Al catel), ALCATEL ONE TOUCH 918D, ONE_TOUCH_918D_ums, ALCATEL ONE TOUCH 918D"
"TCT (Al catel), ALCATEL ONE TOUCH 918D, one_touch_918D_gsm, ALCATEL ONE TOUCH 918D"
"TCT (Al catel), ALCATEL ONE TOUCH 918N, ONE_TOUCH_918N_ums, ALCATEL ONE TOUCH 918N"
"TCT (Al catel), ALCATEL ONE TOUCH 918N, one_touch_918N_gsm, ALCATEL ONE TOUCH 918N"
"TCT (Al catel), ALCATEL ONE TOUCH 918S, one_touch_918S_gsm, ALCATEL ONE TOUCH 918S"
"TCT (Al catel), ALCATEL ONE TOUCH 922, one_touch_922_gsm, ALCATEL ONE TOUCH 922"
"TCT (Al catel), ALCATEL ONE TOUCH 930D, OT-930, ALCATEL ONE TOUCH 930D"
"TCT (Al catel), ALCATEL ONE TOUCH 930D, OT-930, ALCATEL ONE TOUCH 930N"
"TCT (Al catel), ALCATEL ONE TOUCH 985, one_touch_985_gsm, ALCATEL ONE TOUCH 985"
"TCT (Al catel), ALCATEL ONE TOUCH 985, one_touch_985_gsm, ALCATEL ONE TOUCH_985"
"TCT (Al catel), ALCATEL ONE TOUCH 985, one_touch_985_gsm, ALCATEL_one_touch_985"
"TCT (Al catel), ALCATEL ONE TOUCH 985, one_touch_985_gsm, Tel enor_One_Touch_C"
"TCT (Al catel), ALCATEL ONE TOUCH 985D, one_touch_985D_gsm, ALCATEL ONE TOUCH 985D"

supported device.txt

"TCT (Al catel), ALCATEL ONE TOUCH 985N, one_touch_985N_gsm, ALCATEL ONE TOUCH 985N"
 "TCT (Al catel), ALCATEL ONE TOUCH 991, ONE_TOUCH_991D_gsm, ALCATEL ONE TOUCH 991D"
 "TCT (Al catel), ALCATEL ONE TOUCH 991, ONE_TOUCH_991_gsm, ALCATEL ONE TOUCH 991"
 "TCT (Al catel), ALCATEL ONE TOUCH 991, ONE_TOUCH_991_gsm, ALCATEL_one_touch_991"
 "TCT (Al catel), ALCATEL ONE TOUCH 991, ONE_TOUCH_991_gsm, Telenor_Smart_Pro"
 "TCT (Al catel), ALCATEL ONE TOUCH 991, one_touch_991_gsm, ALCATEL ONE TOUCH 991"
 "TCT (Al catel), ALCATEL ONE TOUCH 991A, ONE_TOUCH_991A_gsm, ALCATEL ONE TOUCH 991A"
 "TCT (Al catel), ALCATEL ONE TOUCH 991D, ONE_TOUCH_991D_gsm, ALCATEL ONE TOUCH 991D"
 "TCT (Al catel), ALCATEL ONE TOUCH 991D, one_touch_991D_gsm, ALCATEL ONE TOUCH 991D"
 "TCT (Al catel), ALCATEL ONE TOUCH 991T, one_touch_991T_gsm, ALCATEL ONE TOUCH 991T"
 "TCT (Al catel), ALCATEL ONE TOUCH 992D, Martell_lite_GSM, ALCATEL ONE TOUCH 992"
 "TCT (Al catel), ALCATEL ONE TOUCH 992D, Martell_lite_GSM, ALCATEL ONE TOUCH 992D"
 "TCT (Al catel), ALCATEL ONE TOUCH 992D, Martell_lite_GSM, TCL S500"
 "TCT (Al catel), ALCATEL ONE TOUCH 992D, Martell_lite_GSM, TCL S600"
 "TCT (Al catel), ALCATEL ONE TOUCH 995, one_touch_995_gsm, ALCATEL_one_touch_995"
 "TCT (Al catel), ALCATEL ONE TOUCH 995, one_touch_995_gsm, Optimus_Madri d"
 "TCT (Al catel), ALCATEL ONE TOUCH 995, one_touch_995_gsm, Telenor_Smart_HD"
 "TCT (Al catel), ALCATEL ONE TOUCH 995A, one_touch_995_gsm, ALCATEL_one_touch_995A"
 "TCT (Al catel), ALCATEL ONE TOUCH 997D, Martell_GSM, ALCATEL ONE TOUCH 997"
 "TCT (Al catel), ALCATEL ONE TOUCH 997D, Martell_GSM, ALCATEL ONE TOUCH 997D"
 "TCT (Al catel), ALCATEL ONE TOUCH 997D, Martell_GSM, BASE_Lutea_3"
 "TCT (Al catel), ALCATEL ONE TOUCH 997D, Martell_GSM, TCL S710"
 "TCT (Al catel), ALCATEL ONE TOUCH 997D, Martell_GSM, TCL S800"
 "TCT (Al catel), ALCATEL ONE TOUCH D668, DANIEL, ALCATEL ONE TOUCH D668"
 "TCT (Al catel), ALCATEL ONE TOUCH D668, DANIEL, TCL D668"
 "TCT (Al catel), ALCATEL ONE TOUCH D668, DANIEL, TCL-D668"
 "TCT (Al catel), ALCATEL ONE TOUCH Fierce, Rav4, ALCATEL ONE TOUCH 7024N"
 "TCT (Al catel), ALCATEL ONE TOUCH Fierce, Rav4, ALCATEL ONE TOUCH 7024W"
 "TCT (Al catel), ALCATEL ONE TOUCH Fierce, Rav4, ALCATEL ONE TOUCH Fierce"
 "TCT (Al catel), ALCATEL ONE TOUCH P310A, POP7, ALCATEL ONE TOUCH P310A"
 "TCT (Al catel), ALCATEL ONE TOUCH P320A, POP8, ALCATEL ONE TOUCH P320A"
 "TCT (Al catel), ALCATEL ONE TOUCH P321, POP8, ALCATEL ONE TOUCH P321"
 "TCT (Al catel), ALCATEL ONE TOUCH 918N, one_touch_918_gsm, ALCATEL ONE TOUCH 918N"
 "TCT (Al catel), ALCATEL ONETOUCH 4037R, SOUL4NA, ALCATEL ONE TOUCH 4037R"
 "TCT (Al catel), ALCATEL ONETOUCH 4037R, SOUL4NA, ALCATEL ONETOUCH 4037R"
 "TCT (Al catel), ALCATEL ONETOUCH 6032, Al pha, ALCATEL ONETOUCH 6032"
 "TCT (Al catel), ALCATEL ONETOUCH 6032A, Al pha, ALCATEL ONETOUCH 6032A"
 "TCT (Al catel), ALCATEL ONETOUCH 6032X, Al pha, ALCATEL ONETOUCH 6032X"
 "TCT (Al catel), ALCATEL ONETOUCH 6043D, DI ABLOXPLUS, ALCATEL ONETOUCH 6043D"
 "TCT (Al catel), ALCATEL ONETOUCH FI ash PI us, CROSS2, ALCATEL ONETOUCH FI ash PI us"
 "TCT (Al catel), ALCATEL ONETOUCH IDOL 3 (5.5), i dol 3, 6045B"
 "TCT (Al catel), ALCATEL ONETOUCH IDOL 3 (5.5), i dol 3, 6045F"
 "TCT (Al catel), ALCATEL ONETOUCH IDOL 3 (5.5), i dol 3, 6045I "
 "TCT (Al catel), ALCATEL ONETOUCH IDOL 3 (5.5), i dol 3, 6045K"
 "TCT (Al catel), ALCATEL ONETOUCH IDOL 3 (5.5), i dol 3, 6045Y"
 "TCT (Al catel), ALCATEL ONETOUCH IDOL 3 (5.5), i dol 3, TCL i 806"
 "TCT (Al catel), ALCATEL ONETOUCH P310A, POP7, ALCATEL ONE TOUCH P310A"
 "TCT (Al catel), ALCATEL ONETOUCH P310A, POP7, ALCATEL ONETOUCH P310A"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009A"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009D"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009E"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009F"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009K"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009M"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009S"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (3.5), PI XI 3_35, 4009X"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (4.5), PI XI 3_45_4G, 5017A"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (4.5), PI XI 3_45_4G, 5017D"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI 3 (4.5), PI XI 3_45_4G, 5017E"
 "TCT (Al catel), ALCATEL ONETOUCH PI XI \xe2\x84\xa2 3 (4.5), PI XI 3_45_4G, 5017O"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5), PI XI 3-5, 5015A"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5), PI XI 3-5, 5015D"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5), PI XI 3-5, 5015E"

supported device.txt

"TCT (Al catel), ALCATEL ONETOUCH POP 3 (5), PI XI 3-5, 5015X"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5), PI XI 3-5, 5016A"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5), PI XI 3-5, 5016J"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5.5), PI XI 3-55, 5025D"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5.5), PI XI 3-55, 5025E"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5.5), PI XI 3-55, 5025G"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5.5), PI XI 3-55, 5025X"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5.5), PI XI 3-55, DIGI CEL DL1000"
 "TCT (Al catel), ALCATEL ONETOUCH POP 3 (5.5), PI XI 3-55, S4035 3G"
 "TCT (Al catel), ALCATEL ONETOUCH POP D3, SOUL4NA, ALCATEL ONETOUCH POP D3"
 "TCT (Al catel), ALCATEL ONETOUCH Victory, 7046T, Al catel 7046T"
 "TCT (Al catel), ALCATEL one touch 986+, OT986, ALCATEL one touch 986+ "
 "TCT (Al catel), ALCATEL one touch 990C+, one_touch_990C_Pi us_cdma, ALCATEL one touch 990C+ "
 "TCT (Al catel), ALCATEL one touch J320, Iris, ALCATEL one touch J320"
 "TCT (Al catel), ALCATEL ONE TOUCH 4027A, Pi xi 3-45, ALCATEL ONE TOUCH 4027A"
 "TCT (Al catel), ALCATEL ONE TOUCH 5037A, Yari sL_GSM, ALCATEL ONE TOUCH 5037A"
 "TCT (Al catel), ALCATEL ONE TOUCH 5037X, Yari sL_GSM, ALCATEL ONE TOUCH 5037X"
 "TCT (Al catel), ALCATEL ONE TOUCH 6010X_Orange, ONE_TOUCH_6010X_gsm, ALCATEL ONE TOUCH 6010X_Orange"
 "TCT (Al catel), ALCATEL ONE TOUCH 6030X_Orange, ONE_TOUCH_6030X_gsm, ALCATEL ONE TOUCH 6030X_Orange"
 "TCT (Al catel), ALCATEL ONE TOUCH 7047A, YARI S_55, ALCATEL ONE TOUCH 7047A"
 "TCT (Al catel), ALCATEL ONE TOUCH 903, one_touch_903A_gsm, ALCATEL ONE TOUCH 903"
 "TCT (Al catel), ALCATEL ONE TOUCH 903, one_touch_903_gsm, ALCATEL ONE TOUCH 903"
 "TCT (Al catel), ALCATEL ONE TOUCH 991_Orange, one_touch_991_gsm, ALCATEL ONE TOUCH 991_Orange"
 "TCT (Al catel), ALCATEL ONE TOUCH P310X, POP7, ALCATEL ONE TOUCH P310X"
 "TCT (Al catel), ALCATEL ONE TOUCH P320X, POP8, ALCATEL ONE TOUCH P320X"
 "TCT (Al catel), ALCATEL one_touch_918D, one_touch_918D_umts, ALCATEL one_touch_918D"
 "TCT (Al catel), ALCATEL one_touch_991, ONE_TOUCH_991A_gsm, ALCATEL one_touch_991"
 "TCT (Al catel), ALCATEL one_touch_991, one_touch_991_gsm, ALCATEL one_touch_991"
 "TCT (Al catel), ALCATEL one_touch_995, one_touch_995_gsm, ALCATEL one_touch_995"
 "TCT (Al catel), ALCATEL one_touch_995, one_touch_995_gsm, RPSPE4301"
 "TCT (Al catel), ALCATEL one_touch_995, one_touch_995_gsm, Tel enor_One_Touch_S"
 "TCT (Al catel), ALCATEL one_touch_995, one_touch_995_gsm, Tel enor_Smart_HD"
 "TCT (Al catel), ALCATEL one_touch_995A, one_touch_995_gsm, ALCATEL one_touch_995A"
 "TCT (Al catel), ALCATEL one_touch_995S, one_touch_995_gsm, ALCATEL one_touch_995S"
 "TCT (Al catel), AL00 6032, Al pha, AL00 6032"
 "TCT (Al catel), AM-H100, EOS_I te, AM-H100"
 "TCT (Al catel), ATEL ONE TOUCH 995, one_touch_995_gsm, ALCATEL one_touch_995"
 "TCT (Al catel), Al catel one touch 985, one_touch_985A_gsm, ALCATEL one_touch_985"
 "TCT (Al catel), Al catel one_touch_918_Orange, one_touch_918_gsm, Al catel one_touch_918_Orange"
 "TCT (Al catel), Boost Vi ew 5.0, YARI SXL, Boost Vi ew 5.0"
 "TCT (Al catel), D819, HER08, D819"
 "TCT (Al catel), D820, HER08, D820"
 "TCT (Al catel), D820X, HER08, D820X"
 "TCT (Al catel), DL900, YARI SXL, DL900"
 "TCT (Al catel), E500, X50D, E500"
 "TCT (Al catel), EV07, EV07, MTC 1065"
 "TCT (Al catel), EV07, EV07, onetouch EV07"
 "TCT (Al catel), EV07, EV07, starTIM tab 7"
 "TCT (Al catel), Hero2C, Hero2C, 7055A"
 "TCT (Al catel), I 216A, PI XI 7, I 216A"
 "TCT (Al catel), I 216X, PI XI 7, I 216X"
 "TCT (Al catel), I 220, PI XI 8, I 220"
 "TCT (Al catel), I 221, PI XI 8, I 221"
 "TCT (Al catel), I DOL 2 S, EOS4G, 6050Y"

supported device.txt

"TCT (Al catel), IDOL 2 S, EOS4G, ALCATEL ONE TOUCH 6050Y"
 "TCT (Al catel), IDOL 2 S, EOS4G, Idol 2S_Orange"
 "TCT (Al catel), IDOL 2 S, EOS_l te, 6050A"
 "TCT (Al catel), IDOL 2 S, EOS_l te, 6050F"
 "TCT (Al catel), IDOL 2 S, EOS_l te, 6050W"
 "TCT (Al catel), IDOL 2 S, EOS_l te, 6050Y"
 "TCT (Al catel), IDOL 2 S, EOS_l te, ALCATEL ONE TOUCH 6050Y"
 "TCT (Al catel), IDOL 2 S, EOS_l te, ALCATEL ONETOUCH 6050A"
 "TCT (Al catel), IDOL 2 S, EOS_l te, OWN S5030"
 "TCT (Al catel), IDOL 2 S, EOS_l te, TCL S830U"
 "TCT (Al catel), IDOL 2 S, EOS_l te, TCL S838M"
 "TCT (Al catel), Idol S, Di abl oHD_LTE, ALCATEL ONE TOUCH 6035L"
 "TCT (Al catel), Idol S, Di abl oHD_LTE, BS472"
 "TCT (Al catel), Idol S, Di abl oHD_LTE, MTC 978"
 "TCT (Al catel), Idol S, Di abl o_LTE, ALCATEL ONE TOUCH 6034L"
 "TCT (Al catel), Idol S, Di abl o_LTE, ALCATEL ONE TOUCH 6034M"
 "TCT (Al catel), Idol S, Di abl o_LTE, ALCATEL ONE TOUCH 6034R"
 "TCT (Al catel), Idol S, Di abl o_LTE, ALCATEL ONE TOUCH 6034Y"
 "TCT (Al catel), Idol S, Di abl o_LTE, San Remo 4G"
 "TCT (Al catel), Idol S, Di abl o_LTE, TCL-S850L"
 "TCT (Al catel), Idol X, Di abl oHD_LTE, ALCATEL ONE TOUCH 6035R"
 "TCT (Al catel), Idol 2 MI NI S, MI ATA_l te, 6036A"
 "TCT (Al catel), Idol 2 MI NI S, MI ATA_l te, 6036X"
 "TCT (Al catel), Idol 2 MI NI S, MI ATA_l te, 6036Y"
 "TCT (Al catel), Juke-A554C, A554C, A554C"
 "TCT (Al catel), M812C, M812, M812C"
 "TCT (Al catel), MTC 960, MTC_960_gsm, MTC 960"
 "TCT (Al catel), MTC 970, Beetl e_GSM, MTC 970"
 "TCT (Al catel), MTC975, Camry_GSM, MTC975"
 "TCT (Al catel), MegaFon_SP-A10, one_touch_995_gsm, MegaFon_SP-A10"
 "TCT (Al catel), Megafon Logi n, OT-930, MegaFon_SP-AI "
 "TCT (Al catel), Moov2, move_2_gsm, move 2"
 "TCT (Al catel), ONE TOUCH 4007X, Pi xo_GSM, ONE TOUCH 4007A"
 "TCT (Al catel), ONE TOUCH 4007X, Pi xo_GSM, ONE TOUCH 4007D"
 "TCT (Al catel), ONE TOUCH 4007X, Pi xo_GSM, ONE TOUCH 4007E"
 "TCT (Al catel), ONE TOUCH 4007X, Pi xo_GSM, ONE TOUCH 4007X"
 "TCT (Al catel), ONE TOUCH 4011X, Beetl e_l i teJB, ONE TOUCH 4011X"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, 4016D"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, ONE TOUCH 4015A"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, ONE TOUCH 4015D"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, ONE TOUCH 4015N"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, ONE TOUCH 4015X"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, ONE TOUCH 4015X-orange"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, ONE TOUCH 4016A"
 "TCT (Al catel), ONE TOUCH 4015X, Yari s35_GSM, Orange Yomi "
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, 4032A"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, 4032D"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, 4032E"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, 4032X"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, 4033L"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, MS3B"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, ONE TOUCH 4032A"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, ONE TOUCH 4033A"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, ONE TOUCH 4033D"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, ONE TOUCH 4033E"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, ONE TOUCH 4033X"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, OWN S3010"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, OWN S3010D"
 "TCT (Al catel), ONE TOUCH 4033X, Yari s_M_GSM, TCLJ330"
 "TCT (Al catel), ONE TOUCH 6012A, Cal i forni a_GSM, ONE TOUCH 6012A"
 "TCT (Al catel), ONE TOUCH 6012D, Cal i forni a, ALCATEL ONE TOUCH 6012D"
 "TCT (Al catel), ONE TOUCH 6012D, Cal i forni a, ALCATEL ONE TOUCH 6012X"
 "TCT (Al catel), ONE TOUCH 6012D, Cal i forni a, Mobi l e Sosh"

supported device.txt

"TCT (Al catel), ONE TOUCH 6012D, California, ONE TOUCH 6012A"
 "TCT (Al catel), ONE TOUCH 6012D, California, ONE TOUCH 6012D"
 "TCT (Al catel), ONE TOUCH 6012D, California, ONE TOUCH 6012E"
 "TCT (Al catel), ONE TOUCH 6012D, California, ONE TOUCH 6012X"
 "TCT (Al catel), ONE TOUCH 6012D, California, ONE TOUCH IDOL MINI "
 "TCT (Al catel), ONE TOUCH 6012D, California, Orange Covo"
 "TCT (Al catel), ONE TOUCH 6012D, California, Orange Hi ro"
 "TCT (Al catel), ONE TOUCH 6012X, California, ONE TOUCH 6012X"
 "TCT (Al catel), ONE TOUCH 8020D, SCRIBEPRO, ONE TOUCH 8020D"
 "TCT (Al catel), ONE TOUCH 983, ONE_TOUCH_983_gsm, ALCATEL_one_touch_983"
 "TCT (Al catel), ONE TOUCH 983, ONE_TOUCH_983_gsm, ONE TOUCH 983"
 "TCT (Al catel), ONE TOUCH 983, ONE_TOUCH_983_gsm, VALENCIA"
 "TCT (Al catel), ONE TOUCH 983, one_touch_983_gsm, ALCATEL_one_touch_983"
 "TCT (Al catel), ONE TOUCH C505C, ONE_TOUCH_C505C_cdma, ONE TOUCH C505C"
 "TCT (Al catel), ONE TOUCH EVO7HD, E710, MTC 1078"
 "TCT (Al catel), ONE TOUCH EVO7HD, E710, ONE TOUCH E710"
 "TCT (Al catel), ONE TOUCH EVO7HD, E710, ONE TOUCH EVO7HD"
 "TCT (Al catel), ONE TOUCH EVO8HD, E720, ONE TOUCH EVO7HD"
 "TCT (Al catel), ONE TOUCH EVO8HD, E720, ONE TOUCH EVO8HD"
 "TCT (Al catel), ONE TOUCH SCRIBE 5, Scri be5_gsm, ALCATEL ONE TOUCH 8000A"
 "TCT (Al catel), ONE TOUCH SCRIBE 5, Scri be5_gsm, ALCATEL ONE TOUCH 8000D"
 "TCT (Al catel), ONE TOUCH SCRIBE 5, Scri be5_gsm, TCL Y710"
 "TCT (Al catel), ONE TOUCH T10, GR-TB7, GR-TB7"
 "TCT (Al catel), ONE TOUCH TAB 7, T011, ONE TOUCH TAB 7"
 "TCT (Al catel), ONE TOUCH TAB 7, T011, TCL TAB 7"
 "TCT (Al catel), ONE TOUCH TAB 7HD, T016, ONE TOUCH TAB 7HD"
 "TCT (Al catel), ONE TOUCH TAB 8HD, T021, ONE TOUCH TAB 8HD"
 "TCT (Al catel), ONE TOUCH UI tra 960c, Al l tel, ONE_TOUCH_960C"
 "TCT (Al catel), ONE TOUCH UI tra 960c, ONE_TOUCH_960C, ADR3010"
 "TCT (Al catel), ONE TOUCH UI tra 960c, ONE_TOUCH_960C, ONE TOUCH 960C"
 "TCT (Al catel), ONE TOUCH UI tra 960c, Radi oShack, ADR3010"
 "TCT (Al catel), ONE TOUCH UI tra 960c, nTel os, ONE_TOUCH_960C"
 "TCT (Al catel), ONE TOUCH UI tra 960c, vul can, ONE_TOUCH_960C"
 "TCT (Al catel), ONETOUCH PIXI 3 (8), pi xi 384g, 9022X"
 "TCT (Al catel), ONETOUCH PIXI 3(7), pi xi 37, 9007A"
 "TCT (Al catel), ONETOUCH PIXI 3(7), pi xi 37, 9007X"
 "TCT (Al catel), ONE_TOUCH_P310A, POP7, ONE TOUCH P310A"
 "TCT (Al catel), ONE_TOUCH_P310X, POP7, ALCATEL ONE TOUCH P310X"
 "TCT (Al catel), OT-990C, OT-990C_cdma, OT-990C"
 "TCT (Al catel), OWN S4010, Tel sa, OWN S4010"
 "TCT (Al catel), OWN S5010, Di abl oHD, OWN S5010"
 "TCT (Al catel), OWN_S4025, YARI S_55, OWN_S4025"
 "TCT (Al catel), One Touch 890D, one_touch_890D_gsm, ALCATEL one touch 890D"
 "TCT (Al catel), One Touch 906, one_touch_906_gsm, ALCATEL_one_touch_906Y"
 "TCT (Al catel), One Touch 908, one_touch_908_gsm, ALCATEL ONE TOUCH 908"
 "TCT (Al catel), One Touch 908, one_touch_908_gsm, ALCATEL_one_touch_908"
 "TCT (Al catel), One Touch 908, one_touch_908_gsm, Al catel_one_touch_908F_Orange"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, ALCATEL ONE TOUCH 990"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, ALCATEL one touch 990"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, ALCATEL_one_touch_990"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, Al catel one touch 908F Orange"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, Al catel one touch 990 Orange"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, Los Angel es"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, TCL A990"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, TCL ONE TOUCH 990"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, Tel enor_OneTouch"
 "TCT (Al catel), One Touch 990, one_touch_990_gsm, Vodafone 958"
 "TCT (Al catel), One Touch 990A, one_touch_990A_gsm, ALCATEL_one_touch_990A"
 "TCT (Al catel), One Touch 990S, one_touch_990S_gsm, ALCATEL_one_touch_990S"
 "TCT (Al catel), One Touch 990S, one_touch_990S_gsm, Al catel one touch 990S"
 "TCT (Al catel), Orange_Sego, Orange_Sego, Orange_Sego"
 "TCT (Al catel), P330X, Pop7_LTE, P330X"
 "TCT (Al catel), P330X_orange, Pop7_LTE, P330X_orange"

supported device.txt

"TCT (Al catel), P350X, POP8_LTE, P350X"
 "TCT (Al catel), P360X, POP10, P360X"
 "TCT (Al catel), P688L, Ri o5C, TCL-P688L"
 "TCT (Al catel), P688L, Ri o5C, TOM007"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4003A"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4003J"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4013D"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4013E"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4013J"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4013K"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4013X"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, 4014E"
 "TCT (Al catel), PI XI 3(4), Pi xi 3-4, ONE_TOUCH_PI XI 3D"
 "TCT (Al catel), PI XI 3(4. 5), Pi xi 3-45, 4027A"
 "TCT (Al catel), PI XI 3(4. 5), Pi xi 3-45, 4027D"
 "TCT (Al catel), PI XI 3(4. 5), Pi xi 3-45, 4027N"
 "TCT (Al catel), PI XI 3(4. 5), Pi xi 3-45, 4027X"
 "TCT (Al catel), PI XI 3(4. 5), Pi xi 3-45, 4028A"
 "TCT (Al catel), PI XI 3(4. 5), Pi xi 3-45, 4028E"
 "TCT (Al catel), POP 2, Al to45, 5042A"
 "TCT (Al catel), POP 2, Al to45, 5042D"
 "TCT (Al catel), POP 2, Al to45, 5042X"
 "TCT (Al catel), POP 2 (5), al to5, 7043A"
 "TCT (Al catel), POP 2 (5), al to5, 7043K"
 "TCT (Al catel), POP 2 (5), al to5, 7043Y"
 "TCT (Al catel), POP 2 (5), al to5_premi um, 7044A"
 "TCT (Al catel), POP 2 (5), al to5_premi um, 7044X"
 "TCT (Al catel), POP S3, RI 04G_TF, ALCATEL A845L"
 "TCT (Al catel), POP S3, RI 0_4G, 5050A"
 "TCT (Al catel), POP S3, RI 0_4G, 5050S"
 "TCT (Al catel), POP S3, RI 0_4G, 5050X"
 "TCT (Al catel), POP S3, RI 0_4G, 5050Y"
 "TCT (Al catel), POP S3, RI 0_4G, ALCATEL ONETOUCH 5050X"
 "TCT (Al catel), POP S3, RI 0_4G, Si ru"
 "TCT (Al catel), POP S9, RI 06_l te, 7050Y"
 "TCT (Al catel), POP S9, RI 06_l te, ALCATEL A995L"
 "TCT (Al catel), POP S9, RI 06_l te, STARXTREM II "
 "TCT (Al catel), POP S9, RI 06_l te, Smartphone Androi d by SFR STARXTREM II "
 "TCT (Al catel), POP2 (4), al to4, 4045A"
 "TCT (Al catel), POP2 (4), al to4_8g, 4045A"
 "TCT (Al catel), POP2 (4), al to4_8g, 4045D"
 "TCT (Al catel), POP2 (4), al to4_8g, 4045L"
 "TCT (Al catel), POP2 (4), al to4_8g, 4045O"
 "TCT (Al catel), POP2 (4), al to4_8g, 4045X"
 "TCT (Al catel), POP2 (4. 5), al to45_l atam_b28, 5042G"
 "TCT (Al catel), POP2 (4. 5), al to45_l atam_b28, 5042W"
 "TCT (Al catel), Panda_m14, YARI S_55, Panda_m14"
 "TCT (Al catel), Pi xi 3-3. 5 TF, Pi xi 3-35TF, A463BG"
 "TCT (Al catel), Pi xi 3-4 TF, PI XI 3_4TF, A460G"
 "TCT (Al catel), Pi xo 7, PI X07, I 211"
 "TCT (Al catel), Pi xo 7, PI X07, I 212"
 "TCT (Al catel), Pi xo 7, PI X07, I 213"
 "TCT (Al catel), SMART 4G 5. 5 Enterpri se, M812, SMART 4G 5. 5 Enterpri se"
 "TCT (Al catel), SOUL 4. 5, SOUL45_GSM, 5038X"
 "TCT (Al catel), Smartphone Androi d by SFR STARADDI CT II , one_touch_996_gsm, Smartphone Androi d by SFR STARADDI CT II "
 "TCT (Al catel), Smartphone Androi d by SFR STARADDI CT II , one_touch_996_gsm, Smartphone Androi d by SFR STARADDI CT II "
 "TCT (Al catel), Soul 3. 5, SOUL35, 4018A"
 "TCT (Al catel), Soul 3. 5, SOUL35, 4018D"
 "TCT (Al catel), Soul 3. 5, SOUL35, 4018E"
 "TCT (Al catel), Soul 3. 5, SOUL35, 4018F"
 "TCT (Al catel), Soul 3. 5, SOUL35, 4018M"

supported device.txt

"TCT (Al catel), Soul 3.5, SOUL35, 4018X"
"TCT (Al catel), Soul 3.5, SOUL35, T4018"
"TCT (Al catel), Soul 4, SOUL4, 4035A"
"TCT (Al catel), Soul 4, SOUL4, 4035D"
"TCT (Al catel), Soul 4, SOUL4, 4035X"
"TCT (Al catel), Soul 4, SOUL4, 4035X_Orange"
"TCT (Al catel), Soul 4, SOUL4, 4035Y"
"TCT (Al catel), Soul 4, SOUL4, 4036E"
"TCT (Al catel), Soul 4.5, SOUL45_GSM, 5038A"
"TCT (Al catel), Soul 4.5, SOUL45_GSM, 5038E"
"TCT (Al catel), Soul 4.5, SOUL45_GSM, D45"
"TCT (Al catel), T10, T10, one touch T10"
"TCT (Al catel), T70, PIX07, T70"
"TCT (Al catel), TAB 7 DUAL CORE, T015, TAB 7 DUAL CORE"
"TCT (Al catel), TAB 7 DUAL CORE, T017, TAB 7 DUAL CORE"
"TCT (Al catel), TCL 736L, Rio5C, TCL-J736L"
"TCT (Al catel), TCL 738M, Rio5C, TCL J738M"
"TCT (Al catel), TCL A506, TCL_A506, TCL A506"
"TCT (Al catel), TCL A865, TCL_A865, TCL A865"
"TCT (Al catel), TCL A988, one_touch_993D_gsm, ALCATEL ONE TOUCH 993D"
"TCT (Al catel), TCL A988, one_touch_993_gsm, ALCATEL ONE TOUCH 993"
"TCT (Al catel), TCL A988, one_touch_993_gsm, MTC_968"
"TCT (Al catel), TCL C995, TCL_C995_cdma, TCL C995"
"TCT (Al catel), TCL D35, SOUL35, TCL D35"
"TCT (Al catel), TCL D40 DUAL, D40, TCL D40 DUAL"
"TCT (Al catel), TCL D55, YARIS_55, TCL D55"
"TCT (Al catel), TCL D662, TCL_D662_cdma, TCL D662"
"TCT (Al catel), TCL D706, EG502, TCL D706"
"TCT (Al catel), TCL D768, EG501, TCL D768"
"TCT (Al catel), TCL D920, TCL_D920, TCL D920"
"TCT (Al catel), TCL D920, TCL_D920, TCL-D920"
"TCT (Al catel), TCL DL750, SOUL4, DL750"
"TCT (Al catel), TCL H900M, HERO2, TCL H900M"
"TCT (Al catel), TCL J210C, TCL_J210C_cdma, TCL J210C"
"TCT (Al catel), TCL J210C, TCL_J210C_cdma, TCL-J210C"
"TCT (Al catel), TCL J300, Megane, ALCATEL ONE TOUCH 5020T"
"TCT (Al catel), TCL J300, Megane, TCL J300"
"TCT (Al catel), TCL J310, MeganeB, TCL J310"
"TCT (Al catel), TCL J320, Iris, TCL J320"
"TCT (Al catel), TCL J320C, Daniel_Lite, TCL J320C"
"TCT (Al catel), TCL J320T, IrisTD, TCL J320T"
"TCT (Al catel), TCL J600T, Iris2TD, TCL J600T"
"TCT (Al catel), TCL J620, md501, TCL J620"
"TCT (Al catel), TCL J630, Iris2PI usUMTS, J630"
"TCT (Al catel), TCL J630T, Iris2PI usTD, TCL J630T"
"TCT (Al catel), TCL J720, YARISXL, TCL J720"
"TCT (Al catel), TCL J726T, YARISXL, TCL J726T"
"TCT (Al catel), TCL J900, Camry2, TCL J900"
"TCT (Al catel), TCL J900T, Camry2_TD, TCL J900T"
"TCT (Al catel), TCL J920, YARIS_55, TCL J920"
"TCT (Al catel), TCL J926T, YARIS_55, TCL J926T"
"TCT (Al catel), TCL J928, Prius, TCL J928"
"TCT (Al catel), TCL J929L, Diabolo_LTE, TCL-J929L"
"TCT (Al catel), TCL J938M, RI055_LTE, TCL J938M"
"TCT (Al catel), TCL M2M, CROSS2, TCL M2M"
"TCT (Al catel), TCL M2U, CROSS2, TCL M2U"
"TCT (Al catel), TCL P301C, Cooper_40, TCL P301C"
"TCT (Al catel), TCL P301M, TCL_P301M, TCL P301M"
"TCT (Al catel), TCL P302C, Cooper40, TCL P302C"
"TCT (Al catel), TCL P316L, Festa5_CT, TCL P316L"
"TCT (Al catel), TCL P331M, TCL_P331M, TCL P331M"
"TCT (Al catel), TCL P332U, TCL_P332U, TCL P332U"
"TCT (Al catel), TCL P360W, Focus5_CU, TCL P360W"

supported device.txt

"TCT (Al catel), TCL P500M, Festa_L, TCL P500M"
 "TCT (Al catel), TCL P502U, Festa5_CU, TCL P502U"
 "TCT (Al catel), TCL P520L, Bora5_CT, TCL P520L"
 "TCT (Al catel), TCL P606, Rav4_GSM, TCL P600"
 "TCT (Al catel), TCL P606, Rav4_GSM, TCL P606"
 "TCT (Al catel), TCL P606, Rav4_GSM, TCL P606T"
 "TCT (Al catel), TCL P618L, HUMMER5_CT, TCL P618L"
 "TCT (Al catel), TCL P631M, Ci vi c_X, TCL P631M"
 "TCT (Al catel), TCL P689L, POL055, TCL_P689L"
 "TCT (Al catel), TCL P728M, CROSS_LTE, TCL P728M"
 "TCT (Al catel), TCL S300T, TCLS300T, TCL S300T"
 "TCT (Al catel), TCL S500, TCL_S500_GSM, TCL S500"
 "TCT (Al catel), TCL S520, TCL_S520_GSM, TCL S520"
 "TCT (Al catel), TCL S530T, Cal i forni a, TCL S530T"
 "TCT (Al catel), TCL S600, TCL_S600_GSM, TCL S600"
 "TCT (Al catel), TCL S700, TCLS700, TCL S700"
 "TCT (Al catel), TCL S700T, TCLS700T, TCL S700T"
 "TCT (Al catel), TCL S720, Cross55, TCL S720"
 "TCT (Al catel), TCL S720T, Cross55, TCL S720T"
 "TCT (Al catel), TCL S725T, Cross55_TD_Pl us, TCL_S725T"
 "TCT (Al catel), TCL S820, Di abl o, TCL S820"
 "TCT (Al catel), TCL S850, Di abl oHD, TCL S850"
 "TCT (Al catel), TCL S860, Al pha, TCL S860"
 "TCT (Al catel), TCL S900, S900, TCL S900"
 "TCT (Al catel), TCL S950, DI ABLOX, TCL S950"
 "TCT (Al catel), TCL S950T, DI ABLOX, TCL S950T"
 "TCT (Al catel), TCL S960, DI ABLOXPLUS, TCL S960"
 "TCT (Al catel), TCL S960T, DI ABLOXPLUS, TCL S960T"
 "TCT (Al catel), TCL Y900, Scri be5HD_GSM, TCL Y900"
 "TCT (Al catel), TCL Y910, SCRI BEPRO, TCL Y910"
 "TCT (Al catel), TCL Y910T, SCRI BEPRO, TCL Y910T"
 "TCT (Al catel), TCL i 708U, EOS_MACAN, TCL i 708U"
 "TCT (Al catel), TCL i 718M, EOS2, TCL i 718M"
 "TCT (Al catel), TCL i 718M, EOS_Pl us, TCL i 709M"
 "TCT (Al catel), TCL-J320D, Dani el _l i te_2S, TCL-J320D"
 "TCT (Al catel), TCL-J900C, TCL_J900C, TCL-J900C"
 "TCT (Al catel), TCL-P306C, Ford50, TCL-P306C"
 "TCT (Al catel), TCL_6110A, Tel sa, TCL_6110A"
 "TCT (Al catel), TCL_6110A, Tel sa, TCL_6110A"
 "TCT (Al catel), TCL_J636D, msm7627a_a5y_j 636d, TCL_J636D"
 "TCT (Al catel), TCL_J706T, Focus_L, TCL_J706T"
 "TCT (Al catel), TCL_U980, TCL_U980, TCL_U980"
 "TCT (Al catel), Tel ekom_Pul s, T-Tab, Tel ekom Pul s"
 "TCT (Al catel), Tel enor_Smart, one_touch_985_gsm, Tel enor_Smart"
 "TCT (Al catel), Tel enor_Smart_Mi ni , SOUL4, Tel enor Smart Mi ni "
 "TCT (Al catel), VF_860, Vodafone_Smart_II_gsm, Vodafone Smart II "
 "TCT (Al catel), VF-1296, voda_tab, Vodacom Power Tab 10"
 "TCT (Al catel), VF-1296, voda_tab, Vodafone Tab grand 6"
 "TCT (Al catel), VF-1397, Vodafone_Tab_speed_6, VF-1397"
 "TCT (Al catel), VF-1497, Vodafone_Tab_Pri me, VF-1497"
 "TCT (Al catel), VF685, VF685, VF685"
 "TCT (Al catel), VF695, VF695, VF695"
 "TCT (Al catel), Vodafone_785, Vodafone_785, MTC_982"
 "TCT (Al catel), Vodafone_785, Vodafone_785, Vodafone_785"
 "TCT (Al catel), Vodafone_861, one_touch_922_gsm, ALCATEL ONE TOUCH 922"
 "TCT (Al catel), Vodafone_861, one_touch_922_gsm, Vodafone_861"
 "TCT (Al catel), Vodafone_895, VF-895N, VF-895N"
 "TCT (Al catel), Vodafone_985N, Vodafone985N, Vodafone_985N"
 "TCT (Al catel), Vodafone_Smart_III, Vodafone_975, Vodafone_975"
 "TCT (Al catel), Vodafone_Smart_III (wi th NFC), Vodafone_975N, Vodafone_975N"
 "TCT (Al catel), Vodafone_Smart_Tab_4, Vodafone_Smart_Tab_4, Vodafone_Smart_Tab_4"
 "TCT (Al catel), Vodafone_Smart_Tab_3G, Vodafone_Smart_Tab_3G, Vodafone_Smart_Tab_3G"
 "TCT (Al catel), Vodafone_Smart_Tab_4G, Vodafone_Smart_Tab_4G, Vodafone_Smart_Tab_4G"

supported device.txt

"TCT (Al catel), X35E, X35E, X35E"
 "TCT (Al catel), X50D, X50D, X50D"
 "TCT (Al catel), freebit PandA_m14, YARI S_55, freebit PandA_m14"
 "TCT (Al catel), n1 max, m823_cmcc, M823"
 "TCT (Al catel), one touch 995C+, one_touch_995C_cdma, one touch 995C+ "
 "TCT (Al catel), one touch D920, one_touch_D920, ALCATEL one touch D920"
 "TCT (Al catel), one touch D920, one_touch_D920, one touch D920"
 "TCT (Al catel), one_touch_4030_TLVE, Beetle_GSM, ALCATEL_one_touch_4030A"
 "TCT (Al catel), one_touch_D920_ALIQ, one_touch_D920, one touch D920"
 "TCT (Al catel), onetouch_P689L, POL055, onetouch_P689L"
 "TCT (Al catel), tmn smarta8, ONE_TOUCH_991D_gsm, moche smart a8"
 "TCT (Al catel), tmn smarta8, ONE_TOUCH_991D_gsm, tmn smart a8"
 "TG&Co., TG-L800S, PHX, TG-L800S"
 "THTF, ""TSINGHUA TONGFANG CO., LTD. "", TR10CD1_3, TR10CD1"
 "TMAX, TMAX TM9S775, MI D908A-K, TM9S775"
 "TPS, SMART Spri nt, SMARTSpri nt, SMART Spri nt"
 "TSUNAMi, Tablet Tsunami TSTA080D1, MG080D1T, MG080D1T"
 "TUNTUN Engl i sh, DREAM PAD, del ight, ITP-R408W"
 "TUPAD, TU7_58212_18222, TU7_58212, TU7_18222"
 "Tai wan Mobi le, Amazi ng X3, TX3, Amazi ng X3"
 "Tai wanMobi le, A6S, A6S, A6S"
 "Tai wanMobi le, Amazi ng A8, D78, Amazi ng A8"
 "Tai wanMobi le, Tai wanMobi le A5C, A5C, A5C"
 "Tai wanMobi le, Tai wanMobi le A6S, A6S, A6S"
 "Takara, MI D 107, MI D107, MI D107"
 "Techni col or, , omap4_WT3, T-Hub2"
 "Techno, H7S, qp16_tecno_h7s, H7S"
 "Techno, P5, up08_tecno_p5s, TECNO P5S"
 "Tecno, H5S, up09_tecno_h5s, TECNO H5S"
 "Tecno, M3, up11_tecno_m3s, TECNO M3S"
 "Tecno, PHANTOM-Z-mi ni , PTM-Z-mi ni , PTM-Z-mi ni "
 "Tecno, TECNO-A7S, TECNO-A7S, TECNO-A7S"
 "Tecno, TECNO-C5, TECNO-C5, TECNO-C5"
 "Tecno, TECNO-J5, TECNO-J5, TECNO-J5"
 "Tecno, TECNO-J7, TECNO-J7, TECNO-J7"
 "Tecno, TECNO-M6S, g335_b1, TECNO-M6S"
 "Tecno, TECNO-Y3, TECNO-Y3, TECNO-Y3"
 "Tecno, TECNO-Y3S, TECNO-Y3S, TECNO-Y3S"
 "Tecno, TECNO-Y4, TECNO-Y4, TECNO-Y4"
 "Tecno, TECNO-Y5, TECNO-Y5, TECNO-Y5"
 "Tecno, TECNO-Y6, TECNO-Y6, TECNO-Y6"
 "Tecno, Techno L6, TECNO-L6, TECNO-L6"
 "Tekwi nd, TC97RA1, TC97RA1_1, TC97RA1"
 "Tel e2, Tel e2fon V4, Tel e2fon_v4, Tel e2fon v4"
 "Tel e2, Tel e2fon V5, Tel e2fon_v5, Tel e2fon v5"
 "Tel eepoch, , MaxBravo, PMI 920"
 "Tel eepoch, , U670C, U670C"
 "Tel eepoch, , chaser-921, Chaser"
 "Tel eepoch, Essenti el B SmartTab 1002, T9660R, SmartTAB 1002"
 "Tel eepoch, U675, U675, U675"
 "Tel eepoch, UMX U680C, U680C, U680C"
 "Tel efunken, VP73_Tel efunken, Tel efunken, VP73_Tel efunken"
 "Tel enor, Tel enor Smart, Tel enor_Smart, Tel enor_Smart"
 "Tesco, Hudl 2, HTF8A4, Hudl 2"
 "Tesco, Hudl HT7S3, ht7s3, Hudl HT7S3"
 "Tesco, Hudl HT7S3, ht7s3, hudl ht7s3"
 "Tesco, W032I _C3, w032i _c3, W032I _C3"
 "Tesco, hudl 2, HTF8A4, Hudl 2"
 "Thi npad, TH805, TH805, TH805"
 "Thomson, THOMSON PRI M07 Tabl et, PRI M07, PRI M07"
 "Thomson, THOMSON PRI M08 Tabl et, AMLMY8306P, PRI M08"
 "Thomson, TLi nk 455, TLI NK455, TLI NK455"
 "Ti nhvan, TA80TA1, TA80TA1_1, TA80TA1"

supported device.txt

"Tobi i DynaVox, T10+, T10plus, T10+"
 "Tobi i DynaVox, T7, T7, T7"
 "Toni no Lamborghini ni , Antares, TL66, TL66"
 "Toni no Lamborghini ni , Antares, TL_Antares, Antares"
 "Toshi ba, , WDPF-703TI, Hi kari -i Frame/WDPF-703TI "
 "Toshi ba, , tosebook01, DB50"
 "Toshi ba, , tostab05, AT200"
 "Toshi ba, , tostabg1, LT170"
 "Toshi ba, A204, tos14ast10, A204"
 "Toshi ba, AT10-A/AT15-A (Japan: AT503), tostab12BL, AT10-A"
 "Toshi ba, AT10-A/AT15-A (Japan: AT503), tostab12BL, AT502"
 "Toshi ba, AT10-A/AT15-A (Japan: AT503), tostab12BL, AT503"
 "Toshi ba, AT10-A/AT15-A (Japan: AT503), tostab12BL, AT503_HEMS"
 "Toshi ba, AT100, tostab03, AT100"
 "Toshi ba, AT100, tostab03, Tostab03"
 "Toshi ba, AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703), tostab12BA, AT10LE-A"
 "Toshi ba, AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703), tostab12BA, AT10PE-A"
 "Toshi ba, AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703), tostab12BA, AT702"
 "Toshi ba, AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703), tostab12BA, AT703"
 "Toshi ba, AT400, tostab12AL, AT300SE"
 "Toshi ba, AT400, tostab12AL, AT400"
 "Toshi ba, AT7-A, tost7t, AT374"
 "Toshi ba, AT7-A, tost7t, AT7-A"
 "Toshi ba, AT7-B, tos13t7gt, AT374"
 "Toshi ba, AT7-B, tos13t7gt, AT7-B"
 "Toshi ba, AT7-C, tos14ri y20, A17"
 "Toshi ba, AT7-C, tos14ri y20, AT7-C"
 "Toshi ba, JP: REGZA Tablet AT570 Others: TOSHI BA AT270, tostab11BS, AT270"
 "Toshi ba, JP: REGZA Tablet AT570 Others: TOSHI BA AT270, tostab11BS, AT470"
 "Toshi ba, JP: REGZA Tablet AT570 Others: TOSHI BA AT270, tostab11BS, AT570"
 "Toshi ba, JPN: REGZA Tablet AT500 Other countries: TOSHI BA AT300, tostab11BA, AT300"
 "Toshi ba, JPN: REGZA Tablet AT500 Other countries: TOSHI BA AT300, tostab11BA, AT500"
 "Toshi ba, JPN: REGZA Tablet AT500 Other countries: TOSHI BA AT300, tostab11BA, AT500a"
 "Toshi ba, JPN: REGZA Tablet AT830 Other countries: TOSHI BA AT330, tostab11BT, AT330"
 "Toshi ba, JPN: REGZA Tablet AT830 Other countries: TOSHI BA AT330, tostab11BT, AT830"
 "Toshi ba, L4300, I 4300, I 4300"
 "Toshi ba, L5450, tostv14rtk1, I 5400"
 "Toshi ba, L5450, tostv14rtk1, I 5450"
 "Toshi ba, L5450/L5400, tostv14rtk1, I 5400"
 "Toshi ba, L5450/L5400, tostv14rtk1, I 5450"
 "Toshi ba, L5450/L5400, tostv14rtk2, I 5400"
 "Toshi ba, L5450/L5400, tostv14rtk2, I 5450"
 "Toshi ba, L5450C, I 5450, I 3453"
 "Toshi ba, L5450C, I 5450, I 5450"
 "Toshi ba, L5450ME, tostv14rtk2, I 5400"
 "Toshi ba, L5450ME, tostv14rtk2, I 5450"
 "Toshi ba, L5550/L5551/L5552, tostv15rtk2, I 5550"
 "Toshi ba, L9450, I 9450, I 9450"
 "Toshi ba, TOSHI BA STB10, TOSPASB, TOSPASB"
 "Toshi ba, Thrive 7, tostab04, AT1S0"
 "Toshi ba, tt300/tt301/tt302, Mozart, Mozart"
 "Toughshiel d, R200, R200, R200"
 "Toughshiel d, T700_TABLET, T700_TABLET, T700"
 "TrekStor, TrekStor torino tab 7, torino7, torino tab 7"
 "TrekStor, TrekStor torino tab 8.9, torino89, torino tab 8.9"
 "Trekstor, SurfTab ST70204-3, TREKM7100KLD, SurfTab ST70204-3"
 "Trekstor, SurfTab xintron i 7.0, st70408_4_coho, st70408_4"
 "Trekstor, SurfTab xintron i 7.0, st70408_4_coho, st70408_4_coho"
 "Trekstor, torino tab 8, torino8, torino tab 8"
 "Tri mble Navi gati on, Peopl eNet ConnectedTablet, MS5, MS5"
 "Tri o, TRI O-7.85, astar-y3, TRI O-7.85"
 "Tri o, Tri o 7.85 vQ, Tri o-785-vQ, Tri o 7.85 vQ"
 "Tri o, Tri o AXS 3G, Tri o_AXS_3G, Tri o AXS 3G"

supported device.txt

"Trio, Trio MINI, Trio-MINI, Trio MINI"
 "Trio, Trio MST711, nuclear-MST711, MST711"
 "Trio, Trio-Stealth G4 7, Trio-Stealth-G4-7, Trio-Stealth-G4-7"
 "Trio, Trio-Stealth-G4-101, Trio-Stealth-G4-101, Trio-Stealth G4 10.1"
 "Trio, Trio-Stealth-G4-7.85, Trio-Stealth-G4-785, Trio-Stealth-G4-7.85"
 "Tunisie Telecom, Star Trail by TT, startrail3_tt, StarTrail TT"
 "Turk Telekom, Turk Telekom E4, 722T, E4"
 "U606, Hi sense, U606, STARSHINE III"
 "U688, Hi sense, U688, HS-U688"
 "USA111, IRULU X11, iRULU-X11, iRULU X11"
 "USA111, IRULU X9, X9, X9"
 "USA111, I rulu X7, X7, X7"
 "Ubi qui ti, USS, gri zzi es_tel efi 4wm, USS"
 "Ubi qui ti, UVP, capri_ubq_tel efi 5, UVP"
 "Ubi qui ti, UVP Executi ve, capri_ubq_tel efi 7, UVP Executi ve"
 "Ubi qui ti, UVP Pro, capri_ubq_tel efi 5p, UVP Pro"
 "Ubi qui ti, UVP-X, gri zzi es_tel efi 4x, UVP-X"
 "VAIO, VA-10J, VA-10J, JCI VA-10J"
 "VENSTAR, VENSTAR2050, VENSTAR2050, VENSTAR2050"
 "VF, Vodafone Smart mi ni, Vodafone_875, Vodafone 875"
 "VIBE Z, K910, ki tonw, Lenovo K910"
 "VSN, V. 35, up11_h1_vsn, V. 35"
 "Venturer, i 7, RCT6773W22, i 7"
 "Verizon Wireless, Eli psi s 7, QMV7A, QMV7A"
 "Verizon Wireless, Eli psi s 7, QMV7A, QMV7B"
 "Verizon Wireless, Eli psi s 7 (QMV7A), QMV7A, QMV7A"
 "Verizon Wireless, Eli psi s 7 (QMV7B), QMV7A, QMV7B"
 "Verizon Wireless, Eli psi s 8, QTAQZ3, QTAQZ3"
 "Verizon Wireless, QTAQZ3KID, QTAQZ3KID, QTAQZ3KID"
 "Verssed, FW8977-ED, FW8977-ED, FW8977-ED"
 "Vertu, Aster, al exa, Aster"
 "Vertu, Aster T, al exa, Aster T"
 "Vertu, Constel l ati on V, gambi t, Constel l ati on V"
 "Vertu, Si gnature Touch, odi n, Si gnature Touch"
 "Vertu, Si gnature Touch, ti tan, Si gnature Touch"
 "Vertu, Si gnature Touch, ti tan, Si gnature Touch L"
 "Vertu, VERTU Ti, hermi one, VERTU Ti"
 "Vestel, Farabi, frb3g, Farabi"
 "Vestel, V TAB 7\ \ ' LITE II, V_TAB_7_LI TE_II, V_TAB_7_LI TE_II"
 "Vestel, V TAB 9. 7\ \ ' PRO, VT97PRO, VT97PRO"
 "Vestel, VP100+, ephesus, 10. 1Myros"
 "Vestel, VP100+, ephesus, VP100+ "
 "Vestel, VP73, wi ng-i bt, VP73"
 "Vestel, VP73, wi ng-i bt, VP73_Hyundai "
 "Vestel, VP73, wi ng-i bt, VP73_Myros"
 "Vestel, VP73, wi ng-i bt, VP73_Vox"
 "Vestel, VP73, wi ng-i bt, VP73_I e"
 "Vestel, VP74, wi fi onl y-gms, VP74"
 "Vestel, VP74, wi fi onl y-gms, VP74-Cel cus"
 "Vestel, VP74, wi fi onl y-gms, VP74-Fi nl ux"
 "Vestel, VP74, wi fi onl y-gms, VP74-Luxor"
 "Vestel, VP74, wi fi onl y-gms, VP74-Orava"
 "Vestel, VP74, wi fi onl y-gms, VP74-Tel efunken"
 "Vestel, VP74, wi fi onl y-gms, VP74-Vox"
 "Vestel, VSP145M, VSP145M, VSP145M"
 "Vestel, VSP250g, VSP250g, VSP250g"
 "Vestel, VSP250s, VSP250s, VSP250s"
 "Vestel, VSP355g, g55, VSP355g"
 "Vestel, VSP355s, s55, VSP355s"
 "Vestel, VT10E, VT10E, VT10E"
 "Vestel, VT10E2, VT10E2, S TAB 10\ \ ' II"
 "Vestel, VT10E2, VT10E2, V TAB 10\ \ ' LI TE"
 "Vestel, VT10E2, VT10E2, VT10E2"

supported device.txt

"Vestel , VT785P2, VT785P2, V TAB 7. 85\ \ ' LI TE"
"Vestel , VT785P2, VT785P2, VT785P2-Cel cus"
"Vestel , VT785P2, VT785P2, VT785P2-CI everpad"
"Vestel , VT785P2, VT785P2, VT785P2-Fi nl ux"
"Vestel , VT785P2, VT785P2, VT785P2-Vestel "
"Vi ewSoni c , , v350, Vi ewSoni c-V350"
"Vi ewSoni c , , vi ewpad4, Vi ewSoni c-Vi ewPad4"
"Vi ewSoni c , , vi ewpad7, Vi ewPad7"
"Vi ewSoni c , , vi ewpad7x, Vi ewPad7X"
"Vi ewSoni c , , vi ewpad7x, Vi ewPad7x"
"Vi ewSoni c, VSD221, VSD221, VSD221"
"Vi ewSoni c, VSD231, VSD231-VSA, VSD231"
"Vi ewSoni c, VSD241 Smart Di spl ay, VSD241, VSD241"
"Vi ewSoni c, Vi ewPadi 7Q, vsi 7q_1_coho, vsi 7q_1"
"Vi ewSoni c, Vi ewPadi 7Q, vsi 7q_1_coho, vsi 7q_1_coho"
"Vi ewSoni c, Vi ewPadi 8Q, vsi 8q_1_coho, vsi 8q_1"
"Vi ewSoni c, Vi ewPadi 8Q, vsi 8q_1_coho, vsi 8q_1_coho"
"Vi sual Land, Presti ge El i te7QL, El i te7QL, El i te7QL"
"Vi sual Land, Presti ge El i te7QS, El i te7QS, El i te7QS"
"Vi vo, PD1304DL, PD1304DL, vi vo Y13i L"
"Vi vo, PD1419V, PD1419V, vi vo Y923"
"Vi vo, X5Max, X5Max, vi vo X5Max"
"Vi vo, vi vo V1, V1, vi vo V1"
"Vi vo, vi vo V1Max, Y37, vi vo Y37"
"Vi vo, vi vo X5, X5, vi vo X5"
"Vi vo, vi vo X5M, PD1401CL, vi vo X5M"
"Vi vo, vi vo X5Max S, bbk6752_l wt_kk, vi vo X5Max S"
"Vi vo, vi vo X5MaxV, msm8916_32, vi vo X5MaxV"
"Vi vo, vi vo X5Pro, X5Pro, vi vo X5Pro"
"Vi vo, vi vo X5Pro V, PD1421V, vi vo X5Pro V"
"Vi vo, vi vo Y11, Y11, vi vo Y11"
"Vi vo, vi vo Y15, Y15, vi vo Y15"
"Vi vo, vi vo Y15S, Y15S, vi vo Y15S"
"Vi vo, vi vo Y22, Y22, vi vo Y22"
"Vi vo, vi vo Y27, Y27, vi vo Y27"
"Vi vo, vi vo Y28, Y28, vi vo Y28"
"Vi vo, vi vo Y31, Y31, vi vo Y31"
"Vi vo, vi vo Y33, bbk6735_65c_l , vi vo Y33"
"Vi vo, vi vo Y937, PD1503, vi vo Y937"
"Vi zi o, StreamPl ayer, VAP430, VAP430"
"Vi zi o, Inc. , VTAB1008, VTAB1008, VTAB1008"
"Voni no, Xavy_T7, Xavy_T7, Xavy_T7"
"Vul can, TA10TA2, TA10TA2_1, TA10TA2"
"Vul can, TA71CA1, TA71CA1, TA71CA1"
"Vul can, TA71CA2, TA71CA2_1, TA71CA2"
"W. e. , WETAB700DG, WETAB700DG, WETAB700DG"
"W. e. , WeTab1004B, WeTab1004B, WeTab1004B"
"WACOM, Ci nti q Compani on Hybri d 13HD, Ci nti qCompani onHybri d13HD, Ci nti q Compani on Hybri d 13HD"
"Wi KO, Barry, s7811, BARRY"
"Wi KO, CI NK SLIM 2, s8074, CI NK SLIM 2"
"Wi KO, DARKFULL, s9311, DARKFULL"
"Wi KO, DARKFULL, s9311, Dream"
"Wi KO, DARKNI GHT, s9203, DARKNI GHT"
"Wi KO, DARKNI GHT, s9203, X-tremer"
"Wi KO, HI GHWAY, s9320, HI GHWAY"
"Wi KO, I GGY, s7521, Cynus F4"
"Wi KO, I GGY, s7521, Gol f"
"Wi KO, I GGY, s7521, I GGY"
"WeTek, Pl ay, Pl ay, Pl ay"
"Wel gate, WA-U420D, WA-U420D, WA-U420D"
"Wenu, Kate, Wenu, Kate"
"Wi ko, BI RDY, BI RDY, BI RDY"

"Wi ko, BLOOM, s4700, BLOOM"
 "Wi ko, GETAWAY, s8812, GETAWAY"
 "Wi ko, GOA, s3511, GOA"
 "Wi ko, HIGHWAY 4G, s9321, HIGHWAY 4G"
 "Wi ko, HIGHWAY PURE, I 9010, HIGHWAY PURE"
 "Wi ko, HIGHWAY SIGNS, s4750, HIGHWAY SIGNS"
 "Wi ko, HIGHWAY STAR, I 5560ae, HIGHWAY STAR"
 "Wi ko, JIMMY, s4300ae, JIMMY"
 "Wi ko, KITE, I 4020, KITE"
 "Wi ko, LENNY, s5201ap, LENNY"
 "Wi ko, LENNY2, s5030, LENNY2"
 "Wi ko, MACARON, I 8401_international, MACARON"
 "Wi ko, PULP FAB, S5260, PULP FAB"
 "Wi ko, PULP FAB, S5260, SLIDE2"
 "Wi ko, RAINBOW, s5501, RAINBOW"
 "Wi ko, RAINBOW 4G, I 5503, RAINBOW 4G"
 "Wi ko, RAINBOW LITE, s5222, RAINBOW LITE"
 "Wi ko, RAINBOW UP, s5400, RAINBOW UP"
 "Wi ko, RAINBOW UP 4G, I 5401, RAINBOW UP 4G"
 "Wi ko, RIDGE\t\t, s5513ap, RIDGE"
 "Wi ko, RIDGE 4G, I 5510, RIDGE 4G"
 "Wi ko, RIDGE FAB 4G, I 5320, RIDGE FAB 4G"
 "Wi ko, SELFY, SELFY, SELFY"
 "Wi ko, SELFY 4G, I 4801, SELFY 4G"
 "Wi ko, SLIDE, s8321, SLIDE"
 "Wi ko, SUNSET, s4011, SUNSET"
 "Wi ko, SUNSET2, s4050ap, SUNSET2"
 "Wi ko, WAX, s8515, WAX"
 "Wileyfox, Storm, kipper, Wileyfox Storm"
 "Wileyfox, Wileyfox Swift, crackling, Wileyfox Swift"
 "Wintec, T730, T730, Clear"
 "Wintec, T730, T730, T730"
 "Wintec, T750, T750, Clear"
 "Wistron, DW-21(A), DA-21, DW-21(A)"
 "Wistron, W1011A, w1011a, W1011A"
 "Woongjin, WoongjinThinkbig, BP-1001, BP-1001"
 "Xiaomi, China, HM2013023, 2013023"
 "Xiaomi, China, braveheart, Mi TV"
 "Xiaomi, China, casablanca, Mi BOX1S"
 "Xiaomi, HM 1SC, armani, HM 1AC"
 "Xiaomi, HM 1SC, armani, HM 1S"
 "Xiaomi, HM 1SC, armani, HM 1SC"
 "Xiaomi, HM 1SC, armani, HM 1SW"
 "Xiaomi, HM 1SLTETD, HM2014501, 2014501"
 "Xiaomi, HM 1STD, HM2014011, 2014011"
 "Xiaomi, HM 2A, I te26007, 2014502"
 "Xiaomi, HM 2A, I te26007, HM 2A"
 "Xiaomi, HM 2LTE-BR, HM2014819, 2014819"
 "Xiaomi, HM 2LTE-CMCC, HM2014813, 2014813"
 "Xiaomi, HM 2LTE-CT, HM2014812, 2014812"
 "Xiaomi, HM 2LTE-CU, HM2014811, 2014811"
 "Xiaomi, HM 2LTE-IN, HM2014818, 2014818"
 "Xiaomi, HM 2LTE-SA, HM2014817, 2014817"
 "Xiaomi, HM NOTE 1LTETD, di or, HM NOTE 1LTE"
 "Xiaomi, HM NOTE 1LTETD, di or, HM NOTE 1LTETD"
 "Xiaomi, HM NOTE 1LTETD, di or, HM NOTE 1LTEW"
 "Xiaomi, HM NOTE 1S CT, gucci, HM NOTE 1S"
 "Xiaomi, HM NOTE 1S CT, gucci, gucci "
 "Xiaomi, HM NOTE 1TD, I csh92_wet_tdd, HM NOTE 1TD"
 "Xiaomi, HM NOTE 1W, I csh92_wet_j b9, HM NOTE 1W"
 "Xiaomi, Hong Mi, HM2013022, 2013022"
 "Xiaomi, MI 2, aries, MI 2"
 "Xiaomi, MI 2, aries, MI 2S"

supported device.txt

"Xiaomi , MI 2A, taurus, MI 2A"
"Xiaomi , MI 3W, cancro, MI 3W"
"Xiaomi , MI 4LTE, cancro, MI 4LTE"
"Xiaomi , MI 4LTE, cancro, MI 4W"
"Xiaomi , MI 4LTE-CT, cancro, MI 4LTE"
"Xiaomi , MI NOTE LTE, virgo, MI NOTE LTE"
"Xiaomi , MI NOTE Pro, leo, MI NOTE Pro"
"Xiaomi , MI PAD, mocha, MI PAD"
"Xiaomi , Mi 3, pisces, MI 3"
"Xiaomi , Mi 4i, ferrari, Mi 4i "
"Xiaomi , Mi BOX2, dredd, Mi BOX2"
"Xiaomi , Mi BOX_mini , forrestgump, Mi BOX_mini "
"Xiaomi , Mi TV2, entrapment, Mi TV2"
"Xplore_Technologies, RangerX, i X101T1, i X101T1"
"Xplore_Technologies, RangerX, i X101T1_2G, i X101T1-2G"
"YU, YUPHORIA, YUPHORIA, YU5010"
"YU, Yureka, YUREKA, A05510"
"YU, Yureka, YUREKA, YU5510"
"YU, Yureka, YUREKA, YUREKA"
"Yota Devices, YotaPhone2, yotaphone2, YD201"
"YotaPhone, YotaPhone C9660, yotaphone, C9660"
"ZTE, , BUL_P726G, ZTE-RACER"
"ZTE, , D930, D930"
"ZTE, , Grand-S, ZTE Grand S"
"ZTE, , N720, N720"
"ZTE, , N720_Mi cromax, Mi cromax A60"
"ZTE, , N721, N721"
"ZTE, , N721, ZTE-U N721"
"ZTE, , N721, ZTE_U N721"
"ZTE, , N8010_CT, ZXY-ZTE_N8010"
"ZTE, , N8010_CT_BL, ZXY-ZTE_N8010"
"ZTE, , N8300_CT, ZXY-ZTE N8300"
"ZTE, , NX501, NX501"
"ZTE, , P117A11, ZTE U807"
"ZTE, , P117A13, ZTE U807N"
"ZTE, , P117A20qHD, ZTE U817"
"ZTE, , P117A30, ZTE U935"
"ZTE, , P117T21, ZTE U960E"
"ZTE, , P188T10, ZTE U956"
"ZTE, , P188T20, ZTE U819"
"ZTE, , P253A20, ZTE V768"
"ZTE, , P722G, ZTE-U X876"
"ZTE, , P726CU, ZTE-U X850"
"ZTE, , P726G, ZTE-LINK"
"ZTE, , P726G, ZTE-RACER"
"ZTE, , P726G, ZTE-WAVE"
"ZTE, , P726N, soft stone"
"ZTE, , P726N, soft-stone"
"ZTE, , P726VV, ZTE-U X850"
"ZTE, , P727A, VF945"
"ZTE, , P729B, Orange Tactile internet 2"
"ZTE, , P729C, ZTE-BLADE"
"ZTE, , P810A10, ZTE U880s2"
"ZTE, , P810A20, ZTE U887"
"ZTE, , P810T01, ZTE U791"
"ZTE, , P810T01, ZTE U791(OPEN)"
"ZTE, , P810T02, ZTE U793"
"ZTE, , P825T10, ZTE U808"
"ZTE, , P825T10, ZTE U808(OPEN)"
"ZTE, , QB7211, QB7211"
"ZTE, , QB7211, STARTEXT II "
"ZTE, , T77, T77"
"ZTE, , T9, ZTE-T T9"

"ZTE, , TWM_P726G, Tai wan Mobi le T2"
 "ZTE, , U788, ZTE U788"
 "ZTE, , U790, ZTE U790"
 "ZTE, , U795, ZTE U795"
 "ZTE, , U805, ZTE-T U805"
 "ZTE, , U812, ZTE-T U812"
 "ZTE, , U830, ZTE-T U830"
 "ZTE, , U880E, ZTE U880E"
 "ZTE, , U880F1, ZTE U880F1"
 "ZTE, , U880s, ZTE U880s"
 "ZTE, , U885, ZTE U885"
 "ZTE, , U930HD, ZTE U930HD"
 "ZTE, , U960s, ZTE-T U960s"
 "ZTE, , U960s2, ZTE U960s2"
 "ZTE, , U960s3, ZTE U960s3"
 "ZTE, , V6020_Cl aro, V6020_Cl aro"
 "ZTE, , V66, V66"
 "ZTE, , V68, V68"
 "ZTE, , V71A, STARTAB"
 "ZTE, , V71A, V71B"
 "ZTE, , V768, ZTE V768"
 "ZTE, , V8100_Z55, V8100_Z55"
 "ZTE, , V8200_EE_UK, V8200_EE_UK"
 "ZTE, , V8200_OSK, V8200-Memphi s-orange-Sl ovaki a"
 "ZTE, , V8300_Z39, V8300_Z39"
 "ZTE, , V857, ZTE-U V857"
 "ZTE, , V875m, ZTE-U V875m"
 "ZTE, , X500, X500"
 "ZTE, , X500, X500_USA_General "
 "ZTE, , X500MMB, ZTE-C X500"
 "ZTE, , ZTE-Grand-S, ZTE Grand S"
 "ZTE, , ZTE-N5, ZTE N5"
 "ZTE, , ZTE-N807, ZTE N807"
 "ZTE, , ZTE-N880F, ZTE N880F"
 "ZTE, , ZTE-N881E, ZTE N881E"
 "ZTE, , ZTE-N881F, ZTE N881F"
 "ZTE, , ZTE-N980, ZTE N980"
 "ZTE, , ZTE-N988, ZTE N988"
 "ZTE, , ZTE-U-V889F, ZTE-U V889F"
 "ZTE, , ZTE-V72A, V72A"
 "ZTE, , ZTE-V889F, ZTE V889F"
 "ZTE, , ZTE-V955, ZTE V955"
 "ZTE, , ZTE-V956, ZTE V956"
 "ZTE, , ZTE-V988, ZTE Grand S"
 "ZTE, , ZTE-V988, ZTE V988"
 "ZTE, , ami go, Androi d Edi ti on Starnaute"
 "ZTE, , arthur, N860"
 "ZTE, , atl as40, Acqua"
 "ZTE, , atl as40, BLADE III "
 "ZTE, , atl as40, MEDI ON LI FE P4012"
 "ZTE, , atl as40, N880E"
 "ZTE, , atl as40, ZTE G882"
 "ZTE, , atl as40, ZTE N880E"
 "ZTE, , atl as40, ZTE N881D"
 "ZTE, , atl as40, ZTE N882E"
 "ZTE, , atl as40, ZTE R22"
 "ZTE, , atl as40, ZTE T22"
 "ZTE, , atl as40, ZTE V880E"
 "ZTE, , atl as40, ZTE V889D"
 "ZTE, , banana, ZTE-C N780"
 "ZTE, , bl ade, MegaFon SP-A5"
 "ZTE, , bl ade, V880"
 "ZTE, , bl ade, ZTE Li bra"

supported device.txt

"ZTE, , blade, ZTE-BLADE"
"ZTE, , blade2, ATLAS W"
"ZTE, , blade2, BLADE I I "
"ZTE, , blade2, Blade S"
"ZTE, , blade2, San Francisco I I "
"ZTE, , bladeplus, 008Z"
"ZTE, , bladeplus, V881"
"ZTE, , bladeplus, ZTE V881"
"ZTE, , bladeplus, ZTE-U V881"
"ZTE, , cardhu, ZTE-T T98"
"ZTE, , crane-zte7, K75"
"ZTE, , dana, ZTE N970"
"ZTE, , deepblue, ZTE N790"
"ZTE, , deepblue, ZTE N790S"
"ZTE, , enterprise, ZTE U5"
"ZTE, , enterprise_HK, ZTE Grand Era"
"ZTE, , enterprise_U950, ZTE U950"
"ZTE, , enterprise_U985, ZTE U985"
"ZTE, , enterprise_V985, ZTE V985"
"ZTE, , frosty, ZTE T82"
"ZTE, , hct77_i cs2, V865M"
"ZTE, , hope, N855D"
"ZTE, , hope, N855D_PERFECTUM"
"ZTE, , hope, N855D_YM"
"ZTE, , hope, ZTE N855"
"ZTE, , hope, ZTE N855D"
"ZTE, , hope, ZTE N855D+ "
"ZTE, , illamna, ZTE T81"
"ZTE, , joe, V871"
"ZTE, , joe, Vodafone 945"
"ZTE, , kiska, ZTE V9800"
"ZTE, , mooncake2, MTS-SP102"
"ZTE, , mooncake2, Mtag 281"
"ZTE, , mooncake2, ZTE N660"
"ZTE, , msm7627a, ZTE N880F"
"ZTE, , msm7627a, ZTE V889F"
"ZTE, , msm7627a, ZTE-U V889F"
"ZTE, , msm7630_zteu960, ZTE U960D"
"ZTE, , msm7630_zteu960, ZTE-T U960"
"ZTE, , nice, A21plus"
"ZTE, , nice, ICE"
"ZTE, , nice, KIS I I "
"ZTE, , nice, Orange Zali "
"ZTE, , nice, Turkcell Maxi Plus 5"
"ZTE, , nice, V880S"
"ZTE, , nice, ZTE Kis Pro"
"ZTE, , okmok, ZTE V9500"
"ZTE, , p173a10, ZTE-U V760"
"ZTE, , r750, ZTE-C R750"
"ZTE, , racer2, ARI ZONA"
"ZTE, , racer2, Kyivstar Shine"
"ZTE, , racer2, RACER I I "
"ZTE, , racer2, Racer I I "
"ZTE, , racer2, Turkcell T11"
"ZTE, , racer2, ZTE-U V859"
"ZTE, , roamer, ZTE Roamer"
"ZTE, , roamer, ZTE roamer"
"ZTE, , roamer, ZTE-C N760"
"ZTE, , roamer2, Dubai "
"ZTE, , roamer2, Dublin"
"ZTE, , roamer2, N788_BASHA"
"ZTE, , roamer2, Orange Dublin"
"ZTE, , roamer2, V788D"

supported device.txt

"ZTE, , roamer2, ZTE N788"
"ZTE, , roamer2, ZTE N789"
"ZTE, , roamer2, ZTE V788D"
"ZTE, , roundtop, ZTE V9800"
"ZTE, , sailboat, ZTE V875"
"ZTE, , sean, N850"
"ZTE, , skate, KPN Smart 200"
"ZTE, , skate, MEDION LIFE P4310"
"ZTE, , skate, Monte Carlo"
"ZTE, , skate, Optimus Monte Carlo"
"ZTE, , skate, Orange Monte Carlo"
"ZTE, , skate, ZTE N960"
"ZTE, , skate, ZTE Skate"
"ZTE, , skate, ZTE V960"
"ZTE, , skate, ZTE-SKATE"
"ZTE, , skate, ZTE-Skate"
"ZTE, , skate, ZTE-U V960"
"ZTE, , skateplus, Skate4.3 H"
"ZTE, , turies, Android Edition StarText"
"ZTE, , turies, Vodafone Smart Chat"
"ZTE, , turies, ZTE-Tureis"
"ZTE, , v9plus, BASE Tab 7.1"
"ZTE, , v9plus, Light Tab 2"
"ZTE, , v9plus, Light Tab 2W"
"ZTE, , v9plus, MegaFon V9+"
"ZTE, , v9plus, TT102"
"ZTE, , v9plus, Telnor Touch Pad"
"ZTE, , v9plus, V9+"
"ZTE, , v9plus, V9A"
"ZTE, , v9plus, V9e+"
"ZTE, , v9plus, ZTE V10"
"ZTE, , v9plus, ZTE V9A"
"ZTE, , ventana, ZTE U970"
"ZTE, , ventana_U880F, ZTE U880F"
"ZTE, , ventana_U930, ZTE U930"
"ZTE, , warp2, N861"
"ZTE, , whistler, STARADDICT II"
"ZTE, , whistler, V961"
"ZTE, , whistler, ZTE Grand X"
"ZTE, , whistler, ZTE V970T"
"ZTE, , whistler, ZTE-Mi mosa X"
"ZTE, , z788, ZTE U788+ "
"ZTE, , z795, ZTE U795+ "
"ZTE, , zte_v857, ZTE-U V857"
"ZTE, 009Z, bladeplus, 009Z"
"ZTE, 009Z, bladeplus, ZTE V882"
"ZTE, 009Z, bladeplus, ZTE V886J"
"ZTE, 402ZT, ZTE-402ZT, 402ZT"
"ZTE, A1P, ailsa, A1P"
"ZTE, A1R, biily, A1"
"ZTE, A1R, biily, A1R"
"ZTE, A2, A2, A2"
"ZTE, Amazing A1, roamer2, Amazing A1"
"ZTE, Amazing P6, msm8226, Amazing P6"
"ZTE, Amazing X2, msm8226, Amazing X2"
"ZTE, Amazing X6, P839F30, Amazing X6"
"ZTE, Amazing p5_Lite, V77, Amazing p5_Lite"
"ZTE, Android edition by sfr STARADDICT, skate, Android edition by sfr STARADDICT"
"ZTE, Avea inTouch 2, atlas40, Avea inTouch 2"
"ZTE, Avea inTouch 4, msm8916_32, Avea inTouch 4"
"ZTE, Avea inTouch 4, msm8916_32, ZTE Blade V220"
"ZTE, B760E, ztemt85_bx_kk, B760E"
"ZTE, B760E, ztemt85_bx_kk, B760H"

supported device.txt

"ZTE, BASE Lutea 2, skate, BASE Lutea 2"
 "ZTE, BLADE III_IL, atlas40, BLADE III_IL"
 "ZTE, Baker, ZTE-Baker, Baker"
 "ZTE, Beeline E600, roamer2, Beeline E600"
 "ZTE, Blade, blade, 003Z"
 "ZTE, Blade, blade, Android Edition StarTrail"
 "ZTE, Blade, blade, BASE Lutea"
 "ZTE, Blade, blade, BLADE_N880"
 "ZTE, Blade, blade, Beeline E400"
 "ZTE, Blade, blade, Kyivstar Spark"
 "ZTE, Blade, blade, MF8604"
 "ZTE, Blade, blade, Movistar Prime"
 "ZTE, Blade, blade, N880"
 "ZTE, Blade, blade, Netphone 701"
 "ZTE, Blade, blade, Optimus San Francisco"
 "ZTE, Blade, blade, Orange San Francisco"
 "ZTE, Blade, blade, Orange Tactile internet 2"
 "ZTE, Blade, blade, RTK V8"
 "ZTE, Blade, blade, San Francisco"
 "ZTE, Blade, blade, V8502"
 "ZTE, Blade, blade, WayteQ Li bra"
 "ZTE, Blade, blade, XCD35"
 "ZTE, Blade, blade, ZTE Li bra"
 "ZTE, Blade, blade, ZTE V880"
 "ZTE, Blade, blade, ZTE-BLADE"
 "ZTE, Blade, blade, ZTE-C N880S"
 "ZTE, Blade, blade, ZTE-LI BRA"
 "ZTE, Blade, blade, ZTE-Li bra"
 "ZTE, Blade, blade, ZTE-U V880"
 "ZTE, Blade, blade, a5"
 "ZTE, Blade Apex, coeus, Blade Apex"
 "ZTE, Blade Apex2, msm8226, Blade Apex2"
 "ZTE, Blade G LTE, oceanus, Blade G LTE"
 "ZTE, Blade III, atlas40, Blade III"
 "ZTE, Blade III, atlas40, Skate Pro"
 "ZTE, Blade L2 Plus, ZTE_Blade_L2_PLUS, Blade L2 Plus"
 "ZTE, Blade L3 Plus, Blade_L3_Plus, Blade L3 Plus"
 "ZTE, Blade Q Lux, P816A12, Blade Q Lux"
 "ZTE, Blade S, P839F30, Blade S"
 "ZTE, Blade S, blade2, Blade S"
 "ZTE, Blade S Lite, P839F30, Blade S Lite"
 "ZTE, Blade S6, P839F30, Blade S6"
 "ZTE, Blade S6, P839F30, LS-5008"
 "ZTE, Blade S6, P839F30, NOS SLIM"
 "ZTE, Blade S6 Lite, P839F30, Blade S6"
 "ZTE, Blade S6 Lite, P839F30, Blade S6 Lite"
 "ZTE, Blade S6 Lite, P839F30, ZTE T912"
 "ZTE, Blade S6 Plus, P839F50, Blade S6 Plus"
 "ZTE, Blade V6, P635A20, Blade V6"
 "ZTE, Blade V6, P635A20, ZTE Blade V6"
 "ZTE, Blade V6, P635A20, ZTE T660"
 "ZTE, Blade V6, P635A20, ZTE T663"
 "ZTE, Bouygues Telecom Bs 351, nice, Bouygues Telecom Bs 351"
 "ZTE, Bouygues Telecom Bs 402, P172G10, A4C"
 "ZTE, Bouygues Telecom Bs 402, P172G10, Amazing A4C"
 "ZTE, Bouygues Telecom Bs 402, P172G10, Bouygues Telecom Bs 402"
 "ZTE, Bouygues Telecom Bs 402, P172G10, ZTE Blade Q Mini"
 "ZTE, Cosmote Smart Share, nice, Cosmote Smart Share"
 "ZTE, Cosmote Xpl ore, Cosmote, Cosmote Xpl ore"
 "ZTE, Cosmote Xpl ore, Cosmote-Xpl ore, Cosmote Xpl ore"
 "ZTE, Dialog Q143L, frosty, Dialog Q143L"
 "ZTE, FT142D, msm8226, FT142D"
 "ZTE, Grand Memo, pri ndle, Grand Memo"

supported device.txt

"ZTE, Grand S Flex, iris, Grand S Flex"
 "ZTE, Grand X, P175A20, Grand X"
 "ZTE, Grand X, P175A20, Grand X(M)"
 "ZTE, Grand X, P175A20, ZTE Grand X Classic"
 "ZTE, Grand X, P175A20, ZTE V970"
 "ZTE, Grand X, P175A20, ZTE V970M"
 "ZTE, Grand X, P175A20, ZTE-U V970M"
 "ZTE, Grand X, P175A20, tmn smart a18"
 "ZTE, Grand X In, mfl d_pr2, Grand X In"
 "ZTE, Grand X In, mfl d_pr2, STARADDICT II Plus"
 "ZTE, Grand X In, mfl d_pr2, ZTE Grand X In"
 "ZTE, Grand X Pro, P177A20, Blade Super"
 "ZTE, Grand X Pro, P177A20, Grand X Pro"
 "ZTE, Grand X Pro, P177A20, KPN Smart 300"
 "ZTE, Infinity X^2 mini, msm8226, Infinity X^2 mini "
 "ZTE, K97, K97, K97"
 "ZTE, K97, K97, ZTE K97"
 "ZTE, KIS, roamer2, KIS"
 "ZTE, KIS PLUS, roamer2, KIS PLUS"
 "ZTE, KPN Smart 400, msm8226, KPN Smart 400"
 "ZTE, Karbonn_A1, N721, Karbonn_A1"
 "ZTE, Kis T3, roamer2, Kis T3"
 "ZTE, Leopard MF800, roamer2, Leopard MF800"
 "ZTE, Light Tab 2, v9plus, Light Tab 2"
 "ZTE, M8402, roamer2, M8402"
 "ZTE, MEDI ON LIFE P4310, skate, MEDI ON LIFE P4310"
 "ZTE, MEDI ON Smartphone LIFE E3501, roamer2, MEDI ON Smartphone LIFE E3501"
 "ZTE, MF97A, MF97A, MF97A"
 "ZTE, MF97E, msm8974, MF97E"
 "ZTE, MF97G, msm8974, MF97G"
 "ZTE, MF97W, MF97W, MF97W"
 "ZTE, MS4A, ki ska, MS4A"
 "ZTE, MS4A, roundtop, MS4A"
 "ZTE, Momodesign MD Droid, atlas40, Momodesign MD Droid"
 "ZTE, Movistar Express, QB7211, Movistar Express"
 "ZTE, Movistar Motion, roamer2, Movistar Motion"
 "ZTE, N720, N720, N720"
 "ZTE, N720, N720, ZTE-U N720"
 "ZTE, N720, N720, ZTE_U N720"
 "ZTE, N762, roamer, N762"
 "ZTE, N765_APT, N765, N765_APT"
 "ZTE, N790, deepblue, N790"
 "ZTE, N800, nex, N800"
 "ZTE, N8000_USA Cricket, N8000, N8000_USA Cricket"
 "ZTE, N8000_USA_RS, N8000, N8000_USA_RS"
 "ZTE, N8000_WHITE_CKT, N8000, N8000_WHITE_CKT"
 "ZTE, N8010_APT, N8010_APT, N8010_APT"
 "ZTE, N810, fluid, N810"
 "ZTE, N817, wel lington, N817"
 "ZTE, N8300_Rel i ance, N8300_Rel i ance, N8300_Rel i ance"
 "ZTE, N8303, roamer2, N8303"
 "ZTE, N850, sean, N850"
 "ZTE, N850L, seanplus, N850L"
 "ZTE, N855D, hope, N855D"
 "ZTE, N860, arthur, N860"
 "ZTE, N860, arthur, Warp"
 "ZTE, N861, warp2, N861"
 "ZTE, N910, arthur4g, ZTE-N910"
 "ZTE, N9100, hayes, N9100"
 "ZTE, N9101, apollo, N9101"
 "ZTE, N9130, speed, N9130"
 "ZTE, N9180, N9180, N9180"
 "ZTE, N918St, N918St, BGH Joy Smart AXS II"

supported device.txt

"ZTE, N918St, N918St, BGH Joy Smart AXS II D"
 "ZTE, N918St, N918St, N918St"
 "ZTE, N918St, N918St, ZTE N918St"
 "ZTE, N9500, gordon, N9500"
 "ZTE, N9510, warpl te, N9510"
 "ZTE, N9515, warp4, N9515"
 "ZTE, N9516, eri dani , N9516"
 "ZTE, N9518, warp6, N9518"
 "ZTE, N9520, stormer, N9520"
 "ZTE, N958St, N958St, N958St"
 "ZTE, N9810, quantum, N9810"
 "ZTE, N986D, P188F10, N986+ "
 "ZTE, N986D, P188F10, N986D"
 "ZTE, NE501J, NE501J, NE501J"
 "ZTE, NE501J, NE501J, V5"
 "ZTE, NE501J, NE501J, ZTE_V5"
 "ZTE, NX402, NX40X, NX402"
 "ZTE, NX403A, NX403A, NX403A"
 "ZTE, NX404H, NX404H, NX404H"
 "ZTE, NX405H, NX405H, NX405H"
 "ZTE, NX406E, NX406E, NX406E"
 "ZTE, NX40X, NX402, NX402"
 "ZTE, NX40X_APT, NX40X, NX40X"
 "ZTE, NX40X_APT, NX40X, NX40X_APT"
 "ZTE, NX501, NX501, NX501"
 "ZTE, NX501_APT, NX501, NX501_APT"
 "ZTE, NX503A_Z4, NX503A_Z4, NX503A_Z4"
 "ZTE, NX503J, NX503J, NX503J"
 "ZTE, NX505J, NX505J, NX505J"
 "ZTE, NX506J, NX506J, NX506J"
 "ZTE, NX507J, NX507J, NX507H"
 "ZTE, NX507J, NX507J, NX507J"
 "ZTE, NX508J, NX508J, NX508J"
 "ZTE, NX510J, NX510J, NX510J"
 "ZTE, NX511J, NX511J, NX511J"
 "ZTE, NX512J, NX512J, NX512J"
 "ZTE, NX513J, NX513J, NX513J"
 "ZTE, NX601J, NX601J, NX601J"
 "ZTE, Opti mus Barcel ona, bl ade2, Opti mus Barcel ona"
 "ZTE, Orange Hi 4G, Orange_Hi_4G, Orange Hi 4G"
 "ZTE, Orange Hi 4G, msm8226, Orange Hi 4G"
 "ZTE, Orange Monte Carl o, skate, Orange Monte Carl o"
 "ZTE, Orange Novi , oceanus, Orange Novi "
 "ZTE, Orange Reyo, P172D10, Avea i nTouch 3 Large"
 "ZTE, Orange Reyo, P172D10, Bl ade Q Maxi "
 "ZTE, Orange Reyo, P172D10, Orange Reyo"
 "ZTE, Orange Reyo, P172D10, ZTE Bl ade Q Maxi "
 "ZTE, Orange Rono, Vec4G, Orange Rono"
 "ZTE, Orange Rono, msm8226, Orange Rono"
 "ZTE, Orange Zal i , ni ce, Orange Zal i "
 "ZTE, Preo Teknosa P1, msm8916_32, Preo Teknosa P1"
 "ZTE, RACER III mi ni , roamer2, RACER III mi ni "
 "ZTE, Racer, mooncake, Carl "
 "ZTE, Racer, mooncake, MTC 916"
 "ZTE, Racer, mooncake, MTS-SP100"
 "ZTE, Racer, mooncake, Movi star Li nk"
 "ZTE, Racer, mooncake, RTK D1"
 "ZTE, Racer, mooncake, Racer"
 "ZTE, Racer, mooncake, Tai Wan Mobi le T2"
 "ZTE, Racer, mooncake, V8402"
 "ZTE, Racer, mooncake, Vi p Droi d"
 "ZTE, Racer, mooncake, XCD 28"
 "ZTE, Racer, mooncake, ZTE X850"

supported device.txt

"ZTE, Racer, mooncake, ZTE-C N600"
"ZTE, Racer, mooncake, ZTE-C N600+"
"ZTE, Racer, mooncake, ZTE-LINK"
"ZTE, Racer, mooncake, ZTE-RACER"
"ZTE, Racer, mooncake, ZTE-U V852"
"ZTE, Racer, mooncake, ZTE-U X850"
"ZTE, Rook from EE, P635E40, Rook from EE"
"ZTE, S8Q, MT8123, S8Q"
"ZTE, STARNAUTE 11, V6600, STARNAUTE 11"
"ZTE, STARTRAIL 4, P172E10, Avea inTouch 3"
"ZTE, STARTRAIL 4, P172E10, STARTRAIL 4"
"ZTE, STARTRAIL 4, P172E10, ZTE Blade Q"
"ZTE, STARXTREM, prindle, STARXTREM"
"ZTE, Skate Pro, atlas40, Skate Pro"
"ZTE, SmartTab10, V11A, SmartTab10"
"ZTE, SmartTab7, V71A, SmartTab7"
"ZTE, Soshphone 4G, Vec4G, Soshphone 4G"
"ZTE, Soshphone 4G, msm8226, Soshphone 4G"
"ZTE, Spro 2, msm8974, 502ZT"
"ZTE, Spro 2, msm8974, MF97B"
"ZTE, Spro 2, msm8974, MF97V"
"ZTE, Spro 2, msm8974, Spro 2"
"ZTE, Spro 2, msm8974, ZKB2A"
"ZTE, T-Mobile Vivacity, blade2, T-Mobile Vivacity"
"ZTE, T3, skate, T3"
"ZTE, TQ150, QB7211, TQ150"
"ZTE, TURKCELL T40, TURKCELL-T40, TURKCELL T40"
"ZTE, TURKCELL T50, msm8226, TURKCELL T50"
"ZTE, TURKCELL T50, msm8226, TURKCELL TURBO T50"
"ZTE, TURKCELL T60, P839T60, TURKCELL T60"
"ZTE, TURKCELL T60, msm8916_32, TURKCELL T60"
"ZTE, Telnor Touch Plus, blade2, Telnor Touch Plus"
"ZTE, Turkcell Maxi Plus 5, nice, Turkcell Maxi Plus 5"
"ZTE, U880, U880, ZTE-T U880"
"ZTE, U9180, U9180, U9180"
"ZTE, U9180, U9180, ZTE U9180"
"ZTE, UZTE V790, roamer2, UZTE V790"
"ZTE, UZTE V817, ZTE-V956, UZTE V817"
"ZTE, Ulym 5. 2, msm8916_32, Ulym 5. 2"
"ZTE, V55, V55, V55"
"ZTE, V72C, v72c, V72C"
"ZTE, V72M, eos, V72M"
"ZTE, V8000_USA_Cri cket, V8000, V8000_USA_Cri cket"
"ZTE, V8110, V8110, V8110"
"ZTE, V8200pl us, V8200pl us, V8200pl us"
"ZTE, V8285, MT8382, V8285"
"ZTE, V8403, roamer2, V8403"
"ZTE, V8514, P821E10, V8514"
"ZTE, V865M, hct77_j b, V865M"
"ZTE, V9, v9, A100"
"ZTE, V9, v9, BASE Tab"
"ZTE, V9, v9, BLACK 03"
"ZTE, V9, v9, Beeline M2"
"ZTE, V9, v9, Light"
"ZTE, V9, v9, Light Tab"
"ZTE, V9, v9, MTC 1055"
"ZTE, V9, v9, One Pad"
"ZTE, V9, v9, RTK V9"
"ZTE, V9, v9, T0101"
"ZTE, V9, v9, TT101"
"ZTE, V9, v9, V9"
"ZTE, V9, v9, V9C"
"ZTE, V9, v9, V9c"

supported device.txt

"ZTE, V9, v9, V9e"
"ZTE, V9, v9, myPad P2"
"ZTE, V9180, V9180, V9180"
"ZTE, V96A, V96A, V96A"
"ZTE, V9A, v9plus, Light Tab 2"
"ZTE, V9A, v9plus, V9A"
"ZTE, V9A, v9plus, ZTE V9A"
"ZTE, V9A, v9plus, my Pad P3"
"ZTE, V9A, v9plus, myPad P3"
"ZTE, V9S, V9S, V9S"
"ZTE, V9S, V9S, myPadP4"
"ZTE, Vip Racer III, atlas40, Vip Racer III"
"ZTE, Vodafone Smart Chat, turies, Vodafone Smart Chat"
"ZTE, Vodafone Smart ultra 6, msm8916_32, Vodafone Smart ultra 6"
"ZTE, X500, X500, X500"
"ZTE, X501_USA_Cri cket, X501, X501_USA_Cri cket"
"ZTE, X501_USA_Cri cket, X501, X501_USA_RS"
"ZTE, X501_USA_OM, X501, X501_USA_OM"
"ZTE, X9180, X9180, X9180"
"ZTE, Z660G, ni ce, Z660G"
"ZTE, Z665C, seanplus, Z665C"
"ZTE, Z667, demi , Z667"
"ZTE, Z667T, bonni e, Z667T"
"ZTE, Z730, ada, Z730"
"ZTE, Z740, meti s, Z740"
"ZTE, Z740G, meti s, Z740G"
"ZTE, Z750C, Z750C, Z750C"
"ZTE, Z752C, eros, Z752C"
"ZTE, Z753G, faeri e, Z753G"
"ZTE, Z755, i ri s, Z755"
"ZTE, Z768G, Z768G, Z768G"
"ZTE, Z777, betty, Z777"
"ZTE, Z787, apus, Z787"
"ZTE, Z791G, gi ant, Z791G"
"ZTE, Z792, gi ant, Z792"
"ZTE, Z793C, hera, Z793C"
"ZTE, Z795G, ZTE-Z795G, Z795G"
"ZTE, Z796C, Z796C, Z796C"
"ZTE, Z797C, carol , Z797C"
"ZTE, Z812, xuantan, Z812"
"ZTE, Z813, xuantan, Z813"
"ZTE, Z818L, sunny, Z818L"
"ZTE, Z819L, sungod, Z819L"
"ZTE, Z820, P675T07, Z820"
"ZTE, Z826, hercul i s, Z826"
"ZTE, Z830, grui s, Z830"
"ZTE, Z850, si f, Z850"
"ZTE, Z930L, coeus, Z930L"
"ZTE, Z933, gl aucus, Z933"
"ZTE, Z936L, gi ft, Z936L"
"ZTE, Z955L, l eo, Z955L"
"ZTE, Z958, l ol , Z958"
"ZTE, Z970, draconi s, Z970"
"ZTE, Z980L, cygni , Z980L"
"ZTE, Z987, cygni , Z987"
"ZTE, Z992, avi va, Z992"
"ZTE, Z993, avi va, Z993"
"ZTE, Z995, becky, Z995"
"ZTE, Z998, coeus, Z998"
"ZTE, ZTE A880, ZTE-A880, ZTE A880"
"ZTE, ZTE B790, roamer2, ZTE B790"
"ZTE, ZTE B880, P635N30, ZTE B880"
"ZTE, ZTE B880, S_P635N30, ZTE B880"

supported device.txt

"ZTE, ZTE BLADE III, atlas40, Skate Pro"
"ZTE, ZTE BLADE III, atlas40, ZTE BLADE III"
"ZTE, ZTE BLADE III, atlas40, ZTE Blade III"
"ZTE, ZTE Blade A460, P809A20, Blade A460"
"ZTE, ZTE Blade A460, P809A20, ZTE Blade A460"
"ZTE, ZTE Blade A460, P809A20, ZTE T610"
"ZTE, ZTE Blade Apex, oceanus, ZTE Blade Apex"
"ZTE, ZTE Blade Apex2, msm8226, ZTE Blade Apex2"
"ZTE, ZTE Blade Apex3, msm8916_32, ZTE Blade Apex3"
"ZTE, ZTE Blade C312, P715A20, ZTE Blade C312"
"ZTE, ZTE Blade C340, P172R12, ZTE Blade C340"
"ZTE, ZTE Blade C340, P172R12, ZTE T220"
"ZTE, ZTE Blade C340, P172R12, ZTE V812"
"ZTE, ZTE Blade C370, ZTE_Blade_C370, NOS NOVU"
"ZTE, ZTE Blade C370, ZTE_Blade_C370, ZTE Blade C370"
"ZTE, ZTE Blade G, ZTE-Blade-G, ZTE Blade G"
"ZTE, ZTE Blade G LTE, coeus, ZTE Blade G LTE"
"ZTE, ZTE Blade G Lux, P172F10, BGH Joy Smart A6"
"ZTE, ZTE Blade G Lux, P172F10, BGH Joy Smart A6d"
"ZTE, ZTE Blade G Lux, P172F10, Blade G Lux"
"ZTE, ZTE Blade G Lux, P172F10, DIGICEL DL800"
"ZTE, ZTE Blade G Lux, P172F10, MEO Smart A40"
"ZTE, ZTE Blade G Lux, P172F10, Orange Tado"
"ZTE, ZTE Blade G Lux, P172F10, ZTE Blade G Lux"
"ZTE, ZTE Blade G Lux, P172F10, ZTE Ki s3 max"
"ZTE, ZTE Blade G Lux, P172F10, ZTE V830W"
"ZTE, ZTE Blade HN, ZTE_Blade_HN, ZTE Blade HN"
"ZTE, ZTE Blade III, atlas40, ZTE Blade III"
"ZTE, ZTE Blade III Pro, Blade-III-Pro, ZTE Blade III Pro"
"ZTE, ZTE Blade L2, P182A10, BGH Joy Smart AXS"
"ZTE, ZTE Blade L2, P182A10, BGH Joy Smart AXS D"
"ZTE, ZTE Blade L2, P182A10, Blade L2"
"ZTE, ZTE Blade L2, P182A10, MEO Smart A75"
"ZTE, ZTE Blade L2, P182A10, ZTE Blade L2"
"ZTE, ZTE Blade L3, P182A20, Blade L3"
"ZTE, ZTE Blade L3, P182A20, DIGICEL DL910"
"ZTE, ZTE Blade L3, P182A20, MEO Smart A80"
"ZTE, ZTE Blade L3, P182A20, ZTE Blade L3"
"ZTE, ZTE Blade L3 Apex, ZTE_Blade_L3_Apex, ZTE Blade L3 Apex"
"ZTE, ZTE Blade L3 Plus, ZTE_Blade_L3_Plus, ZTE Blade L3 Plus"
"ZTE, ZTE Blade L370, ZTE_Blade_C370, ZTE Blade L370"
"ZTE, ZTE Blade Q Lux, P632A10, BGH Joy Smart A7G"
"ZTE, ZTE Blade Q Lux, P632A10, Beeline Pro"
"ZTE, ZTE Blade Q Lux, P632A10, UZTE Blade Q Lux"
"ZTE, ZTE Blade Q Lux, P632A10, ZTE Blade A430"
"ZTE, ZTE Blade Q Lux, P632A10, ZTE Blade Q Lux"
"ZTE, ZTE Blade Q Lux, P632A10, ZTE Blade Q Lux 3G"
"ZTE, ZTE Blade Q Lux, P632A10, ZTE Fit 4G Smart"
"ZTE, ZTE Blade Q Lux, P632A10, ZTE T311"
"ZTE, ZTE Blade Q Lux, P816A12, ZTE Blade Q Lux"
"ZTE, ZTE Blade Q Mini, P172G10_UK_VIRGIN, ZTE Blade Q Mini"
"ZTE, ZTE Blade S6 Plus, P839F50, LS-5503"
"ZTE, ZTE Blade S6 Plus, P839F50, ZTE Blade S6 Plus"
"ZTE, ZTE Blade V, ZTE-Blade-V, Vodafone Blade V"
"ZTE, ZTE Blade V, ZTE-Blade-V, ZTE Blade V"
"ZTE, ZTE Blade V2, msm8916_32, ZTE Blade V2"
"ZTE, ZTE Blade V220, msm8916_32, ZTE Blade V220"
"ZTE, ZTE Blade VEC, P692S20_082, ZTE Blade VEC"
"ZTE, ZTE Blade Vec, P692S20_082, Blade Vec"
"ZTE, ZTE Blade Vec, P692S20_082, ZTE Blade Vec"
"ZTE, ZTE Blade Vec, P692S20_082, ZTE Geek 2"
"ZTE, ZTE Blade Vec 4G, msm8226, ZTE Blade Vec 4G"
"ZTE, ZTE Blade Vec Pro, P692S20_M92, ZTE Blade Vec Pro"

supported device.txt

"ZTE, ZTE C310, P172D04, ZTE Blade C310"
 "ZTE, ZTE C310, P172D04, ZTE C310"
 "ZTE, ZTE G601U, P172E02, ZTE G601U"
 "ZTE, ZTE G717C, P692N30, ZTE G717C"
 "ZTE, ZTE G718C, ZTE-G718C, ZTE G718C"
 "ZTE, ZTE G719C, ZTE-G719C, ZTE G719C"
 "ZTE, ZTE G720C, ZTE-G720C, ZTE G720C"
 "ZTE, ZTE G720T, P839T30, ZTE G720T"
 "ZTE, ZTE G720T, V_P839T30, ZTE G720T"
 "ZTE, ZTE GEEK II 4G, msm8226, ZTE GEEK II 4G"
 "ZTE, ZTE GEEK II Pro, ztexasp92_wet_jb9, ZTE GEEK II Pro"
 "ZTE, ZTE GEEK II Pro, ztexasp92_wet_jb9, ZTE M1001"
 "ZTE, ZTE Geek, redhookbay, ZTE Geek"
 "ZTE, ZTE Geek 2 LTE, msm8226, ZTE Geek 2 LTE"
 "ZTE, ZTE Geek 2 pro, P692S20_M92, ZTE Geek 2 pro"
 "ZTE, ZTE Grand Era, enterprise_RU, ZTE Grand Era"
 "ZTE, ZTE Grand Memo LTE, Grand-Memo, ZTE Grand Memo"
 "ZTE, ZTE Grand Memo LTE, Grand-Memo, ZTE Grand Memo LTE"
 "ZTE, ZTE Grand S Flex, iris, ZTE Grand S Flex"
 "ZTE, ZTE Grand S II, P541T50, ZTE Grand S II"
 "ZTE, ZTE Grand S II, P541T50, ZTE S221"
 "ZTE, ZTE Grand S II, P897A21, ZTE Grand S II"
 "ZTE, ZTE Grand S II LTE, msm8974, ZTE Grand S II LTE"
 "ZTE, ZTE Grand X 2, P682F06, Amazing A7"
 "ZTE, ZTE Grand X 2, P682F06, ZTE Grand X 2"
 "ZTE, ZTE Grand X 2, P682F06, ZTE V968"
 "ZTE, ZTE Grand X 2, P682F06, ZTE V969"
 "ZTE, ZTE Grand X Quad Lite, P188F07, Amazing A6"
 "ZTE, ZTE Grand X Quad Lite, P188F07, V8602"
 "ZTE, ZTE Grand X Quad Lite, P188F07, ZTE Grand X Quad Lite"
 "ZTE, ZTE Grand X Quad Lite, P188F07, ZTE Grand X2"
 "ZTE, ZTE Grand X Quad Lite, P188F07, ZTE Skate 2"
 "ZTE, ZTE Grand X Quad Lite, P188F07, ZTE V967S"
 "ZTE, ZTE Grand X2 In, redhookbay, Grand X2 In"
 "ZTE, ZTE Grand X2 In, redhookbay, ZTE Grand X2 In"
 "ZTE, ZTE Kis 3, ZTE-P821E10, MEO SMART A16"
 "ZTE, ZTE Kis 3, ZTE-P821E10, MEO Smart A16"
 "ZTE, ZTE Kis 3, ZTE-P821E10, MOCHE SMART A16"
 "ZTE, ZTE Kis 3, ZTE-P821E10, ZTE Kis 3"
 "ZTE, ZTE Kis 3, ZTE-P821E10, ZTE V811"
 "ZTE, ZTE Kis Lite, roamer2, ZTE Kis Lite"
 "ZTE, ZTE Kis Pro, nice, Optimus Zali"
 "ZTE, ZTE Kis Pro, nice, ZTE Kis Pro"
 "ZTE, ZTE Kis Q, P172D02, ZTE Kis Q"
 "ZTE, ZTE LEO M1, V883M, V883M"
 "ZTE, ZTE LEO M1, V883M, ZTE LEO M1"
 "ZTE, ZTE LEO S1, V972M, V972M"
 "ZTE, ZTE LEO S1, V972M, ZTE LEO S1"
 "ZTE, ZTE LEO S2, V982M_Z64, ZTE LEO S2"
 "ZTE, ZTE M901C, P692N60, ZTE M901C"
 "ZTE, ZTE N5L, prmthus, ZTE N5L"
 "ZTE, ZTE N5S, P189F10, ZTE N5S"
 "ZTE, ZTE N795, deepblue, ZTE N795"
 "ZTE, ZTE N798, atlas40, ZTE N798"
 "ZTE, ZTE N798+, ZTE_N798, ZTE N798+ "
 "ZTE, ZTE N798+, ZTE_N798P, ZTE N798+ "
 "ZTE, ZTE N799D, ZTE-N799D, N799D"
 "ZTE, ZTE N799D, ZTE-N799D, ZTE N799D"
 "ZTE, ZTE N818, ZTE-N818, N818"
 "ZTE, ZTE N818, ZTE-N818, ZTE N818"
 "ZTE, ZTE N880E, atlas40, ZTE N880E"
 "ZTE, ZTE N880G, ZTE-N880G, ZTE N880G"
 "ZTE, ZTE N900, ZTE-N900, ZTE N900"

supported device.txt

"ZTE, ZTE N900D, ZTE-N900D, ZTE N900D"
 "ZTE, ZTE N909, ZTE-N909, ZTE N909"
 "ZTE, ZTE N909D, ZTE-N909D, ZTE N909D"
 "ZTE, ZTE N9120, el den, ZTE N9120"
 "ZTE, ZTE N919, ZTE-N919, ZTE N919"
 "ZTE, ZTE N919D, ZTE-N919D, N919D"
 "ZTE, ZTE N919D, ZTE-N919D, ZTE N919D"
 "ZTE, ZTE N983, P177F03, ZTE N983"
 "ZTE, ZTE N9835, chovar, N9835"
 "ZTE, ZTE N9835, chovar, ZTE N9835"
 "ZTE, ZTE N986, P188F02, N986"
 "ZTE, ZTE N986, P188F02, ZTE N986"
 "ZTE, ZTE Q101T, P810T10, ZTE Q101T"
 "ZTE, ZTE Q201T, P172T24, ZTE Q201T"
 "ZTE, ZTE Q2S-C, P826N50, ZTE Q2S-C"
 "ZTE, ZTE Q2S-T, P826T50, ZTE Q2S-T"
 "ZTE, ZTE Q301C, APT_TW_P810N30, ZTE Q301C"
 "ZTE, ZTE Q301C, P810N30, ZTE Q301C"
 "ZTE, ZTE Q301T, P172T33, ZTE Q301T"
 "ZTE, ZTE Q302C, P809N20, ZTE Q302C"
 "ZTE, ZTE Q5-C, P816N34, ZTE Q5-C"
 "ZTE, ZTE Q5-T, CU_P816T32, ZTE Q5-T"
 "ZTE, ZTE Q5-T, P816T32, ZTE Q5-T"
 "ZTE, ZTE Q501T, P172T31, ZTE Q501T"
 "ZTE, ZTE Q501U, P172F04, ZTE Q501U"
 "ZTE, ZTE Q503U, P682V53, ZTE Q503U"
 "ZTE, ZTE Q505T, P826T20, ZTE Q505T"
 "ZTE, ZTE Q507T, P682T20, ZTE Q507T"
 "ZTE, ZTE Q508U, P816V50, ZTE Q508U"
 "ZTE, ZTE Q509T, P632T31, Amazi ng X5"
 "ZTE, ZTE Q509T, P632T31, MTC SMART Run 4G"
 "ZTE, ZTE Q509T, P632T31, ZTE Bl ade A450"
 "ZTE, ZTE Q509T, P632T31, ZTE Bl ade V2 Li te"
 "ZTE, ZTE Q509T, P632T31, ZTE Q509T"
 "ZTE, ZTE Q7, CMCC_P839V50, ZTE Q7"
 "ZTE, ZTE Q7, CU_P839V50, ZTE Q7"
 "ZTE, ZTE Q7, P839V50, ZTE Q7"
 "ZTE, ZTE Q7-C, P839N50, ZTE Q7-C"
 "ZTE, ZTE Q705U, P682V60, ZTE Q705U"
 "ZTE, ZTE Q801T, P181L30, ZTE Q801T"
 "ZTE, ZTE Q801U, P826V30, ZTE Q801U"
 "ZTE, ZTE Q802C, ZTE-Q802C, ZTE Q802C"
 "ZTE, ZTE Q802D, ZTE-Q802D, ZTE Q802D"
 "ZTE, ZTE Q802T, P826T30, ZTE Q802T"
 "ZTE, ZTE Q805T, P120T55, ZTE Q805T"
 "ZTE, ZTE Q806T, V_P635T30, ZTE Q806T"
 "ZTE, ZTE R83, demeter, ZTE R83"
 "ZTE, ZTE S118, P189S10, Grand S Li te"
 "ZTE, ZTE S118, P189S10, ZTE S118"
 "ZTE, ZTE S2004, msm8974, ZTE S2004"
 "ZTE, ZTE S2005, msm8974, ZTE S2005"
 "ZTE, ZTE S2007, msm8974, ZTE S2007"
 "ZTE, ZTE S2014, ZTE-S2014, ZTE S2014"
 "ZTE, ZTE S2015, ZTE-S2015, ZTE S2015"
 "ZTE, ZTE STAR, msm8226, ZTE GEEK II Pro 4G"
 "ZTE, ZTE STAR, msm8226, ZTE S2002"
 "ZTE, ZTE STAR, msm8226, ZTE STAR"
 "ZTE, ZTE STAR, msm8226, ZTE Star 1"
 "ZTE, ZTE Skate, skate, ZTE Skate"
 "ZTE, ZTE Swi tch X1, deepbl ue, ZTE Swi tch X1"
 "ZTE, ZTE Swi tch X1, deepbl ue, ZTE V796"
 "ZTE, ZTE T12, P173A30T, ZTE T12"
 "ZTE, ZTE T221, P731A20, DI GI CEL DL755"

supported device.txt

"ZTE, ZTE T221, P731A20, ZTE Blade A5"
"ZTE, ZTE T221, P731A20, ZTE Blade AF5"
"ZTE, ZTE T221, P731A20, ZTE Blade C341"
"ZTE, ZTE T221, P731A20, ZTE Blade C342"
"ZTE, ZTE T221, P731A20, ZTE T221"
"ZTE, ZTE T221, P731A20, ZTE T230"
"ZTE, ZTE T28, bluetick, ZTE T28"
"ZTE, ZTE T28, bluetick, ZTE T28 Prepaid"
"ZTE, ZTE T60, turies, ZTE T60"
"ZTE, ZTE T760, P173A10T, ZTE T760"
"ZTE, ZTE T790, roamer2, ZTE T790"
"ZTE, ZTE T792, ZTE-T792, ZTE B792"
"ZTE, ZTE T792, ZTE-T792, ZTE T792"
"ZTE, ZTE T80, msm8226, ZTE T80"
"ZTE, ZTE T81, iliana, ZTE T81"
"ZTE, ZTE T82, frosty, ZTE T82"
"ZTE, ZTE T83, demeter, ZTE T83"
"ZTE, ZTE T84, P816A20, ZTE R84"
"ZTE, ZTE T84, P816A20, ZTE T84"
"ZTE, ZTE T86, msm8226, Amazing X1"
"ZTE, ZTE T86, msm8226, ZTE T86"
"ZTE, ZTE T88, msm8226, ZTE T88"
"ZTE, ZTE T911, P839F30, ZTE T911"
"ZTE, ZTE U5S, P188T51, ZTE U5S"
"ZTE, ZTE U809, P172T11, ZTE U809"
"ZTE, ZTE U816, P988T20, ZTE U816"
"ZTE, ZTE U817, P117A20, ZTE U817"
"ZTE, ZTE U818, P172T21, ZTE U818"
"ZTE, ZTE U879, P172T30, ZTE U879"
"ZTE, ZTE U889, P183T30, ZTE U889"
"ZTE, ZTE U968, P682T51, ZTE U968"
"ZTE, ZTE U969, P682T50, ZTE U969"
"ZTE, ZTE U9815, P945T20, ZTE U9815"
"ZTE, ZTE U988S, pluto, ZTE U988S"
"ZTE, ZTE V5S, P189F13, ZTE Grand Memo Lite"
"ZTE, ZTE V5S, P189F13, ZTE V5S"
"ZTE, ZTE V70, ZTE-V70, ZTE V70"
"ZTE, ZTE V7073, V7073, ZTE V7073"
"ZTE, ZTE V72, V72, MT7A"
"ZTE, ZTE V72, V72, ZTE V72"
"ZTE, ZTE V72, V72, myPad P4 Lite"
"ZTE, ZTE V768, V768, ZTE V768"
"ZTE, ZTE V769M, V769M, V769M"
"ZTE, ZTE V769M, V769M, ZTE LEO Q2"
"ZTE, ZTE V769M, V769M, ZTE V769M"
"ZTE, ZTE V779M, ZTEV779M, ZTE V779M"
"ZTE, ZTE V790, roamer2, ZTE V790"
"ZTE, ZTE V791, P175A40, V791"
"ZTE, ZTE V791, P175A40, ZTE V791"
"ZTE, ZTE V792C, P810D01, ZTE V792C"
"ZTE, ZTE V793, P175A60, Amazing A3"
"ZTE, ZTE V793, P175A60, Cellcom 4G"
"ZTE, ZTE V793, P175A60, M9000"
"ZTE, ZTE V793, P175A60, Telcel T20"
"ZTE, ZTE V793, P175A60, ZTE KIS Flex"
"ZTE, ZTE V793, P175A60, ZTE V793"
"ZTE, ZTE V793, P175A60, tmn smart a6"
"ZTE, ZTE V795, P172D01, BGH Joy Smart A1"
"ZTE, ZTE V795, P172D01, V795(A3S)"
"ZTE, ZTE V795, P172D01, ZTE B795"
"ZTE, ZTE V795, P172D01, ZTE KIS II"
"ZTE, ZTE V795, P172D01, ZTE KIS II PRO"
"ZTE, ZTE V795, P172D01, ZTE KIS II"

supported device.txt

"ZTE, ZTE V795, P172D01, ZTE V795"
"ZTE, ZTE V797, P172D03, VIETTEL V8411"
"ZTE, ZTE V797, P172D03, ZTE V797"
"ZTE, ZTE V807, P177E01, Amazing A4"
"ZTE, ZTE V807, P177E01, Beeline E700"
"ZTE, ZTE V807, P177E01, Leopard MF900"
"ZTE, ZTE V807, P177E01, UZTE V807"
"ZTE, ZTE V807, P177E01, V8501"
"ZTE, ZTE V807, P177E01, ZTE BLADE C"
"ZTE, ZTE V807, P177E01, ZTE V807"
"ZTE, ZTE V807, P177E01, ZTE V889S"
"ZTE, ZTE V808, P172E01, UZTE V808"
"ZTE, ZTE V808, P172E01, ZTE V808"
"ZTE, ZTE V809, P172A10, BGH Joy Smart A2"
"ZTE, ZTE V809, P172A10, ZTE Blade C2"
"ZTE, ZTE V809, P172A10, ZTE T809"
"ZTE, ZTE V809, P172A10, ZTE V809"
"ZTE, ZTE V809, P172A10, meo smart a12"
"ZTE, ZTE V811, ZTE-V811, Beeline Smart2"
"ZTE, ZTE V811, ZTE-V811, ZTE V811"
"ZTE, ZTE V811C, P810E01, ZTE V811C"
"ZTE, ZTE V811W, P821E10, ZTE V811"
"ZTE, ZTE V811W, P821E10, ZTE V811W"
"ZTE, ZTE V813W, P172B20, ZTE Blade C2 Plus"
"ZTE, ZTE V813W, P172B20, ZTE V813W"
"ZTE, ZTE V815W, P172R10, Amazing A4S"
"ZTE, ZTE V815W, P172R10, B8405"
"ZTE, ZTE V815W, P172R10, BGH Joy Smart A5C"
"ZTE, ZTE V815W, P172R10, BGH Joy Smart A5d"
"ZTE, ZTE V815W, P172R10, KIS II Max"
"ZTE, ZTE V815W, P172R10, SMART Start"
"ZTE, ZTE V815W, P172R10, UZTE GRAND V7"
"ZTE, ZTE V815W, P172R10, ZTE B816"
"ZTE, ZTE V815W, P172R10, ZTE Blade Buzz"
"ZTE, ZTE V815W, P172R10, ZTE Blade C320"
"ZTE, ZTE V815W, P172R10, ZTE Blade Q1"
"ZTE, ZTE V815W, P172R10, ZTE Kis II Max"
"ZTE, ZTE V815W, P172R10, ZTE Kis II Max Plus"
"ZTE, ZTE V815W, P172R10, ZTE Kis II Max plus"
"ZTE, ZTE V815W, P172R10, ZTE Maxx"
"ZTE, ZTE V815W, P172R10, ZTE T815"
"ZTE, ZTE V815W, P172R10, ZTE T816"
"ZTE, ZTE V815W, P172R10, ZTE V815W"
"ZTE, ZTE V815W, P172R10, ZTE V816W"
"ZTE, ZTE V817, ZTE-V817, V817"
"ZTE, ZTE V817, ZTE-V817, ZTE V817"
"ZTE, ZTE V817, ZTE-V956, ZTE V817"
"ZTE, ZTE V818, P172F01, ZTE Blade 2"
"ZTE, ZTE V818, P172F01, ZTE V818"
"ZTE, ZTE V829, P172A30, BGH Joy Smart A3"
"ZTE, ZTE V829, P172A30, Blade G Pro"
"ZTE, ZTE V829, P172A30, V8507"
"ZTE, ZTE V829, P172A30, ZTE Blade G Plus"
"ZTE, ZTE V829, P172A30, ZTE Blade G Pro"
"ZTE, ZTE V829, P172A30, ZTE V829"
"ZTE, ZTE V831W, P731A10, Amazing A5S"
"ZTE, ZTE V831W, P731A10, UZTE Blade Q Pro"
"ZTE, ZTE V831W, P731A10, ZTE T320"
"ZTE, ZTE V831W, P731A10, ZTE V831W"
"ZTE, ZTE V879, P172F02, ZTE V879"
"ZTE, ZTE V880E, atlas40, ZTE V880E"
"ZTE, ZTE V880G, ZTE-V880G, ZTE V880G"
"ZTE, ZTE V887, P177A10, ZTE Blade L"

supported device.txt

"ZTE, ZTE V887, P177A10, ZTE V887"
"ZTE, ZTE V887, P177A10, tmn smart a20"
"ZTE, ZTE V889D, atlas40, ZTE V889D"
"ZTE, ZTE V889M, P175A10, UZTE V889M"
"ZTE, ZTE V889M, P175A10, ZTE V889M"
"ZTE, ZTE V891, P986E01, ZTE V891"
"ZTE, ZTE V956, ZTE-V956, ZTE V956"
"ZTE, ZTE V965, P188F03, ZTE Blade G2"
"ZTE, ZTE V965, P188F03, ZTE R880H"
"ZTE, ZTE V965, P188F03, ZTE V880H"
"ZTE, ZTE V965, P188F03, ZTE V965"
"ZTE, ZTE V969, P682F01, ZTE V969"
"ZTE, ZTE V970, whistler, UZTE V970"
"ZTE, ZTE V970, whistler, ZTE V970"
"ZTE, ZTE V975, redhookbay, V975"
"ZTE, ZTE V975, redhookbay, ZTE Geek"
"ZTE, ZTE V975, redhookbay, ZTE V975"
"ZTE, ZTE V9800, ki ska, ZTE V9800"
"ZTE, ZTE V9820, ZTE-V9820, ZTE V9820"
"ZTE, ZTE V983, P177A30, ZTE V983"
"ZTE, ZTE V987, P188F04, UZTE GRAND X Quad"
"ZTE, ZTE V987, P188F04, ZTE Grand X"
"ZTE, ZTE V987, P188F04, ZTE V987"
"ZTE, ZTE V993W, ZTE_V993W, ZTE V993W"
"ZTE, ZTE V9A, v9plus, ZTE V9A"
"ZTE, ZTE Z932L, warplte, Z932L"
"ZTE, ZTE Z932L, warplte, ZTE Z932L"
"ZTE, ZTE-BLADE, blade, ZTE-BLADE"
"ZTE, ZTE-N910, arthur4g, ZTE-N910"
"ZTE, ZTE-SKATE, skate, ZTE-SKATE"
"ZTE, ZTE-U N721, N721, ZTE-U N721"
"ZTE, ZTE-U V760, ztenj 73_gb, MD Smart"
"ZTE, ZTE-U V760, ztenj 73_gb, Telenor Touch Mini "
"ZTE, ZTE-U V760, ztenj 73_gb, ZTE-U V760"
"ZTE, ZTE-U V760, ztenj 73_gb, ZTE-U V856"
"ZTE, ZTE-U V760, ztenj 73_gb, ZTE-U V857"
"ZTE, ZTE-U V760, ztenj 73_gb, moi i E598"
"ZTE, ZTE-V6500, V6500, Eti salat Smartphone"
"ZTE, ZTE-V6500, V6500, ZTE-V6500"
"ZTE, ZTE-V856, zte_v856, ZTE-V856"
"ZTE, ZTE-X500, X500, ZTE-X500"
"ZTE, ZTE-Z990, roamer, ZTE-Z990"
"ZTE, ZTE-Z990G, roamer, ZTE-Z990G"
"ZTE, ZTE_LEO_Q1, hct72_wet_j b3, V765M"
"ZTE, ZTE_LEO_Q1, hct72_wet_j b3, ZTE LEO Q1"
"ZTE, ZTE_LEO_Q1, hct72_wet_j b3, ZTE V765M"
"ZTE, ZTE_LEO_Q1, hct72_wet_j b3, ZTE_CLARO_Q1"
"ZTE, ZTE_LEO_Q1, hct72_wet_j b3, ZTE_LEO_Q1"
"ZTE, ZTE_LEO_Q1, hct72_wet_j b3, mobi fone M9001"
"ZTE, ZTE_N9511, hera, ZTE_N9511"
"ZTE, ZTE_Q701C, ZTE-Q701C, ZTE Q701C"
"ZTE, ZTE_Q801C, ZTE-Q801C, ZTE Q801C"
"ZTE, ZTE_Q801L, ZTE-Q801L, ZTE Q801L"
"ZTE, ZXY-ZTE_N8010, N8010_YM, ZXY-ZTE_N8010"
"ZTE, ZXY-ZTE_V6700, V6700, ZTE V6700"
"ZTE, ZXY-ZTE_V6700, V6700, ZXY-ZTE_V6700"
"ZTE, blade S, blade2, Blade S"
"ZTE, myPad P5, K78, Amazi ng_P5"
"ZTE, myPad P5, K78, myPad P5"
"ZTE, nubi a Z5, NX501, nubi a Z5"
"ZTE, tmn smart a15, atlas40, tmn smart a15"
"ZTE, tmn smart a60, ki ska, tmn smart a60"
"ZTE, tmn smart a7, sailboat, tmn smart a7"

"Zebra, Pol I ux, TC70, TC700H"
"Zebra, Pol I ux, TC75, TC75"
"Zebra, TC55, TC55, TC55"
"Zeki , TBDG734, TBDG734, TBDG734"
"Zeki , TBQG1084, TBQG1084, TBQG1084"
"Zeki , TBQG855, TBQG855, TBQG855"
"Zeki , Zeki TBDG1073, TBDG1073, TBDG1073"
"Zeki , Zeki TBDG874 Tabl et, TBDG874B, TBDG874"
"Zeki , Zeki TBQC1063B, TBQC1063B, TBQC1063"
"Zeki , Zeki TBQG774, TBQG774, TBQG774"
"Zeki , Zeki TBQG884, TBQG884, TBQG884"
"Zettaly, ZA-407, ZA-407, Zettaly Avy ZA-407"
"Zi lo, Zi lo, Zi lo, Zi lo"
"bq, Aquari s E10, Aquari s_E10, Aquari s E10"
"bq, Aquari s E10 3G, Aquari s_E10_3G, Aquari s E10 3G"
"bq, Aquari s E4, Aquari s_E4, Aquari s E4"
"bq, Aquari s E4. 5, Aquari s_E45, Aquari s E4. 5"
"bq, Aquari s E5, Aquari s_E5, Aquari s E5"
"bq, Aquari s E5 FHD, Aquari s_E5_FHD, Aquari s E5 FHD"
"bq, Aquari s E5 HD, Aquari s_E5_HD, Aquari s E5 HD"
"bq, Aquari s E6, Aquari s_E6, Aquari s E6"
"bq, Edi son 3, Edi son_3, Edi son 3"
"bq, Edi son_3_mi ni , Edi son_3_mi ni , Edi son 3 mi ni "
"bq, bq Edi son 3 3G, Edi son_3_3G, Edi son 3 3G"
"essenti el b, Essenti el b- Bl ack Di amond, bi rd77_a_cu_i cs2, Essenti el b-Bl ack Di amond"
"essenti el b, Pyxi s, pyxi s_boul anger, Essenti el b-Pi xi s"
"essenti el b, essenti el b ST7001 Tabl et, ST7001, ST7001"
"geanee, FXC-5A, FXC-5A, FXC-5A"
"harri s, RF-3590-RT, msm8660_cougar, Harri s 12131-1000"
"hi sense, l t971, LT971, LT971"
"i -Buddi e, TA10CA1, TA10CA1, TA10CA1"
"i -Buddi e, TA10CA2, TA10CA2, TA10CA2"
"i -Buddi e, TA10CA3, TA10CA3, TA10CA3"
"i -Buddi e, TA10CA4, TA10CA4, TA10CA4"
"i -Buddi e, TA71CA1, TA71CA1, TA71CA1"
"i -Buddi e, TA71CA5, TA71CA5, TA71CA5"
"i -Buddi e, TA80CA1, TA80CA1, TA80CA1"
"i -Buddi e, TM75A-V2, TM75A-V2, TM75A-V2"
"i -Buddi e, TR10CD1, TR10CD1_2, TR10CD1"
"i -Buddi e, TR10CD1, TR10CD1_4, TR10CD1"
"i -Buddi e, TR10CD1_P, TR10CD1, TR10CD1"
"i -Buddi e, TR10CS1, TR10CS1_12, TR10CS1"
"i -Buddi e, TR10CS1, TR10CS1_2, TR10CS1"
"i -Buddi e, TR10CS1_P, TR10CS1, TR10CS1"
"i -Mobi le, i -mobi le IQ II , i mobi lei q2_sprout, i -mobi le IQ II "
"i -mobi le, IQX KEN, IQX_KEN, IQX_KEN"
"i -mobi le, i -mobi le i -note Wi Fi 1. 1, M1703, i -mobi le M1703"
"i Crai g, CMP791, CMP791, CMP791"
"i Crai g, CMP793, CMP793, CMP793"
"i Crai g, I CRAI G_CLP288, I CRAI G_CLP288, I CRAI G_CLP288"
"i Crai g, I CRAI G_CLP_291, I CRAI G_CLP_291, I CRAI G_CLP291"
"i Crai g, I CRAI G_CMP770, I CRAI G_CMP770, I CRAI G_CMP770"
"i Crai g, I CRAI G_CMP_771, I CRAI G_CMP_771, I CRAI G_CMP771"
"i Crai g, I CRAI G_CMP_773, I CRAI G_CMP_773, I CRAI G_CMP773"
"i Dea USA, CT8, CT8, CT8"
"i DeaUSA, i DeaUSA CT10, CT10, CT10"
"i DeaUSA, i DeaUSA CT7, CT7, CT7"
"i Ri ver, , smdkc110, I LT-MX100"
"i Ri ver, DMT580D, m805_892x, DDA800R"
"i Ri ver, DMT580D, m805_892x, DMT580D"
"i Ri ver, DMT580D, m805_892x, MI T700"
"i Ri ver, MM3202, mm3201, MM-3201"
"i Ri ver, MM3202, mm3201, MM-3202"

supported device.txt

"iRi ver, ULALA, msm7627a_sku3, I -K1"
"iRi ver, WOW Tab+(ITQ1000), i tq1000, ITQ1000"
"iRi ver, WPT005, wi ki pad, WPT005"
"iRi ver, Wow TAB +, i tq701, ITQ701"
"iRi ver, Wow(Window of the world), i tq700, ITQ700"
"iRi ver, Wow(Window of the world), i tq700, YBMK01"
"i Vi ew, 776TPCIII, 776TPCIII, 776TPCIII"
"i Vi ew, i Vi ew 778TPC, 778TPC, 778TPC"
"i Vi ew, i Vi ew 788TPCII, i Vi ew_788TPCII, 788TPCII"
"i Vi ew, i Vi ew 920TPC, 920TPC, 920TPC"
"i Vi ew, i Vi ew SupraPad i 700, g01i, i 700"
"i Vi ew, i Vi ew SupraPad i 785Q, anchor, i 785Q"
"mobi cel, Retro, Retro, Retro"
"mobi stel, Cynus T6, Cynus_T6, Cynus T6"
"myPhone, CUBE, myphone_cube, myPhone Cube"
"nabi, nabi 2 Tablet, mt799, NABI 2-NV7A"
"nabi, nabi 2S Tablet, nabi 2S, SNB02-NV7A"
"nabi, ""nabi Bi g Tab HD\xe2\x84\xa2 20""""""", DMTAB-NV20A, DMTAB-NV20A"
"nabi, ""nabi Bi g Tab HD\xe2\x84\xa2 24""""""", DMTAB-NV24A, DMTAB-NV24A"
"nabi, nabi DreamTab HD8 Tablet, DMTAB, DMTAB-IN08A"
"nabi, nabi DreamTab HD8 Tablet, t8400n, DMTAB-NV08B"
"oi oo, oi oo Model 2, wecct, Model 2"
"oi oo, oi oo Model 3, wecct3, Model 3"
"pendo, PNDPP44QC10, PNDPP44QC10, PNDPP44QC10"
"pendo, PNDPP44QC7, PNDPP44QC7, PNDPP44QC7"
"sugar_aums, QPOINT, QPI -1, QPI -1"
"tecmobi le, Omni sOne, Omni sOne, Omni s One"
"ucal I, EASY1, EASY1, EASY1"